



Spare parts for:

Coffee grinders



Suitable for:

FIORENZATO M.C.



This catalogue is automatically generated.
Therefore, the sequence of the items might
not be always shown at best.
Updates will be issued in case of additions
and/or amendments.

*Suitable **universal spare parts** may not be included*





FIorenzato M.C.



Position	LF code no.	Description
1	1080034	COMPLETE COFFEE HOPPER
2	1252112	COFFEE HOPPER LID
3	1080034	COMPLETE COFFEE HOPPER
4	1252114	COFFEE HOPPER CLOSING SHEET
7	1251030	GRINDING BURRS FIORENZATO MC (PAIR) RH
10	1250209	GRIND.BURR HOLDER LOCKING SPRING
12	1057006	SELECTOR SWITCH 0-1 POSITIONS 12A 400V
12	1446900	TIMER 50 SECONDS 16A 250V
13	1252115	FILTER HOLDER FORK
14	1063911	BEARING 6202 2Z
20	3068024	CAPACITOR μ F 16 450V 50/60Hz
21	3351032	POWER RELAY 66.82 30A 250V
23	1252153	DOSER LID
25	1252154	DOSER CYLINDER
28	1252162	MIXER ROD
33	1250097	STAR LOCKING SPRING
35	1250098	PIN THRUST SPRING
37	1252156	PAWL PIN
40	1250094	DOSER LEVER RETURN SPRING
41	1252157	RH PAWL
42	1252159	RH ALUMINUM DOSER LEVER
43	1252158	ADJUSTMENT KNOB
46	1240033	MICROSWITCH 3A 250V
49	1252155	MICROSWITCH FLAP
50	1343017	STAR ASSEMBLY
52	1385009	COFFEE TAMPER \varnothing 57 mm
52	1385020	COFFEE TAMPER \varnothing 55 mm
55	1240034	MICROSWITCH 3A 250V



FIorenzato M.C.



Position	LF code no.	Description
1	1080034	COMPLETE COFFEE HOPPER
2	1252112	COFFEE HOPPER LID
4	1252114	COFFEE HOPPER CLOSING SHEET
7	1251033	GRINDING BURRS FIORENZATO MC (PAIR) RH
10	1250209	GRIND.BURR HOLDER LOCKING SPRING
12	1057006	SELECTOR SWITCH 0-1 POSITIONS 12A 400V
12	1446900	TIMER 50 SECONDS 16A 250V
13	1252115	FILTER HOLDER FORK
14	1063911	BEARING 6202 2Z
20	3068024	CAPACITOR μ F 16 450V 50/60Hz
21	3351032	POWER RELAY 66.82 30A 250V
23	1252153	DOSER LID
25	1252154	DOSER CYLINDER
28	1252162	MIXER ROD
33	1250097	STAR LOCKING SPRING
35	1250098	PIN THRUST SPRING
37	1252156	PAWL PIN
40	1250094	DOSER LEVER RETURN SPRING
41	1252157	RH PAWL
42	1252159	RH ALUMINUM DOSER LEVER
43	1252158	ADJUSTMENT KNOB
46	1240033	MICROSWITCH 3A 250V
49	1252155	MICROSWITCH FLAP
50	1343017	STAR ASSEMBLY
52	1385009	COFFEE TAMPER \varnothing 57 mm
52	1385020	COFFEE TAMPER \varnothing 55 mm
55	1240034	MICROSWITCH 3A 250V



Suitable for:

Suitable for:

Bearings

1063911 BEARING 6202 2Z
external \varnothing 35 mm-internal \varnothing 15 mm-thickness 11 mm



FIorenzato M.C. 001.004.011

FIorenzato M.C. 700000007

Capacitors

3068019 CAPACITOR μ F 12.5 450V 50/60Hz
operating temperature $-25+85^{\circ}\text{C}$
in compliance with EEC 93/68 and 92/31 regulations



FIorenzato M.C. 001.004.020

FIorenzato M.C. 600000001


3068024 CAPACITOR μ F 16 450V 50/60Hz
operating temperature $-25+85^{\circ}\text{C}$
in compliance with EEC 93/68 and 92/31 regulations



FIorenzato M.C. 001.004.025

Containers for coffee

1252114 COFFEE HOPPER CLOSING SHEET
for Grinder-dispenser (FIorenzato M.C.) F5 - F6



FIorenzato M.C. 001.001.003

FIorenzato M.C. 200000003

1252112 COFFEE HOPPER LID
for Grinder-dispenser (FIorenzato M.C.) F5 - F6



FIorenzato M.C. 001.001.002

FIorenzato M.C. 200000002

1080034 COMPLETE COFFEE HOPPER
for Grinder-dispenser (FIorenzato M.C.) F5 - F6



FIorenzato M.C. 001.001.001

FIorenzato M.C. 001.001.005

FIorenzato M.C. 200000001

FIorenzato M.C. 200000004

Dosers for coffee

1252154 DOSER CYLINDER
for Grinder-dispenser (FIorenzato M.C.) F5 - F6



FIorenzato M.C. 001.003.009

FIorenzato M.C. 200000036

1252153 DOSER LID
for Grinder-dispenser (FIorenzato M.C.) F5 - F6



FIorenzato M.C. 001.003.010

FIorenzato M.C. 200000022

Suitable for:

Suitable for:

1252162 MIXER ROD



FIorenzato M.C. 001.003.037

FIorenzato M.C. 40000016

Forks for portafilter coffee grinder

1252115 FILTER HOLDER FORK

for Grinder-dispenser (FIorenzato M.C.) F5 - F6



FIorenzato M.C. 001.004.018

FIorenzato M.C. 90000025

Grinders

1251030 GRINDING BURRS FIorenzato MC (PAIR) RH

external \varnothing 64 mm - internal \varnothing 37 mm
thickness 8.5 mm - 3 mounting holes
for Grinder-dispenser (FIorenzato M.C.) F5



FIorenzato M.C. 001.002.034

FIorenzato M.C. 40000005

1251033 GRINDING BURRS FIorenzato MC (PAIR) RH

external \varnothing 82.5 mm - internal \varnothing 49 mm
thickness 9.5 mm - 3 mounting holes
for Grinder-dispenser (FIorenzato M.C.) F6



FIorenzato M.C. 001.002.030

FIorenzato M.C. 40000004

Knobs

1252158 ADJUSTMENT KNOB



FIorenzato M.C. 001.003.012

FIorenzato M.C. 40000003

Levers

1252159 RH ALUMINUM DOSER LEVER

for Grinder-dispenser (FIorenzato M.C.) F5 - F6



FIorenzato M.C. 001.003.047

FIorenzato M.C. 900.000.036

FIorenzato M.C. 900000036



Suitable for:

FIorenzato M.C.



Suitable for:


Microswitches

1252155 MICROSWITCH FLAP




FIorenzato M.C. 001.003.017 FIorenzato M.C. 300000019

1240033 MICROSWITCH 3A 250V
for Grinder-dispenser (FIorenzato M.C.) F5 - F6



FIorenzato M.C. 001.003.018 FIorenzato M.C. 600000008

1240034 MICROSWITCH 3A 250V
for Grinder-dispenser (FIorenzato M.C.) F5 - F6
for FIorenzato MC F5-F6



FIorenzato M.C. 001.003.027 FIorenzato M.C. 001.003.108 FIorenzato M.C. 600000036

Pawls for coffee grinder dosers

1252157 RH PAWL



FIorenzato M.C. 001.003.008 FIorenzato M.C. 001.003.081 FIorenzato M.C. 001.003.112
FIorenzato M.C. 001.003.117 FIorenzato M.C. 501.001.007 FIorenzato M.C. 900000035_PLAST

Pins


1252156 PAWL PIN



FIorenzato M.C. 001.003.023 FIorenzato M.C. 400000010

Relays

- 3351032 POWER RELAY 66.82 30A 250V**
 for LC80-LC140-LC1000-LC1500-LC1700-LC2000
 LC2300-LC2300TR-LC2600-LC2800
 for mod. till 06/12
 for FIorenzato MC F5-F6
 for RENEKA VIVAE-VIVAS-VIVA-LC-XL-PLUS-PRESTIGE
 MOSAIC
 for NUOVA SIMONELLI APPIACOMPACT



FIorenzato M.C. 001.003.030

FIorenzato M.C. 60000018

Rotary switches

- 1057006 SELECTOR SWITCH 0-1 POSITIONS 12A 400V**
 for Grinder-dispenser (FIorenzato M.C.) F5 - F6



FIorenzato M.C. 001.004.013

FIorenzato M.C. 60000003

Springs


- 1250094 DOSER LEVER RETURN SPRING**
 for FIorenzato MC F5-F6



FIorenzato M.C. 001.003.048

FIorenzato M.C. 70000004

- 1250209 GRIND.BURR HOLDER LOCKING SPRING**



FIorenzato M.C. 001.002.011

FIorenzato M.C. 70000001

- 1250098 PIN THRUST SPRING**



FIorenzato M.C. 001.003.024

FIorenzato M.C. 70000002

- 1250097 STAR LOCKING SPRING**



FIorenzato M.C. 001.003.032

FIorenzato M.C. 70000003



Suitable for:

FIorenzato M.C.



Suitable for:

Stars and spare parts

1343017 STAR ASSEMBLY



FIorenzato M.C. 001.003.050

FIorenzato M.C. 900000039

Tampers for coffee

1385020 COFFEE TAMPER \varnothing 55 mm



FIorenzato M.C. 001.003.013

FIorenzato M.C. 200000023

1385009 COFFEE TAMPER \varnothing 57 mm



FIorenzato M.C. 001.003.039

FIorenzato M.C. 200000017

Timers

1446900 TIMER 50 SECONDS 16A 250V

mechanical movement with balance wheel
1-minute manually set cycle
bipolar timer with contact capacity 16A 250V
environment temperature max 125°C
square pin 3.5x3.5 mm
for FIorenzato MC F5-F6
for MAZZER M100-MINI-LUX-SUPERJOLLY-MAJOR



FIorenzato M.C. 001.004.028

The data herewith contained may change without notice and LF SpA cannot be held responsible for possible errors stated or resulting by the use of this document. All rights reserved. No part of this publication may be reproduced without written permission by LF SpA.



LF SpA
via Voltri, 80 - 47522 Cesena (FC) ITALIA
Tel. +39 0547 34 11 11 - Fax +39 0547 34 11 10
www.lfircambi724.it - www.lfircambi724.mobi
info@lfircambi.it
Export Dept.: Tel. +39 0547 34 11 50 - Fax: +39 0547 34 11 55
www.lfspareparts724.com - www.lfspareparts724.mobi
export@lfspareparts.com

FRANCE



EPGC Sas
13, Rue des Forts - 59960 Neuville en Ferrain
Tél. +33 (0)3 20 25 06 21
Fax +33 (0)3 20 25 34 12
www.epgc.com
www.epgc724.mobi
epgc@epgc.com

DEUTSCHLAND



LF GmbH
Junkersstrasse, 1 - D-82178 Puchheim - München
Tel. +49 89 89 45 78 66
Fax +49 89 89 45 78 88
www.lfersatzteile724.de
www.lfersatzteile724.mobi
info@lfersatzteile.de

SCHWEIZ



LF GmbH Verkaufsbüro
Sennweidstrasse, 45 - CH-6312 Steinhausen
Tel. +41 (0)41 760 15 80-1
Fax +41 (0)41 760 15 85
www.lfersatzteile724.ch
www.lfersatzteile724.mobi
info@lfersatzteile.ch

ESPAÑA



LF Repuestos Horeca S.L.U.
Calle Ciudad Real, 10 - 45517 Escalonilla - Toledo
Tif. +34 91 477 91 00
Fax +34 91 477 90 81
www.lfrepuestos724.es
www.lfrepuestos724.mobi
info@lfrepuestos.es

UNITED KINGDOM



LF Spare Parts Ltd.
A10a Lakeside Business Park, Broadway Lane
South Cerney, Gloucestershire GL7 5XL
Tel. +44 (0)1285 86 16 25
Fax +44 (0)1285 86 39 49
www.lfspareparts724.co.uk
www.lfspareparts724.mobi
info@lfspareparts.co.uk

RUSSIA



OOO LF
ul, Anatoliya Zhivova, 8 - office 1 - 123100 Moscow
Tel. +7 499 259 85 75
Fax +7 495 725 26 53
www.lfspareparts724.ru
www.lfspareparts724.mobi
info@lfspareparts.ru

CHINA



LF China
Room 102, House 8, Lane 725, Mao Tai Rd.
Changning Dist. - 200336 Shanghai
Tel. +86 (0)21 33 53 66 31
Fax +86 (0)21 33 53 66 32
www.lfspareparts724.com
www.lfspareparts724.mobi
china@lfspareparts.com