



Spare parts for:

## Coffee grinders



Suitable for:

# ROSSI



This catalogue is automatically generated.  
Therefore, the sequence of the items might  
not be always shown at best.


Updates will be issued in case of additions  
and/or amendments.

*Suitable universal spare parts may not be included*





GRINDER ASSEMBLY RR45






# ROSSI



Position	LF code no.	Description
13	1252582	FILTER HOLDER FORK
14	1528631	CROSS HEAD SCREW M4x8 UNI 7687
15	1390003	RELAY BOARD
17	3068019	CAPACITOR $\mu$ F 12.5 450V 50/60Hz
29	3319019	RED BIPOLAR SWITCH 16A 250V
29	3319934	ORANGE BIPOLAR SWITCH 16A 250V
31	1251011	GRINDING BURRS ASTRAL-ROSSI (PAIR) LEFT
35	1252378	THREADED RING NUT 15MCx1
36	1250130	SEEGER $\varnothing$ 35 mm
37	1252377	BEARING LOCKING WASHER
38	1252376	COMPENSATION RING
52	1324933	SPRING SHAFT SEAT
55	1252587	CLOSING SECTOR RH
60	1252590	PIN GUIDE
63	1184012	S/STEEL SCREW T.C.C.E.I. M5x10 UNI 5931
81	3240123	MICROSWITCH 16A 250V
84	1252046	MICROSWITCH BOX
86	1528501	S/STEEL CROSS SCREW M5x12 mm UNI 7689
91	1528627	S/STEEL SCREW T.S.P.C.E.I.M8x20 UNI 5933
93	1252470	COUNTER FOR COFFEE GRINDER/DOSER
101	1241911	COFFEE TAMPER HANDLE
102	1324932	PIN FOR MANUAL COFFEE TAMPER



## GRINDER ASSEMBLY RR55-RR65





# ROSSI




Position	LF code no.	Description
5	3240123	MICROSWITCH 16A 250V
6	1252046	MICROSWITCH BOX
8	1528501	S/STEEL CROSS SCREW M5x12 mm UNI 7689
12	1324933	SPRING SHAFT SEAT
15	1252587	CLOSING SECTOR RH
19	1252590	PIN GUIDE
23	1184012	S/STEEL SCREW T.C.C.E.I. M5x10 UNI 5931
42	1528627	S/STEEL SCREW T.S.P.C.E.I.M8x20 UNI 5933
44	1252470	COUNTER FOR COFFEE GRINDER/DOSER
65	1252583	ADJUSTMENT RING NUT
70	1186497	GASKET FOR COFFEE OUTLET OPENING
72	1528501	S/STEEL CROSS SCREW M5x12 mm UNI 7689
75	1251011	GRINDING BURRS ASTRAL-ROSSI (PAIR) LEFT
78	1528631	CROSS HEAD SCREW M4x8 UNI 7687
86	3068019	CAPACITOR $\mu$ F 12.5 450V 50/60Hz
96	1390003	RELAY BOARD
103	3319019	RED BIPOLAR SWITCH 16A 250V
103	3319934	ORANGE BIPOLAR SWITCH 16A 250V



COFFEE GRINDER RR55OD ON DEMAND

RR55OD





# ROSSI





Position	LF code no.	Description
14	3319019	RED BIPOLAR SWITCH 16A 250V
14	3319934	ORANGE BIPOLAR SWITCH 16A 250V
16	1251094	GRINDING BURRS PAIR ROSSI LH
17	1528631	CROSS HEAD SCREW M4x8 UNI 7687
21	1252378	THREADED RING NUT 15MCx1
22	1250130	SEEGER $\varnothing$ 35 mm
23	1252377	BEARING LOCKING WASHER
24	1252376	COMPENSATION RING
25	3063005	BEARING 6202 2RS
61	3068024	CAPACITOR $\mu$ F 16 450V 50/60Hz



GRINDER ASSEMBLY CC45

CC45








# ROSSI



Position	LF code no.	Description
11	1252583	ADJUSTMENT RING NUT
15	3319019	RED BIPOLAR SWITCH 16A 250V
15	3319934	ORANGE BIPOLAR SWITCH 16A 250V
22	1252050	FILTER HOLDER FORK
25	1251011	GRINDING BURRS ASTRAL-ROSSI (PAIR) LEFT
28	1528631	CROSS HEAD SCREW M4x8 UNI 7687
48	3068019	CAPACITOR $\mu$ F 12.5 450V 50/60Hz
50	1390003	RELAY BOARD
54	3240123	MICROSWITCH 16A 250V
56	1252046	MICROSWITCH BOX
60	1528501	S/STEEL CROSS SCREW M5x12 mm UNI 7689
64	1324933	SPRING SHAFT SEAT
67	1252587	CLOSING SECTOR RH
74	1528627	S/STEEL SCREW T.S.P.C.E.I.M8x20 UNI 5933
76	1252590	PIN GUIDE
80	1184012	S/STEEL SCREW T.C.C.E.I. M5x10 UNI 5931
93	1252470	COUNTER FOR COFFEE GRINDER/DOSER



GRINDER ASSEMBLY R80



RO0401

Positions without LF code no.: upon request



# ROSSI




Position	LF code no.	Description
3	3240123	MICROSWITCH 16A 250V
4	1252046	MICROSWITCH BOX
11	1252587	CLOSING SECTOR RH
13	1528627	S/STEEL SCREW T.S.P.C.E.I.M8x20 UNI 5933
18	1252470	COUNTER FOR COFFEE GRINDER/DOSER
34	1241911	COFFEE TAMPER HANDLE
35	1324932	PIN FOR MANUAL COFFEE TAMPER
41	1252583	ADJUSTMENT RING NUT
47	1319160	THREE-POLE LEVER SWITCH 10A 400V
49	1252582	FILTER HOLDER FORK
51	1251011	GRINDING BURRS ASTRAL-ROSSI (PAIR) LEFT
55	3068019	CAPACITOR $\mu$ F 12.5 450V 50/60Hz
56	1351008	POWER RELAY 60.33
56	3351007	MINI RELAY 55.32 10A 240V 50/60Hz



GRINDER ASSEMBLY MC

MC





# ROSSI




Position	LF code no.	Description
11	1252350	ADJUSTMENT RING NUT
13	1252354	HOPPER SOCKET UNION
17	1251076	CONICAL GRINDING BURRS ROSSI (PAIR) RH
20	1186649	COFFEE OUTLET GASKET
22	3319019	RED BIPOLAR SWITCH 16A 250V
22	3319934	ORANGE BIPOLAR SWITCH 16A 250V
23	1252050	FILTER HOLDER FORK
36	1212010	REDUCTION GEAR FOR CAFFEE GRINDER
41	1212011	PLANETARY GEAR
46	3063005	BEARING 6202 2RS
59	3351007	MINI RELAY 55.32 10A 240V 50/60Hz
60	3068019	CAPACITOR $\mu$ F 12.5 450V 50/60Hz
68	3240123	MICROSWITCH 16A 250V
71	1252046	MICROSWITCH BOX
76	1324933	SPRING SHAFT SEAT
78	1252587	CLOSING SECTOR RH
85	1252590	PIN GUIDE
88	1252470	COUNTER FOR COFFEE GRINDER/DOSER
110	1252357	DOSER BOTTOM LID
116	1250123	DOSER LEVER RETURN SPRING
118	1252359	PAWL PIN



GRINDER ASSEMBLY FM

FM





# ROSSI




Position	LF code no.	Description
5	1251050	CONICAL GRINDING BURRS ROSSI (PAIR) RH



GRINDER ASSEMBLY MAC64

MAC64







# ROSSI



Position	LF code no.	Description
3	1240047	MICROSWITCH 0.1A 250V
11	1090010	DOSER CYLINDER ø 122x94 mm
13	1343059	SPRING HOLDER ROD ø 4x76 mm
15	1343058	TOP STAR
16	1343055	DOSING SHEET
17	1343057	MIDDLE STAR
18	1250148	SHAPED SPRING FOR STAR ø 15x54 mm
20	1252590	PIN GUIDE
26	1528631	CROSS HEAD SCREW M4x8 UNI 7687
29	1528627	S/STEEL SCREW T.S.P.C.E.I.M8x20 UNI 5933
44	1240044	MICROSWITCH 0.1A 250V
46	1252357	DOSER BOTTOM LID
50	1252416	PIN FOR PAWL ø 4x14 mm
53	1250123	DOSER LEVER RETURN SPRING
56	1252413	6-TEETH PAWL
83	1252415	GRINDING ADJUSTMENT SCREW
85	1252414	ADJUSTMENT RING ROD
87	1241077	GRINDING ADJUSTMENT KNOB
96	1186694	GASKET FOR COFFEE OUTLET OPENING
105	3351007	MINI RELAY 55.32 10A 240V 50/60Hz
111	3319019	RED BIPOLAR SWITCH 16A 250V
113	1251090	GR.BURRS ROSSI-BRASILIA(PAIR)TITANIUM LH
113	1251094	GRINDING BURRS PAIR ROSSI LH
115	1528631	CROSS HEAD SCREW M4x8 UNI 7687
118	1252378	THREADED RING NUT 15MCx1
119	1250130	SEEGER ø 35 mm
120	1252377	BEARING LOCKING WASHER
121	1252376	COMPENSATION RING
122	3063005	BEARING 6202 2RS
129	3063005	BEARING 6202 2RS
133	3068024	CAPACITOR µF 16 450V 50/60Hz
141	1528631	CROSS HEAD SCREW M4x8 UNI 7687
146	1252412	COFFEE COLLECTING TRAY
151	1528501	S/STEEL CROSS SCREW M5x12 mm UNI 7689



Suitable for:

# ROSSI



Suitable for:

## Adjustment rings for coffee grinder

**1252350 ADJUSTMENT RING NUT**  
for Grinder-dispenser (BRASILIA) MC  
for Grinder-dispenser (ROSSI) MC



ROSSI S2820

ROSSI S2820.10

## Bearings

**3063005 BEARING 6202 2RS**  
external  $\varnothing$  35 mm - internal  $\varnothing$  15 mm - thickness 11 mm



ROSSI M2510

ROSSI 2510

ROSSI 2524

## Capacitors

**3068019 CAPACITOR  $\mu$ F 12.5 450V 50/60Hz**  
operating temperature  $-25+85^{\circ}\text{C}$   
in compliance with EEC 93/68 and 92/31 regulations



ROSSI 3177

**3068024 CAPACITOR  $\mu$ F 16 450V 50/60Hz**  
operating temperature  $-25+85^{\circ}\text{C}$   
in compliance with EEC 93/68 and 92/31 regulations



ROSSI 3251

## Circlips

**1250130 SEEGER  $\varnothing$  35 mm**  
for Grinder-dispenser (ROSSI) RR45



ROSSI 1640



## Containers for coffee

### 1080917 COFFEE HOPPER

for Grinder-dispenser (BRASILIA) MC - RR45 - RR55  
RR65 - R80  
for Grinder-dispenser (NUOVA SIMONELLI) MDS - MDSA  
for Grinder-dispenser (ROSSI) MC - RR45 - RR55  
RR65 - R80



ROSSI 2737

ROSSI 2737.500.1

## Counters

### 1252470 COUNTER FOR COFFEE GRINDER/DOSER

for Grinder-dispenser (SAN MARCO) SMFK - SMMK  
SM90 - SM91 - SM92 - SM95 - SM96



ROSSI 3314

## Dosers for coffee

### 1252357 DOSER BOTTOM LID

for Grinder-dispenser (BRASILIA) MAC64 - MC  
for Grinder-dispenser (ROSSI) MAC64 - MC



ROSSI 7402

### 1090010 DOSER CYLINDER $\varnothing$ 122x94 mm

for Grinder-dispenser (BRASILIA) MAC64  
for Grinder-dispenser (ROSSI) MAC64



ROSSI 6256

### 1343059 SPRING HOLDER ROD $\varnothing$ 4x76 mm



ROSSI 6264

### 1324933 SPRING SHAFT SEAT



ROSSI 5248



Suitable for:

# ROSSI




Suitable for:

## Electronic printed-circuit boards

### 1390003 RELAY BOARD

for Grinder-dispenser (BRASILIA) CC45 - RR45  
RR55 - RR65  
for Grinder-dispenser (ROSSI) CC45 - RR45 - RR55  
RR65



ROSSI SE01160091

## Feet

### 1313017 FOOT ø 20x15 mm



ROSSI 2740

## Forks for portafilter coffee grinder

### 1252050 FILTER HOLDER FORK

for Grinder-dispenser (BRASILIA) CC45 - MC  
for Grinder-dispenser (ROSSI) CC45 - MC



ROSSI M2846

### 1252582 FILTER HOLDER FORK

for Grinder-dispenser (BRASILIA) RR45 - R80  
for Grinder-dispenser (NUOVA SIMONELLI) MDS - MDSA  
for Grinder-dispenser (ROSSI) RR45 - R80




ROSSI 2722

## Gaskets and seals

### 1186649 COFFEE OUTLET GASKET

for Grinder-dispenser (BRASILIA) MC  
for Grinder-dispenser (ROSSI) MC



ROSSI M2838

### 1186497 GASKET FOR COFFEE OUTLET OPENING


for Grinder-dispenser (BRASILIA) RR55 - RR65  
for Grinder-dispenser (ROSSI) RR55 - RR65



ROSSI M2919

## 1186694 GASKET FOR COFFEE OUTLET OPENING

for Grinder-dispenser (BRASILIA) MC  
for Grinder-dispenser (ROSSI) MC



ROSSI 6427

## Gears

### 1212011 PLANETARY GEAR

for Grinder-dispenser (BRASILIA) MC  
for Grinder-dispenser (ROSSI) MC



ROSSI S5591

### 1212010

### REDUCTION GEAR FOR CAFFEE GRINDER

for Grinder-dispenser (BRASILIA) MC  
for Grinder-dispenser (ROSSI) MC



ROSSI 2800

## Grinders

### 1251050 CONICAL GRINDING BURRS ROSSI (PAIR) RH

external  $\varnothing$  38/30 mm - internal  $\varnothing$  26/7 mm  
thickness 17/20,3 mm  
for Grinder-dispenser (BRASILIA) FM  
for Grinder-dispenser (IBERITAL) MINIMOLINO  
for Grinder-dispenser (ROSSI) FM



ROSSI 5200

### 1251076

### CONICAL GRINDING BURRS ROSSI (PAIR) RH

external  $\varnothing$  68/49 mm - internal  $\varnothing$  41/13 mm  
thickness 25 mm - 4 mounting holes  
inner groove for feather  
for Grinder-dispenser (BRASILIA) MC  
for Grinder-dispenser (CASADIO) GC98  
for Grinder-dispenser (MACAP) M7K - M7KA - M7KT  
for Grinder-dispenser (OBEL) MITOCONIC  
for Grinder-dispenser (ROSSI) MC



ROSSI M5585

ROSSI 5585

### 1251090 GR.BURRS ROSSI-BRASILIA(PAIR)TITANIUM LH

external  $\varnothing$  63.5 mm - internal  $\varnothing$  38 mm  
thickness 9 mm - 3 mounting holes  
for Grinder-dispenser (BRASILIA) MAC64  
for Grinder-dispenser (ROSSI) MAC64



ROSSI 4433.200

### 1251016

### GRINDING BURRS (PAIR) ROSSI LEFT

external  $\varnothing$  50 mm - internal  $\varnothing$  31 mm  
thickness 8.5 mm - 3 mounting holes  
for Grinder-dispenser (BRASILIA) BFD  
for Grinder-dispenser (ROSSI) BFD



ROSSI 5198



Suitable for:

# ROSSI



**1251011 GRINDING BURRS ASTRAL-ROSSI (PAIR) LEFT**  
 external  $\varnothing$  64 mm - internal  $\varnothing$  38 mm  
 thickness 9 mm - 3 fixing holes  
 for Grinder-dispenser (BRASILIA) CC45 - RR45  
 RR55 - RR65 - R80  
 for Grinder-dispenser (FIAMMA RST) MCF4 - MCF7  
 for Grinder-dispenser (NUOVA SIMONELLI) MDS - MDSA  
 for Grinder-dispenser (ROSSI) CC45 - RR45 - RR55  
 RR65 - R80



ROSSI 4433

Suitable for:


**1251094 GRINDING BURRS PAIR ROSSI LH**  
 external  $\varnothing$  63.5 mm - internal  $\varnothing$  38 mm  
 thickness 9 mm - 3 mounting holes  
 for Grinder-dispenser (BRASILIA) MAC64  
 for Grinder-dispenser (ROSSI) MAC64 - RR550D



ROSSI 4433.64


## Grinding burr holders

**1252583 ADJUSTMENT RING NUT**  
 for Grinder-dispenser (BRASILIA) CC45 - RR55  
 RR65 - R80  
 for Grinder-dispenser (NUOVA SIMONELLI) MDS  
 for Grinder-dispenser (ROSSI) CC45 - RR55 - RR65  
 R80



ROSSI 2720

**1252354 HOPPER SOCKET UNION**  
 for Grinder-dispenser (BRASILIA) MC  
 for Grinder-dispenser (ROSSI) MC



ROSSI S5662

**1252378 THREADED RING NUT 15MCx1**  
 for Grinder-dispenser (BRASILIA) MAC64  
 for Grinder-dispenser (NUOVA SIMONELLI) MDS - MDSA  
 for Grinder-dispenser (ROSSI) MAC64 - RR45  
 RR550D



ROSSI 4983

## Ironmongery (screws,nuts,washers)

**1252414 ADJUSTMENT RING ROD**



ROSSI 3558

**1252377 BEARING LOCKING WASHER**  
 for Grinder-dispenser (BRASILIA) RR45  
 for Grinder-dispenser (ROSSI) RR45



ROSSI 4328.1

Suitable for:

**1252376 COMPENSATION RING**  
for Grinder-dispenser (BRASILIA) RR45  
for Grinder-dispenser (ROSSI) RR45



ROSSI 1634

Suitable for:

**1528631 CROSS HEAD SCREW M4x8 UNI 7687**



ROSSI 1256

**1528501 S/STEEL CROSS SCREW M5x12 mm UNI 7689**



ROSSI 1224.10

**1184012 S/STEEL SCREW T.C.C.E.I. M5x10 UNI 5931**



ROSSI 1041

**1528627 S/STEEL SCREW T.S.P.C.E.I. M8x20 UNI 5933**



ROSSI 1218.10

## Knobs

**1241077 GRINDING ADJUSTMENT KNOB**



ROSSI 2861

## Microswitches

**1252046 MICROSWITCH BOX**



ROSSI 2747

**1240044 MICROSWITCH 0.1A 250V**  
for Grinder-dispenser (BRASILIA) MAC64  
for Grinder-dispenser (ROSSI) MAC64



ROSSI 3009.10



Suitable for:

# ROSSI



**1240047 MICROSWITCH 0.1A 250V**  
for Grinder-dispenser (BRASILIA) MAC64  
for Grinder-dispenser (ROSSI) MAC64

Suitable for:

**3240123 MICROSWITCH 16A 250V**




ROSSI 3009



ROSSI 3202

## Pawls for coffee grinder dosers

**1252413 6-TEETH PAWL**




ROSSI 6262

## Pins

**1252415 GRINDING ADJUSTMENT SCREW**  
for Grinder-dispenser (BRASILIA) MAC64  
for Grinder-dispenser (ROSSI) MAC64

**1252359 PAWL PIN**



ROSSI 3549



ROSSI 2690

**1252416 PIN FOR PAWL  $\varnothing$  4x14 mm**




ROSSI 6263

## Relays

**3351007 MINI RELAY 55.32 10A 240V 50/60Hz**  
2 switching contacts  
manual push-button

**1351008 POWER RELAY 60.33**  
for Grinder-dispenser (BRASILIA) R80  
for Grinder-dispenser (ROSSI) R80



ROSSI 3068.10



ROSSI 3068





**Springs**

**1250123 DOSER LEVER RETURN SPRING**  
for BRASILIA MC-MAC64  
for ROSSI MC-MAC64

**1250148 SHAPED SPRING FOR STAR  $\varnothing$  15x54 mm**



ROSSI 2049

ROSSI 2075

**Stars and spare parts**

**1252587 CLOSING SECTOR RH**

**1343055 DOSING SHEET**




ROSSI 3321

ROSSI 6254

**1343057 MIDDLE STAR**  
for Grinder-dispenser (BRASILIA) MAC64  
for Grinder-dispenser (ROSSI) MAC64

**1252590 PIN GUIDE**



ROSSI 6251

ROSSI 2726

**1343058 TOP STAR**  
for Grinder-dispenser (BRASILIA) MAC64  
for Grinder-dispenser (ROSSI) MAC64





ROSSI 6250

**Switches**

**3319934 ORANGE BIPOLAR SWITCH 16A 250V**  
with indicator lamp  
0-1 silk-screen printing  
max temperature 120°C  
mounting hole 22x30 mm

**3319019 RED BIPOLAR SWITCH 16A 250V**  
with indicator lamp  
max temperature 120°C  
mounting hole 22x30 mm



ROSSI 3253

ROSSI 3253



Suitable for:

# ROSSI



Suitable for:

**1319160 THREE-POLE LEVER SWITCH 10A 400V**  
for Grinder-dispenser (BRASILIA) R80  
for Grinder-dispenser (CASADIO) GC98 - G84  
MOKABIX  
for Grinder-dispenser (ROSSI) R80



ROSSI 3170.10


## Tampers for coffee

**1241911 COFFEE TAMPER HANDLE**



ROSSI 2636

**1324932 PIN FOR MANUAL COFFEE TAMPER**



ROSSI 3910

## Trays

**1252412 COFFEE COLLECTING TRAY**  
for Grinder-dispenser (BRASILIA) MAC64  
for Grinder-dispenser (ROSSI) MAC64



ROSSI 6411

*The data herewith contained may change without notice and LF SpA cannot be held responsible for possible errors stated or resulting by the use of this document. All rights reserved. No part of this publication may be reproduced without written permission by LF SpA.*



**LF SpA**  
via Voltri, 80 - 47522 Cesena (FC) ITALIA  
Tel. +39 0547 34 11 11 - Fax +39 0547 34 11 10  
[www.lfricambi724.it](http://www.lfricambi724.it) - [www.lfricambi724.mobi](http://www.lfricambi724.mobi)  
[info@lfricambi.it](mailto:info@lfricambi.it)  
Export Dept.: Tel. +39 0547 34 11 50 - Fax: +39 0547 34 11 55  
[www.lfspareparts724.com](http://www.lfspareparts724.com) - [www.lfspareparts724.mobi](http://www.lfspareparts724.mobi)  
[export@lfspaceparts.com](mailto:export@lfspaceparts.com)

**FRANCE**



**EPGC Sas**  
13, Rue des Forts - 59960 Neuville en Ferrain  
Tél. +33 (0)3 20 25 06 21  
Fax +33 (0)3 20 25 34 12  
[www.epgc.com](http://www.epgc.com)  
[www.epgc724.mobi](http://www.epgc724.mobi)  
[epgc@epgc.com](mailto:epgc@epgc.com)

**DEUTSCHLAND**



**LF GmbH**  
Junkersstrasse, 1 - D-82178 Puchheim - München  
Tel. +49 89 89 45 78 66  
Fax +49 89 89 45 78 88  
[www.lfersatzteile724.de](http://www.lfersatzteile724.de)  
[www.lfersatzteile724.mobi](http://www.lfersatzteile724.mobi)  
[info@lfersatzteile.de](mailto:info@lfersatzteile.de)

**SCHWEIZ**



**LF GmbH Verkaufsbüro**  
Sennweidstrasse, 45 - CH-6312 Steinhausen  
Tel. +41 (0)41 760 15 80-1  
Fax +41 (0)41 760 15 85  
[www.lfersatzteile724.ch](http://www.lfersatzteile724.ch)  
[www.lfersatzteile724.mobi](http://www.lfersatzteile724.mobi)  
[info@lfersatzteile.ch](mailto:info@lfersatzteile.ch)

**ESPAÑA**



**LF Repuestos Horeca S.L.U.**  
Calle Ciudad Real, 10 - 45517 Escalonilla - Toledo  
Tif. +34 91 477 91 00  
Fax +34 91 477 90 81  
[www.lfrepuestos724.es](http://www.lfrepuestos724.es)  
[www.lfrepuestos724.mobi](http://www.lfrepuestos724.mobi)  
[info@lfrepuestos.es](mailto:info@lfrepuestos.es)

**UNITED KINGDOM**



**LF Spare Parts Ltd.**  
A10a Lakeside Business Park, Broadway Lane  
South Cerney, Gloucestershire GL7 5XL  
Tel. +44 (0)1285 86 16 25  
Fax +44 (0)1285 86 39 49  
[www.lfspareparts724.co.uk](http://www.lfspareparts724.co.uk)  
[www.lfspareparts724.mobi](http://www.lfspareparts724.mobi)  
[info@lfspaceparts.co.uk](mailto:info@lfspaceparts.co.uk)

**RUSSIA**



**OOO LF**  
ul, Anatoliya Zhivova, 8 - office 1 - 123100 Moscow  
Tel. +7 499 259 85 75  
Fax +7 495 725 26 53  
[www.lfspareparts724.ru](http://www.lfspareparts724.ru)  
[www.lfspareparts724.mobi](http://www.lfspareparts724.mobi)  
[info@lfspaceparts.ru](mailto:info@lfspaceparts.ru)

**CHINA**



**LF China**  
Room 102, House 8, Lane 725, Mao Tai Rd.  
Changning Dist. - 200336 Shanghai  
Tel. +86 (0)21 33 53 66 31  
Fax +86 (0)21 33 53 66 32  
[www.lfspareparts724.com](http://www.lfspareparts724.com)  
[www.lfspareparts724.mobi](http://www.lfspareparts724.mobi)  
[china@lfspaceparts.com](mailto:china@lfspaceparts.com)