



Spare parts for:

Filter coffee machines



Suitable for:

BRAVILOR BONAMAT



This catalogue is automatically generated.
Therefore, the sequence of the items might
not be always shown at best.

Updates will be issued in case of additions
and/or amendments.

Suitable universal spare parts may not be included

Rel. 2013-09131357





Suitable for:

Suitable for:

Basket paper filters

1160911 BASKET PAPER FILTER \varnothing 110/360 mm 250PCS
250 PIECES BOX



BRAVILOR BONAMAT 7.150.102.301

1160912 BASKET PAPER FILTER \varnothing 152/437 mm 250PCS
250 PIECES BOX



BRAVILOR BONAMAT 7.150.103.301

1160914 BASKET PAPER FILTER \varnothing 203/535 mm 250PCS
250 PIECES BOX



BRAVILOR BONAMAT 7.150.104.301

1160905 BASKET PAPER FILTER \varnothing 280/635 mm 500PCS
500 PIECES BOX
for Filter coffee machine (ANIMO) CN40E



BRAVILOR BONAMAT 7.150.105.301

1160043 BASKET PAPER FILTER \varnothing 85/245 mm 1000PCS
1000 PIECES BOX



BRAVILOR BONAMAT 7.150.101.101 BRAVILOR BONAMAT 7.150.101.103


Boilers

1048027 BOILER FASTENING CLIP



BRAVILOR BONAMAT 6.301.045.001

1048020 BOILER 1710W 240V
boiler \varnothing 64 mm - max overall height 175 mm
complete with 2 safety thermostats
for Filter coffee machine (BRAVILOR BONAMAT)
MATICTWIN - MONDOTWIN




BRAVILOR BONAMAT 6.000.201.675



Suitable for:

1048025 BOILER 2160W 240V
boiler \varnothing 64 mm - max overall height 175 mm
complete with 2 safety thermostats
for Filter coffee machine (BRAVILOR BONAMAT)
ISO-MATIC2 - MATICTWIN - MATIC2WB - MATIC3
MATIC3WB - MONDOTWIN - MONDO1 - MONDO2
MONDO3WB - NOVO - RLX - RL413 - THA10 - TH10



BRAVILOR BONAMAT 6.000.201.652 BRAVILOR BONAMAT 6000201652

Suitable for:

1048022 BOILER 2750W 240V
boiler \varnothing 64 mm - max. overall length 210 mm
for Filter coffee machine (BRAVILOR BONAMAT) THA20
TH20



BRAVILOR BONAMAT 6.000.201.656

1048021 BOILER 6540W 240V
boiler \varnothing 102 mm - max overall height 310 mm
complete with 3 safety thermostats
for Filter coffee machine (BRAVILOR BONAMAT) B10
B10HW



BRAVILOR BONAMAT 6.000.205.582 BRAVILOR BONAMAT 6000205582

1048026 BOILER 6540W 240V
boiler \varnothing 102 mm - max overall height 275 mm
complete with 3 safety thermostats
for Filter coffee machine (BRAVILOR BONAMAT) B10



BRAVILOR BONAMAT 6.205.320.000

Capacitors

1120044 CAPACITOR μ F 0,1 250V
for Filter coffee machine (BRAVILOR BONAMAT)
since 1/01/96
Series MATIC



BRAVILOR BONAMAT 6.211.772.000 BRAVILOR BONAMAT 6211772000

Coffee measuring spoons

1069003 PLASTIC MEASURING SPOON 40 g



BRAVILOR BONAMAT 7.094.100.101



Suitable for:


BRAVILOR BONAMAT



Suitable for:


Contact thermostats

1443020 CONTACT THERMOSTAT 16A 250V
with manual reset
for BRAVILOR-BONAMAT B5-B10-B20-B40-B5HW-B10HW
B20HW-BFT321-BFT322
for BRAVILOR-BONAMAT RLX



BRAVILOR BONAMAT 6.016.008.052

1443021 CONTACT THERMOSTAT 16A 250V
with manual reset - pin M4
for BRAVILOR-BONAMAT B5HW-B10HW-B20HW




BRAVILOR BONAMAT 6.016.008.054

1444020 CONTACT THERMOSTAT 16A 250V
for boiler
for BRAVILOR-BONAMAT HWA50
for BRAVILOR-BONAMAT ISO-MATIC2-MATIC2WB-MATIC3
MATIC3WB-MATIC2WIN-MATIC2KTS-MATIC3KTS
MATIC2WINKTS-MONDO1-MONDO2-MONDO3WB-MONDOTWIN
MONDO2KTS-MONDOTWINKTS-NOVO-RL101-RL102-RL111
RL112-RL121-RL211-RL212-RL214-RL221-RL222-RL224
RL118-RL411-RL413-RLX-TH10-TH20-THKTS-THA10-THA20
THAKTS



BRAVILOR BONAMAT 6.016.008.057 BRAVILOR BONAMAT 6016008057

1444021 CONTACT THERMOSTAT 16A 250V
manual reset
for BRAVILOR-BONAMAT
B5-B5HW-B10-B10HW-B20-B20HW
B40-BFT321-RLX
for BRAVILOR-BONAMAT BOLERO10-BOLERO11-BOLERO20
BOLERO21-BOLERO22-BOLEROXL-FRESHONE
for BRAVILOR-BONAMAT HWA30D-HWA60D



BRAVILOR BONAMAT 6.016.008.064 BRAVILOR BONAMAT 6016008064

CARAFES FOR FILTER COFFEE MACHINES

1224007 COFFEE GLASS CARAFE 1.7 L
for Filter coffee machine (BRAVILOR BONAMAT)
MATIC2WIN - MATIC2 - MATIC3 - MONDOTWIN
MONDO2 - RLX131 - RLX31 - RLX41



BRAVILOR BONAMAT 7.170.401.101 BRAVILOR BONAMAT 7.170.602.101 BRAVILOR BONAMAT 7.170.602.102 BRAVILOR BONAMAT 7.094.301.101

1224005 WATER MEASURING CARAFE 2.2 LITERS
plastic made
for Filter coffee machine (ANIMO) TA100 - TA100W
TVA100 - TVB100
for Filter coffee machine (BRAVILOR BONAMAT)
for Filter coffee machine (CAMURRI)



Dispenser taps and accessories

1359020 DISPENSER TAP PIN



BRAVILOR BONAMAT 6.015.001.214 BRAVILOR BONAMAT 6015001214

1359021 DISPENSER TAP PIN



BRAVILOR BONAMAT 6.015.001.281 BRAVILOR BONAMAT 6015001281



BRAVILOR BONAMAT



Suitable for:

Suitable for:

1786022 GASKET FOR DISPENSING TAP

1786036 GASKET FOR DISPENSING TAP



BRAVILOR BONAMAT 6.015.001.213 BRAVILOR BONAMAT 6015001213

BRAVILOR BONAMAT 6.015.001.006 BRAVILOR BONAMAT 6015001006

1357014 LEVER WITH DIAPHRAGM
for manifold tap
for BRAVILOR-BONAMAT
VHG5-VHG10-VHG20-VHG40-HM505
HM510-HM520-HCM510-HCM520-HWA50

1786036 GASKET FOR DISPENSING TAP



BRAVILOR BONAMAT 6.015.001.144

BRAVILOR BONAMAT 6.015.001.006 BRAVILOR BONAMAT 6015001006

1357021 LEVER WITH DIAPHRAGM
for manifold tap
for BRAVILOR-BONAMAT
B5HW-B10HW-B20HW-RL211-RL212
RL214-RL221-RL222-RL224-RL118-RL411-RL101-RL111
RL121-RL211-RL413
for BRAVILOR-BONAMAT
HW10-HW505-HW510-HW520-HWA505
HWA510-HWA520-HWA20

1357017 MANIFOLD TAP BODY
female connect. \varnothing 18 - chrome-plated metal body
for BRAVILOR-BONAMAT
VHG5-VHG10-VHG20-VHG40-HWA50



BRAVILOR BONAMAT 6.015.001.227

BRAVILOR BONAMAT 6.015.001.110

1357015 MANIFOLD TAP BODY 3/8"
connection \varnothing 3/8" M - chrome-plated metal body
for BRAVILOR-BONAMAT
B5HW-B10HW-B20HW-RL118-RL411
RL101-RL111-RL121-RL211-RL221-RL413
for BRAVILOR-BONAMAT HW10-HWA20

1357016 MANIFOLD TAP BODY 3/8"
connection \varnothing 3/8" M - chrome-plated metal body
for BRAVILOR-BONAMAT HW505-HW510-HW520-HWA505
HWA510-HWA520
for BRAVILOR-BONAMAT RL211-RL212-RL214-RL221-RL222
RL224



BRAVILOR BONAMAT 6.015.001.218

BRAVILOR BONAMAT 6.015.001.212 BRAVILOR BONAMAT 6015001212



BRAVILOR BONAMAT



Suitable for:

Suitable for:

1357013 MANIFOLD TAP 3/8"
 connection \varnothing 3/8"M - chrome-plated metal body
 for BRAVILOR-BONAMAT HV10-HVA20
 for BRAVILOR-BONAMAT RL118-RL411-RL101-RL111-RL121
 RL211-RL221-RL413

1528081 NUT TOP PART



BRAVILOR BONAMAT 6.015.001.230

BRAVILOR BONAMAT 6.214.058.001 BRAVILOR BONAMAT 6214058001

1528083 NUT TOP PART

1225036 TAP LEVER
 for dispenser tap
 for BRAVILOR-BONAMAT VHG5-B5-B5HW-B10-B10HW-B20
 B20HW-B40-BFT321-BFT322-RLX



BRAVILOR BONAMAT 6.242.183.001 BRAVILOR BONAMAT 6242183001

BRAVILOR BONAMAT 6.214.056.001 BRAVILOR BONAMAT 6214056001

1225037 TAP LEVER
 for dispenser tap
 for BRAVILOR-BONAMAT VHG5-B5-B5HW-B10-B10HW-B20
 B20HW-B40-BFT321-BFT322-RLX

3225004 TAP LEVER
 for dispenser tap



BRAVILOR BONAMAT 6.015.001.365 BRAVILOR BONAMAT 6015001365

BRAVILOR BONAMAT 6.242.191.001 BRAVILOR BONAMAT 6242191001

Electric hot plates

1311002 ELECTRIC PLATE 90W 110/240V
 external \varnothing 150 mm - for carafe
 for Filter coffee machine (BRAVILOR BONAMAT)
 MATICTWIN - MATIC2 - MATIC2WB - MATIC3
 MONDOTWIN - MONDO1 - MONDO2 - MONDO3WB - RL101
 RL102 - RL111 - RL112 - RL211 - RL212 - RL214
 RL22 - RL224

1311001 SUPPORT PLATE
 sizes max 150x150 mm
 for Filter coffee machine (BRAVILOR BONAMAT)
 MATICTWIN - MATICTWINKTS - MATIC2 - MATIC2KTS
 MATIC2WB - MATIC3 - MATIC3KTS - MATIC3WB
 MONDOTWIN - MONDOTWINKTS - MONDO1 - MONDO2
 MONDO2KTS - MONDO3WB - RLX




BRAVILOR BONAMAT 6.301.023.000

BRAVILOR BONAMAT 6.401.001.000 BRAVILOR BONAMAT 6401001000


Electronic printed-circuit boards

1390059 ELECTRONIC CIRCUIT BOARD LED
 sizes 60x38 mm
 for Filter coffee machine (BRAVILOR BONAMAT)
 MONDOTWIN - MONDOTWINKTS - MONDO1 - MONDO2
 MONDO2KTS - MONDO3WB - THKTS - TH10 - TH20




BRAVILOR BONAMAT 6.301.714.000 BRAVILOR BONAMAT 6301714000

1390050 ELECTRONIC CIRCUIT BOARD 230V 50/60Hz
 sizes 140x70 mm
 for Filter coffee machine (BRAVILOR BONAMAT)
 MATICTWIN - MATIC2 - MATIC2WB - MATIC3
 MATIC3WB - RL121




BRAVILOR BONAMAT 6.202.970.000 BRAVILOR BONAMAT 6202970000

1390061 ELECTRONIC CIRCUIT BOARD 230V 50/60Hz
 dimensions 140x70 mm
 for Filter coffee machine (BRAVILOR BONAMAT) RL413




BRAVILOR BONAMAT 6.402.061.000

1390048 ELECTRONIC CIRCUIT BOARD 240V 50/60Hz
 sizes 110x60 mm
 for Filter coffee machine (BRAVILOR BONAMAT)
 MONDOTWIN - MONDOTWINKTS - MONDO1 - MONDO2
 MONDO2KTS - MONDO3WB - THKTS - TH10 - TH20




BRAVILOR BONAMAT 6.301.713.000 BRAVILOR BONAMAT 6301713000

1390052 ELECTRONIC CIRCUIT BOARD 240V 50/60Hz
 sizes 156x100 mm
 for Filter coffee machine (BRAVILOR BONAMAT) B10HW
 B20HW - B5HW




BRAVILOR BONAMAT 6.211.996.000

1390053 ELECTRONIC CIRCUIT BOARD 240V 50/60Hz
 sizes 140x70 mm
 for Filter coffee machine (BRAVILOR BONAMAT) RL211
 RL212 - RL214 - RL221 - RL222 - RL224



BRAVILOR BONAMAT 6.202.881.000

1390057 ELECTRONIC CIRCUIT BOARD 240V 50/60Hz
 sizes 140x70 mm
 for Filter coffee machine (BRAVILOR BONAMAT)
 MATICTWIN - MATIC2 - MATIC2WB - MATIC3 - RL101
 RL102 - RL111 - RL112 - THA10 - THA20



BRAVILOR BONAMAT 6.202.743.000

1390062 ELECTRONIC CIRCUIT BOARD 240V 50/60Hz
 sizes 136x80 mm
 for Filter coffee machine (BRAVILOR BONAMAT) B10HW
 B20HW - B5HW - HWA20 - RL101 - RL111 - RL121
 RL211 - RL221 - RL413



BRAVILOR BONAMAT 6.236.086.000 BRAVILOR BONAMAT 6.236.232.000




BRAVILOR BONAMAT



Suitable for:


1390051 PUSH-BUTT.PANEL ELECTR.CIRC.BOARD
sizes 86x42 mm
for Filter coffee machine (BRAVILOR BONAMAT) RL221
RL222 - RL224



BRAVILOR BONAMAT 6.213.206.000


Suitable for:

1390054 PUSH-BUTT.PANEL ELECTR.CIRC.BOARD
sizes 60x39 mm
for Filter coffee machine (BRAVILOR BONAMAT)
MATICTWIN - MATICTWINKTS - MATIC2 - MATIC2KTS
MATIC2WB - MATIC3 - MATIC3KTS - MATIC3WB
THAKTS - THA10 - THA20




BRAVILOR BONAMAT 6.202.966.000 BRAVILOR BONAMAT 6202966000

1390055 PUSH-BUTT.PANEL ELECTR.CIRC.BOARD
sizes 136x100 mm
for Filter coffee machine (BRAVILOR BONAMAT) B10HW
B20HW - B5HW




BRAVILOR BONAMAT 6.211.900.000

1390056 PUSH-BUTT.PANEL ELECTR.CIRC.BOARD
sizes 86x43 mm
for Filter coffee machine (BRAVILOR BONAMAT)
MATICTWIN - MATIC2 - MATIC2WB - MATIC3 - RL101
RL102 - RL111 - RL112 - RL212 - RL214 - RL221
THA10 - THA20



BRAVILOR BONAMAT 6.202.623.000


1390060 PUSH-BUTT.PANEL ELECTR.CIRC.BOARD
sizes 86x42 mm
for Filter coffee machine (BRAVILOR BONAMAT) RL121
RL413



BRAVILOR BONAMAT 6.202.998.000

Energy regulators

1350001 ENERGY ADJUSTER 16A 240V
D-shaped pin \varnothing 6x4.6 mm
for Filter coffee machine (BRAVILOR BONAMAT) VHG10
VHG20 - VHG5



BRAVILOR BONAMAT 6.004.005.003 BRAVILOR BONAMAT 6004005003

Feet

1359001 ANTI-SKID FOOT


for Filter coffee machine (BRAVILOR BONAMAT)
 MATICTWIN - MATIC2 - MATIC2WB - MATIC3
 MATIC3WB - MONDOTWIN - MONDO1 - MONDO2
 MONDO3WB



BRAVILOR BONAMAT 6.401.004.001 BRAVILOR BONAMAT 6401004001

1313010 ANTI-SKID FOOT SUPPORT

for Filter coffee machine (BRAVILOR BONAMAT)
 MATICTWIN - MATIC2 - MATIC2WB - MATIC3
 MATIC3WB - MONDOTWIN - MONDO1 - MONDO2
 MONDO3WB



BRAVILOR BONAMAT 6.401.003.001 BRAVILOR BONAMAT 6401003001

Filter holders for coffee machines

1160951 ST/STEEL FILTER HOLDR BASKET 85/245 mm

size 175x175 mm - altezza totale 95 mm
 for Filter coffee machine (BRAVILOR BONAMAT)
 MATICTWIN - MATIC2 - MATIC2WB - MATIC3
 MATIC3WB - MONDOTWIN - MONDO1 - MONDO2
 MONDO3WB - RLX - RL101 - RL102 - RL111 - RL112
 RL118 - RL121 - RL211 - RL212 - RL214 - RL221
 RL222 - RL224 - RL411 - RL413 - THA10 - THA20
 TH10 - TH20



BRAVILOR BONAMAT 7.090.100.101 BRAVILOR BONAMAT 7.090.101.101

Flowmeters

1455053 VOLUMETRIC FLOWMETER 937-7525/F03

hose-end fitting inlet/outlet \varnothing 12 mm
 nozzle \varnothing 2.5 mm
 for Filter coffee machine (BRAVILOR BONAMAT) B10
 B10HW - B20 - B20HW - B40 - B5 - B5HW



BRAVILOR BONAMAT 6.016.024.004 BRAVILOR BONAMAT 6016024004



Suitable for:


BRAVILOR BONAMAT



Suitable for:

Gaskets and seals

1186880 COLORLESS SILICONE O RING 04287
 for shower head
 for Filter coffee machine (BRAVILOR BONAMAT)
 BFT321 - BFT322 - ISO - MATICKTS - MATICTWIN
 MATIC2 - MATIC2WB - MATIC3 - MATIC3WB
 MONDOKTS - MONDOTWIN - MONDO1 - MONDO2
 MONDO3WB - NOVO - Series RL - Series RLX
 Series TH - Series THA - THAKTS - THKTS




BRAVILOR BONAMAT 6.201.902.001 BRAVILOR BONAMAT 6201902001

1786021 FLAT GASKET \varnothing 12x5x3 mm
 for level glass
 for Filter coffee machine (BRAVILOR BONAMAT)
 HCM510 - HCM520 - HM505 - HM510 - HM520
 HWA505 - HWA510 - HWA520 - HW505 - HW510
 HW520 - RL211 - RL212 - RL214 - RL221 - RL222
 RL224




BRAVILOR BONAMAT 6.015.001.205 BRAVILOR BONAMAT 6015001205

1786020 FLAT GASKET \varnothing 15x5x3 mm
 for level glass
 for Filter coffee machine (BRAVILOR BONAMAT)
 HCM510 - HCM520 - HM505 - HM510 - HM520
 HWA505 - HWA510 - HWA520 - HW505 - HW510
 HW520 - RL211 - RL212 - RL214 - RL221 - RL222
 RL224



BRAVILOR BONAMAT 6.015.001.209 BRAVILOR BONAMAT 6015001209

1186882 FLAT GASKET \varnothing 16x4.5x5 mm
 for level glass
 for Filter coffee machine (BRAVILOR BONAMAT) VHG10
 VHG20 - VHG40 - VHG5




BRAVILOR BONAMAT 6.015.001.012

1186881 FLAT GASKET \varnothing 18x11x3 mm
 for level glass
 for Filter coffee machine (BRAVILOR BONAMAT) VHG10
 VHG20 - VHG40 - VHG5



BRAVILOR BONAMAT 6.015.001.011

3186190 GASKET FOR ELEMENT 23x46 mm
 in rubber
 for Filter coffee machine (BRAVILOR BONAMAT)
 BFT321-001 - BFT321-011 - BFT322-001 - BHW
 CB3 - CB6 - Series HCM5 - Series HM5
 Series HW+5 - HWA20 - HWA30-D - HWA60-D - HW10
 RLX - RL101 - RL111 - RL118 - RL121 - RL211
 RL221 - RL411 - RL413




BRAVILOR BONAMAT 3.011.031.000 BRAVILOR BONAMAT 6.011.031.001 BRAVILOR BONAMAT 6011031001

1186457 RED SILICONE O RING 0177



BRAVILOR BONAMAT 6.011.001.082 BRAVILOR BONAMAT 6011001082

1786019 SILICONE GASKET
 thickness 6 mm - length 270 mm
 for Filter coffee machine (BRAVILOR BONAMAT) B10
 B10HW - B20 - B20HW - B40 - B5 - B5HW



BRAVILOR BONAMAT 6.311.112.001 BRAVILOR BONAMAT 6311112001

Handles

1242018 HANDLE FOR CONTAINER
for Filter coffee machine (BRAVILOR BONAMAT)
HMA505 - HM505



BRAVILOR BONAMAT 6.014.002.072 BRAVILOR BONAMAT 6.240.165.001 BRAVILOR BONAMAT 6014002072

1242021 HANDLE FOR CONTAINER
for Filter coffee machine (BRAVILOR BONAMAT) VHG10



BRAVILOR BONAMAT 6.242.198.001 BRAVILOR BONAMAT 6242198001


Heating elements

1455046 FLEXIBLE HEATING ELEMENT
for Filter coffee machine (BRAVILOR BONAMAT) VHG10



BRAVILOR BONAMAT 6.242.043.000 BRAVILOR BONAMAT 6242043000

1455018 HEATING ELEMENT 100/240V
size 74x49 mm
for Filter coffee machine (BRAVILOR BONAMAT) NOVO



BRAVILOR BONAMAT 6.301.554.000 BRAVILOR BONAMAT 6301554000

1455045 HEATING ELEMENT 100/240V
size 74x49 mm
for Filter coffee machine (BRAVILOR BONAMAT) VHG10



BRAVILOR BONAMAT 6.242.206.000 BRAVILOR BONAMAT 6242206000

1755188 HEATING ELEMENT 1100W 230V
external \varnothing 125 mm - height 40 mm
flange 49x25 mm
for Filter coffee machine (BRAVILOR BONAMAT) RL101
RL111 - RL121 - RL211 - RL221 - RL413



BRAVILOR BONAMAT 6.236.098.000

1755169 HEATING ELEMENT 1200W 240V
length 120 mm - flange 49x25 mm
for Filter coffee machine (BRAVILOR BONAMAT)
BFT321 - B10HW - B20HW - B5HW



BRAVILOR BONAMAT 6.236.158.000 BRAVILOR BONAMAT 6236158000

1755165 HEATING ELEMENT 1710W 240V
external \varnothing 110 mm - height 255 mm
connections \varnothing 14 mm
for Filter coffee machine (BRAVILOR BONAMAT) RL102
RL112 - RL212 - RL222



BRAVILOR BONAMAT 6.000.256.083



BRAVILOR BONAMAT



Suitable for:

1755173 HEATING ELEMENT 1710W 240V

length 100 mm - flange external \varnothing 80 mm
for Filter coffee machine (BRAVILOR BONAMAT)
MATICWIN - MONDOTWIN - RL102 - RL112 - RL212
RL214 - RL222 - RL224



BRAVILOR BONAMAT 6.301.201.000

Suitable for:

1755170 HEATING ELEMENT 2160W 240V


external \varnothing 123 mm - height 35 mm
flange 49x25 mm
for Filter coffee machine (BRAVILOR BONAMAT) HWA20
HWA505 - HW10 - HW505 - RL101 - RL111 - RL118
RL121 - RL211 - RL221 - RL411 - RL413



BRAVILOR BONAMAT 6.236.011.000 BRAVILOR BONAMAT 6236011000

1755171 HEATING ELEMENT 2160W 240V

length 105 mm - flange external \varnothing 80 mm
for Filter coffee machine (BRAVILOR BONAMAT) ISO
MATICWIN - MATIC2 - MATIC2WB - MATIC3
MATIC3WB - MONDOTWIN - MONDO1 - MONDO2
MONDO3WB - NOVO - RLX - RL101 - RL102 - RL111
RL112 - RL118 - RL121 - RL211 - RL221 - RL222
RL413 - THA10 - TH10



BRAVILOR BONAMAT 6.301.002.000 BRAVILOR BONAMAT 6301002000

1455017 HEATING ELEMENT 2270W 240V

external \varnothing 125 mm - height 20 mm
flange 49x25 mm
for Filter coffee machine (BRAVILOR BONAMAT) CB3
CB6 - HM505 - HM510 - HM520 - HWA510 - HWA520



BRAVILOR BONAMAT 6.000.262.014 BRAVILOR BONAMAT 6000262014

1755168 HEATING ELEMENT 2750W 240V

length 140 mm - flange external \varnothing 80 mm
for Filter coffee machine (BRAVILOR BONAMAT) RL211
RL212 - RL214 - RL221 - RL222 - RL224 - THA20
TH20



BRAVILOR BONAMAT 6.301.079.000

1755174 HEATING ELEMENT 3415W 240V

external \varnothing 110 mm - height 255
connections \varnothing 14 mm
for Filter coffee machine (BRAVILOR BONAMAT) HWD30
RL102 - RL112 - RL212 - RL222



BRAVILOR BONAMAT 6.000.256.030

1755172 HEATING ELEMENT 90W 110/240V

sizes 75x49 mm
for Filter coffee machine (BRAVILOR BONAMAT)
MATICWIN - MATICTWINKTS - MATIC2 - MATIC2KTS
MATIC2WB - MATIC3 - MATIC3KTS - MATIC3WB
MONDOTWIN - MONDOTWINKTS - MONDO1 - MONDO2
MONDO2KTS - MONDO3WB - RLX - RL101 - RL102
RL111 - RL112 - RL118 - RL121 - RL211 - RL212
RL214 - RL221 - RL222 - RL224



BRAVILOR BONAMAT 6.401.076.000

1455048 SUPPORT FOR HEATING ELEMENT

for Filter coffee machine (BRAVILOR BONAMAT)
BFT321 - BFT322 - MATIC - MONDO



BRAVILOR BONAMAT 6.203.764.001 BRAVILOR BONAMAT 6203764001

Lamps

1221025 RED INDICATOR LIGHT 220V

ø head 14.5 mm - ø hole 13 mm - 120°C
for Filter coffee machine (BRAVILOR BONAMAT) CB3
CB6 - HCM510 - HCM520 - HM505 - HM510 - HM520
HWA505 - HWA510 - HWA520 - HW505 - HW510
HW520 - MONDOTWIN - MONDO1 - MONDO2 - MONDO3WB
RL118 - RL411 - TH10 - TH20



BRAVILOR BONAMAT 6.005.001.035 BRAVILOR BONAMAT 6005001035

1221029 RED INDICATOR LIGHT 24V

ø head 14.5 mm - ø hole 13 mm - 190°C
for Filter coffee machine (BRAVILOR BONAMAT) HWA50
MONDOTWIN - MONDO1 - MONDO2 - MONDO3WB - RL118
RL411 - TH10 - TH20



BRAVILOR BONAMAT 6.005.001.032

1221024 YELLOW INDICATOR LIGHT 220V

ø head 14.5 mm - ø hole 13 mm - 120°C
for Filter coffee machine (BRAVILOR BONAMAT)
HWA505 - HWA510 - HWA520 - HW505 - HW510
HW520 - MONDOTWIN - MONDO1 - MONDO2 - MONDO3WB
RL118 - RL411 - TH10



BRAVILOR BONAMAT 6.005.001.034 BRAVILOR BONAMAT 6005001034

Level gauges

1201046 GLASS PROTECTION BOTTOM SUPPORT

external ø 18 mm - connections ø 16/10 mm
for Filter coffee machine (BRAVILOR BONAMAT)
HCM510 - HCM520 - HM505 - HM510 - HM520
HWA505 - HWA510 - HWA520 - HW505 - HW510
HW520 - RL211 - RL212 - RL214 - RL221 - RL222
RL224



BRAVILOR BONAMAT 6.015.001.204

1201048 GLASS PROTECTION BOTTOM SUPPORT

external ø 22 mm - connections ø 19/10 mm
for BRAVILOR-BONAMAT VHG5-VHG10-VHG20-VHG40
for Filter coffee machine (BRAVILOR BONAMAT) VHG10
VHG20 - VHG40 - VHG5



BRAVILOR BONAMAT 6.015.001.080

1201045 GLASS PROTECTION TOP CAP

external ø 19 mm - connection ø 16 mm
for Filter coffee machine (BRAVILOR BONAMAT)
HCM510 - HCM520 - HM505 - HM510 - HM520
HWA505 - HWA510 - HWA520 - HW505 - HW510
RL211 - RL212 - RL214 - RL221 - RL222 - RL224



BRAVILOR BONAMAT 6.015.001.210 BRAVILOR BONAMAT 6015001210

1201047 GLASS PROTECTION TOP CAP

external ø 22 mm - connection ø 19 mm
for BRAVILOR-BONAMAT VHG5-VHG10-VHG20-VHG40
for Filter coffee machine (BRAVILOR BONAMAT) VHG10
VHG20 - VHG40 - VHG5



BRAVILOR BONAMAT 6.015.001.010



BRAVILOR BONAMAT



Suitable for:

1201035 LEVEL GLASS \varnothing 12x125 mm
with serigraphy 1-2
for Filter coffee machine (BRAVILOR BONAMAT) RL211
RL212 - RL214 - RL221 - RL222 - RL224



BRAVILOR BONAMAT 6.015.001.207

Suitable for:

1201026 LEVEL GLASS \varnothing 12x182 mm
with serigraphy 1-4
for Filter coffee machine (BRAVILOR BONAMAT)
HWA505 - HW505



BRAVILOR BONAMAT 6.015.001.292 BRAVILOR BONAMAT 6015001292

1201027 LEVEL GLASS \varnothing 12x235 mm
with serigraphy MAX-MIN
for Filter coffee machine (BRAVILOR BONAMAT)
HCM520 - HM520



BRAVILOR BONAMAT 6.015.001.276 BRAVILOR BONAMAT 6015001276

1201037 LEVEL GLASS \varnothing 15x228 mm
with serigraphy 2.5-10
for Filter coffee machine (BRAVILOR BONAMAT) VHG10



BRAVILOR BONAMAT 6.015.001.014

1201038 LEVEL GLASS \varnothing 15x272 mm
with serigraphy 5-20
for Filter coffee machine (BRAVILOR BONAMAT) VHG20




BRAVILOR BONAMAT 6.015.001.051

1201041 LEVEL GLASS PROTECTION \varnothing 19x204 mm
for Filter coffee machine (BRAVILOR BONAMAT) VHG5



BRAVILOR BONAMAT 6.015.001.018

1201042 LEVEL GLASS PROTECTION \varnothing 19x229 mm
for Filter coffee machine (BRAVILOR BONAMAT) VHG10



BRAVILOR BONAMAT 6.015.001.013

1201043 LEVEL GLASS PROTECTION \varnothing 19x273 mm
for Filter coffee machine (BRAVILOR BONAMAT) VHG20



BRAVILOR BONAMAT 6.015.001.052

1201044 LEVEL GLASS PROTECTION \varnothing 19x400 mm
for Filter coffee machine (BRAVILOR BONAMAT) VHG40



BRAVILOR BONAMAT 6.015.001.136



Level tanks

1527027 LEVEL TANK

for Filter coffee machine (BRAVILOR BONAMAT) RLX
RL102 - RL111 - RL112 - RL211 - RL212 - RL214
RL221 - RL222 - RL224 - RL413



BRAVILOR BONAMAT 6.000.202.262

Microswitches

1240124 MAGNETIC MICROSWITCH

cable length 1000 mm - bulb \varnothing 6x32 mm
for Filter coffee machine (BRAVILOR BONAMAT) B10
B10HW - B5 - B5HW



BRAVILOR BONAMAT 6.205.886.000 BRAVILOR BONAMAT 6205886000

Pressure switches

1320009 PRESSURE SWITCH 6A 250V

max. pressure 4 bar
for Filter coffee machine (BRAVILOR BONAMAT) HWD30
RL102 - RL112 - RL212 - RL222



BRAVILOR BONAMAT 6.016.015.005

Probes

1397014 TEMPERATURE PROBE

for BRAVILOR-BONAMAT
B5-B5HW-B10-B10HW-B20-B20HW
B40-RLX
for BRAVILOR-BONAMAT BOLERO10-BOLERO11-BOLERO20
BOLERO21-BOLERO22-BOLEROXL-FRESHONE
for BRAVILOR-BONAMAT HWA30D-HWA60D



BRAVILOR BONAMAT 6.236.188.000 BRAVILOR BONAMAT 6236188000



Suitable for:

Suitable for:

Pumps


1122500 WATER PUMP FLOJET 230V 50Hz
 FOR BIG WATER BOTTLES - 230VAC 50Hz 0.3A
 flow rate 1,1GPM / 4,1LPM
 float switch for water vacuum
 flow switch for use identification
 UL-NSF-CE CERTIFIED



BRAVILOR BONAMAT 7.270.103.101

Regulators and level sensors


1341023 COVER COMPLETE WITH LEVEL PROBE
 for Filter coffee machine (BRAVILOR BONAMAT) MATIC
 MONDO - THA10 - THA20



BRAVILOR BONAMAT 6.402.006.000 BRAVILOR BONAMAT 6402006000


Relays

3351029 BIPOLAR RELAY 62.82.8 16A 250V
 for UNIVERBAR DISHWASHER ERGON-ERGOND-MIDI40
 MIDI40D-COMPACT-MICRO-UBR530/2R-UBF530/2R-ETRACR
 ETRACF
 for BRAVILOR-BONAMAT RL101-RL111-RL121-RL211-RL212
 RL214-RL221-RL222-RL224



BRAVILOR BONAMAT 6.004.002.055

1351009 RELAY TP3250 16A 230V 50Hz
 for BRAVILOR-BONAMAT B5-B10-B5HW-B10HW-B20HW
 BFT321-BFT322
 for BRAVILOR-BONAMAT HVA60D



BRAVILOR BONAMAT 6.004.002.068 BRAVILOR BONAMAT 6004002068

Shower screens for brew group

1081032 SHOWER SCREEN

for Filter coffee machine (BRAVILOR BONAMAT)
 MATICTWIN - MATIC2 - MATIC2WB - MATIC3
 MATIC3WB - MONDOTWIN - MONDO1 - MONDO2
 MONDO3WB - RLX - RL101 - RL102 - RL111 - RL112
 RL118 - RL121 - RL211 - RL212 - RL214 - RL221
 RL222 - RL224 - RL411 - RL413 - THA10 - THA20
 TH10 - TH20



BRAVILOR BONAMAT 6.201.901.001

1081033 SHOWER SCREEN

for Filter coffee machine (ANIMO) ISO - NOVO



BRAVILOR BONAMAT 6.301.598.001 BRAVILOR BONAMAT 6301598001

Showerholder diffusers

1081035 SHOWER HOLDER


for Filter coffee machine (BRAVILOR BONAMAT)
 BFT321 - BFT322 - ISO - NOVO



BRAVILOR BONAMAT 6.301.378.001 BRAVILOR BONAMAT 6301378001

1081034 SPRINKLER

for Filter coffee machine (BRAVILOR BONAMAT)
 MATICTWIN - MATIC2 - MATIC2KTS - MATIC2WB
 MATIC3 - MATIC3WB - MATIKTWINKTS - MATIK3KTS
 MONDOTWIN - MONDOTWINKTS - MONDO1 - MONDO2
 MONDO2KTS - MONDO3WB - RLX - RL101 - RL102
 RL111 - RL112 - RL118 - RL121 - RL211 - RL212
 RL214 - RL221 - RL222 - RL224 - RL411 - RL413
 THAKTS - THA10 - THA20 - THKTS - TH10 - TH20




BRAVILOR BONAMAT 6.201.900.000 BRAVILOR BONAMAT 6201900000

Solenoid valves

1120045 SOLENOID VALVE 230V ø 10 mm


solenoid valve 180° - 230V 50Hz - max 60°C
 inlet 3/4" - outlet ø 10 mm
 with brown flowrate adjuster at the outlet
 for Filter coffee machine (BRAVILOR BONAMAT) HWA20
 MATIC2 - MATIC2KTS - MATIC2WB - MATIC3
 MATIC3KTS - MATIC3WB - THAKTS - THA10 - THA20



BRAVILOR BONAMAT 6.016.001.035 BRAVILOR BONAMAT 6016001035

1120064 SOLENOID VALVE 230V ø 10 mm

solenoid valve 180° - 230V 50Hz - max 60°C
 inlet 3/4" - two outlets ø 10 mm
 with one yellow flowrate adjuster at the outlet
 with one brown flowrate adjuster at the outlet
 for Filter coffee machine (BRAVILOR BONAMAT) B10HW
 B20HW - B5HW - RLX231 - RLX241 - RLX31 - RLX41
 RLX75 - RLX76 - RLX85 - RL102 - RL112 - RL212



BRAVILOR BONAMAT 6.016.001.026



BRAVILOR BONAMAT




Suitable for:

Suitable for:

3120005 SOLENOID VALVE 329 220/240V \varnothing 10 mm
 solenoid valve 180° - 220/240V 50/60Hz - max 90°C
 inlet 3/4" - outlet \varnothing 10 mm



3120000 FILTER FOR INLET SOLENOID VALVE ELBI



BRAVILOR BONAMAT 6.016.001.001 BRAVILOR BONAMAT 6.016.001.017 BRAVILOR BONAMAT 6.016.001.078

3120021 INLET PRESSURE REDUCER 12 L/min BLACK



3120022 INLET PRESSURE REDUCER 16 L/min BLACK



3120019 INLET PRESSURE REDUCER 5.5 L/min BLACK



3120037 OUTLET REDUCER ELBI 0.25 L/min GREEN
 for ELBI solenoid valve
 face value +/- 25%



3120202 OUTLET REDUCER ELBI 0.35 L/min YELLOW
 for ELBI solenoid valve
 face value +/- 25%



3120015 OUTLET REDUCER ELBI 0.5 L/min RED
 for ELBI solenoid valve
 face value +/- 25%



3120016 OUTLET REDUCER ELBI 1.2 L/min NEUTRAL
 for ELBI solenoid valve
 face value +/- 25%



3120203 OUTLET REDUCER ELBI 2 L/min WHITE
 for ELBI solenoid valve
 face value +/- 25%



3120017 OUTLET REDUCER ELBI 2.5 L/min ORANGE
 for ELBI solenoid valve
 face value +/- 25%



3120201 OUTLET REDUCER ELBI 4.7 L/min GREY
 for ELBI solenoid valve
 face value +/- 25%





BRAVILOR BONAMAT



Suitable for:

3120204 OUTLET REDUCER ELBI 5.5 L/min BROWN
for ELBI solenoid valve
face value +/- 25%



Suitable for:

1120063 SOLENOID VALVE 334 220/240V ø 10 mm
solenoid valve 180° - 220/240V 50/60Hz - max 90°C
inlet 3/4" - two outlets ø 10 mm
with two orange flowrate adjusters at the outlet
for Filter coffee machine (BRAVILOR BONAMAT) B10HW
B20HW - B5HW - MATICTWIN - RLX55 - RL101
RL111 - RL211 - RL224 - RL413




1120065 SOLENOID VALVE 369 220/240V ø 10 mm
solenoid valve 180° - 220/240V 50/60Hz - max 90°C
inlet 3/4" - three outlets ø 10 mm
with two orange flowrate adjusters at the outlet
with one red flowrate adjuster at the outlet
for Filter coffee machine (BRAVILOR BONAMAT)
BFT321 - BFT322 - RLX131 - RLX575 - RLX585
RL121 - RL221 - RL222



BRAVILOR BONAMAT 6.016.001.022 BRAVILOR BONAMAT 6.016.001.033 BRAVILOR BONAMAT 6.016.001.036 BRAVILOR BONAMAT 6.016.001.027 BRAVILOR BONAMAT 6.016.001.028

Springs

1250249 PAPER FILTER HOLDING SPRING
length 127 mm - width 102 mm
thickness 2 mm



BRAVILOR BONAMAT 7.091.600.101

1250245 TAPERED SPRING FOR DRAIN TAP
max. external ø 15 mm - length 28 mm



BRAVILOR BONAMAT 6.015.001.215 BRAVILOR BONAMAT 6015001215

1250246 TAPERED SPRING FOR DRAIN TAP
max. external ø 18 mm - length 33 mm



BRAVILOR BONAMAT 6.015.001.027 BRAVILOR BONAMAT 6015001027



Suitable for:

BRAVILOR BONAMAT



Suitable for:

Switches

1319338 BIPOLAR SWITCH 10A 250V

with indicator light
for Filter coffee machine (BRAVILOR BONAMAT) BAHW
BFT321 - BFT322 - B10 - B10HW - B20 - B20HW
B40 - B5 - HWA30-D - HWA60-D - KMD - MATICTWIN
MATICTWINKTS - MATIC2 - MATIC2KTS - MATIC2WB
MATIC3 - MATIC3KTS - MATIC3WB - MONDOTWIN
MONDOTWINKTS - MONDO1 - MONDO2 - MONDO2KTS
MONDO3WB - RLX - THAKTS - THA10 - THA20
THKTS - TH10 - TH20



BRAVILOR BONAMAT 6.004.001.069 BRAVILOR BONAMAT 6004001069

1319337 BLACK BIPOLAR LEVER SWITCH 10A 250V


with orange indicator light
mounting hole 36x15 mm
for Filter coffee machine (BRAVILOR BONAMAT) HWA20
HWA50 - HWD30 - HW10 - MATICTWIN - MATIC2
MATIC2WB - MATIC3 - MATIC3WB - MONDOTWIN
MONDO1 - MONDO2 - MONDO3WB - RL101 - RL102
RL111 - RL112 - RL118 - RL121 - RL211 - RL212
RL214 - RL411 - RL413 - THA10 - THA20 - TH10



BRAVILOR BONAMAT 6.004.001.051

1319362 BUTTON PANEL 5 BUTTONS

for Filter coffee machine (BRAVILOR BONAMAT) B10
B20 - B40 - B5



BRAVILOR BONAMAT 6.211.916.000

1319327 FRAME FOR SWITCH


for Filter coffee machine (BRAVILOR BONAMAT) MATIC
MONDO



BRAVILOR BONAMAT 6.401.217.001 BRAVILOR BONAMAT 6401217001

1319328 ORANGE SINGLE-POLE SWITCH 250V

with indicator light and push-button cover
temperature max 120°C
mounting hole 11x30 mm
for Filter coffee machine (ANIMO) WKI10N
WKI20N3KW - WKI20N6KW - WKI40N - WKI60N
WKI80N
for Filter coffee machine (BRAVILOR BONAMAT)
since 1/01/02
Series B - Series BHW
VHG10 - VHG20 - VHG40 - VHG5



BRAVILOR BONAMAT 6.004.001.080

1319339 SWITCH FRAME


mounting hole 36x15 mm



BRAVILOR BONAMAT 6.004.001.070

1319295 2 PUSH BUTTON PANEL 240V

for Filter coffee machine (BRAVILOR BONAMAT) ISO
NOVO



BRAVILOR BONAMAT 6.301.526.000 BRAVILOR BONAMAT 6301526000


Thermostats

1444037 SINGLE PHASE THERMOSTAT
 D-shaped pin \varnothing 6x4.6 mm
 capillary 360 mm
 bulb \varnothing 6x135 mm
 with stuffing gland fitting
 for Filter coffee machine (BRAVILOR BONAMAT)
 HCM510 - HCM520 - HM505 - HM510 - HM520




BRAVILOR BONAMAT 6.016.005.102

1444035 SINGLE PHASE THERMOSTAT 110°C
 covered capillary 500 mm
 bulb \varnothing 6x113 mm
 with stuffing gland fitting
 for Filter coffee machine (BRAVILOR BONAMAT) RL118
 RL411




BRAVILOR BONAMAT 6.016.005.018

1444036 SINGLE PHASE THERMOSTAT 132°C
 with manual reset
 capillary 880 mm
 bulb \varnothing 3x245 mm
 with stuffing gland fitting
 for Filter coffee machine (BRAVILOR BONAMAT)
 HCM510 - HCM520 - HM505 - HM510 - HM520
 HWA505 - HWA510 - HWA520 - HW505 - HW510
 HW520



BRAVILOR BONAMAT 6.016.008.200 BRAVILOR BONAMAT 6016008200

1444019 SINGLE-PHASE THERMOSTAT 30-85°C
 capillary 750 mm
 bulb \varnothing 6x140 mm
 D-shaped pin 6x4.6 mm
 for Filter coffee machine (BRAVILOR BONAMAT)
 HCM510 - HCM520 - HM505 - HM510 - HM520



BRAVILOR BONAMAT 6.016.005.035 BRAVILOR BONAMAT 6016005035

3744073 SINGLE-PHASE THERMOSTAT 30-95°C
 capillary 700 mm
 bulb 6x140 mm
 D-shaped pin 6x4.6 mm
 for Filter coffee machine (BRAVILOR BONAMAT)
 Series HM - Series HW



BRAVILOR BONAMAT 6.016.005.034 BRAVILOR BONAMAT 6016005034

1444038 THERMOSTAT 165°C 230/400V 20/16A
 bulb \varnothing 3x205 mm
 for BRAVILOR-BONAMAT HW10-HWA20
 for Filter coffee machine (BRAVILOR BONAMAT) HWA20
 HW10 - RL101 - RL111 - RL118 - RL121 - RL211
 RL221 - RL411 - RL413



BRAVILOR BONAMAT 6.016.008.005

1444039 THREE PHASE THERMOSTAT 165°C 400V 25A
 with manual reset
 bulb \varnothing 3x340 mm - connection \varnothing 3/8"
 for Filter coffee machine (BRAVILOR BONAMAT) HWD30
 RL102 - RL112 - RL212 - RL222



BRAVILOR BONAMAT 6.016.008.006

The data herewith contained may change without notice and LF SpA cannot be held responsible for possible errors stated or resulting by the use of this document. All rights reserved. No part of this publication may be reproduced without written permission by LF SpA.



LF SpA
via Voltri, 80 - 47522 Cesena (FC) ITALIA
Tel. +39 0547 34 11 11 - Fax +39 0547 34 11 10
www.lfricambi724.it - www.lfricambi724.mobi
info@lfricambi.it
Export Dept.: Tel. +39 0547 34 11 50 - Fax: +39 0547 34 11 55
www.lfspareparts724.com - www.lfspareparts724.mobi
export@lfspaceparts.com

FRANCE



EPGC Sas
13, Rue des Forts - 59960 Neuville en Ferrain
Tél. +33 (0)3 20 25 06 21
Fax +33 (0)3 20 25 34 12
www.epgc.com
www.epgc724.mobi
epgc@epgc.com

DEUTSCHLAND



LF GmbH
Junkersstrasse, 1 - D-82178 Puchheim - München
Tel. +49 89 89 45 78 66
Fax +49 89 89 45 78 88
www.lfersatzteile724.de
www.lfersatzteile724.mobi
info@lfersatzteile.de

SCHWEIZ



LF GmbH Verkaufsbüro
Sennweidstrasse, 45 - CH-6312 Steinhausen
Tel. +41 (0)41 760 15 80-1
Fax +41 (0)41 760 15 85
www.lfersatzteile724.ch
www.lfersatzteile724.mobi
info@lfersatzteile.ch

ESPAÑA



LF Repuestos Horeca S.L.U.
Calle Ciudad Real, 10 - 45517 Escalonilla - Toledo
Tif. +34 91 477 91 00
Fax +34 91 477 90 81
www.lfrepuestos724.es
www.lfrepuestos724.mobi
info@lfrepuestos.es

UNITED KINGDOM



LF Spare Parts Ltd.
A10a Lakeside Business Park, Broadway Lane
South Cerney, Gloucestershire GL7 5XL
Tel. +44 (0)1285 86 16 25
Fax +44 (0)1285 86 39 49
www.lfspareparts724.co.uk
www.lfspareparts724.mobi
info@lfspaceparts.co.uk

RUSSIA



OOO LF
ul, Anatoliya Zhivova, 8 - office 1 - 123100 Moscow
Tel. +7 499 259 85 75
Fax +7 495 725 26 53
www.lfspareparts724.ru
www.lfspareparts724.mobi
info@lfspaceparts.ru

CHINA



LF China
Room 102, House 8, Lane 725, Mao Tai Rd.
Changning Dist. - 200336 Shanghai
Tel. +86 (0)21 33 53 66 31
Fax +86 (0)21 33 53 66 32
www.lfspareparts724.com
www.lfspareparts724.mobi
china@lfspaceparts.com