



Spare parts for:  
**Laundry machines**



Suitable for:

**AGA**



This catalogue is automatically generated.  
Therefore, the sequence of the items might  
not be always shown at best.  
Updates will be issued in case of additions  
and/or amendments.

*Suitable **universal spare parts** may not be included*





Suitable for:

## AGA



**3786206 DOOR GASKET ø 335 mm**  
for Washing machine (AGA) SUPER16 - SUPER25  
SUPER33 - 520/16 - 520/18



AGA L8/D203

Suitable for:

**3786207 DOOR GASKET ø 365 mm**  
for Washing machine (AGA) 620/30



AGA L14/D3

**3786211 DOOR GASKET ø 400 mm**  
for Dryer (AGA) D50



AGA E50/D3

**3786210 DOOR GASKET ø 405 mm**  
for Washing machine (AGA) SUPER35 - SUPER50




AGA LC16/D3

**3786208 DOOR GASKET ø 470 mm**  
for Washing machine (AGA) 735/50 - 735/70




AGA L22/D3

**3786209 DOOR GASKET ø 510 mm**  
for Washing machine (AGA) L50A - SUPER105



AGA LC44/D3

**3786205 GLASS GASKET ø 265 mm**  
for Washing machine (AGA) 520/16 - 520/18




AGA L8/D35

**5036675 WINDOW GASKET ø 460 mm**  
for Dryer (AGA) E12 - E18 - E26 - E35



AGA L20/D3

**5036676 DOOR GLASS ø 390 mm**  
for DRIER E12-E18-E26-E35




AGA L20/D2A

## Bearings

**3063076 ADJUSTABLE ROLLER BEARING 21310 E**


for AGA WASHING MACHINE S25  
for Washing machine (AGA) S25



AGA 4855003

**3063069 ADJUSTABLE ROLLER BEARING 21311 E1**


for Washing machine (AGA) SUPER33 - SUPER35  
SUPER50 - 735/70



AGA 4855002

**3063070 ADJUSTABLE ROLLER BEARING 22208 E1**

for Washing machine (AGA) S16



AGA 4854002

**3063071 ADJUSTABLE ROLLER BEARING 22210 E1**


for Washing machine (AGA) S16



AGA 4855002

**3063078 ADJUSTABLE ROLLER BEARING 22215 E1**

for Washing machine (AGA) S50



AGA 4857501

**3063079 ADJUSTABLE ROLLER BEARING 22312 E1**


for Washing machine (AGA) L50A - S105



AGA 4856001

**3063001 BEARING 6308 2RS**


for Washing machine (AGA) 520/16 - 520/18  
for Washing machine (IMESA) RC12 - RC18 - RC23  
for Washing machine (WHIRLPOOL) AGB224 - AGB226  
for Washing machine (ZANUSSI) LB70E - LB8G - LB80E



AGA 4824001

**3063003 BEARING 6310 2RS**


for Washing machine (AGA) 620/30  
for Washing machine (FAGOR) CLB160E - CLV160V  
EWM-120 - EWM-160 - LB-120E - LB-160E  
for Washing machine (ZANUSSI) CLB160E - CLB160V  
EWM120 - EWM160 - LB110E - LB120E - LB160E  
LB160V



AGA 4825001

**3063075 BEARING 6311 2RS**


for Washing machine (AGA) 735/50



AGA 4825502

**3063077 ROLLER BEARING NU308E**

for Washing machine (AGA) S25



AGA 4864001



Suitable for:

## AGA




- 3063039 ROLLER BEARING NU309ECP**  
for Washing machine (IMESA) RC14 - RC18 - RC23  
for Washing machine (WHIRLPOOL) AGB224 - AGB226



AGA 4854501

Suitable for:

- 3063073 SUPPORT FLANGE WITH BEARING UC206**  
flange UCF206 external dimensions 110x110 mm  
for AGA DRYER E12-E18-E26-E35  
for Dryer (AGA) E12 - E18 - E26 - E35



AGA 484030/SF

- 3063074 SUPPPORT FLANGE WITH BEARING UC206**  
flange UCF206 external dimensions 160x45 mm  
for Dryer (AGA) E12 - E18 - E26 - E35



AGA 484030/SG

## Belts

- 3062057 MULTIGRIP BELT 880L16 H37 7 GROOVES**  
for Washing machine (AGA) S105



AGA 80-POLIV2235L

- 3062051 TOOTHED BELT SPZX 1362**  
for Dryer (AGA) E26 - E35



AGA 80-SPZX1362

- 3062049 TOOTHED BELT SPZX 1500**  
for Dryer (AGA) E12 - E18



AGA 80-SPZX1500

- 3062106 TOOTHED BELT SPZX 1512**  
for Washing machine (AGA) 520/16



AGA 80-SPZX1512

- 3062052 TOOTHED BELT SPZX 1800**  
for Washing machine (AGA) 520/18



AGA 80-SPZX1800

- 3062053 TOOTHED BELT SPZX 1850**  
for Washing machine (AGA) S25 - S33



AGA 80-SPZX1850





Suitable for:

**3062054 TOOTHED BELT SPZX 1900**  
for Washing machine (AGA) 735/70



AGA 80-SPZX1900

**3062060 TOOTHED BELT SPZX 2840**  
for Washing machine (AGA)



AGA 80-SPZX2840

**3062058 TOOTHED BELT SPZX 925**  
for Washing machine (AGA)



AGA 80-SPZX925

**3062048 TOOTHED BELT XPZ 1420**  
for Washing machine (AGA) S16



AGA 80-SPZX1420

**3062055 V-BELT A80**  
for Washing machine (AGA)



AGA 80-A80

**3062061 V-BELT SPZ 2062**  
for Washing machine (AGA) SUPER35 - SUPER50



AGA 80-SPZX2062

## AGA



Suitable for:

**3062046 TOOTHED BELT SPZX 2120**  
for Washing machine (AGA)



AGA 80-SPZX2120

**3062059 TOOTHED BELT SPZX 3150**  
for Washing machine (AGA) L50A



AGA 80-SPZX3150

**3062062 TOOTHED BELT SPZX 987**  
for Washing machine (AGA) S16



AGA 80-SPZX987

**3062047 V-BELT A100**  
for Dryer (AGA) E50



AGA 80-A100

**3062056 V-BELT A88**  
for Washing machine (AGA) 735/50



AGA 80-A88



Suitable for:

AGA



Suitable for:

## Burners

**3023327 BURNER  $\varnothing$  70x495 mm**  
in stainless steel  
for Dryer (AGA) E12 - E18 - E26



AGA E18/RG1/G

**3023326 BURNER  $\varnothing$  70x655 mm**  
in stainless steel  
for Dryer (AGA) E35



AGA E35/RG1/G

## Castors

**3346178 WHEEL FOR DRUM SUPPORT  $\varnothing$  150x35 mm**  
fixing plate 135x110 mm  
distance between holes 105-80 mm  
for Dryer (AGA) E50



AGA E50/T130

## Electromagnets

**5034468 ELECTROMAGNET DOOR BLOCK 24V 15W**  
for WASHING EXTRACTOR SUPER 25  
SUPER 33-SUPER 35-SUPER 50



AGA A548/09/301


## Electronic printed-circuit boards

**3390256 BLOCK-UNBLOCK CIRCUIT BOARD**  
dimensions 80x70 mm  
for Washing machine (AGA) L50A - SUPER16 - SUPER25  
SUPER33 - 520/16 - 520/18 - 620/30 - 735/50  
735/70



AGA A531/LCD9/01B

**3390255 CIRCUIT BOARD 7 LED**  
dimensions 150x20 mm  
for Washing machine (AGA) L50A - SUPER16 - SUPER25  
SUPER33 - 520/16 - 520/18 - 620/30 - 735/50  
735/70



AGA A531/LCD9/01L




Suitable for:

# AGA




**3390253 DELAY CIRCUIT BOARD 30"**  
for Washing machine (AGA) SUPER35 - SUPER50



AGA L22/E115/B

Suitable for:

**3390254 DELAY CIRCUIT BOARD 60"**  
for Washing machine (AGA)



AGA L22/E215/B


AGA 022/E215/B

**3390252 DISPLAY CIRCUIT BOARD**  
dimensions 190x130 mm  
for Washing machine (AGA) L50A - SUPER16 - SUPER25  
SUPER33 - 520/16 - 520/18 - 620/30 - 735/50  
735/70



AGA A531/LCD9/01D

**3390258 DISPLAY CIRCUIT BOARD 230V**  
dimensions 170x100 mm  
for Dryer (AGA) E12 - E18 - E26 - E35 - E50




AGA A531/DRY/LDS

**3390251 MOTHERBOARD EASY WASH3000**  
dimensions 270x155 mm  
for Washing machine (AGA) L50A - SUPER105  
SUPER16 - SUPER25 - SUPER33 - SUPER35  
SUPER50 - 520/16 - 520/18 - 620/30 - 735/50  
735/70



AGA A531/EW3/01

**3390257 POWER CIRCUIT BOARD**  
dimensions 220x140 mm  
for Washing machine (AGA) L50A - SUPER16 - SUPER25  
SUPER33 - 520/16 - 520/18 - 620/30 - 735/50  
735/70



AGA A531/LCD9/01P

## Electronic thermostats and controllers

**3445274 ELECTRONIC THERMOSTAT IC902 250V 8A**  
ON-OFF command with one point of intervention  
PTC/NTC probe selectable (not included)  
dimensions 77x35 depth 65 mm  
mounting hole 71x29 mm  
for Dryer (AGA) E12 - E18 - E26 - E35 - E50  
for Washing machine (AGA) L50A - SUPER16 - SUPER25  
520/16 - 520/18 - 620/30 - 735/50 - 735/70



AGA A530/902H/01



Suitable for:

AGA



Suitable for:

## Gaskets and seals

- 3786204 DOOR GASKET 1900 mm**  
profile 90x20 mm  
for Dryer (AGA) E12 - E18 - E26 - E35



AGA E18/D03

## Heating elements

- 3455018 HEATING ELEMENT 1200W 220V**  
length 590 mm  
winged part ø 36 mm  
for Dryer (AGA) E12 - E18 - E26 - E35



AGA E18/RE1

- 3455019 HEATING ELEMENT 2000W 220V**  
length 180 mm - width 65 mm  
flange 80x28 mm  
for Washing machine (AGA) SUPER16 - SUPER35  
SUPER50 - 520/16 - 520/18 - 620/30 - 735/50  
735/70



AGA L8/RE201/B

- 5033499 HEATING ELEMENT 2000W 220V**  
immersed length 435 mm  
flange ø 65 mm  
for Washing machine (AGA)



AGA L10/RE101/B

- 3355870 HEATING ELEMENT 3000W 230V**  
length 265 mm - width 65 mm  
flange 80x28 mm  
for Washing machine (AGA) SUPER25 - SUPER33  
for Washing machine (FAGOR) LAC-10 - LC-10  
LC/E-10 - LF-10  
for Washing machine (GRANDIMPIANTI) WFM11 - WR37  
for Washing machine (POLIMATIC) FS10 - FS6 - FS7  
P5 - P6 - P65 - P75 - RS10 - RS13 - RS18  
RS22 - RS6 - RS7  
for Washing machine (PRIMUS) C6 - C8 - FS10 - FS6  
FS7 - F6 - F7 - P6 - P7 - RS10 - RS13 - RS16  
RS18 - RS22 - RS6 - RS7  
for Washing machine (WHIRLPOOL) LSW100 - LWS70  
WACS11 - WACS6 - WACS7 - WACS8 - WAC11 - WAC17  
WAC23 - WAC8



AGA LC12/RE101/B




## Knobs

- 3241710 KNOB  $\varnothing$  48 mm**  
shaft hole  $\varnothing$  6 mm  
for program switch  
for Washing machine (AGA) S16 - S25 - S33 - 520/16  
520/18 - 620/30 - 735/50 - 735/70




AGA L8/A10

- 3241712 SELF-STICK DISK WITH ARROW SYMBOL  $\varnothing$  42 mm**  
for Washing machine (AGA) S16 - S25 - S33 - 520/16  
520/18 - 620/30 - 735/50 - 735/70



AGA L8/A109

- 3241711 SELF-STICK DISK 1-6  $\varnothing$  42 mm**  
for Washing machine (AGA) S16 - S25 - S33 - 520/16  
520/18 - 620/30 - 735/50 - 735/70



AGA L14/A8

## Lamps

- 3221452 NEUTRAL INDICATOR LAMP 250V**  
head  $\varnothing$  13.5 mm - hole  $\varnothing$  10 mm - 120°C  
for Dryer (AGA) E12 - E18 - E26 - E35 - E50  
for Washing machine (AGA) 520/16 - 520/18 - 620/30  
735/50 - 735/70



AGA A519/T/01

- 3221453 RED INDICATOR LAMP 24V**  
head  $\varnothing$  13.5 mm - hole  $\varnothing$  10 mm - 120°C  
for Washing machine (AGA) SUPER35 - SUPER50



AGA A520/R/01

## Microswitches

- 3240829 MICRO SWITCH MF10 16A 250V**  
for Dryer (AGA) E12 - E18 - E26 - E35



AGA A506/10/04

- 3240834 MICROSWITCH 10A 400V**  
for Dryer (AGA) E12 - E18 - E26 - E35  
for Washing machine (AGA) 520/16



AGA A506/10/05



Suitable for:

AGA



Suitable for:

**3240836 MICROSWITCH 5A 250V**  
for Washing machine (AGA) 735/50 - 735/70



AGA A506/10/06

## Outlet solenoid valves and accessories

**3120327 DRAIN SOLENOID VALVE MDB-C-2**  
normally CLOSED - 220/240V 50/60Hz 24AMP  
inlet ø 50 mm - outlet ø 50 mm  
overflow pipe ø 35 mm - with manual lever  
for Washing machine (AGA)



AGA A512/2-2/NC1

**3120050 DRAIN SOLENOID VALVE MDB-O-2**  
normally OPEN - 220/240V 50/60Hz 24AMP  
inlet ø 50 mm - outlet ø 50 mm  
overflow pipe ø 35 mm  
for Washing machine (AGA) 520/16 - 735/50  
for Washing machine (DOMUS) DFI13 - DFI18 - DFI9  
W10 - W13 - W18 - W9  
for Washing machine (FAGOR) LA-10M - LA-13M  
LA-18M - LAC-10 - LAC-14 - LAC-7 - LB-10M  
LB-13M - LB-18M - LC-10 - LC-13 - LC-14  
LC-18 - LC-7 - LC-8 - LF-10 - LF-13 - LF-14  
LF-18 - LF-7 - LF-8  
for Washing machine (IMESA) LM11 - LM14 - LM18  
LM23 - LM6 - LM8 - RC11 - RC14 - RC18 - RC23  
RC8 - R18  
for Washing machine (WHIRLPOOL) AGB208/WP



AGA A512/2-2/NA1

**3120329 DRAIN SOLENOID VALVE MDB-O-2**  
normally OPEN - 24V 50/60Hz 1.27/1.58AMP  
inlet ø 50 mm - outlet ø 50 mm  
overflow pipe ø 35 mm  
WITH FIXING BRACKET FOR MODIFICATION  
for Washing machine (AGA) SUPER16 - SUPER25  
SUPER33 - SUPER35 - SUPER50 - 520/18 - 620/30



AGA A512/2-2/NA3

AGA A512/2-2/NA3+...

**3120331 DRAIN SOLENOID VALVE MDB-O-2**  
normally OPEN - 230V 50/60Hz 18AMP  
inlet ø 50 mm - outlet ø 50 mm  
for Washing machine (AGA) S105 - 735/50 - 735/70



AGA A512/2-2/NA2

## 3120328 WATER DRAIN SOLENOID VALVE MDB-C-2

normally CLOSED - 240V 50/60Hz  
inlet  $\varnothing$  50 mm - outlet  $\varnothing$  50 mm  
with manual lever  
for Washing machine (AGA)



AGA A512/2-2/NC2

## Suitable for:

## 5036861 WATER DRAIN SOLENOID VALVE MDB-C-3

normally CLOSED - 220/240V 50/60Hz 0.24A  
inlet  $\varnothing$  75 mm - outlet  $\varnothing$  80 mm  
overflow pipe  $\varnothing$  35 mm - with manual lever  
for Washing machine (AGA)



AGA A512/2-3/NC1

## Piezo ignitors

## 3001057 PLUG CABLE $\varnothing$ 4x1000 mm

for Dryer (AGA) E12 - E18 - E26 - E35



AGA A547/R14/01T

## 3001058

## PLUG CABLE $\varnothing$ 6x1000 mm

for Dryer (AGA) E12 - E18 - E26 - E35



AGA A546/11/02T

## Pressure switches

## 3320180 PRESSURE SWITCH 105/40 mm 16A 250V

for Washing machine (AGA) L50A - 735/70



AGA A511/761181

## 3320181

## PRESSURE SWITCH 150/60 mm 16A 250V


for Washing machine (AGA) S25 - S33 - 520/16  
520/18 - 620/30 - 735/50 - 735/70



AGA A511/761182

## 3320179 PRESSURE SWITCH 205/140 mm 16A 250V

for Washing machine (AGA) L50A - S25 - S33  
520/16 - 520/18



AGA A511/761184

## 3320176

## PRESSURE SWITCH 265/180 mm 16A 250V

for Washing machine (AGA) L50A - S25 - S33  
520/16 - 520/18



AGA A511/761185

## 3320177 PRESSURE SWITCH 285/190 mm 16A 250V

for Washing machine (AGA) 735/70




AGA A511/761186

## 3320178

## PRESSURE SWITCH 310/210 mm 16A 250V

for Washing machine (AGA) 620/30 - 735/50



AGA A511/761187



Suitable for:

AGA



Suitable for:

**3320182 PRESSURE SWITCH 390/250 mm 16A 250V**  
for Washing machine (AGA) 620/30 - 735/50



AGA A511/761189

## Rating-plates

**3399102 CONTROL PLATE EASY DRY 3000**  
dimensions 135x90 mm  
for Dryer (AGA) E12 - E18 - E26



AGA A531/DRYM/LD

AGA A531/DRYM/LDS

## Rinse aid containers and accessories

**3527007 CONTAINER FOR LIQUID DETERGENT**  
dimensions 104x104x93 mm  
for Washing machine (AGA) L50A



AGA LC16/C99L/H

**3527006 CONTAINER FOR POWDER DETERGENT**  
dimensions 103x103x93 mm  
for Washing machine (AGA) L50A



AGA LC16/C99P/H

**3527008 DETERGENT TANK 270x187 mm**  
for Washing machine (AGA)



AGA L8/C9HW/B

**5052209 SOAP CONTAINER**  
for Washing machine (AGA) SUPER16



AGA L8/C9/I

**5052411 SOAP INLET HOSE**  
for Washing machine (AGA) SUPER16 - SUPER25  
520/16 - 520/18 - 620/30 - 735/50



AGA L14/O102



Suitable for:

**5052212 SOAP TANK GASKET**  
for Washing machine (AGA) SUPER16 - SUPER25  
520/16 - 520/18 - 620/30 - 735/50



AGA L8/C24

## AGA



Suitable for:

**5052211 TANK FOR SOAP CONTAINER**  
for Washing machine (AGA) SUPER16 - SUPER25  
520/16 - 520/18 - 620/30 - 735/50



AGA L7/C110

## Rotary switches


**3057252 SELECTOR SWITCH ENCODER**  
D-shaft  $\varnothing 6 \times 4.6$  mm  
for Washing machine (AGA) L50A - SUPER16 - SUPER25  
SUPER33 - 520/16 - 520/18 - 620/30 - 735/50  
735/70



AGA A531/LCD9/EN


AGA A531/LCD9/ENC

**3057250 SELECTOR SWITCH 0-3 POSITIONS 16A 400V**  
square spindle 5x5 mm  
for Washing machine (AGA) SUPER16 - SUPER33  
520/16 - 520/18 - 620/30 - 735/50 - 735/70



AGA A532/4/02

**3057251 SELECTOR SWITCH 0-5 POSITIONS 12A 400V**  
square spindle 5x5 mm  
for Washing machine (AGA) SUPER16 - SUPER25  
SUPER33 - 520/16 - 520/18 - 620/30 - 735/50  
735/70



AGA A532/6/02

## Shock absorbers

**5034458 GAS SPRING**  
for Washing machine (AGA) SUPER25 - SUPER33  
SUPER35 - SUPER50



AGA LC7/S11

**5034459 GAS SPRING 240N**  
mounting holes  $\varnothing 10$  mm mounting distance 193 mm  
for Washing machine (AGA) SUPER25 - SUPER33  
SUPER35 - SUPER50



AGA LC7/S11/240





Suitable for:

AGA



Suitable for:

## Solenoid valves

**3120330 SOLENOID VALVE 24V ø 14 mm**  
solenoid valvole 180° - 24V 50Hz - max 90°C  
inlet 3/4" - three outlets ø 14 mm  
for Washing machine (AGA) L50A - SUPER16 - SUPER25  
SUPER33 - SUPER35 - 520/18



AGA A512/4-3/4/02

**3120167 SOLENOID VALVE 264A 220/240V ø 14 mm**  
solenoid valve 180° - 220/240V 50/60Hz - max 90°C  
inlet 3/4" - three outlets ø 14 mm  
for Washing machine (AGA) 520/16  
for Washing machine (IMESA) RC11 - RC8  
for Washing machine (WHIRLPOOL) AGB208/WP  
AGB209/WP - AGB214/WP - AGB215/WP



AGA A512/4-3/4/01

## Sparking plugs

**3020399 FLAME DETECTION PLUG**  
for Dryer (AGA) E12 - E18 - E26 - E35



AGA A547/R14/01


**3020398 FLAME SPARKING PLUG**  
for Dryer (AGA) E12 - E18 - E26 - E35



AGA A546/A14/01

## Springs

**5034469 CYLINDER SPRING 23x8 mm**  
for WASHING EXTRACTOR SUPER 25  
SUPER 33-SUPER 35-SUPER 50



AGA 6002301

## Switches

**3319476 SELF-STICK LABEL FOR EMERGENCY PUSH-BUT**



AGA A504/E/01E

**5036674 SINGLE POLE PUSH-BUTTON GREEN 16A 250V**  
mounting hole 22x26 mm  
for Dryer (AGA) E12 - E18 - E26 - E35




AGA A533/VL/01




## Timers

- 3322292 PROGRAMMER 900-914-9936 220V 50Hz**  
D-shaped shaft  $\varnothing$  6x5 mm  
for Washing machine (AGA) S16 - S33 - 520/16  
520/18 - 620/30 - 735/50 - 735/70




AGA A531/C14/112

- 3446143 TIMER 15 MINUTES 16A 250V**  
contact capacity 16(4)A 250V  
max temperature 85°C  
D-shaped pin  $\varnothing$  6x4.6 mm  
for Dryer (AGA) E12 - E18 - E26 - E35 - E50




AGA A507M/15/01

- 3446144 TIMER 60 MINUTES 16A 250V**  
contact capacity 16(4)A 250V  
max temperature 85°C  
D-shaped pin  $\varnothing$  6x4.6 mm  
for Dryer (AGA) E12 - E18 - E26 - E35 - E50



AGA A507M/60/01

- 3322293 TIMER 900-914-9935 220V 50Hz**  
D-shaft  $\varnothing$  6x5 mm  
for Washing machine (AGA) S16 - S25 - S33 - 520/16  
520/18 - 620/30 - 735/50 - 735/70



AGA A531/C13/02

AGA A531/C15/01

## Water tight seals

- 3786193 RETAINER SPRING RING  $\varnothing$  85x65x10 mm**  
for AGA WASHING MACHINE S25  
for WASHING MACHINE AGA 620-30



AGA A796505

AGA 7906505

- 3453018 SEALING RING  $\varnothing$  50x85 mm**  
sealing ring:  
internal  $\varnothing$  50 mm  
external  $\varnothing$  85 mm  
for AGA WASHING MACHINE 520/18-S35



AGA 965001

- 3453019 COUNTER-SEALING RING  $\varnothing$  87.5x52x15 mm**  
for AGA WASHING MACHINE 520/18-S35



AGA 965001C



Suitable for:

## AGA




**3786192 SEALING SPRING RING ø 100x80x10 mm**  
for AGA WASHING MACHINE 735/70-S33-S35



AGA 7908001

Suitable for:

**3786199 SEALING SPRING RING ø 120x70x12 mm**  
for AGA WASHING MACHINE S50



AGA 7907006

**3786196 SEALING SPRING RING ø 120x90x12 mm**  
for AGA WASHING MACHINE S50



AGA 7909001

**3786197 SEALING SPRING RING ø 130x105x12 mm**  
for AGA WASHING MACHINE L50A-S105



AGA 7910501

**3786198 SEALING SPRING RING ø 130x85x12 mm**  
for AGA WASHING MACHINE L50A-S105



AGA 7908509

**3453016 SEALING SPRING RING ø 80x48x10 mm**  
for AGA WASHING MACHINE S16



AGA 7904801

**3786195 SEALING SPRING RING ø 80x55x8 mm**  
for AGA WASHING MACHINE 520/16



AGA 7905501

**3453017 SEALING SPRING RING ø 90x70x10 mm**  
for AGA WASHING MACHINE 735/50-735/70-S33-S35



AGA 7907005

**3786194 SEALING SPRING RING ø 90x72x10 mm**  
for AGA WASHING MACHINE S25



AGA 7907201

*The data herewith contained may change without notice and LF SpA cannot be held responsible for possible errors stated or resulting by the use of this document. All rights reserved. No part of this publication may be reproduced without written permission by LF SpA.*



**LF SpA**

via Voltri, 80 - 47522 Cesena (FC) ITALIA  
Tel. +39 0547 34 11 11 - Fax +39 0547 34 11 10  
[www.lfricambi724.it](http://www.lfricambi724.it) - [www.lfricambi724.mobi](http://www.lfricambi724.mobi)  
[info@lfricambi.it](mailto:info@lfricambi.it)  
Export Dept.: Tel. +39 0547 34 11 50 - Fax: +39 0547 34 11 55  
[www.lfspareparts724.com](http://www.lfspareparts724.com) - [www.lfspareparts724.mobi](http://www.lfspareparts724.mobi)  
[export@lfspareparts.com](mailto:export@lfspareparts.com)

**FRANCE**



**EPGC Sas**

13, Rue des Forts - 59960 Neuville en Ferrain  
Tél. +33 (0)3 20 25 06 21  
Fax +33 (0)3 20 25 34 12  
[www.epgc.com](http://www.epgc.com)  
[www.epgc724.mobi](http://www.epgc724.mobi)  
[epgc@epgc.com](mailto:epgc@epgc.com)

**DEUTSCHLAND**



**LF GmbH**

Junkersstrasse, 1 - D-82178 Puchheim - München  
Tel. +49 89 89 45 78 66  
Fax +49 89 89 45 78 88  
[www.lfersatzteile724.de](http://www.lfersatzteile724.de)  
[www.lfersatzteile724.mobi](http://www.lfersatzteile724.mobi)  
[info@lfersatzteile.de](mailto:info@lfersatzteile.de)

**SCHWEIZ**



**LF GmbH Verkaufsbüro**

Sennweidstrasse, 45 - CH-6312 Steinhausen  
Tel. +41 (0)41 760 15 80-1  
Fax +41 (0)41 760 15 85  
[www.lfersatzteile724.ch](http://www.lfersatzteile724.ch)  
[www.lfersatzteile724.mobi](http://www.lfersatzteile724.mobi)  
[info@lfersatzteile.ch](mailto:info@lfersatzteile.ch)

**ESPAÑA**



**LF Repuestos Horeca S.L.U.**

Calle Ciudad Real, 10 - 45517 Escalonilla - Toledo  
Tlf. +34 91 477 91 00  
Fax +34 91 477 90 81  
[www.lfrepuestos724.es](http://www.lfrepuestos724.es)  
[www.lfrepuestos724.mobi](http://www.lfrepuestos724.mobi)  
[info@lfrepuestos.es](mailto:info@lfrepuestos.es)

**UNITED KINGDOM**



**LF Spare Parts Ltd.**

A10a Lakeside Business Park, Broadway Lane  
South Cerney, Gloucestershire GL7 5XL  
Tel. +44 (0)1285 86 16 25  
Fax +44 (0)1285 86 39 49  
[www.lfspareparts724.co.uk](http://www.lfspareparts724.co.uk)  
[www.lfspareparts724.mobi](http://www.lfspareparts724.mobi)  
[info@lfspareparts.co.uk](mailto:info@lfspareparts.co.uk)

**RUSSIA**



**OOO LF**

ul, Anatoliya Zhivova, 8 - office 1 - 123100 Moscow  
Tel. +7 499 259 85 75  
Fax +7 495 725 26 53  
[www.lfspareparts724.ru](http://www.lfspareparts724.ru)  
[www.lfspareparts724.mobi](http://www.lfspareparts724.mobi)  
[info@lfspareparts.ru](mailto:info@lfspareparts.ru)

**CHINA**



**LF China**

Room 102, House 8, Lane 725, Mao Tai Rd.  
Changning Dist. - 200336 Shanghai  
Tel. +86 (0)21 33 53 66 31  
Fax +86 (0)21 33 53 66 32  
[www.lfspareparts724.com](http://www.lfspareparts724.com)  
[www.lfspareparts724.mobi](http://www.lfspareparts724.mobi)  
[china@lfspareparts.com](mailto:china@lfspareparts.com)