



Spare parts for:
Laundry machines



Suitable for:

WHIRLPOOL



This catalogue is automatically generated.
Therefore, the sequence of the items might
not be always shown at best.
Updates will be issued in case of additions
and/or amendments.

*Suitable **universal spare parts** may not be included*





WHIRLPOOL



Suitable for:

Suitable for:

3786501 BLACK RUBBER DRAWN N°106 EPDM 2.4 m
for Washing machine (IMESA) LM11 - LM14 - LM18
LM23 - LM6 - LM8 - RC11 - RC14 - RC18 - RC23
RC8
for Washing machine (WHIRLPOOL) AGB208 - AGB209
AGB210 - AGB211 - AGB212 - AGB213 - AGB214
AGB215 - AGB216 - AGB217 - AGB218 - AGB230
AGB231 - AGB232 - AGB233 - AGB234 - AGB235
AGB236 - AGB237 - AGB238 - AGB239 - AGB240
AGB241



WHIRLPOOL 483286008444

3186128 BOTTOM TANK GASKET ø 630 mm
for Washing machine (GRANDIMPIANTI) WFM6 - WFM6S
WR11 - WR8
for Washing machine (IMESA) LM11 - LM8
for Washing machine (WHIRLPOOL) AGB233



WHIRLPOOL

3786571 DOOR GASKET
ø 580 mm



WHIRLPOOL 751129

WHIRLPOOL 771985008894

3186133 DOOR GASKET ø 15x21 mm
for Washing machine (IMESA) RC12 - RC16



WHIRLPOOL 483286001275

3186020 DOOR GASKET ø 295 mm
for Washing machine (ZANUSSI) K8 - LB70E - LB8G
LB80E



WHIRLPOOL 160669

WHIRLPOOL 771985003880

3186130 DOOR GASKET ø 300 mm
for Dryer (IMESA) ER14 - ER9 - ES10 - ES14 - ES18
for Dryer (WHIRLPOOL) AGB257 - AGB258 - AGB259
AGB266 - AGB267 - AGB268



WHIRLPOOL 483286009729

3786148 DOOR GASKET ø 370 mm
for Washing machine (MIELE) PW100 - PW80 - WS5508
WS5510 - WS5514
for Washing machine (WHIRLPOOL) WS5508 - WS5510



WHIRLPOOL 745228

WHIRLPOOL 771985007987

3186024 DOOR GLASS GASKET ø 325 mm
for Washing machine (GRANDIMPIANTI) WFM11 - WFM6
WFM6S - WFM8 - WF11 - WF8 - WR11 - WR8
for Washing machine (POLIMATIC) FS10 - FS6 - FS7
P65 - P75 - RS10 - RS6 - RS7
for Washing machine (PRIMUS) C6 - C8 - FS10 - FS6
FS7 - F10 - F6 - F7 - P6 - P7 - RS10 - RS6
RS7
for Washing machine (WHIRLPOOL) LW100 - LW70
WACS11 - WACS6 - WACS7 - WACS8 - WAC11 - WAC8



WHIRLPOOL 750223

WHIRLPOOL 771985008727

3186121 DOOR GLASS GASKET ø 330 mm

for Washing machine (IMESA) LM11 - LM6 - LM8
RC11 - RC6 - RC8
for Washing machine (WHIRLPOOL) AGB208 - AGB209
AGB230 - AGB231 - AGB232



WHIRLPOOL 483286002979

WHIRLPOOL 483286008647

3186113 DOOR TANK GASKET

external ø 400 mm internal ø 270 mm
for Washing machine (DANUBE) GF11 - GF18 - GF8
for Washing machine (GRANDIMPIANTI) WFC8E - WFP6E
WF11 - WF18 - WF8 - WMC11000 - WMC6000
WMC8000
for Washing machine (IPSO) HF110 - HF165 - HF55
HF65 - HF76 - HF95 - HW131 - HW132 - HW164
HW165 - HW55 - HW64 - HW72 - HW75 - HW94
H132
for Washing machine (POLIMATIC) C6 - C8 - FS10
FS6 - FS7 - F10 - F6 - F7 - P65 - P75
for Washing machine (PRIMUS) C6 - C8 - FS10 - FS6
FS7 - F10 - F16 - F6 - F7 - P6 - P7
for Washing machine (WHIRLPOOL) WACS11 - WACS17
WACS6 - WACS7 - WACS8




WHIRLPOOL 750245

WHIRLPOOL 771985008741

3786432 TENSIONING STRIP

for gasket
for Washing machine (DANUBE) GF11 - GF18 - GF8
for Washing machine (GRANDIMPIANTI) WFC8E - WFP6E
WF11 - WF18 - WF8 - WMC11000 - WMC6000
WMC8000
for Washing machine (IPSO) HF55 - HW131 - HW164
HW64 - HW72 - HW75 - HW94
for Washing machine (PRIMUS) FS10 - FS7 - P6 - P7
for Washing machine (WHIRLPOOL) WACS11 - WACS6
WACS7 - WACS8



WHIRLPOOL 752712

WHIRLPOOL 771985009157

3186124 DRUM DOOR GASKET ø 400 mm

for Washing machine (IMESA) LM11 - LM6 - LM8
RC11 - RC6 - RC8
for Washing machine (WHIRLPOOL) AGB208 - AGB209
AGB230 - AGB231 - AGB232



WHIRLPOOL 483286008592

3786568 EXTERNAL DOOR GASKET

for Dryer (ASKO) TDC44
for Dryer (IMESA) ES55 - ES75
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204 - AGB205 - AGB206
AGB207 - SACE5



WHIRLPOOL 483286000316



Suitable for:

3786570 EYEHOLE GASKET

ø 430 mm

for Washing machine (PRIMUS) FS16 - FS22 - LH165

RS13 - RS22

for Washing machine (WHIRLPOOL) LWS220



WHIRLPOOL 757480

WHIRLPOOL 771985011488

Suitable for:

3186111 EYEHOLE GASKET ø 420 mm

for Washing machine (GRANDIMPIANTI) WMC17 - WMC23

WM17 - WM23 - WR18 - WR24

for Washing machine (PRIMUS) RS16 - RS22

for Washing machine (WHIRLPOOL) WAC17 - WAC23



WHIRLPOOL PRI505000041

3786421 EYEHOLE GASKET SET WITH FRONT COLLAR

for Washing machine (WHIRLPOOL) AWM8000F

AWM9100F



WHIRLPOOL 481231018865

WHIRLPOOL 561032

WHIRLPOOL 771985011732

3786436 BACK COLLAR

for eyehole gasket

for Washing machine (WHIRLPOOL) AWM8000 - AWM910

AWM9100 - AWM9100-EU - AWM9100-F - HYDRA



WHIRLPOOL 481240118619


WHIRLPOOL 481240118657

3786435 FRONT COLLAR

for eyehole gasket

for Washing machine (WHIRLPOOL) AWM8000 - AWM910

AWM9100 - AWM9100-EU - AWM9100-F - HYDRA



WHIRLPOOL 481240118621

3786437 EYEHOLE GLASS GASKET

for Dryer (GIRBAU) SEI12

for Dryer (IPSO) DR25 - DR35

for Dryer (PRIMUS) DA11 - DA13 - DA15 - D14 - D25

for Dryer (WHIRLPOOL) SACE11 - SACE13 - SACE15

SACE17 - SACE25 - SWE131 - SWE140 - SWE151

SWE251



WHIRLPOOL 757134

WHIRLPOOL 771985009432

3786127 GASKET FOR DOOR GLASS ø 420 mm

for Washing machine (IMESA) LM14 - LM18 - LM23

LM30 - RC14 - RC18 - RC23 - RC30

for Washing machine (WHIRLPOOL) AGB210 - AGB211

AGB212 - AGB216 - AGB217 - AGB218 - AGB233

AGB234 - AGB235 - AGB239 - AGB240 - AGB241

AGB249 - AGB250 - AGB251



WHIRLPOOL 483286008357

Suitable for:

3786143 GASKET FOR DOOR GLASS ø 435 mm
 for Washing machine (GRANDIMPIANTI) WFM33 - WFM40 WFM55
 for Washing machine (POLIMATIC) FS33 - FS40 - FS55
 for Washing machine (PRIMUS) FS33 - FS40 - FS55
 for Washing machine (WHIRLPOOL) LWS330 - LWS440 LWS550



WHIRLPOOL

3786430 GASKET FOR DRUM
 for Dryer (WHIRLPOOL) AWZ481E



WHIRLPOOL 481946818182

WHIRLPOOL 561237

3786415 GASKET FOR EYEHOLE
 for Washing machine (PRIMUS) F5 - P5
 for Washing machine (WHIRLPOOL) LWS50



WHIRLPOOL 746645

WHIRLPOOL 752003

WHIRLPOOL 771985008518

WHIRLPOOL 771985009000

3786422 GASKET FOR EYEHOLE
 for Washing machine (WHIRLPOOL) AWM8000F
 AWM9100EU - AWM9100F - AWM9100F - HYDRA



WHIRLPOOL 481246668784

Suitable for:

3786128 GASKET FOR DOOR GLASS 2000 mm
 for Washing machine (IMESA) LM40 - LM55 - LM70
 LM85 - RC40 - RC55 - RC70



WHIRLPOOL 483286001274


3786413 GASKET FOR EYEHOLE
 for Washing machine (MIELE) PW51 - PW61 - WS5425
 WS5426
 for Washing machine (WHIRLPOOL) PW51 - PW61
 WS5425 - WS5426



WHIRLPOOL 746370

WHIRLPOOL 771985008417

3786419 GASKET FOR EYEHOLE
 for Washing machine (ASKO) WMC55
 for Washing machine (IMESA) LM5 - WMC55
 for Washing machine (PRIMUS) PW5
 for Washing machine (WHIRLPOOL) AGB201 - AGB202
 AGB203



WHIRLPOOL 747023

WHIRLPOOL 771985010618

3786436 BACK COLLAR
 for eyehole gasket
 for Washing machine (WHIRLPOOL) AWM8000 - AWM910
 AWM9100 - AWM9100-EU - AWM9100-F - HYDRA



WHIRLPOOL 481240118619

WHIRLPOOL 481240118657




Suitable for:

WHIRLPOOL



Suitable for:

3786435 FRONT COLLAR
for eyehole gasket
for Washing machine (WHIRLPOOL) AWM8000 - AWM910
AWM9100 - AWM9100-EU - AWM9100-F - HYDRA




WHIRLPOOL 481240118621

3786424 GASKET FOR EYEHOLE
for Washing machine (WHIRLPOOL) AWM8000 - AWM910
AWM9100 - AWM9100EU - AWM9100F - HYDRA



WHIRLPOOL 481246668785

3786435 FRONT COLLAR
for eyehole gasket
for Washing machine (WHIRLPOOL) AWM8000 - AWM910
AWM9100 - AWM9100-EU - AWM9100-F - HYDRA



WHIRLPOOL 481240118621

3786427 GASKET FOR EYEHOLE
for Dryer (GIRBAU) SEI12
for Dryer (IPSO) DR25 - DR35
for Dryer (PRIMUS) DA11 - DA13 - DA15 - DA25
for Dryer (WHIRLPOOL) DA11 - DA13 - DA15 - DA25
SACE11 - SACE13 - SACE17 - SWE111 - SWE131
SWE151 - SWE251



WHIRLPOOL 757123

WHIRLPOOL 771985009421

3786572 LOWER GASKET
length 425 x width 30 mm



WHIRLPOOL 483286009877

3786436 BACK COLLAR
for eyehole gasket
for Washing machine (WHIRLPOOL) AWM8000 - AWM910
AWM9100 - AWM9100-EU - AWM9100-F - HYDRA



WHIRLPOOL 481240118619

WHIRLPOOL 481240118657

3786420 GREASEPROOF GASKET FOR EYEHOLE



WHIRLPOOL 481246068532

WHIRLPOOL 481246068617

3786573 SIDE GASKET
length 490 x width 30 mm



WHIRLPOOL 483286009878



Suitable for:

WHIRLPOOL



3786575 TANK DOOR GASKET



WHIRLPOOL

Suitable for:

3786414 TANK GASKET

for Washing machine (WHIRLPOOL) AWM8000 - AWM910
AWM9100 - AWM9100-EU - AWM9100-F - HYDRA




WHIRLPOOL 481253268124

WHIRLPOOL 561044

WHIRLPOOL 771985011734

3786434 TANK GASKET - 12 HOLES

for Washing machine (PRIMUS) P6 - P7 - RS10 - RS7
for Washing machine (WHIRLPOOL) WACS6 - WACS7
WAC11 - WAC8



WHIRLPOOL 750334

WHIRLPOOL 771985008796

Air Chambers

3060090 AIR CHAMBER


for Washing machine (IMESA) LM11 - LM14 - LM18
LM23 - LM30 - LM40 - LM55 - LM6 - LM70 - LM8
LM85 - RC11 - RC14 - RC18 - RC23 - RC30 - RC40
RC55 - RC6 - RC70 - RC8
for Washing machine (WHIRLPOOL) AGB209 - AGB210
AGB211 - AGB214 - AGB215 - AGB216 - AGB217
AGB218 - AGB222 - AGB223 - AGB224 - AGB225
AGB226 - AGB230/WP - AGB231 - AGB231/WP
AGB232 - AGB232/WP - AGB236/WP - AGB237
AGB237/WP - AGB238 - AGB238/WP - AGB239
AGB240 - AGB241 - AGB247 - AGB248 - AGB249
AGB250 - AGB251 - AGB253 - AGB254 - AGB256



WHIRLPOOL 483286008285

3060112 COMPRESSION CHAMBER

for Washing machine (WHIRLPOOL) AWM1000 - AWM1001
AWM1008 - AWM1900 - AWM8000 - AWM8900
AWM9000 - AWM910 - AWM9100 - AWM9100-EU
AWM9100-F - HYDRA



WHIRLPOOL 481241868292

WHIRLPOOL 561106

WHIRLPOOL 771985011748

3060113 GASKET FOR COMPRESSION CHAMBER



WHIRLPOOL 481253058098

WHIRLPOOL 561120



Suitable for:

WHIRLPOOL



Suitable for:

Alarms

3446195 ALARM INTERMITTENT 220V 50/60 HZ
for Dryer (WHIRLPOOL) AWZ481E



WHIRLPOOL 481228018024

WHIRLPOOL 561245

Bearings

3063091 BALL BEARING
17 x 40 x 12 mm
for Dryer (IMESA) ES10 - ES14 - ES18
for Dryer (WHIRLPOOL) AGB257 - AGB258 - AGB259
AGB260 - AGB261 - AGB262 - AGB263 - AGB264
AGB265 - AGB266 - AGB267 - AGB268 - AGB269
AGB270 - AGB271 - AGB272 - AGB273 - AGB274
AGB275 - AGB276 - AGB277 - AGB278 - AGB279
AGB280 - AGB281 - AGB282 - AGB283



WHIRLPOOL 483286009752

3453024 BEARING FOR DRUM
for Dryer (MIELE) PT126 - PT131
for Dryer (WHIRLPOOL) SW90



WHIRLPOOL 745798

WHIRLPOOL 771985008211

3063087 BEARING FOR TANK
for Washing machine (PRIMUS) F6 - RS6 - RS7
for Washing machine (WHIRLPOOL) LWS70 - LW70
WAC8



WHIRLPOOL 752116

WHIRLPOOL 771985009075


3063088 BEARING FOR TANK
for Washing machine (PRIMUS) LWS100 - LWS70
LW100 - LW70 - RS7 - WAC11 - WAC17
for Washing machine (WHIRLPOOL) F10 - F6 - F7
RS10 - RS16 - RS6 - WAC8



WHIRLPOOL 752117

WHIRLPOOL 771985009076

3063094 BEARING HOLDER PLATE 6204



WHIRLPOOL 757107

WHIRLPOOL 771985009405

3324028 BEARING SKF YAR 206-2F
without flanges
for Dryer (IMESA) ES10 - ES14 - ES18
for Dryer (WHIRLPOOL) AGB257 - AGB258 - AGB259
AGB260 - AGB261 - AGB262



WHIRLPOOL 483286009757

3063038 BEARING YAR207-2F

for Dryer (IMESA) ES10 - ES14 - ES18
for Dryer (WHIRLPOOL) AGB257/WP - AGB258/WP
AGB259 - AGB260/WP - AGB261/WP - AGB262/WP




WHIRLPOOL 482386009759

WHIRLPOOL 483286009759

3063041 BEARING 3214A


for Washing machine (IMESA) RC30 - RC40



WHIRLPOOL 483286003027

3063044 BEARING 3305A 2RS


for PRIMUS WASHING MACHINE P7-C8
for POLIMATIC WASHING MACHINE P75
for Washing machine (POLIMATIC) P75
for Washing machine (PRIMUS) C8 - P7
for Washing machine (WHIRLPOOL) WACS7



WHIRLPOOL

3063045 BEARING 3307A 2RS


for Washing machine (POLIMATIC) P75
for Washing machine (PRIMUS) C8 - P7
for Washing machine (WHIRLPOOL) LWS160 - WACS7
WAC17



WHIRLPOOL

3063048 BEARING 6209 2Z

for Washing machine (DOMUS) DFI9 - W10 - W9
for Washing machine (FAGOR) LA-10M - LB-10M - LC-8
LF-8
for Washing machine (PRIMUS) F10 - F7 - RS10
RS16
for Washing machine (WHIRLPOOL) LWS100 - LW100
WAC11 - WAC17



WHIRLPOOL 752118

WHIRLPOOL 771985009077

3063093 BEARING 6306 2RS

for Washing machine (PRIMUS) F5 - P5
for Washing machine (WHIRLPOOL) LWS50 - LWS51



WHIRLPOOL 752024

WHIRLPOOL 771985009013

3063002 BEARING 6307 2RS

for Washing machine (POLIMATIC) FS10 - FS6 - FS7
P65 - RS13
for Washing machine (PRIMUS) C6 - FS10 - FS6 - FS7
P5 - P6 - RS13
for Washing machine (WHIRLPOOL) LWS51 - WACS11
WACS6 - WACS8
for Washing machine (ZANUSSI)



WHIRLPOOL 752023

WHIRLPOOL 771985009012

3063067 BEARING 6307 2Z

for Dryer (IPSO) CD165 - CD220 - CD350
for Washing machine (DANUBE) GF10 - GF11 - GF6
GF8
for Washing machine (GRANDIMPIANTI) WFEC11 - WFEC6
WFEC8 - WFM11 - WFM6 - WFM6S - WFM8 - WR11
WR8
for Washing machine (IPSO) HC100 - HC60 - HC65
HC75 - HF55 - HF65 - HF75 - HF95 - HW55 - HW64
HW72 - HW94 - WE55 - WE73 - WE95 - WFF100
WFF65 - WFF75 - WF100 - WF65 - WF75
for Washing machine (WHIRLPOOL) HYDRA AWM9000
HYDRA AWM9100



WHIRLPOOL 481252028183

WHIRLPOOL 561138

WHIRLPOOL 771985011752



Suitable for:

3063001 BEARING 6308 2RS

for Washing machine (AGA) 520/16 - 520/18
for Washing machine (IMESA) RC12 - RC18 - RC23
for Washing machine (WHIRLPOOL) AGB224 - AGB226
for Washing machine (ZANUSSI) LB70E - LB8G - LB80E



WHIRLPOOL 483286008567

Suitable for:

3063108 KIT PIN FOR DRUM

for Dryer (GIRBAU) SEI12
for Dryer (IPSO) DR25 - DR35
for Dryer (PRIMUS) DA11 - DA13 - DA15
for Dryer (WHIRLPOOL) SACE11 - SACE13 - SACE17
SWE111 - SWE131 - SWE151



WHIRLPOOL 757158

WHIRLPOOL 7719850059456

3063105 PIVOTING ROLLER BEARING C22214E

for Washing machine (IMESA) LM14 - LM18 - LM23
for Washing machine (WHIRLPOOL) AGB233 - AGB234
AGB235 - AGB239 - AGB240 - AGB241 - AGB249
AGB250 - AGB251




WHIRLPOOL

WHIRLPOOL 483286008462

3063040 ROLLER BEARING NU209ECP

for Washing machine (IMESA) LM11 - LM6 - LM8
RC11 - RC6 - RC8
for Washing machine (WHIRLPOOL) AGB208 - AGB209
AGB214 - AGB215 - AGB230 - AGB231 - AGB232
AGB236 - AGB237 - AGB238



WHIRLPOOL 483286008631

3063042 ROLLER BEARING NU217ECP

for Washing machine (IMESA) RC30 - RC40



WHIRLPOOL 483286003026

3063104 ROLLER BEARING NU2216 ECP

for Washing machine (IMESA) LM14 - LM18 - LM23
for Washing machine (WHIRLPOOL) AGB233 - AGB234
AGB235 - AGB239 - AGB240 - AGB241 - AGB249
AGB250 - AGB251



WHIRLPOOL

WHIRLPOOL 483286008461


3063039 ROLLER BEARING NU309ECP

for Washing machine (IMESA) RC14 - RC18 - RC23
for Washing machine (WHIRLPOOL) AGB224 - AGB226



WHIRLPOOL 483286003346

3063095 SPACER



WHIRLPOOL 757112

WHIRLPOOL 771985009410

3063106 WHEEL FOR BASKET SUPPORT

for Dryer (IMESA) ES5
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB205 - AGB207 - SACE5



WHIRLPOOL 483286000284

Belts

5016934 BELT A 073 13x1854 mm

for Dryer (IMESA) ES10 - ES14 - ES18 - ES23 - ES24
ES34
for Dryer (WHIRLPOOL) AGB257 - AGB258 - AGB259
AGB260 - AGB261 - AGB262 - AGB263 - AGB264



WHIRLPOOL 483286002715

WHIRLPOOL 483286009754

3062092 BELT IMESA A 048

for Dryer (IMESA) ES10 - ES14 - ES18
for Dryer (WHIRLPOOL) AGB257 - AGB258 - AGB259
AGB260 - AGB261 - AGB262 - AGB266



WHIRLPOOL 483286009749

3062087 BELT IMESA A 049



WHIRLPOOL 483286000594

5042708 BELT XPZ 1950LW

for Washing machine (IPSO) WE234 - WE245



WHIRLPOOL 752135

WHIRLPOOL 752411

WHIRLPOOL 771985009092

WHIRLPOOL 771985009126

3062064 BELT 0209Y09B17 2350 mm


length 2375 mm
for DRYER DANUBE DD8
for DRYERC FAGOR SE/7
for DRYER IPSO DD8
for DRYER GIRBAU SDE7
for DRYER PRIMUS D9-DA9-DAM/S9
for DRYER WHIRLPOOL SACE8-SACE86-SACE8T-
SWE90-SWE290-SWE390-SW91-SW291-SW391
for Dryer (DANUBE) DD8
for Dryer (FAGOR) S/E-7
for Dryer (GIRBAU) SDE7
for Dryer (IPSO) DD8
for Dryer (PRIMUS) DAM/S9 - DA9 - D9
for Dryer (WHIRLPOOL) SACE8 - SACE8C - SACE8T
SWE290 - SWE291 - SWE390 - SWE391 - SWE90



WHIRLPOOL 722042

WHIRLPOOL 771985007866

3062108 BELT 1936H



WHIRLPOOL 481235818164



Suitable for:

Suitable for:

3062112 BELT 1951 H7

3062022 MULTIGRIP BELT J 1209 H12 4 GROOVES
for Washing machine (ASKO) WMC55 - WMP55
for Washing machine (GRANDIMPIANTI) WFEC5
for Washing machine (IMESA) LM5
for Washing machine (PRIMUS) PW5
for Washing machine (WHIRLPOOL) AGB200 - AGB201
AGB202 - AGB203



WHIRLPOOL 481235818156

WHIRLPOOL 483286009891

WHIRLPOOL 747007

WHIRLPOOL 771985008629

3062023 MULTIGRIP BELT 7PH 1970 H11 6 GROOVES
with belt tightening spring kit
for Dryer (ASKO) TDC44 - TD33
for Dryer (IMESA) ES5
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204 - AGB205 - AGB206
AGB207 - SACE5

3062067 SMOOTH BELT V TT138
for Dryer (PRIMUS) D15 - D25 - D35
for Dryer (WHIRLPOOL) SACE25 - SWE150 - SW25



WHIRLPOOL 483286000286

WHIRLPOOL 747119

WHIRLPOOL 771985008662

WHIRLPOOL 751496

WHIRLPOOL 771985007774

WHIRLPOOL 771985008937

3062021 TOOTHED BELT AX91 13X2341
for Washing machine (IMESA) LM40 - LM55 - RC23
for Washing machine (WHIRLPOOL) AGB212 - AGB226
AGB243 - AGB244

3062066 TOOTHED BELT MULTIV J8 1165
for Dryer (PRIMUS) D15
for Dryer (WHIRLPOOL) SWE150



WHIRLPOOL 483286008537

WHIRLPOOL 722045

WHIRLPOOL 771985007869

WHIRLPOOL 771988007869

3062071 TOOTHED BELT POLY V 1150J
for Dryer (PRIMUS) D14 - D15 - D25 - D35
for Dryer (WHIRLPOOL) SACE25 - SWE150 - SW25



WHIRLPOOL 751028

WHIRLPOOL 771985008831

Suitable for:

3062069 TOOTHED BELT POLY V 2391 J

for Dryer (GIRBAU) ST112
for Dryer (IPSO) DR25
for Dryer (PRIMUS) DA11 - DA13
for Dryer (WHIRLPOOL) SACE11 - SACE13 - SWE111
SWE131



WHIRLPOOL 753316

WHIRLPOOL 771985009265

Suitable for:

3053552 BELT TENSIONING ROLLER



WHIRLPOOL 757116

WHIRLPOOL 771985009414

3062065 TOOTHED BELT POLY V 2606J

for Dryer (IPSO) DR35
for Dryer (PRIMUS) DA15
for Dryer (WHIRLPOOL) SACE17 - SWE151



WHIRLPOOL 753317

WHIRLPOOL 771985009266

3053552 BELT TENSIONING ROLLER



WHIRLPOOL 757116

WHIRLPOOL 771985009414

3062072 TOOTHED BELT POLY V 7PJE1304

for Washing machine (WHIRLPOOL) AWM8000 - AWM9000
AWM910 - AWM9100 - HYDRA



WHIRLPOOL 481235818187
WHIRLPOOL 771985011733

WHIRLPOOL 481235818209

WHIRLPOOL 561041

3062098 TOOTHED BELT SPZ 1562 LW



WHIRLPOOL 752962

WHIRLPOOL 771985009198

3062111 TOOTHED BELT SPZ 2037



WHIRLPOOL 756320

WHIRLPOOL 771985009351

3062106 TOOTHED BELT SPZX 1512

for Washing machine (AGA) 520/16



WHIRLPOOL 757450

WHIRLPOOL 771985009532

5041457 TOOTHED BELT TM M406386 DF

height 12 mm - length 1600 mm
for Dryer (PRIMUS) D14
for Dryer (WHIRLPOOL) SWE140



WHIRLPOOL 751015

WHIRLPOOL 771985008819

3062019 TOOTHED BELT XPA 1482

for Washing machine (IMESA) LM11 - LM6 - LM8
for Washing machine (WHIRLPOOL) AGB230 - AGB231
AGB232 - AGB236 - AGB237 - AGB238 - AGB536



WHIRLPOOL 483286008605



Suitable for:

3062073 TOOTHED BELT XPA 1700

for Washing machine (IMESA) RC11 - RC6 - RC8
for Washing machine (WHIRLPOOL) AGB208 - AGB209
AGB214 - AGB215



WHIRLPOOL 483286009151

Suitable for:

3062017 TOOTHED BELT XPA 1750

for Washing machine (IMESA) LM14 - LM18 - LM23
for Washing machine (WHIRLPOOL) AGB233 - AGB234
AGB235 - AGB239 - AGB240 - AGB241 - AGB249
AGB250 - AGB251



WHIRLPOOL 483286008282

3062018 TOOTHED BELT XPA 2032

for Washing machine (IMESA) RC14 - RC18
for Washing machine (WHIRLPOOL) AGB210 - AGB211
AGB216 - AGB217



WHIRLPOOL 483286008738

WHIRLPOOL 750241

3062020 TOOTHED BELT XPA 2240

for Washing machine (IMESA) LM30



WHIRLPOOL 483286003163

3062031 TOOTHED BELT XPZ 1000

for double-motor machines
for Washing machine (GRANDIMPIANTI) WM40000
for Washing machine (IPSO) HF205
for Washing machine (POLIMATIC) FS40 - FS55
for Washing machine (PRIMUS) FS40 - FS55



WHIRLPOOL 756325

WHIRLPOOL 771985009356

3062105 TOOTHED BELT XPZ 1137 LW



WHIRLPOOL 752961

WHIRLPOOL 771985009197

3062024 TOOTHED BELT XPZ 1587

for Washing machine (GRANDIMPIANTI) WFM11
for Washing machine (POLIMATIC) FS6
for Washing machine (PRIMUS) FS6
for Washing machine (WHIRLPOOL) WACS11



WHIRLPOOL 757440

WHIRLPOOL 771985009522

3062070 TOOTHED BELT XPZ 1600

width 9mm



WHIRLPOOL 750288

WHIRLPOOL 771985008763

3062107 TOOTHED BELT XPZ 2160



WHIRLPOOL 757467

WHIRLPOOL 771985010532

3062109 TOOTHED BELT XPZ 2187



WHIRLPOOL 753121

WHIRLPOOL 771985009221



WHIRLPOOL



Suitable for:

3062063 TOOTHED CONVEYOR BELT
for Dryer (WHIRLPOOL) CPT48 - HELIOS-AWZ481
HELIOS-AWZ481E



WHIRLPOOL 481935818142

WHIRLPOOL 561231

WHIRLPOOL 771985011763

Suitable for:

3062068 V TOOTHED BELT 5PJ1956
for Dryer (PRIMUS) D5
for Dryer (WHIRLPOOL) SWE50 - SWE51



WHIRLPOOL 751046

WHIRLPOOL 771985008847

3062001 V-BELT A66 13x1676 Li H13
for Washing machine (ZANUSSI) LB8



WHIRLPOOL 166027

3062008 V-BELT SPZ1800 LW H10
for Washing machine (FAGOR) LAC-10 - LAC-7 - LC-10
LC-7
for Washing machine (ZANUSSI) LB121E - LB81E



WHIRLPOOL 191341

WHIRLPOOL 771985005405

3062110 V-BELT XPZ 1320
for Washing machine (PRIMUS) F22 - F22S
for Washing machine (WHIRLPOOL) LWS220 - WAC23



WHIRLPOOL 753116

WHIRLPOOL 771985009219

3062003 V-BELT 13x2160Li A-85
for 12/16KG
for Washing machine (ZANUSSI)



WHIRLPOOL 166344


3062007 V-BELT 3V 750
for Washing machine (ZANUSSI) CLB160E - CLB160V
EWM120 - EWM160 - LB120E - LB160E



WHIRLPOOL 147308

Castors

3062079 FRONT WHEEL FOR DRYER MANIFOLD



WHIRLPOOL 481252878033

3062076 AXIS
for back roll



WHIRLPOOL 481252028068



Suitable for:

3062077 BACK WHEEL FOR DRYER WITH AXIS




WHIRLPOOL 481225898003

WHIRLPOOL



Suitable for:

3062081 CLAMP




WHIRLPOOL 481253258005

3346208 NUT



WHIRLPOOL 481252878069

3062080 WHEEL FOR MANIFOLD
for Dryer (DANUBE) DD8
for Dryer (GIRBAU) SE/7
for Dryer (IPSO) DD8
for Dryer (PRIMUS) DAM9 - DA9
for Dryer (WHIRLPOOL) SACE8 - SWE290 - SWE291
SWE90



WHIRLPOOL 751174

WHIRLPOOL 771985008912

3062084 CLAMP



WHIRLPOOL 751175

WHIRLPOOL 771985008913

3062075 AXIS
for pulley



WHIRLPOOL 722031

WHIRLPOOL 771985007858

3062082 WASHER
for Dryer (DANUBE) DD8
for Dryer (FAGOR) SE/7
for Dryer (GIRBAU) SDE7
for Dryer (IPSO) DD8
for Dryer (PRIMUS) DAM/S9 - DA9 - D9
for Dryer (WHIRLPOOL) SACE8 - SACE8T - SACE86
SWE290 - SWE390 - SWE90 - SW291 - SW391 - SW91



WHIRLPOOL 751173

WHIRLPOOL 771985008911

Centrifugal fans

3340121 COOLING MOTOR

mod. R2E140-BN14-09
240V - 120W - 0,51 A - 50 Hz - 1,5 μ F - 1900 RPM
230 V - 115 W - 0,51 A - 50 Hz - 2 μ F - 2000 RPM
capacitor not included



WHIRLPOOL 746119

WHIRLPOOL 771985008348

3340045

SINGLE-PHASE MOTOR VENTILATOR

50 Hz - 0.12 HP - 0.7 A - 230 V - 2800 RPM
mounting distance 70 mm



WHIRLPOOL 483286009547

Circlips

3063096 BACK CLAMP

for bearing
for Washing machine (WHIRLPOOL) AWM9000 - AWM9100
AWM9100EU - AWM9100F - HYDRA



WHIRLPOOL 481201118523

WHIRLPOOL 481201118525

3002012

CIRCLIPS



WHIRLPOOL

3391029 CLAMP

for bearing



WHIRLPOOL 752337

WHIRLPOOL 771985009120

3391030

CLAMP

for bearing
for Washing machine (POLIMATIC) RS10 - RS16
for Washing machine (PRIMUS) F10 - F7 - RS10
RS16
for Washing machine (WHIRLPOOL) LWS100 - LW100
WAC11 - WAC17



WHIRLPOOL 48328600

WHIRLPOOL 752338

WHIRLPOOL 771985009121

3002010 SEEGER RING



WHIRLPOOL

3002011

SEEGER RING $\varnothing$ 100 mm




WHIRLPOOL



Suitable for:

Suitable for:

3391031 SEEGER RING $\varnothing$ 40 mm
for bearing
for Dryer (IMESA) ES10 - ES10INV - ES14 - ES14INV
ES18 - ES18INV
for Dryer (WHIRLPOOL) AGB257 - AGB257/WP - AGB258
AGB258/WP - AGB259 - AGB260 - AGB260/WP
AGB261 - AGB261/WP - AGB262 - AGB262/WP
AGB263 - AGB264 - AGB265 - AGB266 - AGB267
AGB268 - AGB269 - AGB270 - AGB271 - AGB272
AGB273 - AGB274 - AGB275 - AGB276 - AGB277
AGB278 - AGB279 - AGB280 - AGB281 - AGB282
AGB283



WHIRLPOOL 483286002859

Contact thermostats

3744091 CONTACT THERMOSTAT
2 pieces



WHIRLPOOL 481225928681

3744089 CONTACT THERMOSTAT FOR ELEMENT



WHIRLPOOL 751031

WHIRLPOOL 771985008833

3744090 CONTACT THERMOSTAT FOR ELEMENT



WHIRLPOOL 751317

WHIRLPOOL 771985008929

5041552 CONTACT THERMOSTAT L340-50F 140°C

for Dryer (GIRBAU) SE112
for Dryer (IPSO) DR25 - DR35
for Dryer (PRIMUS) DA11 - DA13 - DA15 - D14
for Dryer (WHIRLPOOL) SACE11 - SACE13 - SACE17
SWE111 - SWE131 - SWE151



WHIRLPOOL 721009

WHIRLPOOL 771985007753

3443017 CONTACT THERMOSTAT WITH MANUAL RESET
safety temperature limiting device
fixed temperature 150°C
contact capacity 16(4)A 250V
for Dryer (WHIRLPOOL)
for Dryer (ZANUSSI)



WHIRLPOOL 148750

WHIRLPOOL 771985001994

3744092 CONTACT THERMOSTAT 140°C



WHIRLPOOL 745837

WHIRLPOOL 771985008242

3744038 CONTACT THERMOSTAT 150° C
 mounting distance 40 mm
 for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC
 ES5EIE
 for Dryer (PRIMUS) DAM5
 for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP
 AGB206/WP - AGB207/WP - SACE5 - SE5GC - SE5GE
 SE5IC - SE5IE



WHIRLPOOL 48328600297

WHIRLPOOL 747108

WHIRLPOOL 771985008651

3443063 CONTACT THERMOSTAT 155° C
 with manual reset - 16A 250V
 for Dryer (IMESA) ES10 - ES55 - ES75
 for Dryer (WHIRLPOOL) AGB257 - AGB265 - AGB266
 AGB269 - AGB274 - AGB278 - AGB283



WHIRLPOOL 483286002766

3744093 CONTACT THERMOSTAT 163° C



WHIRLPOOL 746079

WHIRLPOOL 771985008331

3744032 CONTACT THERMOSTAT 170° C
 for Dryer (WHIRLPOOL) AWZ481E



WHIRLPOOL 481940118734

WHIRLPOOL 561270

WHIRLPOOL 771985011784

3744031 SAFETY THERMOSTAT
 for Dryer (WHIRLPOOL) AWZ481E



WHIRLPOOL 481928228665

WHIRLPOOL 561272

WHIRLPOOL 771985012055

3744033 SAFETY THERMOSTAT
 for Dryer (FAGOR) S/E-7
 for Dryer (GIRBAU) SE7
 for Dryer (IPSO) DD8
 for Dryer (PRIMUS) DAM9 - DA9
 for Dryer (WHIRLPOOL) SACE8 - SWE290 - SWE291
 SWE390 - SWE391 - SWE90 - SWE91



WHIRLPOOL 722041

WHIRLPOOL 771985007865

3744035 SAFETY THERMOSTAT
 for Dryer (GIRBAU) SEI12
 for Dryer (IPSO) DR25 - DR35
 for Dryer (PRIMUS) DA11 - DA13 - DA15
 for Dryer (WHIRLPOOL) SACE11 - SACE13 - SACE17
 SWE111 - SWE131 - SWE151



WHIRLPOOL 757146

WHIRLPOOL 771985009444

3744037 SAFETY THERMOSTAT
 for Dryer (GIRBAU) SEI12
 for Dryer (IPSO) DR25 - DR35
 for Dryer (PRIMUS) DA11 - DA13 - DA15 - D25
 for Dryer (WHIRLPOOL) SACE11 - SACE13 - SACE17
 SACE25 - SWE111 - SWE131 - SWE151 - SWE250



WHIRLPOOL 753330

WHIRLPOOL 771985009277



Suitable for:

5043418 SAFETY THERMOSTAT
for Dryer (PRIMUS) D14
for Dryer (WHIRLPOOL) SWE140



WHIRLPOOL 771985008886

Suitable for:


3744076 SAFETY THERMOSTAT KIT 350°C
for Dryer (PRIMUS) D25
for Dryer (WHIRLPOOL) SACE25 - SWE250



WHIRLPOOL 721101

WHIRLPOOL 771985007801

3744036 SAFETY THERMOSTAT 225°C
for Dryer (FAGOR) S/E-7
for Dryer (GIRBAU) SE7
for Dryer (IPSO) DD8
for Dryer (PRIMUS) DAM9 - DA9
for Dryer (WHIRLPOOL) SACE8 - SWE290 - SWE390
SWE90 - SWE91



WHIRLPOOL 751206

WHIRLPOOL 771985008923

3744029 SAFETY THERMOSTAT 300°C
for Dryer (PRIMUS)
for Dryer (WHIRLPOOL)



WHIRLPOOL 722010

WHIRLPOOL 771985007838

3744030 THERMOSTAT 240 V
for Dryer (WHIRLPOOL) AWZ481E



WHIRLPOOL 481928248311

WHIRLPOOL 561269

WHIRLPOOL 771985011783

3744088 THERMOSTAT 30-90°C
bulb $\varnothing$ 6 x length 100 mm
capillary length 1500 mm



WHIRLPOOL 483286002874

Contactors

3454056 CONTACTOR MOD. A16-30-01
3 normally open contacts
1 normally closed auxiliary contact
power contact 30A - 230V
4 Kw / 230 V - 7,5 Kw / 440 V



WHIRLPOOL 483286002765

3454025 CONTACTOR MOD. LC1 D32
for heating 220-230V-50Hz-7.5Kw
for Washing machine (GRANDIMPIANTI) WFP120
for Washing machine (PRIMUS) FS10 - FS120 - FS16
FS23 - FS7 - MB140 - MB180 - MB26 - MB33
MB44 - MB66 - MB90 - RS10 - RS16 - RS22 - RS7
XS22
for Washing machine (WHIRLPOOL) WACS11 - WACS17
WACS28AE - WACS28AV - WACS35AE - WACS35AV
WACS46AE - WACS46AV - WACS70AE - WACS70AV
WACS8 - WAC11 - WAC17 - WAC23 - WAC8



WHIRLPOOL 750029

WHIRLPOOL 771985008705




Suitable for:

WHIRLPOOL



3454024 CONTACTOR 4S - MOD. TP3250

'16A 250V - 10A 400V
'50/60Hz
for Dryer (ASKO) TDC44
for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC
ES5EIE
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP
AGB206/WP - AGB207/WP - SACE5 - SE5GC - SE5GE
SE5IC - SE5IE



WHIRLPOOL 483286000307

WHIRLPOOL 747112

WHIRLPOOL 771985008655

3454023

FREQUENCY CONVERTER

LS SV0004IC5-1F



WHIRLPOOL 483286009585

3351054 THERMAL RELAY T7 DU

1.6 - 2.5 A
for Dryer (IMESA) ES10 - ES10INV - ES14 - ES14INV
ES18 - ES18INV - ES23 - ES34
for Dryer (WHIRLPOOL) AGB257/WP - AGB258/WP
AGB259/WP - AGB260/WP - AGB261/WP - AGB262/WP
AGB263/WP - AGB264/WP



WHIRLPOOL 483286009765

3454027

3-PHASE CONTACTOR

for motor 24V-2.2Kw
for Dryer (PRIMUS) DA11 - DA13 - DA15
for Dryer (WHIRLPOOL) SACE11 - SACE13 - SACE17
SWE111 - SWE131 - SWE151



WHIRLPOOL 753334

WHIRLPOOL 771985009280

Delaying devices

3360004 DELAY SWITCH NT07062

for Washing machine (ZANUSSI) LB110 - LB120
LB160 - LB70 - LB80



WHIRLPOOL 147344

WHIRLPOOL 771985001588

Door catches

3398083 DOOR BLOCK ES10/32

for Dryer (IMESA) ES10 - ES10INV - ES14 - ES14INV
ES18 - ES18INV
for Dryer (WHIRLPOOL) AGB257/WP - AGB258/WP
AGB260/WP - AGB261/WP - AGB262/WP - DE10MP
DE10MPI - DE14MP - DE14MPI - DE18MP - DE18MPI



WHIRLPOOL 483286009722



Suitable for:

WHIRLPOOL



Suitable for:

Door catches

3242625 DOOR HOOK
for Washing machine (PRIMUS) P5
for Washing machine (WHIRLPOOL) LWS51M



WHIRLPOOL 746614

WHIRLPOOL 771985008487

3242638 HOOK PRESSURE SPRING



WHIRLPOOL 746660

WHIRLPOOL 771985008533

3242637 PLASTIC FINGER
for hook



WHIRLPOOL 746668

WHIRLPOOL 771985008541

3242624 LOCK HOOK
for Washing machine (WHIRLPOOL) AWM910
AWM9100-EU - AWM9100-F - HYDRA




WHIRLPOOL 481241728087

WHIRLPOOL 561021

WHIRLPOOL 771985011731


3242641 SAFETY FINGER
for Washing machine (WHIRLPOOL) AWM910
AWM9100-EU - AWM9100-F - HYDRA



WHIRLPOOL 481249818264

WHIRLPOOL 561022

3242642 SAFETY SPRING



WHIRLPOOL 481249258044

WHIRLPOOL 561023

3242643 SAFETY WASHER



WHIRLPOOL 481253218068

WHIRLPOOL 561024

3242644 SCREW FOR LOCK HOOK



WHIRLPOOL 481250238352

WHIRLPOOL 561129

Drain hoses

3450165 CONNECTION SLEEVE

total length 150 mm
internal $\varnothing$ 110 mm



WHIRLPOOL 757419

WHIRLPOOL 771985009493

5045876 DRAIN PIPE

length 65 mm
for Washing machine (GRANDIMPIANTI) WFM8 - WF8 WR8
for Washing machine (PRIMUS) F6 - F7 - RS6 - RS7
for Washing machine (WHIRLPOOL) LW70 - WACS8 WAC8



WHIRLPOOL 771985009494

3449280 EXHAUST PIPE SET

for Dryer (WHIRLPOOL) AWZ481E - HELIOS



WHIRLPOOL 481253018054

WHIRLPOOL 561293

WHIRLPOOL 771985013011

5031547 PIPE $\varnothing$ 19x26 mm 3/4Fx3/4FC 450 mm

for Washing machine (IMESA) LM14 - LM18 - LM23 RC14 - RC18 - RC23



WHIRLPOOL 483286008258

3450164 SLEEVE

overall length 170 mm



WHIRLPOOL 756283

WHIRLPOOL 771985009314

Drain tanks

3786441 DRIP TANK

for Dryer (WHIRLPOOL) AWZ481E - 016074 HELIOS



WHIRLPOOL 481946699046

WHIRLPOOL 561285

3786433 SELF-ADHESIVE GASKET 370mm

for drip tray
for Dryer (WHIRLPOOL) AWZ481E - HELIOS-AWZ481



WHIRLPOOL 481946818183

WHIRLPOOL 561300



Suitable for:

3527013 TANK FOR CONDENSATE
for Dryer (ASKO) TDC44
for Dryer (IMESA) ES5
for Dryer (WHIRLPOOL) AGB205 - AGB207



WHIRLPOOL 483286000361

Suitable for:


3527014 INJECTOR FOR TANK
for Dryer (ASKO) TDC44
for Dryer (IMESA) ES5
for Dryer (WHIRLPOOL) AGB205 - AGB207



WHIRLPOOL 483286000363

Electrical gas valves and accessories


3526066 HONEYWELL VALVE V4400C Ø 3/4" FF 220V
inlet Ø 3/4"F - outlet Ø 3/4"F
thermocouple connection ASA pitch
maximum gas inlet pressure 60 mbar
room temperature 0÷70°C
power supply 230V 50Hz



WHIRLPOOL 157340

Electromagnets


3121020 COMPLETE DOOR LOCK WITHOUT DELAYER
for Washing machine (GRANDIMPIANTI) WFM11 - WFM18
WFM8 - WF18E
for Washing machine (POLIMATIC) FS16 - FS22 - FS23
FS23PR
for Washing machine (PRIMUS) FS16 - FS22 - FS23
FS23PRO
for Washing machine (WHIRLPOOL) 016004-WACS17



WHIRLPOOL 757463

WHIRLPOOL 771985009545


3242633 COMPLETE LOCK 220V
for washing machine Whirlpool 7.5 KG
mod. WACS8 - 016002 - 10 kg mod. WACS11 016003
Primus 7.5 kg mod. FS7 - 10 kg mod. FS10



WHIRLPOOL 756291

WHIRLPOOL 771985009322

3803013 DOOR CONTACT
110-240V
for lock mod.682-P10



WHIRLPOOL 751004

WHIRLPOOL 771985008810



Suitable for:

3242626 KEY LOCK PIN
placed in the locks



WHIRLPOOL 756393

WHIRLPOOL 771985011871

3242636 COMPLETE LOCK 220V



WHIRLPOOL 752682

WHIRLPOOL 771985009146

3240777 MICROSWITCH 8A 250V

for Washing machine (GRANDIMPIANTI) WFM11 - WFM18
WFM8 - WR11 - WR18 - WR24 - WR37 - WR8
for Washing machine (POLIMATIC) FS10 - FS16 - FS23
FS23PRO - FS6 - FS7 - RS10 - RS13 - RS18
RS22 - RS27 - RS35 - RS6 - RS7
for Washing machine (PRIMUS) FS10 - FS16 - FS23
FS23PRO - FS6 - FS7 - RS10 - RS13 - RS18
RS22 - RS27 - RS35 - RS6 - RS7
for Washing machine (WHIRLPOOL) 016002-WACS8
016003-WACS11 - 016013-WAC8 - 016014-WAC11
016015-WAC17 - 016016-WAC23



WHIRLPOOL 757447

WHIRLPOOL 771985009529

3242632 DOOR LATCH
250 V $\bar{y}$ 50/60 Hz
for washing machine



WHIRLPOOL 481228058041

WHIRLPOOL 561074

WHIRLPOOL 771985011600

WHIRLPOOL



Suitable for:

3240777 MICROSWITCH 8A 250V
for Washing machine (GRANDIMPIANTI) WFM11 - WFM18
WFM8 - WR11 - WR18 - WR24 - WR37 - WR8
for Washing machine (POLIMATIC) FS10 - FS16 - FS23
FS23PRO - FS6 - FS7 - RS10 - RS13 - RS18
RS22 - RS27 - RS35 - RS6 - RS7
for Washing machine (PRIMUS) FS10 - FS16 - FS23
FS23PRO - FS6 - FS7 - RS10 - RS13 - RS18
RS22 - RS27 - RS35 - RS6 - RS7
for Washing machine (WHIRLPOOL) 016002-WACS8
016003-WACS11 - 016013-WAC8 - 016014-WAC11
016015-WAC17 - 016016-WAC23



WHIRLPOOL 757447

WHIRLPOOL 771985009529

3242626 KEY LOCK PIN
placed in the locks




WHIRLPOOL 756393

WHIRLPOOL 771985011871



Suitable for:

3242631 DOOR LOCK



WHIRLPOOL 483286009882

WHIRLPOOL 747006

WHIRLPOOL 771985008628

Suitable for:

3803015 DOOR LOCK CONTACT

for Washing machine (IMESA) LM5EGDP - LM5EGDV
LM5EIDP - LM5EIDV
for Washing machine (PRIMUS) PW5
for Washing machine (WHIRLPOOL) AGB200/WP
AGB201/WP - AGB202/WP - AGB203/WP



WHIRLPOOL 483286009884

WHIRLPOOL 747024

WHIRLPOOL 771985012221

3121013 DOOR LOCK KIT 220V
for Washing machine (ZANUSSI) LB121 - LB161 - LB81
W160



WHIRLPOOL 191892

WHIRLPOOL 771985005440

3121022 DOOR LOCK 220/240V 50Hz
for Washing machine (GRANDIMPIANTI) WFM6 - WFM6S
for Washing machine (MIELE)
for Washing machine (POLIMATIC) P65 - P75
for Washing machine (PRIMUS) C6 - C8 - MB16 - MB26
MB33 - MB44 - MB66 - P6 - P7
for Washing machine (WHIRLPOOL) 016017-WACS28AE
016018-WACS28AV - 016019-WACS35AE
016020-WACS35AV - 016021-WACS46AE
016022-WACS46AV - 016023-WACS70AE
016024-WACS70AV




WHIRLPOOL 746836

WHIRLPOOL 750305

WHIRLPOOL 771985008606

WHIRLPOOL 771985008778

3121009 DOOR LOCK 220/240V 50Hz 16A
for Washing machine (ZANUSSI) WE55QSR - W355H



WHIRLPOOL 192918


3121031 DOOR LOCK 220V



WHIRLPOOL 746050

WHIRLPOOL 771985008318

3121017 DOOR LOCK 24V
for Washing machine (IMESA) LM11 - LM6 - LM8
RC11 - RC6 - RC8



WHIRLPOOL 483286008579

3121023 DOOR OPENING ELECTROMAGNET 205V
for Washing machine (GRANDIMPIANTI) WFM11 - WFM18
WFM8 - WR11 - WR18 - WR24 - WR37 - WR8
for Washing machine (POLIMATIC) FS10 - FS16 - FS23
FS23PRO - FS6 - FS7 - RS10 - RS13 - RS18
RS22 - RS27 - RS35 - RS6 - RS7 - XS22
for Washing machine (PRIMUS) FS10 - FS16 - FS23
FS23PRO - FS6 - FS7 - RS10 - RS13 - RS18
RS22 - RS27 - RS35 - RS6 - RS7 - XS22



WHIRLPOOL 751005

WHIRLPOOL 771985008811



WHIRLPOOL



Suitable for:

3121018 DOOR OPENING ELECTROMAGNET 220/240V 50Hz
model TT2-1
for Washing machine (IMESA) LM30 - LM40 - LM55
LM70 - LM85 - RC30 - RC40 - RC55 - RC70



WHIRLPOOL 483286001804


Suitable for:

3121019 DOOR OPENING ELECTROMAGNET 240V 50Hz
for Washing machine (IMESA) LM14 - LM18 - LM23
RC14 - RC18 - RC23



WHIRLPOOL 483286008366

3242635 ELECTRONIC LOCK
204/264 V - 50 Hz
locking distance 83 mm



WHIRLPOOL 483286008273

3242648 MAGNET FOR DOOR
for door lock



WHIRLPOOL 483286000314

3242651 MAGNET SUPPORT 60 x 27 mm




WHIRLPOOL 483286000315

WHIRLPOOL 747123

WHIRLPOOL 771985008666

Electronic boxes

3091011 ELECTRONIC CONTROL BOX 501EFD
230V 50/60Hz
for Dryer (IMESA) ES10 - ES14 - ES18 - ES23 - ES34
ES55 - ES75
for Dryer (WHIRLPOOL) AGB276 - AGB277 - AGB279
AGB281 - AGB282 - AGB283



WHIRLPOOL 483286000761


3091038 FLAME CONTROLLER MOD.MICRO56N24
24V - 50/60Hz
for Dryer (WHIRLPOOL) SWE140



WHIRLPOOL


Electronic printed-circuit boards

3390281 CONTROL BOARD
for Dryer (WHIRLPOOL) AWZ139/03 - AWZ1390
TRA4240 - TRA4350 - TRA4470



WHIRLPOOL 481931039521

3390286 CONTROL BOARD
for Washing machine (WHIRLPOOL) AWM8050-F
AWM8100-F



WHIRLPOOL 481221458158



Suitable for:

3390287 CONTROL BOARD

for Washing machine (WHIRLPOOL) AWM9000-F
AWM9100-F



WHIRLPOOL 481221479826

WHIRLPOOL 481232128367

WHIRLPOOL 561067

WHIRLPOOL 771985011532

Suitable for:

3390237 DOOR ACTIVATING BOARD KIT

for Washing machine (IMESA) LM11 - LM6 - LM8
RC11 - RC6 - RC8
for Washing machine (WHIRLPOOL) AGB208/WP
AGB209/WP - AGB214/WP - AGB215/WP - AGB230/WP
AGB231/WP - AGB232/WP - AGB236/WP - AGB237/WP
AGB238/WP



WHIRLPOOL 483286008638

3390312 ECC CONTROL BOARD

for Dryer (IMESA) ES10 - ES10INV - ES14 - ES14INV
ES18 - ES18INV - ES23 - ES34 - ES55
for Dryer (WHIRLPOOL) AGB257/WP - AGB258/WP
AGB259/WP - AGB260/WP - AGB261/WP - AGB262/WP
AGB263/WP - AGB264/WP - AGB265/WP



WHIRLPOOL 483286000683

WHIRLPOOL 483286009713


3390335 DISPLAY BOARD



WHIRLPOOL 483286000682

3390284 ELECTRONIC BOARD

for Dryer (PRIMUS) DA11 - DA13 - DA15 - D25
for Dryer (WHIRLPOOL) SACE11 - SACE13 - SACE17
SACE25 - SWE111 - SWE131 - SWE151 - SWE250



WHIRLPOOL 757100


WHIRLPOOL 757484

WHIRLPOOL 771985009398

WHIRLPOOL 771985011614

3322328 CONTROL KEYBOARD

OPL electronic control
for Dryer (PRIMUS) DA11 - DA13 - DA15 - D25
for Dryer (WHIRLPOOL) SACE11 - SACE13 - SACE17
SACE25 - SWE111 - SWE131 - SWE151




WHIRLPOOL 757128

WHIRLPOOL 771985009426

3390285 ELECTRONIC BOARD FOR DISPLAY

switch assembly
for Washing machine (WHIRLPOOL) AGB650/WP
AWM9100-EU - AWM9100-F



WHIRLPOOL 481227628408

WHIRLPOOL 481227628452

3028014 CONTROL BOARD

with handle
for Washing machine (WHIRLPOOL) AWM910 - AWM9100
AWM9100-F



WHIRLPOOL 481245213722



Suitable for:

3028015 PLATE

for Washing machine (WHIRLPOOL) AWM910 - AWM9100
AWM9100-F



WHIRLPOOL 481245213723

WHIRLPOOL




Suitable for:

3242656

PROGRAMMER KNOB

for Washing machine (WHIRLPOOL) HYDRA AWM9100



WHIRLPOOL 481241028998

WHIRLPOOL 481241029191

3390331 ELECTRONIC BOARD HYDRA




WHIRLPOOL 480111100355

3390288 ELECTRONIC BOARD IM6-IM9

for Washing machine (IMESA) LM11 - LM14 - LM18
LM23 - LM6 - LM8 - RC11 - RC14 - RC18 - RC23
RC8

for Washing machine (WHIRLPOOL) AGB208/WP
AGB209/WP - AGB210/WP - AGB211/WP - AGB212/WP
AGB214/WP - AGB215/WP - AGB216/WP - AGB217/WP
AGB218/WP - AGB230/WP - AGB231/WP - AGB232/WP
AGB233/WP - AGB234/WP - AGB235/WP - AGB236/WP
AGB237/WP - AGB238/WP - AGB239/WP - AGB240/WP
AGB241/WP




WHIRLPOOL 483286008476

3390301 ELECTRONIC BOARD MCB FC

for Washing machine (PRIMUS) FS10 - FS16 - FS22
FS33 - FS40 - FS55 - FS6 - FS7 - MB16 - MB26
MB33 - MB44 - MB66 - RS10 - RS13 - RS16 - RS18
RS22 - RS27 - RS35 - RS6 - RS7 - XS22 - XS35
XS43

for Washing machine (WHIRLPOOL) LWS220 - WACS11
WACS16AE - WACS17 - WACS23 - WACS28AE
WACS28AV - WACS35 - WACS35AE - WACS35AV
WACS42 - WACS46AE - WACS46AV - WACS55
WACS70AE - WACS70AV - WACS8 - WAC11 - WAC17
WAC23 - WAC8



WHIRLPOOL

3322330 CONTROL KEYBOARD MCB LC

for Washing machine (PRIMUS) FS10 - FS16 - FS22
FS33 - FS40 - FS55 - FS6 - FS7 - MB16 - MB26
MB33 - MB44 - MB66 - RS10 - RS13 - RS16 - RS18
RS22 - RS27 - RS35 - RS6 - RS7 - XS22 - XS35
XS43


for Washing machine (WHIRLPOOL) LWS220 - WACS11
WACS16A - WACS17 - WACS23 - WACS28A - WACS28AE
WACS28AV - WACS35A - WACS35AE - WACS35AV
WACS42 - WACS46A - WACS46AE - WACS46AV
WACS55 - WACS70A - WACS70AE - WACS70AV - WACS8
WAC11 - WAC17 - WAC23 - WAC8



WHIRLPOOL

3390337 ELECTRONIC BOARD NON PROGRAMMED


for programming it is necessary
model, serial number of the equipment



WHIRLPOOL 481221479827

3390332 ELECTRONIC BOARD TYPE 10173

for door unlocking



WHIRLPOOL 481221458174



Suitable for:

WHIRLPOOL



Suitable for:

3390283 ELECTRONIC POWER BOARD

for Dryer (ASKO) TDC44
for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC
ES5EIE
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP
AGB206/WP - AGB207/WP - SACE5 - SE5GC - SE5GE
SE5IC - SE5IE



WHIRLPOOL 48328600305


5025792 LOGIC CIRCUIT BOARD IM6 BLUE DISPLAY

dimensions 170 x 110 mm
for Washing machine (IMESA) - Series LM
Series RC
for Washing machine (WHIRLPOOL) AGB208 - AGB209
AGB210 - AGB211 - AGB212 - AGB213 - AGB214
AGB215 - AGB216 - AGB217 - AGB218 - AGB230
AGB231 - AGB232 - AGB233 - AGB234 - AGB235
AGB236 - AGB237 - AGB238 - AGB239 - AGB240
AGB241 - AGB242 - AGB243 - AGB244 - AGB245
AGB246 - AGB247 - AGB248 - AGB249 - AGB250
AGB251 - AGB252 - AGB253 - AGB254



WHIRLPOOL 483286008249

3390334 LOGIC CIRCUIT BOARD IM9



WHIRLPOOL 483286008251

3319660 DIAPHRAGM KEYBOARD IM6

for Washing machine (IMESA) LM11 - LM14 - LM18
LM23 - LM6 - LM8 - RC11 - RC14 - RC18 - RC23
RC8
for Washing machine (WHIRLPOOL) AGB208 - AGB208/WP
AGB209 - AGB209/WP - AGB210 - AGB210/WP
AGB211 - AGB211/WP - AGB212 - AGB212/WP
AGB213 - AGB214 - AGB214/WP - AGB215
AGB215/WP - AGB216 - AGB216/WP - AGB217
AGB217/WP - AGB218 - AGB218/WP - AGB230/WP
AGB231/WP - AGB232/WP - AGB233/WP - AGB234/WP
AGB235/WP - AGB236 - AGB237 - AGB238 - AGB239
AGB240 - AGB240/WP - AGB241 - AGB241/WP
AGB242 - AGB243 - AGB244 - AGB245 - AGB246
AGB247 - AGB248 - AGB249 - AGB250 - AGB251
AGB252 - AGB253 - AGB254



WHIRLPOOL 483286008261

3340065 MOTOR CONTROL UNIT

for Washing machine (ASKO) WMC55
for Washing machine (IMESA) LM5 - LM5EGDP
LM5EGDV - LM5EIDP - LM5EIDV
for Washing machine (PRIMUS) PW5
for Washing machine (WHIRLPOOL) AGB200 - AGB200/WP
AGB201 - AGB201/WP - AGB202 - AGB202/WP
AGB203 - AGB203/WP - WACS5 - WES5GP - WES5GV
WES5IP - WES5IV



WHIRLPOOL 483286009849

WHIRLPOOL 747002

WHIRLPOOL 771985008624



Suitable for:

WHIRLPOOL



3390289 POWER BOARD

for Washing machine (WHIRLPOOL) AWM9100-EU
AWM9100-F



WHIRLPOOL 481221478867

WHIRLPOOL 481221479471

WHIRLPOOL 481221479772

WHIRLPOOL 481221479871

WHIRLPOOL 561068

WHIRLPOOL 771985011739

3390282 POWER SUPPLY BOARD PWR

for Washing machine (PRIMUS) C6 - C8 - FS10 - FS16
FS7 - RS10 - RS13 - RS16 - RS18 - RS22 - RS27
RS35 - RS6 - RS7
for Washing machine (WHIRLPOOL) WACS11 - WACS17
WACS8 - WAC11 - WAC17 - WAC23 - WAC8



WHIRLPOOL 757400

WHIRLPOOL 771985009474


3319718 KEY BOARD EASY CONTROL



WHIRLPOOL

3322327 PROGRAMMER MCBLC

for Washing machine (PRIMUS) FS10 - FS16 - FS7
P6 - P7 - RS10 - RS16 - RS22 - RS7
for Washing machine (WHIRLPOOL) WACS11 - WACS17
WACS8 - WAC11 - WAC17 - WAC23 - WAC8



WHIRLPOOL 757401

WHIRLPOOL 771985009475

Feet

3313069 ADJUSTABLE FOOT - M10 x 25 mm - ø 45 mm

for Washing machine (IMESA) LM11 - LM6 - LM8
for Washing machine (WHIRLPOOL) AGB230/WP
AGB231/WP - AGB232/WP - AGB237/WP - AGB238/WP
AGB536/WP - WES11MP - WES11ST - WES6MP
WES6ST - WES8MP - WES8ST



WHIRLPOOL 483286000962

WHIRLPOOL 4832860008614

3313070 ADJUSTABLE FOOT - M10 x 30 mm - ø 50 mm

for Dryer (ELFRAMO) ES23
for Dryer (IMESA) ES10 - ES10INV - ES14 - ES14INV
ES18 - ES18INV - ES34
for Dryer (WHIRLPOOL) AGB257/WP - AGB258/WP
AGB259 - AGB260/WP - AGB261/WP - AGB262/WP
AGB263/WP - AGB264/WP - DE10MP - DE10MPI
DE14MP - DE14MPI - DE18MP - DE18MPI - DE23MPI
DE34MPI



WHIRLPOOL 4832860009771



Suitable for:

WHIRLPOOL



Suitable for:

Filters

3160467 AIR FILTER ES10/34 (FIREPROOF SCREEN)

605x260 mm

for Dryer (IMESA) ES10 - ES10INV - ES14 - ES14INV

ES18 - ES18INV - ES23 - ES34 - E18IMB24SAXA

for Dryer (WHIRLPOOL) AGB257/WP - AGB258/WP

AGB259/WP - AGB260/WP - AGB261/WP - AGB262/WP

AGB263/WP - AGB264/WP



WHIRLPOOL 483286009732

3160492 COMPLETE FILTER SUPPORT



WHIRLPOOL 483286000317

3786569 FILTER HOLDER GASKET



WHIRLPOOL

3160426 DOOR FILTER

for Dryer (WHIRLPOOL) AWZ481E



WHIRLPOOL 480112100112

WHIRLPOOL 481248128168

WHIRLPOOL 561289

WHIRLPOOL 771985011792

3160427 DOOR FILTER

for Dryer (WHIRLPOOL) AWZ481E



WHIRLPOOL 481944019766

WHIRLPOOL 561286

3160431 DRYER FILTER



WHIRLPOOL 481248058322

3160438 GASKET FOR FILTER



WHIRLPOOL 481246688521

3160424 FILTER

dimensions 350 x 500 mm

for Dryer (WHIRLPOOL) AWZ481E



WHIRLPOOL 481248418002

WHIRLPOOL 561291

3160423 FILTER SUPPORT



WHIRLPOOL 481240418438

WHIRLPOOL 561292

Suitable for:

3160425 FILTER

for Dryer (MIELE) T5205 - T5206 - T5212 - T5213
for Dryer (WHIRLPOOL) PT125 - PT126 - PT130
PT131 - SW90



WHIRLPOOL 745742


WHIRLPOOL 746089

WHIRLPOOL 746489

WHIRLPOOL 771985008177

Suitable for:

3160432 FILTER



WHIRLPOOL 745838

WHIRLPOOL 771985008243

3160433 FILTER

for Dryer (PRIMUS) D9
for Dryer (WHIRLPOOL) SWE90




WHIRLPOOL 751163

WHIRLPOOL 771985008903

3160436 FILTER

for Dryer (ASKO) TDC44
for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC
ES5EIE
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP
AGB206/WP - AGB207/WP - SACE5 - SE5GC - SE5GE
SE5IC - SE5IE




WHIRLPOOL 483286000319

WHIRLPOOL 747121

WHIRLPOOL 771985008664

3123128 FILTER FOR CONDENSER

for Dryer (MIELE) PT126 - PT131
for Dryer (WHIRLPOOL) SW90




WHIRLPOOL 746110

WHIRLPOOL 771985008341

3123129 FILTER FOR CONDENSER

length 360 mm/width.240 mm
for Dryer (ASKO) TDC44
for Dryer (IMESA) ES5EGC
for Dryer (PRIMUS) DAMC5
for Dryer (WHIRLPOOL) AGB205 - SACE5



WHIRLPOOL 483286000353

WHIRLPOOL 747116

WHIRLPOOL 771985008659

3160428 FILTER 510 x 510 mm



WHIRLPOOL 721052

WHIRLPOOL 771982007772

3160430 FILTER 610 x 610 mm

for Dryer (PRIMUS) D14 - D25
for Dryer (WHIRLPOOL) SACE25 - SWE250
for Washing machine (GIRBAU) SMI12E



WHIRLPOOL 721051

WHIRLPOOL 771985007771



WHIRLPOOL



Suitable for:

3160429 FILTER 620 x 620 mm
for Dryer (IPSO) DR25 - DR35
for Dryer (PRIMUS) DA11 - DA13 - DA15
for Dryer (WHIRLPOOL) SACE11 - SACE13 - SACE15
SWE111 - SWE131 - SWE151



WHIRLPOOL 753315

WHIRLPOOL 771985009264

Suitable for:

3160437 FRONT GRID FOR DOOR FILTER
for Dryer (WHIRLPOOL) AWZ481E



WHIRLPOOL 481245838065

WHIRLPOOL 561288

3160493 GAUZE FILTER



WHIRLPOOL 757002

WHIRLPOOL 771985009392

3160494 PILE FILTER



WHIRLPOOL 746700

WHIRLPOOL 771985008551

Flanges

3161005 BACK FLANGE



WHIRLPOOL

Flowmeters

3090199 FLOWRATE METER
for Washing machine (WHIRLPOOL) AWM9100-EU
AWM9100-F



WHIRLPOOL 481227128522

WHIRLPOOL 561072

WHIRLPOOL 771985011743

3501241 FLOWRATE METER.NOZZLE FOR PROD.DISPENSER
for Washing machine (WHIRLPOOL) AWM9100-F



WHIRLPOOL 481252648159

3449281 PIPE
between the tank and the volumetric meter
for Washing machine (WHIRLPOOL) AWM9100EU
AWM9100F - HYDRA



WHIRLPOOL 481253029276

3786443 TORIC GASKET 8.1 x 1.6 mm



WHIRLPOOL 481263058102

Fuses

3049123 FUSE HOLDER

for Washing machine (IMESA) LM11 - LM14 - LM18
LM23 - LM6 - LM8 - RC11 - RC14 - RC18 - RC23
RC8
for Washing machine (WHIRLPOOL) AGB208 - AGB208/WP
AGB209 - AGB209/WP - AGB210 - AGB210/WP
AGB211 - AGB211/WP - AGB212 - AGB212/WP
AGB214 - AGB214/WP - AGB215 - AGB215/WP
AGB216 - AGB216/WP - AGB217 - AGB217/WP
AGB218 - AGB218/WP - AGB230 - AGB230/WP
AGB231 - AGB231/WP - AGB232 - AGB232/WP
AGB233 - AGB233/WP - AGB234 - AGB234/WP
AGB235 - AGB235/WP - AGB238 - AGB238/WP
AGB240 - AGB240/WP - AGB241 - AGB241/WP



WHIRLPOOL 483286008309

WHIRLPOOL 483286008313

3049124 FUSE 250V 1A - 10 PCS

dimensions 5x20 mm
for Washing machine (IMESA) LM11 - LM14 - LM18
LM23 - LM6 - LM8 - RC11 - RC14 - RC18 - RC23
RC8
for Washing machine (WHIRLPOOL) AGB208 - AGB209
AGB210 - AGB211 - AGB212 - AGB214 - AGB215
AGB216 - AGB217 - AGB218 - AGB230 - AGB231
AGB232 - AGB233 - AGB234 - AGB235 - AGB236/WP
AGB237/WP - AGB238 - AGB238/WP - AGB239/WP
AGB240 - AGB241



WHIRLPOOL 483286002957

Gaskets and seals

3186185 CIRCULAR GASKET ø 5 mm

sold per meter
1 meter for washing machines up to 23 Kg capacity
2 meters for larger washing machines
for Washing machine (IMESA) LM11 - LM30 - LM40
LM50 - LM6 - LM70 - LM8 - LM85 - RC11 - RC14
RC18 - RC23 - RC30 - RC40 - RC55 - RC6 - RC70
RC8
for Washing machine (WHIRLPOOL) AGB209 - AGB210
AGB211 - AGB213 - AGB214 - AGB215 - AGB216
AGB217 - AGB218 - AGB219 - AGB220 - AGB221
AGB222 - AGB223 - AGB224 - AGB225 - AGB226
AGB227 - AGB228 - AGB229 - AGB231 - AGB232
AGB236 - AGB237 - AGB238 - AGB239 - AGB240
AGB241 - AGB242 - AGB243 - AGB244 - AGB245
AGB246 - AGB247 - AGB248 - AGB249 - AGB250



WHIRLPOOL 483286008466

3786440 COPPER GASKET 14x20x2 mm STUFFING GLAND



WHIRLPOOL 752319

WHIRLPOOL 7719850085009115

WHIRLPOOL 771985009115

3786566 FELT GASKET

for Dryer (IPSO) DR25 - DR35
for Dryer (PRIMUS) DA11 - DA13 - DA15
for Dryer (WHIRLPOOL) BWE111 - SWE111 - SWE131



WHIRLPOOL 757120

WHIRLPOOL 771985009418



Suitable for:

3786429 FELT STRIP

ø 470 mm
for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC
ES5EIE
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP
AGB206/WP - AGB207/WP - SACE5



WHIRLPOOL 483286000292

Suitable for:

3391028 FELT STRIP CLAMP

for Dryer (IMESA) ES5 - ES5EGC - ES5EGE - ES5EIC
ES5EIE
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204 - AGB204/WP - AGB205
AGB205/WP - AGB206 - AGB206/WP - AGB207
AGB207/WP - SACE5



WHIRLPOOL 483286000291

3786510 GASKET FOR DETERGENT TANK LM8/11

for Washing machine (WHIRLPOOL) AGB208/WP
AGB214/WP - AGB230/WP - AGB231/WP - AGB232/WP
AGB236/WP - AGB237/WP



WHIRLPOOL 483286008188

3786431 GASKET FOR MANIFOLD

ext.ø 410 mm - int.ø 380 mm
for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC
ES5EIE - ES55 - ES75
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204 - AGB204/WP - AGB205
AGB205/WP - AGB206 - AGB206/WP - AGB207
AGB207/WP - SACE5



WHIRLPOOL 483286000279

WHIRLPOOL 747104

WHIRLPOOL 771985008647

3786423 MANIFOLD GASKET

SWE390-SWE91-SWE291-SWE391
for Dryer (FAGOR) SE-7
for Dryer (GIRBAU) SE/7
for Dryer (IPSO) DD8
for Dryer (PRIMUS) DA9 - D9
for Dryer (WHIRLPOOL) SACE8 - SWE290 - SWE291
SWE390 - SWE391 - SWE90 - SWE91



WHIRLPOOL 751160

WHIRLPOOL 751176

WHIRLPOOL 771985008901

WHIRLPOOL 771985008914

5043175 RING SUPPORT GASKET

for WASHING MACHINE PRIMUS FS16



WHIRLPOOL 771985009186

3786418 SELF ADHESIVE FELT SHIM

length 47 mm
for Dryer (PRIMUS) DA9
for Dryer (WHIRLPOOL) 016025-SACE8



WHIRLPOOL 722051

WHIRLPOOL 771985007875

3786428 SELF-ADHESIVE GASKET FOR FRONT PANEL

length 600 mm
for Dryer (WHIRLPOOL) AWZ481E - HELIOS-AWZ481



WHIRLPOOL 481946818179

WHIRLPOOL 561225



WHIRLPOOL



Suitable for:

3786439 SPACER GASKET




WHIRLPOOL 757104

WHIRLPOOL 771985009402

Suitable for:

3786574 TANK GASKET ø 630 mm



WHIRLPOOL 752706

WHIRLPOOL 771985009153

Gears

3212012 CHAIN TENSIONING PINION



WHIRLPOOL 721044

WHIRLPOOL 771985007767

Glasses

5005546 DOOR GLASS FOR WASHING MACHINE
for WASHING MACHINE RC/LM6-11



WHIRLPOOL 483286008642

3520012 FRONT DOOR GLASS
for Washing machine (PRIMUS) FS10 - FS7 - P6 - P7
for Washing machine (WHIRLPOOL) WACS11 - WACS6
WACS7 - WACS8



WHIRLPOOL 752657


WHIRLPOOL 771985009135

3520014 FRONT DOOR GLASS
for Washing machine (WHIRLPOOL) AWM9100-EU
AWM9100-F




WHIRLPOOL 481245078019

3393004 EXTERNAL FRAME FOR FRONT DOOR GLASS
for Washing machine (WHIRLPOOL) AWM910 - AWM9100
AWM9100-F



WHIRLPOOL 481244010718

3393005 INTERNAL FRAME FOR FRONT DOOR GLASS
for Washing machine (WHIRLPOOL) AWM910 - AWM9100
AWM9100-F




WHIRLPOOL 481244010794



Suitable for:

Suitable for:

3520017 FRONT DOOR GLASS ES10/32



WHIRLPOOL 483286009725

3520013 FRONT DOOR GLASS FASTENER

for Dryer (IMESA) ES10 - ES14 - ES18 - ES23 - ES34
for Dryer (WHIRLPOOL) AGB257/WP - AGB258/WP
AGB259/WP - AGB260/WP - AGB261/WP - AGB262/WP
AGB263/WP - AGB264/WP



WHIRLPOOL 483286009724

Handles

3242467 BLUE PUSH-BUTTON DOOR HANDLE

for Washing machine (IMESA) LM14 - LM18 - LM23
RC14 - RC18 - RC23
for Washing machine (WHIRLPOOL) AGB210/WP
AGB211/WP - AGB212/WP - AGB216/WP - AGB217/WP
AGB218/WP - AGB233/WP - AGB234/WP - AGB235/WP
AGB239/WP - AGB240/WP - AGB241/WP - WES14MP
WES18MP - WES18ST



WHIRLPOOL 483286008356

9014042 RECTANGULAR MAGNET 32x13x8 mm

for Dryer (IMESA) ES55 - ES75



WHIRLPOOL 483286008354

3242022 DOOR CATCH

for LB80E-LB120E-LB160E-CLB160E-LB70E-LB110E
for Washing machine (ZANUSSI) CLB160E - LB110E
LB120E - LB160E - LB70E - LB80E



WHIRLPOOL 147074

WHIRLPOOL 771985001479

3398051 RETAINER FOR WINDOW

for Washing machine (ZANUSSI) CLB160E - LB110E
LB120E - LB160E - LB70E - LB80E



WHIRLPOOL 147071

WHIRLPOOL 771985001476

3250053 SPRING FOR RETAINER



WHIRLPOOL 147073

WHIRLPOOL 771985001478



WHIRLPOOL



Suitable for:

Suitable for:

3242628 DOOR HANDLE
for Dryer (WHIRLPOOL) AWZ481E

3242645 DOOR HANDLE PIN



WHIRLPOOL 481249818329

WHIRLPOOL 561217


WHIRLPOOL 771985011760

WHIRLPOOL 481226318006

WHIRLPOOL 561219

3242639 DOOR SEAL

3242630 SCREW FOR DOOR HANDLE



WHIRLPOOL 481946698658

WHIRLPOOL 561222

WHIRLPOOL 771985011382

WHIRLPOOL 481250318006

WHIRLPOOL 561327

3242629 SELF ADHESIVE PLATE
for door handle

3242627 SELF-ADHESIVE
for door handle
for Washing machine (WHIRLPOOL) AWM910 - AWM9100



WHIRLPOOL 481249878592


WHIRLPOOL 561218

WHIRLPOOL 481249818263

WHIRLPOOL 561019

WHIRLPOOL 771985011730

3242715 DOOR HANDLE



WHIRLPOOL 757011

3242650 DOOR LOCKING PLATE
for Washing machine (WHIRLPOOL) AWM910 - AWM9100

3242647 SCREW 3.5x10 - F - A2F
for door locking plate
for Washing machine (WHIRLPOOL) AWM910 - AWM9100



WHIRLPOOL 481241728086

WHIRLPOOL 561020

WHIRLPOOL 481250218624

WHIRLPOOL 561128



Suitable for:

3453020 DRUM PLATE

for Dryer (FAGOR) SE-7
for Dryer (GIRBAU) SE7
for Dryer (IPSO) DD8
for Dryer (PRIMUS) DA9 - D9
for Dryer (WHIRLPOOL) SACE8 - SWE290 - SWE291
SWE390 - SWE391 - SWE90 - SWE91




WHIRLPOOL 751167

WHIRLPOOL 771985008907

Suitable for:

3453025 BRACKET

for Dryer (FAGOR) SE-7
for Dryer (GIRBAU) SE7
for Dryer (IPSO) DD8
for Dryer (PRIMUS) DA9 - D9
for Dryer (WHIRLPOOL) SACE8 - SWE290 - SWE291
SWE390 - SWE391 - SWE90 - SWE91




WHIRLPOOL 757028

WHIRLPOOL 771985009396

WHIRLPOOL 771985009693

3242646 FRONT DOOR PLIERS



WHIRLPOOL 481240148585

WHIRLPOOL 561029

3242714 HANDLE INSERT



WHIRLPOOL 481241778119

3242649 ROLL HOLDER - 10 PCS

for Dryer (IMESA) DAM5 - ES5EGC - ES5EGE - ES5EIC
ES5EIE
for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP
AGB206/WP - AGB207/WP - SACE5 - SE5GC - SE5GE
SE5IC - SE5IE



WHIRLPOOL 483286000322

WHIRLPOOL 747139

WHIRLPOOL 771985011930

Heating elements

3355639 FINNED HEAT.ELEMENT 3000W 220V

length 330 mm - width 105 mm
fixing nut 14 mm
for Dryer (IMESA) ES10 - ES14
for Dryer (WHIRLPOOL) AGB257/WP - AGB258/WP
AGB260/WP - AGB261/WP - AGB266 - AGB267
AGB269 - AGB270 - AGB275 - AGB276 - AGB278
AGB279



WHIRLPOOL 483286009782

3455324 FINNED HEATING ELEMENT 4000W 230V

useful length 630 mm overall length 675 mm
width 120 mm fittings ø 14
for dryer area
for Dryer (IMESA) ES10 - ES14 - ES18 - ES23 - ES34
for Dryer (WHIRLPOOL) AGB259 - AGB259/WP
AGB262/WP - AGB263 - AGB263/WP - AGB264
AGB264/WP - AGB268 - AGB271 - AGB272 - AGB273
AGB277 - AGB280 - AGB281 - AGB282



WHIRLPOOL 482386000565

WHIRLPOOL 483286000565

3355869 HEATING ELEMENT PROTECTION

flange 80x22 mm
for Washing machine (IMESA) LM18
for Washing machine (POLIMATIC) FS10 - FS16 - FS23
FS23PRO - FS33 - FS40 - FS55 - FS6 - FS7 - P65
P75 - RS13 - RS27 - RS35
for Washing machine (PRIMUS) FS10 - FS16 - FS23
FS23PRO - FS33 - FS40 - FS55 - FS6 - FS7
MB26 - MB33 - MB44 - MB66 - P6 - P7 - RS13
RS27 - RS35
for Washing machine (WHIRLPOOL) WACS11 - WACS28AE
WACS28AV - WACS35 - WACS35AE - WACS35AV
WACS42 - WACS46AE - WACS46AV - WACS55 - WACS6
WACS7 - WACS70AE - WACS70AV - WACS8 - WAC11
WAC17 - WAC23 - WAC8



WHIRLPOOL 752317

WHIRLPOOL 771985009114

3455344 HEATING ELEMENT GROUP WITH KLIXONS

3400W 400V
for Dryer (PRIMUS) DA5
for Dryer (WHIRLPOOL) SWE51 - SWE51M



WHIRLPOOL 746711

WHIRLPOOL 771985008562

3455260 HEATING ELEMENT 10 KW

length 500 mm
for Dryer (PRIMUS) D25
for Dryer (WHIRLPOOL) SACE25 - SWE250



WHIRLPOOL 751509

WHIRLPOOL 771985008947

3455262 HEATING ELEMENT 1000 W - 230 V

blue and red
overall length 265 mm - width 30 mm
for Washing machine (ASKO) WMC55
for Washing machine (IMESA) LM5 - LM5EGDP
LM5EGDV - LM5EIDP - LM5EIDV
for Washing machine (PRIMUS) PW5
for Washing machine (WHIRLPOOL) AGB200 - AGB200/WP
AGB201 - AGB201/WP - AGB202 - AGB202/WP
AGB203 - AGB203/WP - WACS5



WHIRLPOOL 483286009873

WHIRLPOOL 747005

WHIRLPOOL 771985008627

3355553 HEATING ELEMENT 1800W 220V

immersed length 365 mm
width 65 mm
flange 80x27 mm
for Washing machine (ZANUSSI) LB80



WHIRLPOOL 147079

WHIRLPOOL 771985001484

3755985 HEATING ELEMENT 1800W 230V

length 355 mm - width 40 mm
flange 58x25 mm
for Washing machine (ZANUSSI) LB121E - LB81E
WE66MP



WHIRLPOOL 191931

WHIRLPOOL 771985005445



Suitable for:

Suitable for:

3355571 HEATING ELEMENT 2000W 220V

length 220 mm - width 65 mm
flange 80x25 mm
for Washing machine (IMESA) LM6 - LM8 - RC6 - RC8
for Washing machine (WHIRLPOOL) AGB208/WP
AGB214/WP - AGB230/WP - AGB231/WP - AGB236/WP
AGB237/WP



WHIRLPOOL 483286008604

3355873 HEATING ELEMENT 2000W 230V

length 260 mm - width 65 mm
flange 80x28 mm
for Washing machine (FAGOR) LAC-7 - LC-7 - LC/AC-7
LC/E-7 - LF-7
for Washing machine (GRANDIMPIANTI) WFM6 - WFM6S
WFM8 - WR11 - WR37 - WR8
for Washing machine (POLIMATIC) FS10 - FS6 - FS7
P65 - P75 - RS10 - RS13 - RS6 - RS7
for Washing machine (PRIMUS) C6 - C8 - FS10 - FS6
FS7 - F10 - F6 - F7 - P6 - P7 - RS10 - RS13
RS6 - RS7
for Washing machine (WHIRLPOOL) LSW100 - LWS70
WACS11 - WACS6 - WACS7 - WACS8 - WAC11 - WAC8



WHIRLPOOL 750018

WHIRLPOOL 771985008694

3455263 HEATING ELEMENT 2000W 230V

white and red
overall length 355 mm - width 30 mm
flange 54x27 mm
for WASHING MACHINE ASKO WMC55
for WASHING MACHINE IMESA LM5
for WASHING MACHINE PRIMUS PW5
for WASHING MACHINE WHIRLPOOL AGB200 A 203-WACS5
for Washing machine (ASKO) WMC55
for Washing machine (IMESA) LM5 - LM5EGDP
LM5EGDV - LM5EIDP - LM5EIDV
for Washing machine (PRIMUS) PW5
for Washing machine (WHIRLPOOL) AGB200 - AGB200/WP
AGB201 - AGB201/WP - AGB202 - AGB202/WP
AGB203 - AGB203/WP - WACS5



WHIRLPOOL 483286009872

WHIRLPOOL 747004

WHIRLPOOL 771985008622

3455254 HEATING ELEMENT 2050W 230V

immersed length 225 mm
flange 80 x 25 mm
for Washing machine (WHIRLPOOL) AWM9100-EU
AWM9100-F




WHIRLPOOL 481225928871

WHIRLPOOL 561058

WHIRLPOOL 771985011738

3455267 HEATING ELEMENT FASTENING DEVICE



WHIRLPOOL 481240118581

WHIRLPOOL 561059



Suitable for:

3455268 SCREW PMP 1951 - M4x14 SS



WHIRLPOOL



Suitable for:

WHIRLPOOL 481256018069

3455345 HEATING ELEMENT 2050W 230V
overall length 240 mm - bracket 80x25 mm
with CTN probe



WHIRLPOOL 481225928823

WHIRLPOOL 481225928919

3355554 HEATING ELEMENT 2400W 220V
immersed length 365 mm
width 65 mm
flange 80x27 mm
for Washing machine (ZANUSSI) EWM120 - LB120E
LB70



WHIRLPOOL 147316


WHIRLPOOL 771985001581

3355572 HEATING ELEMENT 2500W 220V
immersed length 255 mm
width 65 mm
flange 80x25 mm
for Washing machine (IMESA) LM6 - LM8 - RC6 - RC8
for Washing machine (WHIRLPOOL) AGB208 - AGB214
AGB230 - AGB231 - AGB236 - AGB237



WHIRLPOOL

3355019 HEATING ELEMENT 2400W 220V
immersed length 360x50 mm
flange external dimensions 66x30 mm
for Washing machine (ZANUSSI) K12 - PKE12



WHIRLPOOL 146665

WHIRLPOOL 771985008538

3355060 HEATING ELEMENT 2500W 220V
length 420 mm
width 200 mm
for Dryer (ZANUSSI)



WHIRLPOOL 145550

WHIRLPOOL 771985001069

3355187 HEATING ELEMENT 2500W 230V
immersed length 310 mm
flange 26x61 mm
for Washing machine (WHIRLPOOL) LB121E - LB81E
LC7 - WE66MP
for Washing machine (ZANUSSI) LB121E - LB81E - LC7
WE66MP



WHIRLPOOL 172566

WHIRLPOOL 192731


WHIRLPOOL 771985005477



Suitable for:

3455258 HEATING ELEMENT 2500W 230V

for DRIER MIELE T5205
for DRIER WHIRLPOOL PT126
for Dryer (MIELE) T5205
for Dryer (WHIRLPOOL) PT126




WHIRLPOOL 746074

WHIRLPOOL 771985008327

Suitable for:

3455264 HEATING ELEMENT 2500W 230V CONDENSER

for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC
ES5EIE
for Dryer (PRIMUS) DAM/C5
for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP
AGB206/WP - AGB207/WP - SACE5 - SE5GC - SE5GE
SE5IC - SE5IE - 016064 - 016066



WHIRLPOOL 483286000359

WHIRLPOOL 707120

WHIRLPOOL 771985008663

3355879 HEATING ELEMENT 2650W 230V

length 285 mm - width 65 mm
for Washing machine (MIELE) WS5425 - WS5426
WS5436
for Washing machine (WHIRLPOOL) PW51 - PW61



WHIRLPOOL 745138

WHIRLPOOL 771985007913

3355878 HEATING ELEMENT 2760W 400V

length 285 mm - width 65 mm
for Washing machine (MIELE) WS5425 - WS5426
for Washing machine (WHIRLPOOL) PW51 - PW61




WHIRLPOOL 745139

WHIRLPOOL 771985007914

3355020 HEATING ELEMENT 2800W 220V

immersed length 480x50 mm
flange external dimensions 66x30 mm
for Washing machine (ZANUSSI) K16 - PKE16



WHIRLPOOL 166266

WHIRLPOOL 771985003965

3355555 HEATING ELEMENT 3000W 220V

immersed length 345 mm
width 60 mm
flange 80x27 mm
for Washing machine (ZANUSSI) CLB160E - EWM160
LB110E - LB160E



WHIRLPOOL 147335

WHIRLPOOL 771985001587

3355573 HEATING ELEMENT 3000W 220V

length 280 mm - width 65 mm
flange 80x25 mm
for Washing machine (DANUBE) WED13
for Washing machine (DOMUS) DFI13 - W13
for Washing machine (FAGOR) LA-13M - LB-13M
LC-13 - LF-13
for Washing machine (IMESA) LM11 - LM14 - RC11
RC14
for Washing machine (WHIRLPOOL) AGB209/WP
AGB210/WP - AGB215/WP - AGB216/WP - AGB232
AGB233/WP - AGB238 - AGB239/WP - AGB248
AGB249 - AGB538/WP



WHIRLPOOL 483286008271

3355529 HEATING ELEMENT 4000W 220/230V

immersed length 440 mm
width 65 mm
flange 28x81 mm
for Washing machine (ZANUSSI) CLC12EC - CLC35
LC12EC



WHIRLPOOL 190508

WHIRLPOOL 771985005391

Suitable for:

3355574 HEATING ELEMENT 4000W 220V
length 440 mm - width 65 mm
flange 80x28 mm
for Washing machine (IMESA) LM18 - LM30 - LM40
RC18 - RC30 - RC40
for Washing machine (WHIRLPOOL) AGB211/WP
AGB217/WP - AGB225 - AGB234/WP - AGB240/WP
AGB242 - AGB243 - AGB250 - AGB252 - AGB253



WHIRLPOOL 483286008518

Suitable for:

3455257 HEATING ELEMENT 4000W 220V
for Dryer (GIRBAU) SEI12
for Dryer (IPSO) DR25
for Dryer (PRIMUS) DA11 - DA13 - DA15 - DA25
for Dryer (WHIRLPOOL) SACE11 - SWE111



WHIRLPOOL 757155

WHIRLPOOL 771985009453

3755992 HEATING ELEMENT 4000W 220V
length 500 mm - width 65 mm
flange 80x28 mm
for Washing machine (ZANUSSI) LC12E



WHIRLPOOL 771985011813

3755272 HEATING ELEMENT 4000W 230V
submersed length 345 mm
width 70 mm
bracket 80x27 mm
for Washing machine (ZANUSSI) LB161 - W160 - W230



WHIRLPOOL 191473

WHIRLPOOL 771985005429

3355557 HEATING ELEMENT 4500W 220V
ø 265 mm
connection ø 14 mm
for Dryer (ZANUSSI) D350E - TT210E - TT600E



WHIRLPOOL 172082

3455265 HEATING ELEMENT 4500W 380V
for DRIER FAGOR SE-7
for DRIER GIRBAU SE7-SDE7
for DRIER PRIMUS DA9-D9
for DRIER WHIRLPOOL SACE8-SWE90-SWE290-SWE390-SWE91-SWE291-SWE391
for Dryer (DANUBE) TD8
for Dryer (FAGOR) SE-7
for Dryer (GIRBAU) SDE7 - SE7
for Dryer (PRIMUS) DA9 - D8 - D9
for Dryer (WHIRLPOOL) SACE8 - SWE290 - SWE291
SWE390 - SWE391 - SWE90 - SWE91



WHIRLPOOL 751101

WHIRLPOOL 771985008875

3455253 HEATING ELEMENT 4600W 240V
for DRIER WHIRLPOOL HELIOS-AWZ481
for Dryer (WHIRLPOOL) AWZ481 - AWZ481E - HELIOS



WHIRLPOOL 481925928864

WHIRLPOOL 561250

WHIRLPOOL 771985011781

3455266 FUSE-HOLDER PROTECTION FOR ELEMENT
for heating element



WHIRLPOOL 481925928861

WHIRLPOOL 561251



Suitable for:

3049122 THERMAL FUSE

for Dryer (WHIRLPOOL) AWZ481E - HELIOS-AWZ481



WHIRLPOOL 481925228095

WHIRLPOOL 561271

WHIRLPOOL 771985011785

WHIRLPOOL



Suitable for:

3355575 HEATING ELEMENT 5000W 220V

length 445 mm - width 65 mm

flange 80x25 mm

for Washing machine (IMESA) LM18 - LM23 - LM30

LM40 - LM55 - LM70 - LM85 - RC18 - RC23 - RC30

RC40 - RC55 - RC70

for Washing machine (WHIRLPOOL) AGB212 - AGB212/WP

AGB218 - AGB218/WP - AGB221 - AGB226 - AGB229

AGB235 - AGB235/WP - AGB241 - AGB241/WP

AGB244 - AGB245 - AGB251 - AGB254 - AGB255



WHIRLPOOL 483286008488

3355874 HEATING ELEMENT 6000W 230V

length 475 mm- width 65 mm

flange 80x28 mm

for Washing machine (GRANDIMPIANTI) WFM40 - WFM55

for Washing machine (POLIMATIC) FS16 - FS23

FS23PRO - FS40 - FS55 - RS27 - RS35 - XS22

for Washing machine (PRIMUS) FS16 - FS23 - FS23PRO

FS40 - FS55 - MB44 - MB66 - RS16 - RS22 - RS27

RS35 - XS22

for Washing machine (WHIRLPOOL) WACS17 - WACS42

WACS46AE - WACS46AV - WACS55 - WACS70

WACS70AE - WACS70AV - WAC17 - WAC23



WHIRLPOOL 750021

WHIRLPOOL 771985008697

3455252 HEATING ELEMENT 7000W 240V

for DRIER PRIMUS D25

for DRIER WHIRLPOOL SWE250-SACE25

for Dryer (PRIMUS) D25

for Dryer (WHIRLPOOL) SACE25 - SWE250



WHIRLPOOL 721029

WHIRLPOOL 771985007761

5041537 HEATING ELEMENT 6000W 220V

length 350 mm - flange 95x65 mm

for DRIER PRIMUS D14-DE14-SWE140

for DRIER WHIRLPOOL AGB204 A 207-SACE5



WHIRLPOOL 751127

WHIRLPOOL 771985008892

3455256 HEATING ELEMENT 7000W 230V

for Dryer (IPSO) DR35

for Dryer (PRIMUS) DA13

for Dryer (WHIRLPOOL) SACE13 - SWE111



WHIRLPOOL 757156

WHIRLPOOL 771985009454

3455255 HEATING ELEMENT 8000W 220V

length 50 mm

flange 95x54 mm

for DRIER PRIMUS DA15

for DRIER WHIRLPOOL SWE151-SACE17

for Dryer (PRIMUS) DA15

for Dryer (WHIRLPOOL) SACE17 - SWE151



WHIRLPOOL 753328

WHIRLPOOL 771985009275

3455261 HEATING ELEMENTS SET 4500 W 380 V

with contactor and klixon
for Dryer (FAGOR) SE-7
for Dryer (GIRBAU) SDE7 - SE7
for Dryer (PRIMUS) DA9 - D9
for Dryer (WHIRLPOOL) SACE8 - SWE290 - SWE291
SWE390 - SWE391 - SWE90 - SWE91



WHIRLPOOL 751100

WHIRLPOOL 771985008874

3355870

HEATING ELEMENT 3000W 230V

length 265 mm - width 65 mm
flange 80x28 mm
for Washing machine (AGA) SUPER25 - SUPER33
for Washing machine (FAGOR) LAC-10 - LC-10
LC/E-10 - LF-10
for Washing machine (GRANDIMPIANTI) WFM11 - WR37
for Washing machine (POLIMATIC) FS10 - FS6 - FS7
P5 - P6 - P65 - P75 - RS10 - RS13 - RS18
RS22 - RS6 - RS7
for Washing machine (PRIMUS) C6 - C8 - FS10 - FS6
FS7 - F6 - F7 - P6 - P7 - RS10 - RS13 - RS16
RS18 - RS22 - RS6 - RS7
for Washing machine (WHIRLPOOL) LSW100 - LWS70
WACS11 - WACS6 - WACS7 - WACS8 - WAC11 - WAC17
WAC23 - WAC8



WHIRLPOOL 750020

WHIRLPOOL 771985008696

Hinges

3053486 COMPLETE HINGE

for round door
for Washing machine (PRIMUS) C6 - C8 - FS10 - FS6
FS7 - F10 - F6 - F8 - P6 - P7
for Washing machine (WHIRLPOOL) FS16 - LWS70
LW100 - RS16 - SR22 - WACS11 - WACS17 - WACS6
WACS7 - WACS8



WHIRLPOOL

3053494

HINGE FLAP



WHIRLPOOL 757427

WHIRLPOOL 771985009501

3053490 COMPLETE HINGE

for corner door
for Washing machine (PRIMUS) C6 - C8 - FS10 - FS16
FS6 - FS7 - F10 - F6 - F8 - P6 - P7 - RS16
SR22
for Washing machine (WHIRLPOOL) LWS70 - LW100
WACS11 - WACS17 - WACS6 - WACS7 - WACS8




WHIRLPOOL 746823

WHIRLPOOL 771985008595

3053494

HINGE FLAP



WHIRLPOOL 757427

WHIRLPOOL 771985009501



Suitable for:

Suitable for:

3053484 COMPLETE TOP HINGE

for dryer door 5 kg
for Dryer (ASKO) TDC44
for Dryer (IMESA) ES5 - ES5EGC - ES5EIC - ES5EIE
RS5EGC
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204 - AGB204/WP - AGB205
AGB205/WP - AGB206 - AGB206/WP - AGB207
AGB207/WP - SACE5



WHIRLPOOL 483286000312

3053491 BEARING FOR HINGE

for Dryer (ASKO) TDC44
for Dryer (IMESA) ES5 - ES5EGC - ES5EGE - ES5EIC
ES5EIE
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204 - AGB204/WP - AGB205
AGB205/WP - AGB206 - AGB206/WP - AGB207
AGB207/WP - SACE5



WHIRLPOOL 483286000321

3053485 COMPLETE BOTTOM HINGE

for dryer door 5 kg
for Dryer (ASKO) TDC44
for Dryer (IMESA) ES5 - ES5EGC - ES5EGE - ES5EIC
ES5EIE
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204 - AGB204/WP - AGB205
AGB205/WP - AGB206 - AGB206/WP - AGB207
AGB207/WP - SACE5



WHIRLPOOL 483286000313

3053546 DOOR HINGE



WHIRLPOOL

3053550 HINGE PIN

ø 5 x length 135 mm



WHIRLPOOL

3053488 FRONT DOOR HINGE

for Washing machine (WHIRLPOOL) AWM9000 - AWM910
AWM910-EU - AWM910-F - AWM9100-B - HYDRA



WHIRLPOOL 481241719178

WHIRLPOOL 561012

WHIRLPOOL 771985012970

3242640 SCREW DIN 7500 - CM 5 x14 for hinge



WHIRLPOOL 481256018068

WHIRLPOOL 561030



WHIRLPOOL



Suitable for:

Suitable for:

3053556 FRONT DOOR HINGE
for Washing machine (IMESA) LM14 - LM18 - LM23
RC14 - RC18 - RC23
for Washing machine (WHIRLPOOL) AGB210 - AGB211
AGB212 - AGB233 - AGB234 - AGB235

3053544 FRONT DOOR HINGE




WHIRLPOOL 583286008281

WHIRLPOOL 483286008352

3053487 HINGE
for Washing machine (PRIMUS) P5
for Washing machine (WHIRLPOOL) LWS51M

3053492 AXIS
for hinge



WHIRLPOOL 746610


WHIRLPOOL 771985008483

WHIRLPOOL 752044

WHIRLPOOL 771985009031

3053545 HINGE FOR DOOR

3053551 HINGE PIN



WHIRLPOOL 481241719244

WHIRLPOOL 750311

WHIRLPOOL 771985008782

3053537 LOWER HINGE



WHIRLPOOL 209353

WHIRLPOOL 771985006173

3053362 4 HOLES DOOR HINGE
for Washing machine (IMESA) LM11 - LM6 - LM8
RC11 - RC6 - RC8
for Washing machine (WHIRLPOOL) AGB208 - AGB209
AGB230 - AGB230/WP - AGB231 - AGB231/WP
AGB232 - AGB232/WP - AGB236/WP - AGB237/WP
AGB238/WP

3053493 HINGE FASTENING DEVICE



WHIRLPOOL 483286002977

WHIRLPOOL 483286008643

WHIRLPOOL 483286008644



Suitable for:

WHIRLPOOL



Suitable for:

Interference suppression filters

3454019 TRAP CAPACITOR 0.47 μ F - 16A- 275V

50/60 Hz
for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC
ES5EIE
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP
AGB206/WP - AGB207/WP - SACE5 - SE5GC - SE5GE
SE5IC - SE5IE
for Washing machine (IMESA) LM5EGDP - LM5EGDV
LM5EIDP - LM5EIDV
for Washing machine (PRIMUS) PW5
for Washing machine (WHIRLPOOL) AGB200/WP
AGB201/WP - AGB202/WP - AGB203/WP - WACS5
WACS5M - WES5GP - WES5GV - WES5IP - WES5IV



WHIRLPOOL 483286009929

WHIRLPOOL 747014

WHIRLPOOL 771985008636

3454020 TRAP CAPACITOR 1 μ F

for Washing machine (WHIRLPOOL) AWM910
AWM9100-EU - AWM9100-F



WHIRLPOOL 481212118142

WHIRLPOOL 771985011561

WHIRLPOOL 481212118285

WHIRLPOOL 561054

Ironmongery (screws,nuts,washers)

3063099 NUT

for bearing



WHIRLPOOL 757174

WHIRLPOOL 771985011580

3063098 WASHER FOR BEARING



WHIRLPOOL 757108

WHIRLPOOL 771985009406

Lamps

3221598 LAMP BUSHING

for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC
ES5EIE
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP
AGB206/WP - AGB207/WP - SACE5 - SE5GC - SE5GE
SE5IC - SE5IE



WHIRLPOOL 483286000282

3221597 LAMP SUPPORT

for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC
ES5EIE
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP
AGB206/WP - AGB207/WP - SACE5 - SE5GC - SE5GE
SE5IC - SE5IE



WHIRLPOOL 483286000281



Suitable for:

WHIRLPOOL



3221596 WHITE INDICATOR LIGHT 220 V - ø 13 mm



WHIRLPOOL 752179

WHIRLPOOL 771985009099

Locks

3388009 BOX LOCK for Dryer (IMESA) ES10 - ES10INV - ES14 - ES14INV ES18 - ES18INV - ES23 - ES34 for Dryer (WHIRLPOOL) AGB257/WP - AGB258/WP AGB259/WP - AGB260/WP - AGB261/WP - AGB262/WP AGB263/WP - AGB264/WP



WHIRLPOOL 483286009608

WHIRLPOOL 483286009719

3242634 COIN CONTAINER LOCK for coin washing machine for Washing machine (IMESA) LM11 - LM14 - LM18 LM23 - LM8 - RC11 - RC14 - RC18 - RC23 - RC8 for Washing machine (WHIRLPOOL) AGB208/WP AGB209/WP - AGB210/WP - AGB211/WP - AGB212/WP AGB214/WP - AGB215/WP - AGB216/WP - AGB217/WP AGB218/WP - AGB222/WP - AGB223/WP - AGB224/WP AGB225/WP - AGB226/WP - AGB230/WP - AGB231/WP AGB232/WP - AGB233/WP - AGB234/WP - AGB235/WP AGB236/WP - AGB237/WP - AGB238/WP - AGB239/WP AGB240/WP - AGB241/WP - AGB247/WP - AGB248/WP AGB249/WP - AGB250/WP - AGB251/WP



WHIRLPOOL 483286008478

Microswitches

3803021 DOOR MAGNETIC CONTACT for product dispenser for Washing machine (PRIMUS) MB16 - MB26 - MB33 MB44 - MB66 for Washing machine (WHIRLPOOL) 016017-WACS28AE 016018-WACS28AV - 016019-WACS35AE 016020-WACS35AV - 016021-WACS46AE 016022-WACS46AV - 016023-WACS70AE 016024-WACS70AV



WHIRLPOOL

3803014 DOOR MICRO CONTACT 5A - 250 V for Dryer (PRIMUS) DA11 - DA17 for Dryer (WHIRLPOOL) 016028-SACE11 016032-SACE17



WHIRLPOOL 757147

WHIRLPOOL 771985009445



Suitable for:

3803016 DOOR MICRO CONTACT

10 A - 250 V
for Dryer (PRIMUS) DA11 - DA13 - DA15
for Dryer (WHIRLPOOL) SACE13 - 016028-SACE11
016032-SACE17




WHIRLPOOL 753314

WHIRLPOOL 771985092363

Suitable for:

3803011 DOOR SAFETY DEVICE

for Washing machine (PRIMUS) P5
for Washing machine (WHIRLPOOL) LWS51



WHIRLPOOL 746601

WHIRLPOOL 771985008474

3803017 DOOR SAFETY DEVICE

for Dryer (WHIRLPOOL) 016074-HELIOS-AWZ481E



WHIRLPOOL 481227138469

WHIRLPOOL 561279

WHIRLPOOL 771985011791

3240749 MAGNETIC MICROSWITCH ES10 1V

250V 0,04A contact NA
cable length 1400 mm
for Dryer (IMESA) ES10 - ES55 - ES75



WHIRLPOOL 483286008369

9014042 RECTANGULAR MAGNET 32x13x8 mm

for Dryer (IMESA) ES55 - ES75



WHIRLPOOL 483286008354

3803010 MICRO SWITCH

15 A - 250 V
for Dryer (WHIRLPOOL) 016074-HELIOS-AWZ481E



WHIRLPOOL 481227138425

WHIRLPOOL 561276

WHIRLPOOL 771985011789

3225012 LEVER

for Dryer (WHIRLPOOL) HELIOS-AWZ481



WHIRLPOOL 481240448899

3803012 MICRO SWITCH

5 A - 250 V
for Dryer (IMESA) ES5ECG - ES5EIC
for Dryer (WHIRLPOOL) AGB205/WP - AGB207/WP
016066-SE5GC - 016066-SE5IC



WHIRLPOOL 483286000357

WHIRLPOOL 771985008861

3803023 FLOAT FOR MICRO SWITCH ø 45 mm

for Dryer (IMESA) ES5ECG - ES5ECI
for Dryer (WHIRLPOOL) AGB205/WP - AGB207/WP
016066-SE5GC - 016066-SE5IC



WHIRLPOOL 483286000355

Suitable for:

3803019 MICRO SWITCH
with fastening and support
for Washing machine (IMESA) LM11 - LM6 - LM8
for Washing machine (WHIRLPOOL) AGB230/WP
AGB231/WP - AGB232/WP - AGB237/WP - AGB238/WP
AGB536/WP



WHIRLPOOL 483286008231

Suitable for:

3803020 MICRO SWITCH
0.1 A - 250 V
for Washing machine (PRIMUS) P6 - P7
for Washing machine (WHIRLPOOL) 016001-WACS6
016071-WACS7



WHIRLPOOL 746803


WHIRLPOOL 771985008577

3803022 MICRO SWITCH SET
for Dryer (PRIMUS) DA13



WHIRLPOOL


3803044 MICROSWITCH



WHIRLPOOL 746703

WHIRLPOOL 771985008554

3803046 MICROSWITCH DOOR 3SE4 300
16(4) A - 380 V



WHIRLPOOL 751061

WHIRLPOOL 771985008852


3240795 MICROSWITCH 10A 250V
for Washing machine (GIRBAU) HS5008 - HS6008
HS6017
for Washing machine (PRIMUS) DAMS9



WHIRLPOOL 757012

WHIRLPOOL 771985009394

3240136 MICROSWITCH 16A 250V
for Washing machine (DOMUS) DFI27 - W10
for Washing machine (FAGOR) LA-10M - LA-13M
LA-18M - LA-25M - LB-10M - LB-13M - LB-18M
for Washing machine (GRANDIMPIANTI) WFEC11
WFEC18 - WFEC6 - WFEC8 - WFP50 - WFP63 - WF11
WF18 - WF23 - WF26 - WF33 - WF8 - WR11 - WR18
WR26 - WR33 - WR8
for Washing machine (IPSO) HC100 - HC135 - HC165
HC60 - HC65 - HC75 - HF110 - HF132 - HF145
HF150 - HF165 - HF176 - HF185 - HF205 - HF235
HF245 - HF304 - HF450 - HF55 - HF570 - HF65
HF75 - HF95 - HW131 - HW164 - HW55 - HW64
HW72 - HW94 - WE110 - WE132 - WE165 - WE176
WE181 - WE234 - WE245 - WE304 - WE55 - WE73
WE95 - WFF100 - WFF135 - WFF150 - WFF165



WHIRLPOOL 483286000283

WHIRLPOOL 747105

WHIRLPOOL 771985008648

3454058 TRAP CONTACT
for DRYER MIELE T5205



WHIRLPOOL 745737

WHIRLPOOL 771985008213

WHIRLPOOL 745801

WHIRLPOOL 771985008175



Suitable for:


WHIRLPOOL



Suitable for:

Motors

3340026 MOTOR AND MOTOR CONTROL BOARD SET
mod. AHV 2-42-P-09 - 0-380
380 HZ / 250V
for Washing machine (PRIMUS) P6 - P7
for Washing machine (WHIRLPOOL) WACS6 - WACS7
WAC17 - WAC8



WHIRLPOOL 746840

WHIRLPOOL 771985010825

3340120 MOTOR BER-MAR ME 15-63/2 KD
220/240V 50/60Hz - capacitor 8 μ F
for Dryer (MIELE) T5205 - T5212
for Dryer (WHIRLPOOL) PT126



WHIRLPOOL 745744

WHIRLPOOL 771985008178

3340119 MOTOR CIM 2/55-132 WHE11
195V 3.7A 800W 290Hz
motor revolutions 17000
for Washing machine (WHIRLPOOL) AWM8000 - AWM8050
AWM8100



WHIRLPOOL 481236158351

3340122 MOTOR JQA48T17D11001AP 1/4HP 60Hz
TS.80.S4.4000 - 0256014
for Dryer (PRIMUS) DA13 - D11
for Dryer (WHIRLPOOL) SWE111 - SWE131



WHIRLPOOL 757101

WHIRLPOOL 771985009399

3340067 MOTOR LM5
for Washing machine (ASKO) WMC55
for Washing machine (IMESA) LM5 - LM5EGDP
LM5EGDV - LM5EIDP - LM5EIDV
for Washing machine (PRIMUS) PW5
for Washing machine (WHIRLPOOL) AGB200 - AGB200/WP
AGB201 - AGB201/WP - AGB202 - AGB202/WP
AGB203 - AGB203/WP - WES5GP - WES5GV - WES5IP
WES5IV



WHIRLPOOL 483286009845

WHIRLPOOL 747001

WHIRLPOOL 771985008623

3340117 MOTOR WEG AL80-04 THREE-PHASE
0.75Kw 230/400V 50Hz 2.97/1.71A
1400 motor revolutions
for Washing machine (PRIMUS) FS6 - FS7
for Washing machine (WHIRLPOOL) WACS8



WHIRLPOOL 757438

WHIRLPOOL 771985009520

3340032 SINGLE-PHASE CONVEYOR MOTOR SC5
220 / 240 V - 50 Hz - 1425 rev./min
for Dryer (GIRBAU) SEI12
for Dryer (PRIMUS) DA11 - DA13 - DA15 - DA17
DA25
for Dryer (WHIRLPOOL) SACG11 - SACG13 - SACG15
SACG17 - SWG111 - SWG131 - SWG151



WHIRLPOOL 757149

WHIRLPOOL 771985009447

3340033 SINGLE-PHASE MOTOR
220 V - 50 Hz - 1425 rev./min
for Dryer (FAGOR) SE-7
for Dryer (GIRBAU) SE7
for Dryer (PRIMUS) DA9 - D9
for Dryer (WHIRLPOOL) SACE8 - SWE290 - SWE291
SWE390 - SWE391 - SWE90 - SWE91




WHIRLPOOL 721067

WHIRLPOOL 771985007782

3340029 SINGLE-PHASE MOTOR VENTILATOR

220/240 V - 8 μ F - 50 Hz
2850 RPM - 1.1 A - 270 W
for Dryer (IMESA) ES5EGC - ES5EIC
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204 - AGB205/WP
AGB207/WP - SE5GC - SE5IC



WHIRLPOOL 48286000344

WHIRLPOOL 747100

WHIRLPOOL 483286000261

WHIRLPOOL 771985008643

WHIRLPOOL 483286000344

3340038 FRONT FAN FOR MOTOR VENTILATOR

$\varnothing$ 115 mm / thickness 53 mm



WHIRLPOOL 483286000341

WHIRLPOOL 747114

WHIRLPOOL 771985008657

3340037 MOTOR VENTILATOR IMPELLER

$\varnothing$ 115 mm - thickness 43 mm



WHIRLPOOL 483286000262

WHIRLPOOL 771985008644

WHIRLPOOL 483286000345

WHIRLPOOL 747101

3340036 MOTOR VENTILATOR REAR CASE



WHIRLPOOL 483286000343

3340027 THREE-PHASE MOTOR

195 V - 5 A - 820 W - 310 Hz - 17500 RPM
for Washing machine (WHIRLPOOL) AWM910
AWM9100-EU - AWM9100-F



WHIRLPOOL 481236158375

WHIRLPOOL 771985011735

WHIRLPOOL 481236158446

WHIRLPOOL 561053

3340028 THREE-PHASE MOTOR HANNING

230/400 V - 50 Hz
for Washing machine (PRIMUS) F10 - RS10
for Washing machine (WHIRLPOOL) LW100 - WAC11



WHIRLPOOL 752111

WHIRLPOOL 771985009070

3340030 THREE-PHASE MOTOR 1.1kW 1.5Hp

230/380V - 1500 motor revolutions
for Washing machine (IMESA) LM6
for Washing machine (WHIRLPOOL) AGB230/WP - AGB231
AGB232 - AGB233 - AGB234 - AGB235 - AGB236/WP



WHIRLPOOL 483286008618

3340023 THREE-PHASE MOTOR 1.5kW 2Hp

230/400V - 1500 motor revolutions - IP54
for Washing machine (IMESA) LM11 - LM8
for Washing machine (WHIRLPOOL) AGB231 - AGB232
AGB237 - AGB238 - AGB247 - AGB248



WHIRLPOOL 483286008663




WHIRLPOOL



Suitable for:

3340034 THREE-PHASE MOTOR 2A 3Hp 250V
for Dryer (WHIRLPOOL) AWZ481E - HELIOS



WHIRLPOOL 481236138027

WHIRLPOOL 561246

3340039 FAN GASKET
for Dryer (WHIRLPOOL) AWZ481 - AWZ481E - HELIOS



WHIRLPOOL 481946818187

WHIRLPOOL 561299

3340041 LID GASKET
for Dryer (WHIRLPOOL) AWZ481 - AWZ481E - HELIOS



WHIRLPOOL 481946818188

WHIRLPOOL 561301

3340035 THREE-PHASE MOTOR 220/380V
HP 0.5 - 0.37 KW - 1400/1700 rev/min
for Dryer (IMESA) ES10 - ES10INV - ES14 - ES14INV
ES18 - ES18INV
for Dryer (WHIRLPOOL) AGB257 - AGB257/WP - AGB258
AGB258/WP - AGB259 - AGB259/WP - AGB260
AGB260/WP - AGB261 - AGB261/WP - AGB262
AGB262/WP - AGB266 - AGB267 - AGB268 - AGB269
AGB270 - AGB271 - AGB275 - AGB276 - AGB277
AGB278 - AGB279 - AGB280



WHIRLPOOL 483286009747

Suitable for:

3340042 FAN
ø 188 mm / thickness 75 mm
for Dryer (WHIRLPOOL) AWZ481 - AWZ481E - HELIOS



WHIRLPOOL 481951528255

WHIRLPOOL 561249

3340040 LID
for propeller
for Dryer (WHIRLPOOL) AWZ481 - AWZ481E - HELIOS



WHIRLPOOL 481946258181

WHIRLPOOL 561281

3049122 THERMAL FUSE
for Dryer (WHIRLPOOL) AWZ481E - HELIOS-AWZ481



WHIRLPOOL 481925228095

WHIRLPOOL 561271

WHIRLPOOL 771985011785

3122712 IMPELLER ø 317 mm
for motor
fastening hole ø 14 mm



WHIRLPOOL 483286009745



Suitable for:

3318014 SPA PULLEY 67x1 WITH HOLE 14 GROOVE 5

for Dryer (IMESA) ES10 - ES10INV - ES14 - ES14INV
ES18 - ES18INV
for Dryer (WHIRLPOOL) AGB257/WP - AGB258/WP
AGB259/WP - AGB260/WP - AGB261/WP - AGB262/WP
AGB266/WP - AGB267/WP - AGB268/WP - AGB269/WP
AGB270/WP - AGB271/WP - AGB275/WP - AGB276/WP
AGB277/WP - AGB278/WP - AGB279/WP - AGB280/WP



WHIRLPOOL 483286009748

WHIRLPOOL




Suitable for:

Outlet solenoid valves and accessories

3120049 DRAIN SOLENOID VALVE MDB-C-55

normally CLOSED - 220/240V 50/60Hz 24AMP
inlet ø 55 mm - outlet ø 60 mm
overflow pipe ø 35 mm
for Washing machine (ZANUSSI) LB8




WHIRLPOOL 146432

WHIRLPOOL 771985001245

3120179 DRAIN SOLENOID VALVE MDB-C-55

normally CLOSED - 220/240V 50/60Hz 24AMP
inlet ø 55 mm - outlet ø 60 mm
for Washing machine (ZANUSSI) LB120 - LB160 - LB70
LB80



WHIRLPOOL 047064

WHIRLPOOL 771985001473

3120050 DRAIN SOLENOID VALVE MDB-0-2

normally OPEN - 220/240V 50/60Hz 24AMP
inlet ø 50 mm - outlet ø 50 mm
overflow pipe ø 35 mm
for Washing machine (AGA) 520/16 - 735/50
for Washing machine (DOMUS) DFI13 - DFI18 - DFI9
W10 - W13 - W18 - W9
for Washing machine (FAGOR) LA-10M - LA-13M
LA-18M - LAC-10 - LAC-14 - LAC-7 - LB-10M
LB-13M - LB-18M - LC-10 - LC-13 - LC-14
LC-18 - LC-7 - LC-8 - LF-10 - LF-13 - LF-14
LF-18 - LF-7 - LF-8
for Washing machine (IMESA) LM11 - LM14 - LM18
LM23 - LM6 - LM8 - RC11 - RC14 - RC18 - RC23
RC8 - R18
for Washing machine (WHIRLPOOL) AGB208/WP



WHIRLPOOL 483286008384

3120144 DRAIN SOLENOID VALVE MDB-0-3

normally OPEN - 220/240V 50/60Hz 18AMP
inlet ø 75 mm - outlet ø 80 mm
overflow pipe ø 35 mm
for Washing machine (GIRBAU) HS4022 - LS320
for Washing machine (GRANDIMPIANTI) WFP50 - WFP63
WF23 - WF26 - WF33 - WR26 - WR33
for Washing machine (IMESA) LM30 - LM40 - LM55
LM70 - LM85 - RC30 - RC40 - RC55 - RC70
for Washing machine (IPSO) HF145 - HF176 - HF205
HF234 - HF245 - HF304 - HF450 - HF455 - HF570
HF575 - HF730 - HF900 - WE110 - WE132 - WE165
WE176 - WE234 - WE245 - WE304 - WE55 - WE73
WE95



WHIRLPOOL 483286001251




Suitable for:

WHIRLPOOL



Suitable for:

3120180 DRAIN SOLENOID VALVE MDB-0-55
normally OPEN - 220/240V 50/60Hz 24AMP
inlet ø 55 mm - outlet ø 60 mm
for Washing machine (ZANUSSI) CLB160 - LB110
LB120 - LB160 - LB70 - LB80



WHIRLPOOL 147346

WHIRLPOOL 771985001589

3120146 DRAIN SOLENOID VALVE MDB-0-3RA
normally OPEN - 230V 50/60Hz 18AMP
inlet ø 76 mm - outlet ø 78 mm
for Washing machine (GRANDIMPIANTI) WFM11 - WFM18
WFM22 - WFM33 - WFM40 - WFM55 - WFM8 - WF11
WF18 - WF8
for Washing machine (POLIMATIC) FS10 - FS23
FS23PRO - FS33 - FS40 - FS55 - FS6 - FS7
RS10 - RS13 - RS18 - RS22 - RS27 - RS35 - RS6
RS7 - XS22
for Washing machine (PRIMUS) FS10 - FS23 - FS23PRO
FS33 - FS40 - FS55 - FS6 - FS7 - RS10 - RS13
RS18 - RS22 - RS27 - RS35 - RS6 - RS7 - XS22
for Washing machine (WHIRLPOOL) 016002-WACS11
016004-WACS17



WHIRLPOOL 751024

WHIRLPOOL 771985008827

3120185 SOLENOID VALVE PNEUMATIC ø 86-76 mm
inlet ø 86 mm
outlet ø 76 mm
overflow pipe ø 44 mm
coil 220/240V 50/60Hz
for Washing machine (ZANUSSI) LB121E - LB81E
W100 - W75



WHIRLPOOL 191350

WHIRLPOOL 771985005406

3120063 3-WAY SOLENOID VALVE 230V 50Hz
for Washing machine (ZANUSSI) WB3130H - WE106
WE365H - WE375H - WE66 - W3105H - W3130H



WHIRLPOOL 771985006245

Piezo ignitors

3806010 CONNECTING CABLE FOR PLUG
length 450 mm



WHIRLPOOL 483286009802

Pins

3324035 LEFT SHAFT
for Dryer (WHIRLPOOL) HELIOS



WHIRLPOOL 481253598088

3324034 RIGHT SHAFT
for Dryer (WHIRLPOOL) HELIOS



WHIRLPOOL 481953598594

Portholes

5027105 COMPLETE WASHING MACHINE DOOR

external ø 350 mm
for Washing machine (IMESA) LM5




WHIRLPOOL 483286009874

Pressure switches

3320198 PRESS.SWITCH - 2 LEVELS - 55/35 - 80/60

for Washing machine (WHIRLPOOL) AWM9100-EU
AWM9100-F



WHIRLPOOL 481227128521

WHIRLPOOL 561051

WHIRLPOOL 771985011487

3320218

PRESSOSTAT 230V 16(4)A

3 levels: 70/25 - 100/50 - 140/90



WHIRLPOOL 746638

WHIRLPOOL 771985008511

3320220 PRESSOSTAT 230V 16A

3 levels: 150/70 - 185/80 - 200/90



WHIRLPOOL 752114

WHIRLPOOL 771985009073

3320219

PRESSOSTAT 250V 16A

3 levels: 150/80 - 240/100 - 285/160



WHIRLPOOL 752114

WHIRLPOOL 771985009074

3320221 PRESSOSTAT 55-35-280

for Washing machine (WHIRLPOOL) AWM1000




WHIRLPOOL 481227128582

3320216

PRESSURE SWITCH

for Washing machine (ZANUSSI) LB161



WHIRLPOOL 191428

WHIRLPOOL 771985013200

5045977 PRESSURE SWITCH 45/20 - 160/105 mm

for Washing machine (MIELE) W6073AV
for Washing machine (WHIRLPOOL) PW75



WHIRLPOOL

3320068

PRESSURE SWITCH 150/70-175/95 mm

2 levels
16(4)A-250V
for Washing machine (IMESA)
till 31/12/02
Series LM - Series RC



WHIRLPOOL



Suitable for:

3320159 PRESSURE SWITCH 34/20 mm 1,5A 250V
for Dryer (IMESA) ES10 - ES10INV - ES14 - ES14INV
ES18 - ES18INV - ES23 - ES34 - ES55 - ES75
for Dryer (WHIRLPOOL) AGB257/WP - AGB258/WP
AGB259/WP - AGB260/WP - AGB261/WP - AGB262/WP
AGB263/WP - AGB264/WP - AGB265/WP



WHIRLPOOL 483286009681


Suitable for:

3320156 PRESSURE SWITCH 40/15 mm 16A 250V
for Washing machine (ZANUSSI) W365H - W375H




WHIRLPOOL

3320158 PRESSURE SWITCH 87/35-310/265
for Washing machine (ASKO) WMC55 - WMP55
for Washing machine (GRANDIMPIANTI) WFEC5
for Washing machine (IMESA) LM5EGDP - LM5EGDV
LM5EIDP - LM5EIDV
for Washing machine (PRIMUS) PW5
for Washing machine (WHIRLPOOL) AGB200/WP
AGB201/WP - AGB202/WP - AGB203/WP



WHIRLPOOL 483286009921

3320209 SAFETY PRESSURE SWITCH
for Washing machine (ASKO) WMC55 - WMP55
for Washing machine (GRANDIMPIANTI) WFEC5
for Washing machine (IMESA) LM5EGDP - LM5EGDV
LM5EIDP - LM5EIDV
for Washing machine (PRIMUS) PW5
for Washing machine (WHIRLPOOL) AGB200/WP
AGB201/WP - AGB202/WP - AGB203/WP



WHIRLPOOL 483286009919

WHIRLPOOL 747012

WHIRLPOOL 771985008634

Probes

3397180 CTN PROBE
ø 10 x overall length 49 mm



WHIRLPOOL 481228219485

3455269 CTN PROBE FOR HEATING ELEMENT
for Washing machine (WHIRLPOOL) AWM9100-EU
AWM9100-F



WHIRLPOOL 481225928692

WHIRLPOOL 481225928863

WHIRLPOOL 561079

3397169 HUMIDITY PROBE
cable length 1250 mm
for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC
ES5EIE
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP
AGB206/WP - AGB207/WP - SACE5 - SE5GC - SE5GE
SE5IC - SE5IE



WHIRLPOOL 483286000267

WHIRLPOOL 747102

WHIRLPOOL 771985008645

3397170 PROBE
cable length 1340 mm
for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC
ES5EIE
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP
AGB206/WP - AGB207/WP - SACE5 - SE5GC - SE5GE
SE5IC - SE5IE



WHIRLPOOL 483286000273

WHIRLPOOL 747135

3445253 PROBE PT1000

cable length 3000 mm - bulb $\varnothing$ 6x40 mm
for Washing machine (IMESA) LM11 - LM14 - LM18
LM23 - LM30 - LM40 - LM55 - LM6 - LM70 - LM8
LM85 - RC11 - RC14 - RC18 - RC23 - RC30 - RC40
RC55 - RC6 - RC70 - RC8
for Washing machine (WHIRLPOOL) AGB208/WP
AGB209/WP - AGB210/WP - AGB211/WP - AGB212/WP
AGB214/WP - AGB215/WP - AGB216/WP - AGB217/WP
AGB218/WP - AGB230/WP - AGB231/WP - AGB232/WP
AGB233/WP - AGB234/WP - AGB235/WP - AGB236/WP
AGB237/WP - AGB238/WP - AGB239/WP - AGB240/WP
AGB241/WP



WHIRLPOOL 483286008279

3445255 TANK TEMPERATURE PROBE

cable length 2000 mm - bulb $\varnothing$ 6x60 mm
for Washing machine (POLIMATIC) P65 - P75
for Washing machine (PRIMUS) FS10 - FS16 - FS7
MB26 - MB33 - MB44 - MB66 - P6 - P7 - RS10
RS16 - RS22 - RS7
for Washing machine (WHIRLPOOL) WACS11 - WACS17
WACS28AE - WACS28AV - WACS35AE - WACS35AV
WACS46AE - WACS46AV - WACS6 - WACS7 - WACS70AE
WACS70AV - WACS8 - WAC11 - WAC17 - WAC23
WAC8




WHIRLPOOL 746821

WHIRLPOOL 757409

WHIRLPOOL 771985009483

3744040 NUT M14

for Washing machine (PRIMUS) C6 - C8 - FS10 - FS16
FS6 - FS7 - MB16 - MB22 - MB33 - MB44 - MB66
P6 - P7 - RS16 - RS22 - RS6 - RS7
for Washing machine (WHIRLPOOL) LW100 - LW70
WACS11 - WACS16E - WACS17 - WACS28A - WACS35A
WACS46A - WACS6 - WACS7 - WACS70A - WACS8
WAC11 - WAC17 - WAC23 - WAC8



WHIRLPOOL 757456

WHIRLPOOL 7719850085009528

WHIRLPOOL 771985009528

3744039 STUFFING GLAND $\varnothing$ 6 mm

for probe
for Washing machine (PRIMUS) FS10 - FS16 - FS7
MB26 - MB33 - MB44 - MB66 - P6 - P7 - RS10
RS16 - RS22 - RS7
for Washing machine (WHIRLPOOL) WACS11 - WACS17
WACS28AE - WACS28AV - WACS35AE - WACS35AV
WACS46AE - WACS46AV - WACS6 - WACS7 - WACS70AE
WACS70AV - WACS8 - WAC11 - WAC17 - WAC23
WAC8



WHIRLPOOL 746822

WHIRLPOOL 7719850085008594

WHIRLPOOL 771985008594



Suitable for:

WHIRLPOOL



3397172 TEMPERATURE PROBE
cable length 1500 mm - 2 wires



WHIRLPOOL 482386009503

Suitable for:


3445252 TEMPERATURE PROBE KTY84
cable length 3000 mm - bulb $\varnothing$ 6x40 mm
for Dryer (IMESA) ES10 - ES14 - ES18 - ES23 - ES34
ES55 - ES75
for Dryer (WHIRLPOOL) AGB257 - AGB258 - AGB259
AGB260 - AGB261 - AGB262 - AGB263 - AGB264
AGB266 - AGB267 - AGB268 - AGB269 - AGB270
AGB271 - AGB272 - AGB275 - AGB276 - AGB277
AGB278 - AGB279 - AGB280 - AGB281 - AGB282
for Washing machine (IMESA) LM11 - LM14 - LM18
LM23 - LM30 - LM40 - LM55 - LM6 - LM70 - LM8
LM85 - RC11 - RC14 - RC18 - RC23 - RC30 - RC40
RC55 - RC6 - RC70 - RC8
for Washing machine (WHIRLPOOL) AGB209 - AGB210
AGB211 - AGB213 - AGB214 - AGB215 - AGB216
AGB217 - AGB218 - AGB219 - AGB220 - AGB221



WHIRLPOOL 483286000721

WHIRLPOOL 483286009741

3397171 THERMISTOR FOR TEMPERATURE PROBE
for Dryer (PRIMUS) DA11 - DA13 - DA15 - DA9
for Dryer (WHIRLPOOL) SACE11 - SACE13 - SACE17
SACE8 - SWE111 - SWE131 - SWE151



WHIRLPOOL 753321

WHIRLPOOL 771985009269

Pulleys

3318010 BELT PULLEY
for Dryer (PRIMUS) DAM/S9 - DA9 - D9
for Dryer (WHIRLPOOL) SACE8 - SACE8C - SACE8T



WHIRLPOOL 722050

WHIRLPOOL 771985007874

3062075 AXIS
for pulley



WHIRLPOOL 722031

WHIRLPOOL 771985007858



Suitable for:

3062084 CLAMP



WHIRLPOOL 751175

WHIRLPOOL 771985008913

WHIRLPOOL



Suitable for:

3062082

WASHER

for Dryer (DANUBE) DD8
for Dryer (FAGOR) SE/7
for Dryer (GIRBAU) SDE7
for Dryer (IPSO) DD8
for Dryer (PRIMUS) DAM/S9 - DA9 - D9
for Dryer (WHIRLPOOL) SACE8 - SACE8T - SACE86
SWE290 - SWE390 - SWE90 - SW291 - SW391 - SW91



WHIRLPOOL 751173

WHIRLPOOL 771985008911

3391060 COMPLETE SUPPORT WITH PULLEY



WHIRLPOOL 481940479189

3318025 DOUBLE PULLEY ø 380 mm

for Washing machine (PRIMUS) F10 - F6 - F7
for Washing machine (WHIRLPOOL) LWS100 - LWS70



WHIRLPOOL 752119

WHIRLPOOL 771985009078

3318026 PULLEY



WHIRLPOOL 481252858037

3318012 PULLEY ø 297 mm

for washing machine drum
for Washing machine (GRANDIMPIANTI) WFM6
for Washing machine (PRIMUS) C6 - C8 - P6 - P7
RS10 - RS6 - RS7
for Washing machine (WHIRLPOOL) WACS6 - WACS7
WAC11 - WAC8



WHIRLPOOL 746818

WHIRLPOOL 771985008591

3318027 TENSOR FOR PULLEY



WHIRLPOOL 481235818055



Suitable for:

WHIRLPOOL



Suitable for:

Pumps

3122705 DRAIN PUMP
220-240Vac - 50 HZ - 0.35 A
for Washing machine (WHIRLPOOL) AWM9100-F




WHIRLPOOL 481236018533
WHIRLPOOL 771985011680

WHIRLPOOL 481236018572

WHIRLPOOL 561055

3122711 GASKET FOR PUMP
for Washing machine (WHIRLPOOL) AWM9000
AWM9000-F - AWM910 - AWM9100-EU - AWM9100-F



WHIRLPOOL 481246688707

WHIRLPOOL 561111

3160422 PUMP FILTER
for Washing machine (WHIRLPOOL) AWM9000
AWM9000-F - AWM910 - AWM9100-EU - AWM9100-F



WHIRLPOOL 481248058317

WHIRLPOOL 561110

WHIRLPOOL 771985011750

3122709 RUBBER PIECE
for pump
for Washing machine (WHIRLPOOL) AWM9100-F



WHIRLPOOL 481246688758

WHIRLPOOL 561057

WHIRLPOOL 771985011737

3122710 RUBBER PIECE
for pump
for Washing machine (WHIRLPOOL) AWM9000
AWM9000-F - AWM910 - AWM9100 - AWM9100-F



WHIRLPOOL 481246688757

WHIRLPOOL 561056

WHIRLPOOL 771985011736

3122706 DRAIN PUMP
M73.2 - 220-240Vac - 50 HZ - 0.35A - 45 W
for Washing machine (WHIRLPOOL) AWM9100-F



WHIRLPOOL 481236018563

3160422 PUMP FILTER
for Washing machine (WHIRLPOOL) AWM9000
AWM9000-F - AWM910 - AWM9100-EU - AWM9100-F




WHIRLPOOL 481248058317

WHIRLPOOL 561110

WHIRLPOOL 771985011750

3122711 GASKET FOR PUMP
for Washing machine (WHIRLPOOL) AWM9000
AWM9000-F - AWM910 - AWM9100-EU - AWM9100-F



WHIRLPOOL 481246688707

WHIRLPOOL 561111



Suitable for:

WHIRLPOOL




3122778 DRAIN PUMP ASKOLL M150
220/240V 50Hz 45W 0,35A



WHIRLPOOL 481236018565

3122472 DRAIN PUMP DE30B4-026 220V
220V 50Hz 95W
for Washing machine (MIELE) PW50 - PW60
for Washing machine (WHIRLPOOL) WS5405 - WS5406



WHIRLPOOL 745184

3122707 FILTER CASE WITH GASKET
for Washing machine (MIELE) PW50 - PW60
for Washing machine (WHIRLPOOL) WS5405 - WS5406



WHIRLPOOL 745175

WHIRLPOOL 771985007940

3160434 FILTER WITH GASKET



WHIRLPOOL 745176

WHIRLPOOL 771985007941

3786408 GASKET FOR FILTER CASE



WHIRLPOOL 745177

WHIRLPOOL 771985007942


3160435 FILTER CAP



WHIRLPOOL 745180

WHIRLPOOL 771985007945

3122708 FILTER INTERNAL CARTER
with gasket



WHIRLPOOL 745178

WHIRLPOOL 771985007943


3786409 GASKET FOR FILTER



WHIRLPOOL 745179

WHIRLPOOL 771985007944

3786410 PUMP GASKET



WHIRLPOOL 745183


WHIRLPOOL 771985007947



Suitable for:

Suitable for:

3122703 DRAIN PUMP HANNING BE 30 B5 - 024
230-240 V - 50 HZ - 95 W
for Washing machine (MIELE) PW51 - PW61
for Washing machine (WHIRLPOOL) WS5425 - WS5426



WHIRLPOOL 745921

WHIRLPOOL 771985008297

3160416 FILTER CASE WITH TUBE
for Washing machine (MIELE) PW51 - PW61
for Washing machine (WHIRLPOOL) WS5425 - WS5426



WHIRLPOOL 746481

WHIRLPOOL 771985008442


3160417 FILTER INTERNAL CARTER



WHIRLPOOL 746489

WHIRLPOOL 771985008444

3160420 SPRING
for filter carter external cap



WHIRLPOOL 746487

WHIRLPOOL 771985012001

3122704 DRAIN PUMP HANNING DPS25-047
30 W - 220 V - 50 Hz
for Washing machine (IMESA) LM5EGDP - LM5EIDP
PLM6
for Washing machine (PRIMUS) PW5
for Washing machine (WHIRLPOOL) AGB200/WP
AGB202/WP - WACS5 - WACS5M - WES5GP - WES5IP



WHIRLPOOL 483286009857

WHIRLPOOL 747003

WHIRLPOOL 771985008625

3160421 FILTER CASE COVER
for Washing machine (MIELE) PW51 - PW61 - W840
for Washing machine (WHIRLPOOL) WS5424 - WS5426



WHIRLPOOL 746486


WHIRLPOOL 771985008443

3160419 FILTER EXTERNAL CASE



WHIRLPOOL 746488

3160418 PUMP FILTER



WHIRLPOOL 746485

3122779 DRAIN PUMP MOD. 68856
34W - 220/240V - 50Hz - 0,3A
for Washing machine (WHIRLPOOL) AWM256 - AWM276
AWM287 - AWM410 - AWM4610 - AWM5010 - FL1019
FL1057 - FL1117 - FL1219 - FL1250 - FL1266
FL1348 - FL1362 - FL1419 - FL1448 - FL1462
FL8135 - FL856 - FL885 - FL9060 - FL956
MAGIC21200 - WAK7773



WHIRLPOOL 481231028144



Suitable for:

WHIRLPOOL



Suitable for:

3122780 OUTLET ELECTROPUMP ASKOLL M150
220/240V 50Hz 45W 0,35A



WHIRLPOOL 481236018548

WHIRLPOOL 481236018597

Rating-plates

3786411 BLACK PVC PANEL
for Dryer (ASKO) TDC44 - TD33
for Dryer (IMESA) ES5
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204 - AGB205 - AGB206
AGB207 - SACE5
for Washing machine (ASKO) WMC55 - WMP55
for Washing machine (IMESA) LM5
for Washing machine (PRIMUS) PW5
for Washing machine (WHIRLPOOL) AGB200 - AGB201
AGB202 - AGB203



WHIRLPOOL 483286000301

WHIRLPOOL 747018

WHIRLPOOL 771985008640

3028019 FRONT PANEL COMPLETE



WHIRLPOOL 481245214056

3242654 KNOB
for Dryer (WHIRLPOOL) AWZ481 - AWZ481E - HELIOS



WHIRLPOOL 481241238012

WHIRLPOOL 561243

3242653 KNOB
for Dryer (WHIRLPOOL) HELIOS AWZ481E




WHIRLPOOL 481241238011

WHIRLPOOL 561244

WHIRLPOOL 771985012312

3242655 PROGRAMMER KNOB
for Dryer (WHIRLPOOL) HELIOS AWZ481E



WHIRLPOOL 481241248035

WHIRLPOOL 561242



Suitable for:

3319643 UNIT DISPLAY KEYBOARD

for Dryer (ASKO) TDC44
for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC
ES5EIE
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP
AGB206/WP - AGB207/WP - SACE5 - SE5GC - SE5GE
SE5IC - SE5IE
for Washing machine (ASKO) WMC55
for Washing machine (IMESA) LM5
for Washing machine (PRIMUS) PW5
for Washing machine (WHIRLPOOL) AGB200/WP
AGB201/WP - AGB202/WP - AGB203/WP



WHIRLPOOL 48328600303

Suitable for:

3322329 UNIT DISPLAY KEYBOARD

for Dryer (ASKO) - Series ES5 - TDC44
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP
AGB206/WP - AGB207/WP
for Washing machine (ASKO) WMC55
for Washing machine (IMESA) LM5EGDP - LM5EGDV
LM5EIDP - LM5EIDV
for Washing machine (PRIMUS) PW5
for Washing machine (WHIRLPOOL) AGB200/WP
AGB201/WP - AGB202/WP - AGB203/WP - WES5GP
WES5GV - WES5IP - WES5IV



WHIRLPOOL 483286009904

WHIRLPOOL 747150

Relays

3351055 RELAY LY2F

for Dryer (PRIMUS) DA11 - DA13 - DA17
for Dryer (WHIRLPOOL) SACE11 - SACE13 - SACE17




WHIRLPOOL 751514

WHIRLPOOL 771985008950

Reversing switches

3210023 REVERSING SWITCH PR1840

for Washing machine (PRIMUS) F10 - F6 - F7 - RS10
RS16 - RS22 - RS7
for Washing machine (WHIRLPOOL) WAC11 - WAC17
WAC23 - WAC8



WHIRLPOOL 751025

WHIRLPOOL 771985008828

Rings

5038658 BOTTOM LID CLOSING RING

for Washing machine (IMESA) RC14 EVOLUTION
RC18 EVOLUTION - RC23 EVOLUTION
for Washing machine (WHIRLPOOL) AGB240



WHIRLPOOL

Rinse aid containers and accessories

3066035 DETERGENT TANK

for Washing machine (IMESA) LM5EGDP - LM5EGDV
LM5EIDP - LM5EIDV
for Washing machine (PRIMUS) PW5
for Washing machine (WHIRLPOOL) AGB200/WP
AGB201/WP - AGB202/WP - AGB203/WP - WES5GP
WES5GV - WES5IP - WES5IV



WHIRLPOOL 483286009911

WHIRLPOOL 747019

WHIRLPOOL 771985008641

3449274 SLEEVE

for detergent dispenser
for Washing machine (IMESA) LM5EGDP - LM5EGDV
LM5EIDP - LM5EIDV
for Washing machine (WHIRLPOOL) AGB200/WP
AGB201/WP - AGB202/WP - AGB203/WP - WES5GP
WES5GV - WES5IP - WES5IV



WHIRLPOOL 483286009912

WHIRLPOOL 747151

3066044 DETERGENT TANK



WHIRLPOOL 483286009899


3066046 EXTERNAL TANK



WHIRLPOOL 752673

3066030 PRODUCT TANK

for Washing machine (WHIRLPOOL) AWM9100



WHIRLPOOL 481241868279

WHIRLPOOL 561094

WHIRLPOOL 771985012230

3449281 PIPE

between the tank and the volumetric meter
for Washing machine (WHIRLPOOL) AWM9100EU
AWM9100F - HYDRA



WHIRLPOOL 481253029276

3501239 PRODUCT DISPENSER NOZZLE

for Washing machine (WHIRLPOOL) AWM9100-F



WHIRLPOOL 481252648161

3501240 PRODUCT DISPENSER NOZZLE

for Washing machine (WHIRLPOOL) AWM9100-EU
AWM9100-F



WHIRLPOOL 481252648035

3786442 SEALING GASKET

for Washing machine (WHIRLPOOL) AWM910 - AWM9100
AWM9100EU - AWM9100F - HYDRA



WHIRLPOOL 481253058164

3449275 SLEEVE ELBOW

for product dispenser
for Washing machine (WHIRLPOOL) AWM910 - AWM9100
AWM9100EU - AWM9100F - HYDRA



WHIRLPOOL 481253048626

WHIRLPOOL 561093



Suitable for:

3066033

TANK DRAWER

for Washing machine (WHIRLPOOL) AWM9100



WHIRLPOOL 481241889012

WHIRLPOOL 561095

WHIRLPOOL 771985011747

WHIRLPOOL




Suitable for:

3066032

PRODUCT TANK

for Washing machine (PRIMUS) P6 - P7

for Washing machine (WHIRLPOOL) 016001-WACS6
016071-WACS7



WHIRLPOOL 752034

WHIRLPOOL 771985009023

3242623

CONTAINER HANDLE

for Washing machine (GRANDIMPIANTI) WFM11 - WFM6
WFM8

for Washing machine (PRIMUS) F5 - P5 - P6 - P7
for Washing machine (WHIRLPOOL) LWS50 - LWS51M
WACS6 - WACS7



WHIRLPOOL 746839


WHIRLPOOL 771985010612

3066038

CONTAINER PLATE

for Washing machine (PRIMUS) P6 - P7

for Washing machine (WHIRLPOOL) 016001-WACS6
016071-WACS7



WHIRLPOOL 746837

WHIRLPOOL 771985010610

3066039

CONTAINER SUPPORT PLATE

for Washing machine (PRIMUS) P6 - P7

for Washing machine (WHIRLPOOL) 016001-WACS6
016071-WACS7



WHIRLPOOL 746838

WHIRLPOOL 771985010611

3353002

SLEEVE

for product dispenser

for Washing machine (GRANDIMPIANTI) WFM6

for Washing machine (PRIMUS) F5 - P5 - P6 - P7

for Washing machine (WHIRLPOOL) LWS50 - LWS51M
016001-WACS6 - 016071-WACS7



WHIRLPOOL 752019

WHIRLPOOL 771985000008



Suitable for:

WHIRLPOOL



Suitable for:

Rotary switches

3057285 ALARM BELL SWITCH - 2 POSITIONS

Mod. 8316076 - 10A - 250 V
for Dryer (WHIRLPOOL) AWZ481E - HELIOS-AWZ481E




WHIRLPOOL 481227618454

WHIRLPOOL 771985011787

3242654

KNOB

for Dryer (WHIRLPOOL) AWZ481 - AWZ481E - HELIOS




WHIRLPOOL 481241238012

WHIRLPOOL 561243

3057284 MANUAL STOP SELECTOR SWITCH MOD.8562100

230 VAC-50/60 Hz-5A
for Dryer (WHIRLPOOL) AWZ481E - HELIOS-AWZ481E



WHIRLPOOL 481227618455

WHIRLPOOL 481227618483

WHIRLPOOL 561275

WHIRLPOOL 771985011788

3057310

POTENTIOMETER 120/240V

50/60 Hz - 2.5W



WHIRLPOOL 753309

WHIRLPOOL 771985009259

3057309 TEMPERATURE SELECTOR SWITCH

25A 240V




WHIRLPOOL 751113

WHIRLPOOL 771985008882

3057286 TEMPERATURE SELECTOR SWITCH 3 POSITIONS

Mod. 3399642-1A-125/250Vac-50/60 Hz
for Dryer (WHIRLPOOL) AWZ481E - HELIOS-AWZ481E



WHIRLPOOL 481227618372

WHIRLPOOL 561273

WHIRLPOOL 771985011786

3242653

KNOB

for Dryer (WHIRLPOOL) HELIOS AWZ481E



WHIRLPOOL 481241238011

WHIRLPOOL 561244

WHIRLPOOL 771985012312



Suitable for:

WHIRLPOOL



Suitable for:

3057287 VIBRATION SELECTOR SWITCH MOD. 63.731

5A-250V
for Washing machine (GIRBAU) AS26 - AS33 - AS44
AS66 - WFM33 - WFM40 - WFM55
for Washing machine (PRIMUS) MB16 - MB26 - MB33
MB44 - MB66
for Washing machine (WHIRLPOOL) WACS16AE - WACS28
WACS28AE - WACS28AV - WACS35 - WACS35AE
WACS35AV - WACS46 - WACS46AE - WACS46AV
WACS70 - WACS70AE - WACS70AV



WHIRLPOOL 752122

WHIRLPOOL 771985009081

Shock absorbers

3007023 COMPLETE SHOCK ABSORBER TYPE 006

for Washing machine (GRANDIMPIANTI) WFM11 - WFM18
for Washing machine (PRIMUS) FS10 - FS16 - FS7
for Washing machine (WHIRLPOOL) WACS11 - WACS17
WACS8



WHIRLPOOL 757466

WHIRLPOOL 771985010465

3007025 RUBBER RING FOR SHOCK ABSORBER for shock absorber



WHIRLPOOL 757528

WHIRLPOOL 771985012708

3007038 SPRING FOR SHOCK ABSORBER for 6-7 Kg yellow ø external 38-49 mm - ø internal 28-38 mm length 138 mm - ø thread 5 mm



WHIRLPOOL 757406

WHIRLPOOL 771985009480

3007026 RING FOR SHOCK ABSORBER for shock absorber



WHIRLPOOL 757529

WHIRLPOOL 771985012710

3007027 SHOCK ABSORBER SPRING length 135 mm - ø 38-27 mm



WHIRLPOOL 753342

WHIRLPOOL 771985008802

3007030 WASHER ø 35 mm



WHIRLPOOL 752801

WHIRLPOOL 771985010934

Suitable for:

3007005 COMPLETE SUSPA SHOCK ABSORBER

for Washing machine (IMESA) LM11 - LM14 - LM18
LM23 - LM6 - LM8
for Washing machine (WHIRLPOOL) AGB231 - AGB232
AGB236 - AGB237 - AGB238 - AGB239 - AGB240
AGB241 - AGB247 - AGB248 - AGB249 - AGB250
AGB251



WHIRLPOOL 483286008381

Suitable for:

3007029 SHOCK ABSORBER SPRING

ø 48 - length 130 mm



WHIRLPOOL 483286008405

3007020 SHOCK ABSORBER

for washing machine
length 260 mm
for Washing machine (WHIRLPOOL) AWM1000 - AWM1001
AWM1008 - AWM8900 - AWM9000 - AWM910 - AWM9100
AWM9100EU - AWM9100F - HYDRA



WHIRLPOOL 481246648095

WHIRLPOOL 561016

WHIRLPOOL 771985011698

3007028 NUT A M8



WHIRLPOOL 481250218399

3007034 SHOCK ABSORBER 2210.200.36

holes ø 10 mm
max extent 190 mm
total length 210 mm



WHIRLPOOL 483286009521

3007035 SHOCK ABSORBER R1064 B10C08

overall length 395 mm



WHIRLPOOL 756317

WHIRLPOOL 771985009348

3007013 SHOCK ABSORBER SPRING TYP006

overall length 355 mm
for Washing machine (DANUBE) GF10 - GF15 - GF6
GF8 - HF65 - HF76 - HF95
for Washing machine (GRANDIMPIANTI) WFEC11
WFEC18 - WFEC8 - WFM11 - WFM18
for Washing machine (IPSO) HC100 - HC135 - HC165
HC60 - HC65 - HC75 - HF110 - HF132 - HF165
HM165 - HW131 - HW164 - HW55 - HW64 - HW72
HW75 - HW94
for Washing machine (PRIMUS) FS10 - FS16 - FS7
for Washing machine (WHIRLPOOL) WACS11 - WACS17
WACS8



WHIRLPOOL 752795

WHIRLPOOL 771985009172

3007010 SHOCK ABSORBER TYP 012 140N

for Washing machine (DANUBE) GF10 - GF15 - GF18
GF8
for Washing machine (GRANDIMPIANTI) WFEC11
WFEC18 - WFEC8 - WFM11 - WFM18 - WFM6 - WFM6S
for Washing machine (IPSO) HF150 - HF185 - HW131
HW164 - HW64 - HW72 - HW75 - HW94
for Washing machine (PRIMUS) FS10 - FS7 - P6 - P7
for Washing machine (WHIRLPOOL) WACS11 - WACS6
WACS7 - WACS8



WHIRLPOOL 172379

WHIRLPOOL 752123

WHIRLPOOL 771985009082



Suitable for:

WHIRLPOOL



5050500 SHOCK ABSORBER TYPE 012 250N
distance between holes 183 mm closed
for Washing machine (FAGOR) LA-25M



Suitable for:

3007009 SHOCK ABSORBER 01230005 80/80N 34/08
for Washing machine (DANUBE) GF11 - GF8
for Washing machine (GRANDIMPIANTI) WFEC11 - WFEC8
for Washing machine (IMESA) LM11 - LM6 - LM8
for Washing machine (IPSO) HF55 - HF65 - HF76
HF95
for Washing machine (WHIRLPOOL) AGB231 - AGB232
AGB237 - AGB238 - AGB247 - AGB248



WHIRLPOOL

WHIRLPOOL 483286008662

Sleeves

3248082 DETERGENT HOSE 220 mm
inlet and outlet internal $\varnothing$ 80 mm
for Washing machine (IMESA) LM30 - LM40 - LM55
LM70 - LM85
for Washing machine (WHIRLPOOL) AGB245 - AGB246
AGB255 - AGB256



WHIRLPOOL 483286001157

3449279 OUTLET SLEEVE
for Washing machine (IMESA) RC14 - RC18 - RC23
for Washing machine (WHIRLPOOL) AGB210/WP
AGB211/WP - AGB212/WP - AGB216/WP - AGB217/WP
AGB218/WP



WHIRLPOOL 483286008386

3353004 SLEEVE
for product dispenser
for Washing machine (GRANDIMPIANTI) WR11 - WR18
WR24 - WR37 - WR8
for Washing machine (PRIMUS) RS10 - RS16 - RS22
RS7
for Washing machine (WHIRLPOOL) 016013-WAC8
016014-WAC11 - 016015-WAC17 - 016016-WAC23



WHIRLPOOL 752210

WHIRLPOOL 771985009101

3394333 HOSE CLAMP $\varnothing$ 90-110 mm
for Washing machine (GRANDIMPIANTI) WR11 - WR18
WR24 - WR37 - WR8
for Washing machine (PRIMUS) RS10 - RS16 - RS22
RS7
for Washing machine (WHIRLPOOL) WAC11 - WAC17
WAC23 - WAC8



WHIRLPOOL 752220

WHIRLPOOL 771985009102

Suitable for:

Suitable for:

3248142 TANK COUPLING

for Washing machine (IMESA) LM11 - LM14 - LM18
LM23 - LM6 - LM8 - RC11 - RC14 - RC18 - RC23
RC6 - RC8
for Washing machine (WHIRLPOOL) AGB209 - AGB210
AGB211 - AGB214 - AGB215 - AGB216 - AGB217
AGB218 - AGB222 - AGB223 - AGB224 - AGB225
AGB226 - AGB231 - AGB232 - AGB237 - AGB238
AGB239 - AGB240 - AGB241 - AGB247 - AGB248
AGB249 - AGB250 - AGB251



WHIRLPOOL 483286008244

3449276 TANK/PUMP SLEEVE

for Washing machine (WHIRLPOOL) AWM9100EU
AWM9100F - HYDRA



WHIRLPOOL 481253029278

WHIRLPOOL 561107

WHIRLPOOL 771985011749

Solenoid valves

3356136 DRAIN PUMP

inlet and outlet $\varnothing$ external 55 mm
220 V - 50 Hz - 0.1 bar - 13 min. 50°C
for WASHING MACHINE MIELE PW80/100
forp WASHING MACHINE WHIRPOOL WS5508/5510



WHIRLPOOL 745232

WHIRLPOOL 771985007991

3120516 SERVO CONTROLLED SOLENOID VALVE 3/4"

for Washing machine (IMESA) LM11 - LM14 - LM18
LM23 - LM6 - LM7 - LM8 - RC11 - RC14 - RC18
RC23 - RC8
for Washing machine (WHIRLPOOL) AGB208/WP
AGB209/WP - AGB210/WP - AGB211/WP - AGB212/WP
AGB214/WP - AGB215/WP - AGB216/WP - AGB217/WP
AGB218/WP - AGB230/WP - AGB231/WP - AGB232/WP
AGB233/WP - AGB234/WP - AGB235/WP - AGB236/WP
AGB237/WP - AGB238/WP - AGB239/WP - AGB240/WP
AGB241/WP - AGB247/WP - AGB248/WP



WHIRLPOOL 483286008326

3120294 SOLENOID VALVE 230V $\varnothing$ 3/4" M

solenoid valve 180° - 230V 50Hz
inlet-outlet 3/4" M
for Washing machine (IMESA) LM14 - LM18 - LM23
RC14 - RC18 - RC23
for Washing machine (WHIRLPOOL) AGB210/WP
AGB211/WP - AGB212/WP - AGB216/WP - AGB217/WP
AGB218/WP - AGB233/WP - AGB234/WP - AGB235/WP
AGB239/WP - AGB240/WP - AGB241/WP



WHIRLPOOL 483286008342

WHIRLPOOL 483286008466

3120166 SOLENOID VALVE 263A 220/240V $\varnothing$ 14 mm

solenoid valve 90° - 220/240V 50/60Hz - max 90°C
inlet 3/4" - triple outlet $\varnothing$ 14 mm
for Washing machine (GRANDIMPIANTI) WFM33 - WFM40
WFM55 - WR11 - WR18 - WR24 - WR26 - WR37 - WR8
for Washing machine (IMESA) RS10 - RS16 - RS22
RS7
for Washing machine (POLIMATIC) RS10 - RS35 - RS6
RS7
for Washing machine (PRIMUS) FS10 - FS6 - FS7
PS7 - RS10 - RS35 - RS6 - RS7
for Washing machine (WHIRLPOOL) WACS11 - WACS17
WACS23 - WACS6 - WACS7 - WACS8 - WAC11 - WAC17
WAC23 - WAC8



WHIRLPOOL 752132

WHIRLPOOL 771985009089



WHIRLPOOL



Suitable for:

3120167 SOLENOID VALVE 264A 220/240V ø 14 mm
solenoid valve 180° - 220/240V 50/60Hz - max 90°C
inlet 3/4" - three outlets ø 14 mm
for Washing machine (AGA) 520/16
for Washing machine (IMESA) RC11 - RC8
for Washing machine (WHIRLPOOL) AGB208/WP
AGB209/WP - AGB214/WP - AGB215/WP



WHIRLPOOL 483286008635

Suitable for:

3120490 WATER SOLENOID VALVE
1 -way left 180°-220v
inlet M 3/4" - outlet ø 13.5 mm
for Washing machine (WHIRLPOOL) AWM9100-EU
AWM9100-F - HYDRA



WHIRLPOOL 481228128429

WHIRLPOOL 516069

WHIRLPOOL 771985011740

3120491 WATER SOLENOID VALVE
1 -way left 180°-220v
inlet M 3/4" - outlet ø 13.5 mm
for Washing machine (WHIRLPOOL) AWM9100-EU
AWM9100-F - HYDRA



WHIRLPOOL 481228128432

WHIRLPOOL 561070

WHIRLPOOL 771985011741

Sparking plugs

3020377 FLAME SPARKING PLUG
for Dryer (IMESA) ES55




WHIRLPOOL 483286009802

3020391 FLAME SPARKING PLUG
ø 7 mm - overall length 215 mm
for Dryer (IMESA) ES75



WHIRLPOOL 483286001045

3806011 SPARKING PLUG
ø 9 x length 65 mm - bracket 50x22 mm



WHIRLPOOL 753323

WHIRLPOOL 771985009271

Springs

3250228 SUSPENSION SPRING
overall length 150 mm - ø 30 mm



WHIRLPOOL

3250229 SUSPENSION SPRING
overall length 155 mm - ø 30 mm



WHIRLPOOL 746802

WHIRLPOOL 771985008576

Supports

3325003 BEARING SPACER
for Washing machine (IMESA) LM14 - LM18 - LM23
for Washing machine (WHIRLPOOL) AGB233 - AGB234
AGB235 - AGB239 - AGB240 - AGB241 - AGB249
AGB250 - AGB251



WHIRLPOOL

3391061 SPACER



WHIRLPOOL


Switches

3319662 DIAPHRAGM KEYBOARD IM9
for Washing machine (IMESA) LM11 - LM14 - LM18
LM23 - LM6 - LM8 - RC11 - RC14 - RC18 - RC23
RC8
for Washing machine (WHIRLPOOL) AGB208/WP
AGB209/WP - AGB210/WP - AGB211/WP - AGB212/WP
AGB213 - AGB214/WP - AGB215/WP - AGB216/WP
AGB217/WP - AGB218/WP - AGB230 - AGB231
AGB232 - AGB233/WP - AGB234/WP - AGB235/WP
AGB236/WP - AGB237/WP - AGB238/WP - AGB239
AGB240/WP - AGB241/WP - AGB242 - AGB243
AGB244 - AGB245



WHIRLPOOL 483286008262


3319640 DOOR OPENING SWITCH
for Washing machine (PRIMUS) P5
for Washing machine (WHIRLPOOL) LWS51M



WHIRLPOOL 746618

WHIRLPOOL 771985008491

3319641 SWITCH KNOB
for Washing machine (PRIMUS) P5
for Washing machine (WHIRLPOOL) LWS51M



WHIRLPOOL 746617

WHIRLPOOL 771985008490




WHIRLPOOL



Suitable for:


3319595 FORWARD/BACKWARD ROTARY SELECTOR SWITCH
red/yellow



WHIRLPOOL 483286009535


Suitable for:

3241852 KNOB
ON/OFF - 66x66 mm
for Washing machine (IMESA) LM11 - LM14 - LM18
LM23 - LM6 - LM8
for Washing machine (WHIRLPOOL) AGB230/WP
AGB231/WP - AGB232/WP - AGB233/WP - AGB234/WP
AGB235/WP - AGB236/WP - AGB237/WP - AGB238/WP
AGB239/WP - AGB240/WP - AGB241/WP - WES11MP
WES11ST - WES14ST - WES18MP - WES18ST - WES6MP
WES6ST - WES8MP - WES8ST



WHIRLPOOL 483286008412


3319592 POWER SWITCH 3 KEYS
for Washing machine (MIELE) PW51 - PW61
for Washing machine (WHIRLPOOL) WS5425 - WS5426



WHIRLPOOL 745283

WHIRLPOOL 771985008037


3319590 PUSH-BUTTON PANEL 6 BUTTONS
for Washing machine (PRIMUS) P5
for Washing machine (WHIRLPOOL) LWS51M



WHIRLPOOL 746611

WHIRLPOOL 771985008484

3319591 PUSH-BUTTON KNOB
for Washing machine (PRIMUS) P5
for Washing machine (WHIRLPOOL) LWS51M



WHIRLPOOL 746623

WHIRLPOOL 771985008496


3319680 RED EMERGENCY PUSH-BUTTON
for Washing machine (IMESA) LM11 - LM14 - LM18
LM23 - LM6 - LM8 - RC11 - RC14 - RC18 - RC23
RC8
for Washing machine (WHIRLPOOL) AGB208/WP
AGB209/WP - AGB211/WP - AGB212/WP - AGB213
AGB214/WP - AGB217/WP - AGB218/WP - AGB230/WP
AGB231/WP - AGB232/WP - AGB234/WP - AGB235/WP
AGB236/WP - AGB237/WP - AGB238/WP - AGB239/WP
AGB240/WP - AGB241/WP



WHIRLPOOL 483286008247

WHIRLPOOL 483286008595

3454029 CONTACTOR MCB-01
for emergency stop




WHIRLPOOL 483286008248

Suitable for:

Suitable for:

3319598 START POWER SWITCH

for Dryer (PRIMUS) DAM9 - DA9
for Dryer (WHIRLPOOL) SACE8
for Washing machine (PRIMUS) P5



WHIRLPOOL 722002

WHIRLPOOL 771985007831

3319596 START/STOP SWITCH - 4 FASTON

for Washing machine (PRIMUS) P6 - P7
for Washing machine (WHIRLPOOL) WACS6 - WACS7



WHIRLPOOL 746806

WHIRLPOOL 771985008580

3319597 SEALING CAP

for switch
for Washing machine (PRIMUS) P6 - P7
for Washing machine (WHIRLPOOL) WACS6 - WACS7



WHIRLPOOL 746809

WHIRLPOOL 771985008583

5041498 STOP BUTTON

for WASHING MACHINE GRANDIMPIANTI WFP120-
AS26-AS33-AS44-AS66
for WASHING MACHINE PRIMUS MB26-MB33-MB44
MB66-FS16
for WHIRLPOOL WASHING MACHINE WACS28AE-
WACS28AV-WACS35AE-WACS35AV-WACS46AE-WACS46AV-
WACS70AE-WACS70AV
for DRIER PRIMUS T24



WHIRLPOOL




Suitable for:

Suitable for:

3319593 SWITCH 4591 W2 - START/STOP - 6 FASTONS

for Dryer (ASKO) TDC44
for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC
ES5EIE
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP
AGB206/WP - AGB207/WP - SACE5 - SE5GC - SE5GE
SE5IC - SE5IE
for Washing machine (IMESA) LM5EGDP - LM5EGDV
LM5EIDP - LM5EIDV
for Washing machine (PRIMUS) PW5
for Washing machine (WHIRLPOOL) AGB200/WP
AGB201/WP - AGB202/WP - WACS5 - WACS5M
WES5GP - WES5GV - WES5IP



WHIRLPOOL 483286009926

WHIRLPOOL 747010

WHIRLPOOL 771985008632

3319599 PUSH-BUTTON LAMP


for Dryer (ASKO) TDC44
for Dryer (IMESA) ES5 - ES5EGC - ES5EGE - ES5EIC
ES5EIE
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204 - AGB204/WP - AGB205
AGB205/WP - AGB206 - AGB206/WP - AGB207
AGB207/WP - SECE5 - SE5GC - SE5GE - SE5IC
SE5IE
for Washing machine (ASKO) WMC55
for Washing machine (IMESA) LM5 - LM5EGDP
LM5EGDV - LM5EIDP - LM5EIDV
for Washing machine (PRIMUS) PW5
for Washing machine (WHIRLPOOL) AGB200 - AGB200/WP
AGB201 - AGB201/WP - AGB202 - AGB202/WP
AGB203 - AGB203/WP - WACS5 - WACS5M - WES5GP



WHIRLPOOL 483286000304

3319600 PUSH-BUTTON SPRING

for Dryer (ASKO) TDC44
for Dryer (IMESA) ES5EGC - ES5EGE - ES5EIC
ES5EIE
for Dryer (PRIMUS) DAM5
for Dryer (WHIRLPOOL) AGB204/WP - AGB205/WP
AGB206/WP - AGB207/WP - SACE5 - SE5GC - SE5GE
SE5IE
for Washing machine (ASKO) WMC55
for Washing machine (IMESA) LM5EGDP - LM5EGDV
LM5EIDP - LM5EIDV
for Washing machine (PRIMUS) PW5
for Washing machine (WHIRLPOOL) AGB200/WP
AGB201/WP - AGB202/WP - AGB203/WP - WACS5
WACS5M - WES5GP - WES5GV - WES5IP - WES5IV



WHIRLPOOL 483286009908

5041503 WHITE BUTTON SWITCH 40x14 mm

snap-in
16A 3/4HP 125/250VAC
for DRIER PRIMUS SWE140-D14



WHIRLPOOL 771985007817

Thermostats

3444006 THERMOSTAT TR2 0-210°C
D-shaped pin $\varnothing$ 6x4.6 mm
capillary length 1000 mm - 15A 250V
bulb $\varnothing$ 5x140 mm



WHIRLPOOL 483286003376

3444328 THERMOSTAT 30-40-60-90°C
4 set temperatures 30°-40°-60°-90°C
capillary 1050 mm
bulb $\varnothing$ 6x125 mm
16A 250V
for Washing machine (PRIMUS) RS10 - RS16 - RS22
RS7
for Washing machine (WHIRLPOOL) WAC11 - WAC17
WAC23 - WAC8




WHIRLPOOL 750008

WHIRLPOOL 771985008685

Timers

3322326 PROGRAMMER
mod.900-912/7927



WHIRLPOOL 481228218663

3322325 PROGRAMMER M460-G
for Dryer (WHIRLPOOL) HELIOS-AWZ481E



WHIRLPOOL 481228219632

WHIRLPOOL 561267

WHIRLPOOL 771985011782

3242655 PROGRAMMER KNOB
for Dryer (WHIRLPOOL) HELIOS AWZ481E



WHIRLPOOL 481241248035

WHIRLPOOL 561242


3446210 TIMER M460-G
1/3HP 240V 50Hz 25A



WHIRLPOOL 757003

WHIRLPOOL 771985009393

3446211 TIMER M481
3/4HP 20/10A 125/250V 50Hz



WHIRLPOOL



WHIRLPOOL



Suitable for:

3446212 **TIMER 15 MINUTES**
230 V - 50 Hz



WHIRLPOOL 483286002872

Suitable for:


3446068 **TIMER 514 44C-07**
220V 50Hz
D-shaped pin 6X4.6 mm
for Washing machine (ZANUSSI) LB121 - LB161 - LB81
W100 - W160 - W75



WHIRLPOOL 191475

WHIRLPOOL 771985005431

3446213 **TIMER 60 MINUTES**
230 V - 50 Hz



WHIRLPOOL 483286002873

3446196 **TIMER 60 MINUTES - 24V**
for Dryer (GIRBAU) SE112
for Dryer (IPSO) DR25 - DR35
for Dryer (PRIMUS) DA11 - DA13 - DA15 - D25 - D35
D55 - D77
for Dryer (WHIRLPOOL) SACE11 - SACE13 - SACE17
SACE25 - SACE35 - SACE55 - SWE111 - SWE131
SWE151 - SWE251 - SWE351 - SWE551



WHIRLPOOL 751505

WHIRLPOOL 771985008944

3446194 **60 MINUTE TIMER**
3/4 HP - 20/10 A - 125/250 V - 50 Hz
25 A - 250 V - 50Hz
for Dryer (PRIMUS) D25
for Dryer (WHIRLPOOL) SACE25



WHIRLPOOL 721131

WHIRLPOOL 771985007816

Water tight seals

3786129 **ELASTIC SEALING RING 65x105x13/14.5 mm**
for IMESA WASHING MACHINE RC14-RC18-RC23



WHIRLPOOL 483286008571

3786132 **ELASTIC SEALING RING 85x110x12 mm**
for IMESA WASHING MACHINE
LM14-LM18-LM23-RC30-RC40



WHIRLPOOL 483286008467

Suitable for:

3786131 ELASTIC SEALING RING 100x130x10 mm
for IMESA WASHING MACHINE LM14-LM18-LM23



WHIRLPOOL 483286008511

Suitable for:

3786134 ELASTIC SEALING RING 110x140x12 mm
for IMESA WASHING MACHINE LM30-RC55-RC70



WHIRLPOOL 483286002949

3786130 ELASTIC SEALING RING 110x140x14.5/16 mm
for IMESA WASHING MACHINE RC30-RC40



WHIRLPOOL 483286008468

3786133 ELASTIC SEALING RING 130x160x12 mm
for IMESA WASHING MACHINE LM40-LM55-LM70-LM85



WHIRLPOOL 483286001426

3453013 RETAINER RING ø 58x88x18 mm
sealing ring:
internal ø 58 mm
external ø 88 mm
thickness 18 mm
for GRANDIMPIANTI WASHING MACHINE WFM18
for IPSO WASHING MACHINE HF110-HF132-HF165-HF145
HF176-HF205-HF234-HW131-HW164-WE110-WE132-WE165
WE176-WE234-WE181-WF135-WF165-WF150-WF185-WF235
WFF135-WFF165-WFF150-WFF185-WFF235



WHIRLPOOL 752935

WHIRLPOOL 752944

WHIRLPOOL 771985009182

WHIRLPOOL 771985009191

3453037 SEALING RING



WHIRLPOOL 483286009893

3786417 SEALING RING
for tank
f/ WASHING MACHINE WHIRLPOOL
HYDRA-AWM9000-AWM9100



WHIRLPOOL 481253068029

3453030 SEALING RING ø 40x68x12 mm
sealing ring:
internal ø 40 mm
external ø 68 mm
thickness 12 mm
for GRANDIMPIANTI WASHING MACHINE
WFEC8-WFEC11-WR8
WR11-WFM6-WFM6S
for PRIMUS WASHING MACH.P6-P7-RS6-RS7-RS10-F6-C6
for POLIMATIC WASHING MACHINE P65-P75-RS6-RS7-RS10
for IPSO WASHING MACHINE HC60-HC65-HC75-HC100-HF55
HF65-HF75-HF95-HW64-HW72-HW94-WE55-WE73-WE95-WF65
WF75-WF100-WFF65-WFF75-WFF100
for IMESA WASHING MACHINE LK8



WHIRLPOOL 750263

WHIRLPOOL 771985008750



WHIRLPOOL



Suitable for:

3453005 SEALING RING $\varnothing$ 50x80x13 mm

sealing ring:
internal $\varnothing$ 50 mm
external $\varnothing$ 80 mm
thickness 13 mm
for GRANDIMPIANTI WASHING MACHINE
WFM8-WFM11-WR11
WR18
for PRIMUS WASHING MACHINE FS6-FS7-FS10-RS13
for POLIMATIC WASHING MACHINE FS6-FS7-FS10-RS13



WHIRLPOOL 750269

WHIRLPOOL 771985008753

Suitable for:

3453039 COUNTER-SEAL RING $\varnothing$ 50x70x5 mm for PRIMUS F7-F10-RS10-RS16 for WHIRLPOOL LW100-LWS100-WAC11-WAC17



WHIRLPOOL 752336

WHIRLPOOL 771985009119

3453006 SEALING RING $\varnothing$ 60x88x18 mm


sealing ring:
internal $\varnothing$ 58 mm
external $\varnothing$ 88 mm
thickness 18 mm
f/ GRANDIMPIANTI WASHING MACHINE
WFM18-WFEC18-WR18
WR26
for PRIMUS WASHING MACHINE FS16-RS18-RS22
for POLIMATIC WASHING MACHINE FS16-RS18-RS22
for IPSO WASHING MACHINE HC135-HC165-HF234-WE181
WE234



WHIRLPOOL 752944

WHIRLPOOL 771985009191

3063097 SEALING RING WITH GASKET dimensions 40x58x5 mm



WHIRLPOOL 50264

WHIRLPOOL 750264

WHIRLPOOL 771985008751

3186295 SEALING RING 130/160/14-5/16 mm for IMESA WASHING MACHINE LM30-RC55-RC70



WHIRLPOOL 483286002951

3186296 SEALING RING 60/90/13-5/15 mm for IMESA WASHING MACH. LM6-LM8-LM11-RC6-RC8-RC11




WHIRLPOOL 483286008634

3786416 TANK SEALING BUSHING



WHIRLPOOL 481252448014

3786438 TANK SEALING GASKET



WHIRLPOOL 71985008498

WHIRLPOOL 746625

WHIRLPOOL 771985008498

The data herewith contained may change without notice and LF SpA cannot be held responsible for possible errors stated or resulting by the use of this document. All rights reserved. No part of this publication may be reproduced without written permission by LF SpA.



LF SpA

via Voltri, 80 - 47522 Cesena (FC) ITALIA
Tel. +39 0547 34 11 11 - Fax +39 0547 34 11 10
www.lfricambi724.it - www.lfricambi724.mobi
info@lfricambi.it
Export Dept.: Tel. +39 0547 34 11 50 - Fax: +39 0547 34 11 55
www.lfspareparts724.com - www.lfspareparts724.mobi
export@lfspareparts.com

FRANCE



EPGC Sas

13, Rue des Forts - 59960 Neuville en Ferrain
Tél. +33 (0)3 20 25 06 21
Fax +33 (0)3 20 25 34 12
www.epgc.com
www.epgc724.mobi
epgc@epgc.com

DEUTSCHLAND



LF GmbH

Junkersstrasse, 1 - D-82178 Puchheim - München
Tel. +49 89 89 45 78 66
Fax +49 89 89 45 78 88
www.lfersatzteile724.de
www.lfersatzteile724.mobi
info@lfersatzteile.de

SCHWEIZ



LF GmbH Verkaufsbüro

Sennweidstrasse, 45 - CH-6312 Steinhausen
Tel. +41 (0)41 760 15 80-1
Fax +41 (0)41 760 15 85
www.lfersatzteile724.ch
www.lfersatzteile724.mobi
info@lfersatzteile.ch

ESPAÑA



LF Repuestos Horeca S.L.U.

Calle Ciudad Real, 10 - 45517 Escalonilla - Toledo
Tlf. +34 91 477 91 00
Fax +34 91 477 90 81
www.lfrepuestos724.es
www.lfrepuestos724.mobi
info@lfrepuestos.es

UNITED KINGDOM



LF Spare Parts Ltd.

A10a Lakeside Business Park, Broadway Lane
South Cerney, Gloucestershire GL7 5XL
Tel. +44 (0)1285 86 16 25
Fax +44 (0)1285 86 39 49
www.lfspareparts724.co.uk
www.lfspareparts724.mobi
info@lfspareparts.co.uk

RUSSIA



OOO LF

ul, Anatoliya Zhivova, 8 - office 1 - 123100 Moscow
Tel. +7 499 259 85 75
Fax +7 495 725 26 53
www.lfspareparts724.ru
www.lfspareparts724.mobi
info@lfspareparts.ru

CHINA



LF China

Room 102, House 8, Lane 725, Mao Tai Rd.
Changning Dist. - 200336 Shanghai
Tel. +86 (0)21 33 53 66 31
Fax +86 (0)21 33 53 66 32
www.lfspareparts724.com
www.lfspareparts724.mobi
china@lfspareparts.com