



Spare parts for:

Warewashing equipment



Suitable for:

BONNET



This catalogue is automatically generated.
Therefore, the sequence of the items might
not be always shown at best.

Updates will be issued in case of additions
and/or amendments.

*Suitable **universal spare parts** may not be included*





Suitable for:

BONNET

Suitable for:



Air traps

3060100 AIR CHAMBER
 for Dishwasher (BONNET) INO11L - INO14LA - INO18LA
 INO19T - INO5F
 for Glasswasher/Cupwasher (BONNET) INO7F



BONNET 15179

BONNET 54397

3060105 AIR CHAMBER FASTENING KIT
 for Dishwasher (BONNET) - Series INO
 for Dishwasher pull-through (BONNET) - Series GTI



BONNET 15179K

3060101 AIR CHAMBER
 for Dishwasher (BONNET) INO36



BONNET 981204

3060001 AIR CHAMBER ø 150x65 mm
 for Pan/utensilwashing machines (BONNET) LU800



BONNET 5330E


3060609 AIR CHAMBER COMPLETE ø 34x79 mm
 complete with flat O-ring gasket and connector
 hose end fitting ø 6 mm
 for Glasswasher/Cupwasher (BONNET)
 VR1000R - VR1000RAD - VR1500C - VR1500CAD
 for Dishwasher (BONNET) EOLYA CRISTAL 35
 EOLYA CRISTAL 35A - EOLYA CRISTAL 40
 EOLYA CRISTAL 40A - EOLYA FRONTALE
 EOLYA FRONTALE A - EOLYA TOP
 for Glasswasher/Cupwasher (BONNET)
 LV385



BONNET 2001861H

BONNET 5848E

3060072 AIR CHAMBER ø 34x79 mm
 for Dishwasher (BONNET) EOLYA CRISTAL 35
 EOLYA CRISTAL 35A - EOLYA CRISTAL 40
 EOLYA CRISTAL 40A - EOLYA FRONTALE
 EOLYA FRONTALE A



BONNET 2001105H

3060607 FITTING FOR AIR CHAMBER
 for Dishwasher (BONNET) EOLYA CRISTAL 35
 EOLYA CRISTAL 35A - EOLYA CRISTAL 40
 EOLYA CRISTAL 40A - EOLYA FRONTALE
 EOLYA FRONTALE A - EOLYA TOP



BONNET 2001571H

6437019 GASKET FLAT EPDM ø 22x13x1.5 mm
 for Dishwasher (BONNET) EOLYA CRISTAL 35
 EOLYA CRISTAL 35A - EOLYA CRISTAL 40
 EOLYA CRISTAL 40A - EOLYA FRONTALE
 EOLYA FRONTALE A



BONNET 2001366H



Suitable for:

3060608 O-RING O3050 EPDM

for Dishwasher (BONNET) EOLYA CRISTAL 35
EOLYA CRISTAL 35A - EOLYA CRISTAL 40
EOLYA CRISTAL 40A - EOLYA FRONTALE
EOLYA FRONTALE A



BONNET 2001376H

BONNET



Suitable for:

3060018 AIR CHAMBER COMPLETE 75x40x80 mm

hose end fitting \varnothing 5.5 mm
complete with flat gasket and fastening nut
for Dishwasher hood type (BONNET) INO60 - INO80



BONNET

3060601 AIR CHAMBER COMPLETE 85x20x80 mm

with two O-ring gaskets, bajo bolt and
hose end fitting \varnothing 5 mm
for Glasswasher/Cupwasher (BONNET)
VR1000R - VR1000RAD - VR1500C - VR1500CAD



BONNET 5567E

3060602 FITTING HOSE-END FOR AIR CHAMBER

hose end fitting \varnothing 6 mm
for Glasswasher/Cupwasher (BONNET) VR1000R
VR1000RAD - VR1500C - VR1500CAD



BONNET

3060605 FITTING

for Glasswasher/Cupwasher (BONNET) VR1000R
VR1000RAD - VR1500C - VR1500CAD



BONNET

1186318 O-RING O3043 EPDM

for Glasswasher/Cupwasher (BONNET)
VR1000R - VR1500C
for Dishwasher (BONNET) EOLYA CRISTAL 35
EOLYA CRISTAL 35A - EOLYA CRISTAL 40
EOLYA CRISTAL 40A



BONNET 2001912H

BONNET 366381



Suitable for:

3060603 RETAINING BOLT FOR FITTING
for Glasswasher/Cupwasher (BONNET) VR1000R
VR1000RAD - VR1500C - VR1500CAD




BONNET

3060126 AIR CHAMBER 63x35 mm
hose end fitting \varnothing 6 mm
for Dishwasher (BONNET) EOLYA BATTERIE 600
EOLYA FRONTALE PLUS - EOLYA TOP



BONNET 2001106H

5034335 NUT PLASTIC GRAY 3/4"
for Dishwasher (BONNET) EOLYA BATTERIE 600
EOLYA FRONTALE PLUS - EOLYA TOP



BONNET 2001201H

5034976 SYSTEM INLET CRP
overall dimensions 154x97x40 mm
three hose end fittings \varnothing 6/8/22 mm
for Dishwasher (BONNET) EOLYA BATTERIE 600
EOLYA FRONTALE PLUS



BONNET 2002222H

BONNET

Suitable for:




5034334 GASKET FOR AIR CHAMBER
external \varnothing 33 mm - thickness 2.4 mm
for Dishwasher (BONNET) EOLYA BATTERIE 600
EOLYA FRONTALE PLUS - EOLYA TOP



BONNET 2001359H

5025701 TANK AIR-GAP LP COMPLETE
external dimensions 470x165x60 mm
for Dishwasher (BONNET) EOLYA BATTERIE 600
EOLYA FRONTALE PLUS



BONNET 2001619H

BONNET 2001902H

Axial motors

3240501 AXIAL FAN SUNON 120x120x38 mm
ball bearings
230V 50/60Hz 22W 2850rpm
DP200A 2123XBT.GN



BONNET 304194

BONNET 906107



Bearings

- 1063912 BEARING 6201 ZZ NSK**
 external \varnothing 32mm - internal \varnothing 12mm - thickness 10mm
 for Dishwasher (BONNET) EOLYA FRONTALE
 EOLYA FRONTALE A - EOLYA FRONTALE PLUS



BONNET 983650

Boiler safety valves

- 3526275 EXHAUST VALVE ASSEMBLY**



BONNET 2002298H

- 3526008 VENT VALVE**
 \varnothing fittings 19 mm
 for Dishwasher (BONNET) EOLYA FRONTALE
 EOLYA FRONTALE A



BONNET 2001253H

Boilers

- 6104060 BOILER \varnothing 145x403 mm**
 for Dishwasher (BONNET) EOLYA FRONTALE
 EOLYA FRONTALE A



BONNET 2002149H

- 3024019 BOILER \varnothing 190x410 mm**
 for Dishwasher (BONNET) EOLYA TOP



BONNET 2001602H

Bushings

- 6417111 WASHING ARM BUSHING THREAD 3/4"**
 for Dishwasher (BONNET) EOLYA FRONTALE
 EOLYA FRONTALE A - EOLYA FRONTALE PLUS



BONNET 2001395H



Suitable for:

BONNET



Suitable for:

Capacitors, electrical

3068024 CAPACITOR μ F 16 450V 50/60Hz
 operating temperature $-25+85^{\circ}\text{C}$
 in compliance with EEC 93/68 and 92/31 regulations
 for Dishwasher (BONNET) EOLYA FRONTALE
 EOLYA FRONTALE A - EOLYA FRONTALE PLUS



BONNET 2001118H

BONNET 2002168H

BONNET 304259

3068027 CAPACITOR μ F 20 450V 50/60Hz
 operating temperature $-25+85^{\circ}\text{C}$
 in compliance with EEC 93/68 and 92/31 regulations
 for Dishwasher (BONNET)
 EOLYA TOP



BONNET 2001119H

BONNET 2002417H

3068010 CAPACITOR μ F 6.3 450V 50/60Hz
 operating temperature $-25+85^{\circ}\text{C}$
 in compliance with EEC 93/68 and EEC 92/31 regulat
 for Dishwasher (BONNET) EOLYA CRISTAL 40
 EOLYA CRISTAL 40A




BONNET 2000059

BONNET 2001121H

Castors, rollers and accessories

3346033 HANDLE SUPPORT
 for Dishwasher (BONNET) EOLYA TOP



BONNET 2001241H

3346135 HOOD BUMPER
 for Dishwasher (BONNET) EOLYA TOP



BONNET 2001932H

3242142 LIFTING WHEEL FOR HOOD
 for Dishwasher (BONNET) EOLYA TOP



BONNET 2002072H

3738001 SWIVELLING WHEEL
 with STAINLESS STEEL supports
 dimension $\varnothing 125 \times 30$ mm - load capacity 100 Kg
 pin hole $\varnothing 13$ mm



BONNET 983080



Clamps

3449402 DOUBLE-WIRE CLAMP 7.8-8.3 - 100 PCS
for hoses \varnothing 7.8÷8.3 mm



BONNET 2001114H

3449472 HOSE CLAMP 40-60
for pipes \varnothing 40÷60 mm
made of stainless steel AISI 304
height 12 mm and screw E7
suitable for food industry
for Dishwasher (BONNET)
EOLYA TOP



BONNET 2001113H

BONNET 2002537H

Contact thermostats

3443082 ADJUSTMENT THERMOSTAT
for Dishwasher (BONNET) INO45
for Dishwasher hood type (BONNET) INO81



BONNET 901032


BONNET 901033

3444622 CONTACT SAFETY THERMOSTAT 200°C
with manual reset - pin M4
for Dishwasher (BONNET) EOLYA FRONTALE PLUS



BONNET 2001683H

3444607 CONTACT THERMOSTAT 110°C
with manual reset
for Dishwasher (BONNET) EOLYA CRISTAL 35
EOLYA CRISTAL 35A - EOLYA CRISTAL 40
EOLYA CRISTAL 40A - EOLYA FRONTALE
EOLYA FRONTALE A



BONNET 2001685H

3443081 CONTACT THERMOSTAT 125°C M4
for Dishwasher (BONNET) EOLYA FRONTALE PLUS



BONNET 2001682H

3444608 CONTACT THERMOSTAT 60°C
automatic reset - for wash tank



BONNET 2001680H

3444606 CONTACT THERMOSTAT 80°C
safety thermostat - for boiler



BONNET 2001684H



Suitable for:

BONNET



3444609 CONTACT THERMOSTAT 95°C
 manual reset
 for Dishwasher (BONNET)
 LCB2000
 for Dishwasher (BONNET)
 EOLYA CRISTAL 35 - EOLYA CRISTAL 35A
 EOLYA CRISTAL 40 - EOLYA CRISTAL 40A
 EOLYA FRONTALE - EOLYA FRONTALE A
 EOLYA FRONTALE PLUS - LCB2000
 EOLYA BATTERIE 600 - EOLYA TOP



BONNET 2001681H

BONNET 2001855H

3443083 GASKET THERMOSTAT ø 40 mm
 internal hole ø 22 mm
 for Dishwasher (BONNET)
 INO45
 for Dishwasher hood type (BONNET)
 INO81
 for Dishwasher (BONNET) INO61



BONNET 16014M

BONNET 966086

3443016 YELLOW/BROWN CONTACT THERMOSTAT
 NO contact operating temperature 35÷46°C
 NC contact operating temperature 52-60°C
 16A 250V



BONNET 5011E

Contactors

3454015 CONTACTOR SCHNEIDER LC1D18P7
 18A 400V 7.5Kw - coil 230V 50/60Hz
 3 normally open contacts
 1 normally open auxiliary contact
 1 normally closed auxiliary contact



BONNET 1700732

BONNET 300698

3454066 CONTACTOR SCHNEIDER LC1D25P7
 25A 400V 11Kw - coil 230V 50/60Hz
 3 normally open contacts
 1 normally open auxiliary contact
 1 normally closed auxiliary contact



BONNET 300697

BONNET 300699

BONNET 300760

BONNET 5875E

BONNET 900130

BONNET 905239

BONNET 905241

BONNET 905686

BONNET 906759

BONNET 910566

3351049 CONTACTOR SIEMENS 3RT2016-1AP01
 9A 400V 4Kw - coil 230V 50/60Hz
 3 normally open contacts
 1 normally open auxiliary contact
 for Dishwasher (BONNET) EOLYA BATTERIE 600
 EOLYA FRONTALE PLUS - EOLYA TOP



BONNET 2001923H

3454072 CONTACTOR SIEMENS 3RT2017-1AB01
 12A 400V 5.5Kw - coil 24V 50/60Hz
 3 contacts NO
 1 NO auxiliary contact
 for Dishwasher hood type (BONNET) ino60 - INO80



BONNET 2001138H

BONNET 2001140H


BONNET 5875E



Controllers and changeover switches

3322613 CONTROL SELECTOR P265 4 CAMS

1st cycle 60 seconds
2nd cycle 20 minutes
230V 50/60Hz
2 motors



BONNET 2001550H

3322601 CONTROLLER D94.04 3 CAMS LEFT-HAND

180 seconds cycle
220/240V 50/60Hz
D-shaped pin \varnothing 6x4.6 mm
for Glasswasher/Cupwasher (BONNET) VR1000H



BONNET 3649E

BONNET 3730E

3322612 CONTROLLER D94.92M 6 CAMS

1st cycle 60 seconds
2nd cycle 120 seconds
3rd cycle 180 seconds
220/240V 50/60Hz
2 motors
for Dishwasher hood type (BONNET) INO60



BONNET 5870E

3322609 CONTROLLER PWE5 3 CAMS

150 seconds cycle
230V 50/60Hz
without pin
former model 600/636/5200
for Glasswasher/Cupwasher (BONNET) VR1000R




BONNET 2001964H

BONNET 5506E

3446197 CONTROLLER P255 7 CAMS


1st cycle 6 seconds
2nd cycle 180 seconds
230V 50/60Hz



BONNET 905035

3322605 CONTROLLER 9449 1 CAM

40 seconds cycle
220/240V 50/60Hz
without pin
for Glasswasher/Cupwasher (BONNET) VR1000R - VR1000RAD - VR1500C - VR1500CAD



BONNET 2001965H

BONNET 5507E

3322308 PROGRAMMER P11600/24

for Dishwasher (BONNET) INO 11 - INO 14L
INO 14LA - INO 18LA - INO 19T - INO 5 - INO 7



BONNET 54383

3322607 TIMER 7003F3 3 CAMS

cycle 6 minutes
230V 50HZ
for Dishwasher (BONNET) INO36



BONNET 905026



Suitable for:

BONNET



Suitable for:

Curtains

3456009 DISHWASHER CURTAIN 655x400 mm
for Dishwasher conveyor type (BONNET) GTI



BONNET 1244722
BONNET 44125

BONNET 1244723
BONNET 44126

BONNET 33189M
BONNET 44127

3456024 INLET/OUTLET CURTAIN 545x405 mm



BONNET 2001632H

3456012 SHAFT 650 mm
for Dishwasher conveyor type (BONNET) LCM



BONNET 1232383

3456008 SHAFT 685 mm
for Dishwasher conveyor type (BONNET) LCM



BONNET 27254

Door catches

3242613 DOOR CATCH
distance 72.5 mm



BONNET 231504

3398601 DOOR CATCH
for Glasswasher/Cupwasher (BONNET) VR1000R
VR1000RAD - VR1500C - VR1500CAD



BONNET 3656E

3398605 DOOR CATCH
for Dishwasher (BONNET) EOLYA FRONTALE
EOLYA FRONTALE A



BONNET 2001307H

6329012 LATCH LOCK ENHANCED
for Dishwasher (BONNET) EOLYA CRISTAL 35
EOLYA CRISTAL 35A - EOLYA CRISTAL 40
EOLYA CRISTAL 40A



BONNET 2001383H

3398077 PAWL SPRING
for Dishwasher (BONNET) EOLYA CRISTAL 35
EOLYA CRISTAL 35A - EOLYA CRISTAL 40
EOLYA CRISTAL 40A




BONNET 2001628H



Door gaskets for dishwashers

3786034 DOOR GASKET
 profile dimensions 20x6 mm
 sold per metre
 for U60=132
 for Dishwasher (BONNET)
 EOLYA BATTERIE 600



BONNET 2001905H


BONNET 2001949H

3786035 DOOR GASKET 1370 mm
 profile dimensions 13x11 mm
 for Dishwasher (BONNET) EOLYA FRONTALE PLUS




BONNET 2001365H

6437057 DOOR GASKET 395 mm
 profile dimensions 16x11 mm
 for Dishwasher (BONNET) EOLYA CRISTAL 35
 EOLYA CRISTAL 35A



BONNET 2001362H

6437058 DOOR GASKET 430 mm
 profile dimensions 16x11 mm
 per LAVABICCHIERI 40F-400-E40
 for Dishwasher (BONNET) EOLYA CRISTAL 40/40A



BONNET 2001363H

3786037 DOOR GASKET 567 mm
 for 050F-050FP
 profile dimensions 32x7 mm
 for Dishwasher (BONNET) EOLYA FRONTALE
 EOLYA FRONTALE A



BONNET 2001364H

Drain assembly

3316036 COMPLETE DRAIN ASSEMBLY \varnothing 1"1/2
 connection \varnothing 1"1/2
 for Dishwasher (BONNET) EOLYA BATTERIE 600



BONNET 2001644H

3349442 DRAIN ASSEMBLY
 inlet ext. \varnothing 82 mm - inlet int. \varnothing 38mm
 outlet ext. \varnothing 40 mm - outlet int. \varnothing 30 mm
 for Dishwasher (BONNET) INO11L - INO5F
 for Glasswasher/Cupwasher (BONNET) INO7F
 for Dishwasher (BONNET) INO11L - INO5F - INO7F



BONNET 42505



Suitable for:

BONNET



3316606 DRAIN ASSEMBLY CONNECTION \varnothing 1"1/4
outlet external \varnothing 31 mm
for Dishwasher (BONNET) EOLYA FRONTALE
EOLYA FRONTALE A



BONNET 2001646H

Suitable for:

3186615 GASKET FLAT RUBBER \varnothing 51x40x2.5 mm
for Dishwasher (BONNET) EOLYA FRONTALE
EOLYA FRONTALE A



BONNET 2001874H

BONNET 5914E

3243902 NUT PLASTIC - CONNECTION \varnothing 1"1/4
for Dishwasher (BONNET) EOLYA FRONTALE
EOLYA FRONTALE A



BONNET 2001200H

3316603 PLASTIC DRAIN ASSEMBLY 3/4"
inner hole \varnothing 22 mm
for Dishwasher (BONNET) EOLYA BATTERIE 600
EOLYA FRONTALE PLUS



BONNET 2001026H

3186616 GASKET FLAT ASBESTOS FREE \varnothing 35x27x1.5mm
for Dishwasher (BONNET) EOLYA BATTERIE 600
EOLYA FRONTALE PLUS



BONNET 2001348H

1186655 O-RING 04131 EPDM
for Dishwasher (BONNET) EOLYA TOP



BONNET 15138K

BONNET 2001917H

Drain hoses

3450186 DRAIN PIPE \varnothing 23x630 mm
sleeves internal \varnothing 21 mm
for Dishwasher (BONNET) EOLYA FRONTALE



BONNET 2001398H

6143137 DRAIN PIPE \varnothing 24x2500 mm
bent hose internal \varnothing 22 mm
straight hose internal \varnothing 18 mm
for Dishwasher (BONNET) EOLYA CRISTAL 35
EOLYA CRISTAL 35A - EOLYA FRONTALE PLUS
INO45



BONNET 2001740H

BONNET 919024



Suitable for:

BONNET




3450188 DRAIN PIPE \varnothing 28x300 mm
sleeves internal \varnothing 23 mm
for Dishwasher (BONNET) EOLYA FRONTALE
EOLYA FRONTALE A



BONNET 2001391H

Suitable for:

3450028 DRAIN PIPE \varnothing 29x1500 mm
muffs internal \varnothing 24 and 28 mm
max temperature 90°C
for Dishwasher (BONNET) EOLYA CRISTAL 35
EOLYA CRISTAL 35A - EOLYA CRISTAL 40
EOLYA CRISTAL 40A



BONNET 2001842H

3450038 DRAIN PIPE \varnothing 34x2000 mm
muff internal \varnothing 33 mm
max temperature 90°C



BONNET 2001739H

3450604 DRAIN PIPE \varnothing 50x1900 mm
elbow sleeve internal \varnothing 50 mm
pipe internal \varnothing 35 mm
max temperature 90°C
for Dishwasher (BONNET) EOLYA TOP



BONNET 2001854H

BONNET 5834E

Drain plugs

3448614 OVERFLOW PIPE \varnothing 22x168 mm
made of plastic
for Dishwasher (BONNET) EOLYA CRISTAL 35
EOLYA CRISTAL 35A - EOLYA CRISTAL 40
EOLYA CRISTAL 40A



BONNET 2001699H

3160602 OVERFLOW PIPE \varnothing 25x215 mm - GREY
for Glasswasher/Cupwasher (BONNET) VR1000R
VR1000RAD - VR1500C - VR1500CAD



BONNET 5579E

BONNET 5580E

3448196 OVERFLOW PIPE \varnothing 32x215 mm



BONNET 2001700H

3448195 OVERFLOW PIPE \varnothing 35x147 mm
for drain electropump
for Dishwasher (BONNET) EOLYA FRONTALE
EOLYA FRONTALE A



BONNET 2001703H



Suitable for:

BONNET



3448317 OVERFLOW PIPE ø 35x365 mm
for Dishwasher hood type (BONNET) INO61 - INO81



BONNET 014647M

BONNET 241467

Suitable for:

3448613 OVERFLOW PIPE ø 36x148 mm
made of plastic
for Dishwasher (BONNET) EOLYA FRONTALE
EOLYA FRONTALE A



BONNET 2001701H

3448615 OVERFLOW PIPE ø 37x385 mm
made of plastic



BONNET 2001901H

1186655 O-RING 04131 EPDM
for Dishwasher (BONNET) EOLYA TOP



BONNET 15138K

BONNET 2001917H

3448601 OVERFLOW PIPE ø 38x200 mm
in plastic
for Glasswasher/Cupwasher (BONNET) VR1000H



BONNET 3745E

3448167 OVERFLOW PIPE ø 38x287 mm
made of plastic



BONNET 2001934H

1186655 O-RING 04131 EPDM
for Dishwasher (BONNET) EOLYA TOP



BONNET 15138K

BONNET 2001917H

Drain pumps

3122327 DRAIN ELECTRIC PUMP 40W 240V 50Hz
inlet external ø 24 mm - output external ø 23 mm
for Dishwasher (BONNET)
EOLYA FRONTALE - EOLYA FRONTALE A



BONNET 2001518H

3122906 DRAIN ELECTRO-PUMP 40W 230/240V 50Hz
inlet external ø 30 mm - outlet external ø 23 mm
for Dishwasher (BONNET) EOLYA TOP




BONNET 2001523H

- | | |
|--|---|
| <p>3122199 DRAIN ELECTRO-PUMP 40W 230V 50Hz
 inlet external \varnothing 30 mm - outlet external \varnothing 22 mm
 for Dishwasher (BONNET)
 EOLYA CRISTAL 35 - EOLYA CRISTAL 35A
 EOLYA CRISTAL 40 - EOLYA CRISTAL 40A
 EOLYA FRONTALE PLUS
 for Dishwasher hood type (BONNET)
 INO 81</p> | <p>3122642 DRAIN PUMP 90W 230V 50Hz
 inlet external \varnothing 34 mm - outlet external \varnothing 24 mm</p> |
|--|---|



BONNET 2001519H

BONNET 904031



BONNET 904018

Electrical cables


- 3050150** **ELECTRICAL CABLE FOR POWER SUPPLY**
with plug SCHUKO - 3 wires \varnothing 1.5 mm
overall length 2500 mm
for Dishwasher (BONNET) EOLYA CRISTAL 35
EOLYA CRISTAL 35A - EOLYA CRISTAL 40
EOLYA CRISTAL 40A



BONNET 2001255H

Electronic printed-circuit boards

- 6041523** **CABLE FLAT 10-POLE 1200 mm**
FOR WAREWASHER
for Dishwasher (BONNET) EOLYA BATTERIE 600



BONNET 2001927H


- 3390194** **CABLE FLAT 10-POLE 3100 mm**



BONNET 2001086H

BONNET 2002191H

- 3390034** **CIRCUIT BOARD**
without EPROM
dimensione 135x100 mm
for Dishwasher (BONNET) EOLYA BATTERIE 600
EOLYA CRISTAL 35 - EOLYA CRISTAL 35A
EOLYA CRISTAL 40 - EOLYA CRISTAL 40A
EOLYA FRONTALE - EOLYA FRONTALE A
EOLYA FRONTALE PLUS - EOLYA TOP



BONNET 2001914H




Suitable for:

BONNET



3390210 CONTROL BOARD
dimensions 97x120 mm
for Dishwasher (BONNET) EOLYA BATTERIE 600
EOLYA TOP



BONNET 2001920H

6080934 CABLE FLAT 10-POLE LENGTH 730 mm
for NIAGARA 281
for Dishwasher (BONNET) EOLYA TOP




BONNET 2001087H

5054819 ELECTROMECHANICAL BOARD MWASH
dimensions 133x82 mm



BONNET 2002140H


5059436 ELECTRONIC CIRCUIT BOARD
dimensions 177x126 mm
for Dishwasher (BONNET) EOLYA BATTERIE 600
EOLYA FRONTALE PLUS



BONNET 2002141H


BONNET 2002541H

3390195 HOOD MICROPROCESSOR RIVER NM
for Dishwasher (BONNET)
EOLYA TOP - OREANE LC PRO GL74TH
EOLYA TOP




BONNET 2001413H

7109050 PC BOARD GET50
dimensions 152x80 mm
for Dishwasher (BONNET)
EOLYA CRISTAL40A - EOLYA FRONTALE A - SV72B0
EOLYA CRISTAL 35 - EOLYA CRISTAL 35A
EOLYA CRISTAL 40 - EOLYA FRONTALE
EOLYA FRONTALE A - EOLYA TOP



BONNET 2002184H

3390191 SUPPLEMENTARY CIRCUIT BOARD
for Dishwasher (BONNET) EOLYA BATTERIE 600
EOLYA FRONTALE PLUS



BONNET 2001922H



Suitable for:

3319253 4 BUTTONS 2 DISPLAY BOARD NEW MODEL
 totally interchangeable with the old model
 dimensions 285x35 mm
 for Dishwasher (BONNET) EOLYA CRISTAL 35
 EOLYA CRISTAL 35A - EOLYA CRISTAL 40
 EOLYA CRISTAL 40A - EOLYA FRONTALE
 EOLYA FRONTALE A - EOLYA FRONTALE PLUS



BONNET 2002490H

Suitable for:

3319250 10-WAYS FLAT CABLE 2300 mm
 for Dishwasher (BONNET)
 EOLYA CRISTAL 35 - EOLYA CRISTAL 35A
 EOLYA CRISTAL 40 - EOLYA CRISTAL 40A
 EOLYA FRONTALE - EOLYA FRONTALE A
 EOLYA FRONTALE PLUS
 EOLYA BATTERIE 600



BONNET 2001085H

BONNET 2002483H


Feet

3313076 ADJUSTABLE FOOT ϕ 29h
 overall height 32 mm - thread M8x20
 for Dishwasher (BONNET) EOLYA FRONTALE
 EOLYA FRONTALE A - EOLYA FRONTALE PLUS



BONNET 2001492H

3313601 HEXAGONAL FOOT
 for Dishwasher (BONNET) EOLYA CRISTAL 35
 EOLYA CRISTAL 35A - EOLYA CRISTAL 40
 EOLYA CRISTAL 40A



BONNET 2001969H

3313005 STAINLESS STEEL FOOT ϕ 2" x h 125 mm
 with fixed screw M12x25 mm
 for Dishwasher (BONNET)
 EOLYA TOP



BONNET 2001489H

BONNET 2001871H

Filters

3160217 DRAIN PUMP FILTER ϕ 62x117 mm
 for Dishwasher (BONNET) EOLYA FRONTALE
 EOLYA FRONTALE A



BONNET 2001270H

3160604 EXTERNAL FILTER ϕ 135x90 mm - GREY
 for Glasswasher/Cupwasher (BONNET) VR1000R
 VR1000RAD - VR1500C - VR1500CAD



BONNET 5581E



Suitable for:

BONNET



5026564 FILTER COLLECTION WITH HANDLE
external dimensions 355x118x164 mm



BONNET 2001262H

3391071 FILTER SUPPORT
for Dishwasher hood type (BONNET) INO81



BONNET 983766

3160623 FILTER SUPPORT WITH EXTENSION
for Dishwasher (BONNET) EOLYA FRONTALE
EOLYA FRONTALE A



BONNET 2001664H

3160616 DRAIN OUTLET BODY
for Dishwasher (BONNET) EOLYA TOP



BONNET 2001850H

BONNET 5829E

3160615 O-RING GASKET 0201 EPDM
for Dishwasher (BONNET) EOLYA TOP



BONNET 2001851H

BONNET 5830E


3160613 PUMP FILTER ø 155x120 mm
for Dishwasher (BONNET) EOLYA FRONTALE
EOLYA FRONTALE A - EOLYA TOP



BONNET 2001853H

BONNET 5832E

3186614 SUPPORT GASKET
for Dishwasher (BONNET) EOLYA FRONTALE
EOLYA FRONTALE A



BONNET 2001356H

3160605 INTERNAL FILTER ø 136x75 mm - GREY
for Glasswasher/Cupwasher (BONNET) VR1000R
VR1000RAD - VR1500C - VR1500CAD



BONNET 5582E

3160622 PLASTIC WASH PUMP FILTER ø 112 mm
for Dishwasher (BONNET)
EOLYA CRISTAL 35 - EOLYA CRISTAL 35A
EOLYA CRISTAL 40 - EOLYA CRISTAL 40A



BONNET 2001259H

BONNET 2002442H



BONNET



Suitable for:

3160519 PROTECTION FOR WASTE COLLECTION FILTER
for Dishwasher hood type (BONNET) INO81



BONNET 014637M

Suitable for:

3160614 RETAINING ASSEMBLY FOR DRAIN
for Dishwasher (BONNET)
EOLYA TOP



BONNET 2001852H
BONNET 5831E

BONNET 2002504H

BONNET 429038_V

3160397 TANK FILTER EXTERNAL ø 150 mm
for Dishwasher hood type (BONNET) INO81



BONNET 981246

3160462 WATER FILTER ø 1/2"FF



BONNET 91297387

Fittings

3090609 FITTING FOR RINSE AID INLET
for boiler
for Dishwasher (BONNET) EOLYA BATTERIE 600



BONNET 2001860H

3186613 GASKET FLAT FIBRE ø 12x8x1.5 mm
for Dishwasher (BONNET) EOLYA BATTERIE 600



BONNET 966079K

3349347 NICHEL-PL.HOSE-END FITTING ø 3/8" M ø 12
for Dishwasher (BONNET) EOLYA BATTERIE 600



BONNET 27221

Floats

3024054 BOILER FLOAT 25x130 mm
for Dishwasher (BONNET) PF700



BONNET 1244666



Suitable for:

BONNET



Suitable for:

Fuses

3049041 QUICK ACTING FUSE \varnothing 5x20 mm - 10 PCS
250V 315mA
for Dishwasher (BONNET) EOLYA BATTERIE 600
EOLYA TOP



BONNET 309316

3049045 QUICK ACTING FUSE \varnothing 5x20 mm - 10 PCS
250V 800mA
for Dishwasher (BONNET) EOLYA BATTERIE 600
EOLYA TOP



BONNET 2001921H

3049052 QUICK ACTING FUSE \varnothing 5x20 mm - 10 PCS
250V 4A
for Dishwasher (BONNET) EOLYA BATTERIE 600
EOLYA CRISTAL 35 - EOLYA CRISTAL 35A
EOLYA CRISTAL 40 - EOLYA CRISTAL 40A
EOLYA FRONTALE - EOLYA FRONTALE A
EOLYA FRONTALE PLUS - EOLYA TOP



BONNET 2001981H

BONNET 2002146H

Gaskets and seals

3786036 FLAT PTFE GASKET \varnothing 22x9x1 mm
for rinse arm
for Dishwasher (BONNET) EOLYA FRONTALE PLUS



BONNET 2001350H

3786346 GASKET FLAT ASBESTOS FREE \varnothing 14x9x2 mm
100 piece pack



BONNET 966067

5048655 GASKET FLAT EPDM \varnothing 45x33x2 mm
shore 70°
for Dishwasher (BONNET) EOLYA BATTERIE 600
EOLYA FRONTALE PLUS



BONNET 2002225H

6437091 GASKET FLAT PTFE \varnothing 13x6x0.5 mm
for Dishwasher (BONNET) EOLYA FRONTALE PLUS



BONNET 2001349H

Suitable for:

Suitable for:

3786705 TOP ARM FLANGE GASKET
for Dishwasher hood type (BONNET) IN061 - IN081



BONNET 966090

Guides

5014124 COVER SLIDEWAY 588 mm
for Dishwasher (BONNET)
EOLYA TOP



BONNET 2001309H

BONNET 2002415H

5033994 SLIDER CONVEYOR SHAFT CARRIAGE



BONNET 2001484H

Handles

5037999 HANDLE BRIDGE GRAY
distance between holes 73 mm
for Dishwasher (BONNET)
IN060 - IN061
for Dishwasher hood type (BONNET)
IN080
IN080



BONNET 2001525H

5051174 PULL HANDLE HOOD RIVER
for Dishwasher (BONNET) EOLYA TOP



BONNET 2001511H

Heating elements

3455232 BOILER HEATING ELEMENT 10000W 220/380V
immersed length 330 mm
flange \varnothing 13 mm - internal \varnothing 83 mm
with gasket \varnothing 83 mm
for Dishwasher (BONNET) INOMS20 - INOMS35
INOMS50 - INO10 - INO11 - INO14L - INO14LA
INO15 - INO16B
for Dishwasher pull-through (BONNET) GTI



BONNET 24520

3455231 BOILER HEATING ELEMENT 6000W 220/380V
immersed length 360 mm
flange \varnothing 13 mm - internal \varnothing 83 mm
with gasket \varnothing 83 mm
for Dishwasher (BONNET) INO10 - INO11 - INO14L
INO14LA - INO15 - INO4B1 - INO4CT - INO5F
INO6
for Glasswasher/Cupwasher (BONNET) IN07F



BONNET 24521



Suitable for:

BONNET



6467002 COVER FOR HEATING ELEMENT BOILER
 ø 68 mm - height 40 mm
 for Dishwasher (BONNET) EOLYA BATTERIE 600
 EOLYA FRONTALE - EOLYA FRONTALE A
 EOLYA FRONTALE PLUS



BONNET 2001859H

3455460 HEATING ELEMENT FOR BOILER 12000W 230V
 immersed length 395 mm
 external ø flange 72 mm
 for Dishwasher hood type (BONNET) INO81



BONNET 903126

3355118 HEATING ELEMENT FOR BOILER 2000W 220V
 immersed length 180 mm
 connection ø 1"1/4 (43 mm)
 complete with gasket ø 54 mm (3186010)
 nut (3528232) and washer (3528238) on request



BONNET 3696E

3355601 HEATING ELEMENT FOR BOILER 2400W 220V
 immersed length 200 mm
 external ø flange 63 mm - with probe receptacle
 complete with O-Ring gasket ø 58 mm (3186013)
 for Glasswasher/Cupwasher (BONNET) VR1000R



BONNET 5535E

BONNET 5536E

3186013 O-RING GASKET 06187 EPDM ø 58 mm
 for Dishwasher (BONNET) EOLYA BATTERIE 600
 EOLYA FRONTALE - EOLYA FRONTALE A
 EOLYA FRONTALE PLUS - EOLYA TOP



BONNET 2001827H

3455334 HEATING ELEMENT FOR BOILER 2600W 230V
 immersed length 265 mm
 external ø flange 55 mm - with probe receptacle
 complete with O-Ring gasket ø 48 mm (3186001)
 for Dishwasher (BONNET) EOLYA CRISTAL 35
 EOLYA CRISTAL 35A - EOLYA CRISTAL 40
 EOLYA CRISTAL 40A



BONNET 2001621H

3455235 HEATING ELEMENT FOR BOILER 3300W 220V
 immersed length 570 mm
 flange 80x27 mm - with probe receptacle
 for Dishwasher (BONNET) INO18 - INO19



BONNET 44017



- 3455238 HEATING ELEMENT FOR BOILER 4500W 220V**
 immersed length 275 mm
 flange external \varnothing 72 with probe receptacle
 complete with O-ring gasket \varnothing 67 mm (3186014)
 for Dishwasher (BONNET) INO38



BONNET 903108

- 3355293 HEATING ELEMENT FOR BOILER 4500W 230/400**
 immersed length 370 mm
 flange external \varnothing 63 mm
 complete with O-ring gasket \varnothing 58 mm (3186013)



BONNET 5079E

- 3355496 HEATING ELEMENT FOR BOILER 4500W 230V**
 immersed depth 310 mm
 flange external \varnothing 63 mm - with probe receptacle
 complete with O-ring gasket \varnothing 58 mm (3186013)



BONNET 903141

- 3455409 HEATING ELEMENT FOR BOILER 4900W 230/400**
 immersed length 330 mm
 external \varnothing flange 63 mm - with probe receptacle
 con guarnizione OR \varnothing 58 mm (3186013)
 for Dishwasher (BONNET) EOLYA FRONTALE
 EOLYA FRONTALE A - EOLYA FRONTALE PLUS



BONNET 2001622H

- 3186013 O-RING GASKET 06187 EPDM \varnothing 58 mm**
 for Dishwasher (BONNET) EOLYA BATTERIE 600
 EOLYA FRONTALE - EOLYA FRONTALE A
 EOLYA FRONTALE PLUS - EOLYA TOP



BONNET 2001827H

- 3186013 O-RING GASKET 06187 EPDM \varnothing 58 mm**
 for Dishwasher (BONNET) EOLYA BATTERIE 600
 EOLYA FRONTALE - EOLYA FRONTALE A
 EOLYA FRONTALE PLUS - EOLYA TOP



BONNET 2001827H

- 3455236 HEATING ELEMENT FOR BOILER 5000W 220V**
 immersed length 570 mm
 flange 80x27 mm - with probe receptacle
 for Dishwasher (BONNET) INO18 - INO19



BONNET 44018



Suitable for:

BONNET



3355602 HEATING ELEMENT FOR BOILER 5355W 240/415
 immersed length 340 mm
 ext. \varnothing flange 63 mm - with bulbholder sheathing
 complete with gasket OR \varnothing 58 mm (3186013)
 nut (3528232) and washer (3528238) on request
 for Dishwasher hood type (BONNET)
 INO60



BONNET 2001898H

BONNET 230034_V

BONNET 5845E

3186013 O-RING GASKET 06187 EPDM \varnothing 58 mm
 for Dishwasher (BONNET) EOLYA BATTERIE 600
 EOLYA FRONTALE - EOLYA FRONTALE A
 EOLYA FRONTALE PLUS - EOLYA TOP



BONNET 2001827H

3455243 HEATING ELEMENT FOR BOILER 6000W 230/400
 immersed length 285 mm
 external \varnothing flange 72 mm - with probe receptacle
 complete with O-ring gasket \varnothing 67 mm (3186014)



BONNET 903102

3355626 HEATING ELEMENT FOR BOILER 7600W 230V
 immersed length 385 mm
 width 65 mm - flange 80x27 mm



BONNET 2001624H

3355621 HEATING ELEMENT FOR BOILER 8000W 230/400
 immersed length 365 mm
 ext. \varnothing flange 63 mm - with bulbholder sheathing
 complete with gasket OR \varnothing 58 mm (3186013)
 nut (3528232) and washer (3528238) on request



BONNET 2001876H

3455233 HEATING ELEMENT FOR BOILER 9000W 220/380
 immersed length 515 mm
 external \varnothing flange 63 mm
 complete with O-ring gasket \varnothing 58 mm (3186013)
 for Dishwasher pull-through (BONNET) GTI



BONNET 1244688

BONNET 44496

3455244 HEATING ELEMENT FOR BOILER 9000W 230/400
 immersed length 385 mm
 external \varnothing flange 72 mm - with probe receptacle
 complete with O-ring gasket \varnothing 67 mm (3186014)



BONNET 903113

3455412 HEATING ELEMENT FOR TANK 1400W 230V
 immersed length 150 mm - width 120 mm
 with tube of dispelling paste
 for Dishwasher (BONNET) EOLYA FRONTALE PLUS



BONNET 2001380H



3455237 HEATING ELEMENT FOR TANK 1500W 220V
 immersed length 245 mm
 flange 80x27 mm
 for Dishwasher (BONNET) INO36
 for Dishwasher (BONNET) INO45



BONNET 903121

Suitable for:

3455229 HEATING ELEMENT FOR TANK 3000W 220/380V
 immersed length 295 mm
 external ø flange 55 mm
 complete with O-ring gasket ø 48 mm (3186001)
 for Dishwasher (BONNET) INO10 - INO11 - INO14L
 INO14LA - INO15



BONNET 40999

3355619 HEATING ELEMENT FOR TANK 600W 230V
 immersed length 155 mm
 width 47 mm - flange 50x27 mm
 for Dishwasher (BONNET) EOLYA CRISTAL 35
 EOLYA CRISTAL 35A - EOLYA CRISTAL 40
 EOLYA CRISTAL 40A



BONNET 2001625H

3355611 HEATING ELEMENT TANK 2050/2450W 220/240V
 immersed length 290 mm
 width 120 mm - fittings ø 10 mm
 for Glasswasher/Cupwasher (BONNET) VR1000R
 VR1000RAD - VR1500C - VR1500CAD



BONNET 5514E

3355291 HEATING ELEMENT TANK 2200W 230V
 immersed length 325 mm - width 80 mm
 fittings ø 14 mm
 for Dishwasher (BONNET) INO3F



BONNET 5065E

3355607 HEATING ELEMENT TANK 2750/3250W 220/240V
 immersed length 370 mm
 connections ø 10 mm
 for Dishwasher hood type (BONNET)
 INO60 - INO80
 for Dishwasher (BONNET) EOLYA FRONTALE
 EOLYA FRONTALE A



BONNET 2001864H

BONNET 5856E

3755073 HEATING ELEMENT TANK 3000W 230V
 immersed depth 320 mm
 width 55 mm - fittings ø 10 mm
 complete with nuts and gaskets
 for Dishwasher (BONNET)
 EOLYA TOP



BONNET 2001933H

BONNET 2002426H

3455408 HEATING ELEMENT WITH BLADES 2000W 240V
 immersed length 440 mm
 length of part with blades 400 mm
 width 195 mm - fittings ø 14 mm



BONNET 2001207H



Suitable for:

BONNET



Suitable for:

3355101 HEATING ELEMENT 3000W 220/380V

immersed length 410 mm
width 60 mm - flange 80x27 mm



BONNET 903101

3755946 HEATING ELEMENT 9500W 230V

immersed length 335 mm
flange external \varnothing 63 mm - bulbholder sheathing complete with gasket OR \varnothing 58 mm (3186013) nut (3528232) and washer (3528238) on request for Dishwasher (BONNET) EOLYA BATTERIE 600 EOLYA TOP



BONNET 2001941H

3186013 O-RING GASKET 06187 EPDM \varnothing 58 mm

for Dishwasher (BONNET) EOLYA BATTERIE 600
EOLYA FRONTALE - EOLYA FRONTALE A
EOLYA FRONTALE PLUS - EOLYA TOP



BONNET 2001827H

3455413 KIT HEATING ELEMENT 6000W 240/415V

immersed length 360 mm
external \varnothing flange 63 mm - with probe receptacle complete with O-Ring gasket \varnothing 58 mm (3186013) e co cap for contact protection for Dishwasher (BONNET) EOLYA BATTERIE 600



BONNET 2001858H

Hinges, catches and accessories

3053613 DOOR ROD STRIKE PIN

for Dishwasher (BONNET) EOLYA CRISTAL 40
EOLYA CRISTAL 40A



BONNET 2001083H

3053614 DOOR STRIKE PIN SMALL PLATE



BONNET 2001504H



Suitable for:

Suitable for:

3053615 DOOR SLIDE ROD 270 mm
for Dishwasher (BONNET) EOLYA FRONTALE
EOLYA FRONTALE A

3398609 DOOR RETAINER



BONNET 2001692H

BONNET 2001195H

3398607 STRIKE PLATE



BONNET 2001081H

3053601 RIGHT-HAND DOOR HINGE

3053052 SPRING FOR LEFTHAND DOOR HINGE
for Dishwasher (BONNET) INO3



BONNET 5565E

BONNET 5027E

3053053 SPRING FOR RIGHTHAND DOOR HINGE
for Dishwasher (BONNET) INO3

3053594 THREADED PIN FOR COVER SPRING
length 500 mm M10
for Dishwasher hood type (BONNET) INO61 - INO81



BONNET 5028E

BONNET 241448

Hose-end fittings

3315031 ELBOW FITTING INLET/OUTLET BOILER
thread 1/4" - tapered connection \varnothing 12 mm
for Dishwasher (BONNET) EOLYA FRONTALE
EOLYA FRONTALE A

3315014 RINSE HOSE-END FITTING
 \varnothing insert 12 mm
for all new models
for Dishwasher (BONNET) EOLYA BATTERIE 600
EOLYA FRONTALE PLUS - EOLYA TOP



BONNET 2001857H

BONNET 2001572H

BONNET 5835E



Suitable for:

BONNET



Suitable for:

3315102 T HOSE-END FITTING 11.5 mm



BONNET 2001574H

Hydraulic piping

6143174 HOSE RINSE 142 mm
external \varnothing 10 mm - internal \varnothing 7 mm
for Dishwasher (BONNET) EOLYA FRONTALE
EOLYA FRONTALE A



BONNET 2001758H

3243696 INSERT FOR CLAMP
for Dishwasher (BONNET) EOLYA FRONTALE
EOLYA FRONTALE A - EOLYA TOP



BONNET 2001849H

BONNET 5819E

3349489 PIPE
internal \varnothing 70 mm - external \varnothing 80 mm
temperature -40° to $+100^{\circ}\text{C}$
sold per meter



BONNET 14040601

3450736 PRESSURE SWITCH PIPE \varnothing 4x8.5 mm - 10 m
made of black rubber
external \varnothing 8.5 mm
internal \varnothing 4 mm



BONNET 15133K

3450336 PRESSURE SWITCH PIPE \varnothing 4x8.5 mm - 100 m
made of black rubber
external \varnothing 8.5 mm
internal \varnothing 4 mm



BONNET 15133K

3450622 PRESSURE SWITCH PIPE \varnothing 5x11 mm - 5 m
temperature -30° to $+110^{\circ}\text{C}$
operating pressure 10 bar
burst pressure 40 bar
non-toxic rubber hose
external \varnothing 11 mm
internal \varnothing 5 mm
5-m bundles
for 50-m bundles see 3450652
for Dishwasher (BONNET)
EOLYA BATTERIE 600 - EOLYA CRISTAL 35
EOLYA CRISTAL 35A - EOLYA CRISTAL 40
EOLYA CRISTAL 40A - EOLYA FRONTALE A
EOLYA FRONTALE PLUS
EOLYA TOP



BONNET 2001744H

BONNET 2002194H



BONNET



Suitable for:

3450176 PVC ø 4x7 mm - 150 m
for Dishwasher (BONNET) EOLYA CRISTAL 35
EOLYA CRISTAL 35A - EOLYA FRONTALE
EOLYA FRONTALE A



BONNET 2001748H

Suitable for:

3449298 PVC HOSE CLEAR ø 4x6 mm
sold per meter
for Dishwasher (BONNET)
EOLYA BATTERIE 600 - EOLYA CRISTAL 40
EOLYA CRISTAL 40A - EOLYA FRONTALE
EOLYA FRONTALE A - EOLYA FRONTALE PLUS
EOLYA FRONTALE PLUS - INO61



BONNET 2001722H

BONNET 2001745H

BONNET 904938

3450114 PVC PIPE ø 4/7 mm - 10 mt
alimentary
for Dishwasher (BONNET) EOLYA BATTERIE 600
EOLYA CRISTAL 35 - EOLYA CRISTAL 35A
EOLYA CRISTAL 40 - EOLYA CRISTAL 40A
EOLYA FRONTALE - EOLYA FRONTALE A
EOLYA FRONTALE PLUS



BONNET 2001723H

3450115 PVC PIPE ø 6/9 mm - 10 mt
alimentary
for Dishwasher (BONNET) EOLYA FRONTALE PLUS



BONNET 2001747H

3450151 REINFORCED RUBBER HOSE ø 38x46 mm
temperature -40+100°C
internal ø 38 mm - external ø 46 mm
SOLD PER METER



BONNET 28445

3450621 RUBBER PIPE 110°C. ø 10x16 mm - 5 m
temperature -30°+110°C
operating pressure 10 bar
burst pressure 40 bar
non-toxic rubber hose
external ø 16 mm
internal ø 10 mm
for 40 m rolls see 3450651
for Dishwasher (BONNET)
EOLYA CRISTAL 35 - EOLYA CRISTAL 35A
EOLYA CRISTAL 40 - EOLYA CRISTAL 40A
EOLYA FRONTALE - EOLYA FRONTALE A
EOLYA BATTERIE 600 - EOLYA FRONTALE PLUS



BONNET 2001726H

BONNET 2002221H

BONNET 2001728H

BONNET 3450621

BONNET 2001737H

3450125 RUBBER PIPE 20x30 mm
sold per meter
for Dishwasher (BONNET) EOLYA BATTERIE 600



BONNET 2001903H



Suitable for:

BONNET



Suitable for:

Indicator lights

3221547 GREEN INDICATOR LAMP 24V
head \varnothing 14 mm - hole \varnothing 12 mm
wire connection length 190 mm
nichel plated brass case



BONNET

3221499 GREEN INDICATOR LAMP 250V
head \varnothing 14 mm - hole \varnothing 13 mm



BONNET S297P15

3221544 GREEN INDICATOR LAMP 400V
head \varnothing 14 mm - hole \varnothing 12 mm
wire connection length 190 mm
nichel plated brass case



BONNET

5045040 INDICATOR LAMP GREEN 12/24V
head \varnothing 7 mm - hole \varnothing 6 mm
with cable length 220 mm



BONNET 2001678H

3221539 INDICATOR LAMP GREEN 240V
 \varnothing head 13.5 mm - \varnothing hole 10 mm - 120°C
wire connection length 200 mm



BONNET 308334

3221592 INDICATOR LAMP GREEN 250V
 \varnothing hole 6 mm - 120°C



BONNET 907533

6216029 INDICATOR LAMP ORANGE 12/24V
head \varnothing 7 mm - hole \varnothing 6 mm
with cable length 200 mm



BONNET 2001677H

5047239 INDICATOR LAMP ORANGE 250V
hole \varnothing 6 mm - 120°C



BONNET 907534

3221514 INDICATOR LIGHT RED 250V
head \varnothing 14 mm - hole \varnothing 12 mm
wire connection length 190 mm
nichel plated brass case



BONNET

3221096 ORANGE INDICATOR LAMP 230V
head \varnothing 7 mm - hole \varnothing 6 mm
wire connection length 210 mm



BONNET 2002147H



Suitable for:

3221546 ORANGE INDICATOR LAMP 24V
 head \varnothing 14 mm - hole \varnothing 12 mm
 wire connection length 190 mm
 nichel plated brass case



BONNET

Suitable for:

3221515 ORANGE INDICATOR LAMP 250V
 head \varnothing 14 mm - hole \varnothing 13 mm



BONNET S298P15

BONNET 645298

3221519 ORANGE INDICATOR LAMP 400V
 head \varnothing 7 mm - hole \varnothing 6 mm
 connection by PVC wires length 250 mm



BONNET 905445

3221543 ORANGE INDICATOR LAMP 400V
 head \varnothing 14 mm - hole \varnothing 12 mm
 wire connection length 190 mm
 nichel plated brass case



BONNET

3221548 RED INDICATOR LAMP 24V
 head \varnothing 14 mm - hole \varnothing 12 mm
 wire connection length 190 mm
 nichel plated brass case



BONNET

3221498 RED INDICATOR LAMP 250V
 head \varnothing 14 mm - hole \varnothing 13 mm



BONNET S296P15

BONNET 645296

3221500 RED INDICATOR LAMP 250V
 head 14x14 mm - hole \varnothing 14 mm



BONNET 907501

3221545 RED INDICATOR LAMP 400V
 head \varnothing 14 mm - hole \varnothing 12 mm
 wire connection length 190 mm
 nichel plated brass case



BONNET

3221021 RED LAMP RECEPTACLE
 head \varnothing 14.5 mm - hole \varnothing 12 mm



BONNET 904359

3221646 WHITE LAMP 250V
 for Dishwasher (BONNET) INO61
 for Dishwasher hood type (BONNET) INO81
 for Dishwasher (BONNET) INO61



BONNET 907535



Suitable for:

BONNET



Suitable for:


Inlet hoses

3449055 INLET ELBOW HOSE \varnothing 3/4" FF 1500 mm
thermoplastic hose \varnothing 13x19 mm
brass fittings \varnothing 3/4"F with gaskets
max temperature 90°C
max pressure 10 bar
with WRAS approval



BONNET 42551

3449056 INLET ELBOW HOSE \varnothing 3/4" FF 2000 mm
thermoplastic hose \varnothing 13x19 mm
brass fittings \varnothing 3/4"F with gaskets
max temperature 90°C
max pressure 10 bar
with WRAS approval
for Dishwasher (BONNET) EOLYA BATTERIE 600
EOLYA CRISTAL 35 - EOLYA CRISTAL 35A
EOLYA CRISTAL 40 - EOLYA CRISTAL 40A
EOLYA FRONTALE - EOLYA FRONTALE A - EOLYA TOP



BONNET 2001738H

3449072 INLET ELBOW HOSE \varnothing 3/4" FF 2000 mm
EPDM hose covered in nylon braiding \varnothing 10x14 mm
brass fittings 3/4"F
max temperature 90°C
max pressure 10 bar
for Dishwasher hood type (BONNET) IN080
for Pan/utensilwashing machines (BONNET)
EOLYA CRISTAL 35 - EOLYA CRISTAL 35A
EOLYA CRISTAL 40 - EOLYA CRISTAL 40A
EOLYA FRONTALE PLUS



BONNET 2001753H

Ironmongery (screws,nuts,washers)

3528106 HEXAGONAL HEAD SCREW M5x16
st./steel - UNI 5739 - DIN 933 - ISO 4017



BONNET 16055K


BONNET 989018

6080998 PLASTIC SCREW M4x6 mm
for RIVER 282
for Dishwasher (BONNET) EOLYA TOP



BONNET 2001770H

5061324 WASHER FLAT PTFE \varnothing 22x9.5x1 mm



BONNET 2002267H



Magnets

3737003 COVER MAGNET
for Dishwasher hood type (BONNET) INO81



BONNET 900087

6999108 MAGNET FOR MICRO SWITCH DOOR
dimensions 23x18 mm
for Dishwasher (BONNET) EOLYA FRONTALE
EOLYA FRONTALE A



BONNET 2001294H

Manifolds for dishwashers

3743860 BOTTOM MANIFOLD
for Dishwasher hood type (BONNET) INO61 - INO81



BONNET 56596

BONNET 981261

3186333 EPDM O-RING GASKET 06200
for Dishwasher (BONNET) INO45 - INO61



BONNET 15082K

BONNET 966084

3743271 EXTERNAL WASH - RINSE PIPE



BONNET 2001126H

3743270 EXTERNAL WASH PIPE
for Dishwasher (BONNET) EOLYA FRONTALE
EOLYA FRONTALE A



BONNET 2001128H

3450185 HOSE OUTLET FOR WASH CONVEYOR H620 mm




BONNET 2001750H

6441010 INSERT FOR MANIFOLD SEALING
internal \varnothing 18 mm
for Dishwasher (BONNET) EOLYA CRISTAL 40
EOLYA CRISTAL 40A



BONNET 2001976H

3243686 NUT FOR SPINDLE SUPPORT
for Dishwasher (BONNET) EOLYA CRISTAL 35
EOLYA CRISTAL 35A - EOLYA CRISTAL 40
EOLYA CRISTAL 40A



BONNET 2001196H



Suitable for:

BONNET




3743202 WASH OUTLET HOSE GOLD COMPLETE
for Dishwasher (BONNET) EOLYA TOP



BONNET 2001129H

BONNET 2001189H

5036646 FITTING WASH UPPER EXTERNAL
hose-end \varnothing 45 / 12 mm
for Dishwasher (BONNET) EOLYA TOP



BONNET 2001580H

Suitable for:

3248215 COUPLING FOR BOTTOM EXTERNAL WASH
external connection \varnothing 45.5 mm
internal fitting \varnothing 10.5 mm
for Dishwasher (BONNET) EOLYA TOP



BONNET 2001579H

3786044 GASKET FLAT EPDM \varnothing 61x47x2 mm
for Dishwasher (BONNET) EOLYA TOP



BONNET 2001368H

3743072 WASHING UPPER MANIFOLD
total length 415 mm



BONNET 5805E

Microswitches

3240608 MAGNETIC MICROSWITCH
250-mm cable
for Dishwasher (BONNET)
EOLYA BATTERIE 600 - EOLYA CRISTAL 35
EOLYA CRISTAL 35A - EOLYA CRISTAL 40
EOLYA CRISTAL 40A - EOLYA FRONTALE
EOLYA FRONTALE A - EOLYA FRONTALE PLUS
EOLYA TOP



BONNET 2001136H

BONNET 2001844H

BONNET 2002431H

3240610 MAGNET FOR HOOD MICROSWITCH
dimensions 40x13x8 mm
for Dishwasher (BONNET)
EOLYA FRONTALE - EOLYA FRONTALE A - EOLYA TOP



BONNET 2001884H

BONNET 2002082H

BONNET 2002096H



Suitable for:

3240189 MICRO SWITCH M1DX20 10A 250V



BONNET 1700340

BONNET 300682

BONNET 900502

Suitable for:


3240933 MICROSWITCH KBE1S11P 3A 240V
for Dishwasher (BONNET) INO18LA - INO19GTI
INO19T
for Dishwasher (BONNET) INO14



BONNET 900506

BONNET 904303

3240601 MICROSWITCH N16 250V
contact capacity 16A 250V
for Glasswasher/Cupwasher (BONNET) VR1000R
VR1000RAD - VR1500C - VR1500CAD




BONNET 3755E

3240410 MICROSWITCH 16(4)A 250V



BONNET 303621


3803002 POSITION MICROSWITCH 15A 380V
crouzet 83.850.301



BONNET 900506


Non-return and expansion valves

3523601 NON-RETURN VALVE
for Dishwasher (BONNET) EOLYA CRISTAL 35
EOLYA CRISTAL 35A - EOLYA CRISTAL 40
EOLYA CRISTAL 40A - EOLYA TOP



BONNET 2001916H

3526278 NON-RETURN VALVE
for Dishwasher (BONNET) EOLYA FRONTALE
EOLYA FRONTALE A



BONNET 2001179H



Suitable for:

BONNET



Suitable for:

OR and ORM gaskets

3786460 EPDM GASKET ORM 1620-50



BONNET 966032

3786454 EPDM O-RING GASKET 0153

for Dishwasher (BONNET) EOLYA CRISTAL 35
EOLYA CRISTAL 35A - EOLYA CRISTAL 40
EOLYA CRISTAL 40A



BONNET 2001373H

5022973 GASKET O-RING 04275 EPDM
for Dishwasher (BONNET) EOLYA BATTERIE 600




BONNET 2001911H

3786332 GASKET ORM 1620-40 EPDM
for Dishwasher (BONNET) INO10 - INO16 - INO16B
INO16L - INO16LA - INO20 - INO35 - INO50



BONNET 1276E

6456074 O-RING 02325 EPDM
for pump housing
for Dishwasher (BONNET) EOLYA CRISTAL 35
EOLYA CRISTAL 35A - EOLYA CRISTAL 40
EOLYA CRISTAL 40A



BONNET 2001378H

Pegs

3055608 FEEDING SQUARE
for Dishwasher pull-through (BONNET) LT90
for Dishwasher (BONNET) LT300 - LT90



BONNET 241849

**Pegs**

3055679 PLASTIC PEG
for Dishwasher pull-through (BONNET)



BONNET 30754

3055678 FEEDING PIN
for Dishwasher pull-through (BONNET)



BONNET 30751

5033995 PLUG FOR COVEYOR HALT \varnothing 17.5x25 mm



BONNET 2001676H

Pins

3743859 BOTTOM WATER INLET PIPE
for Dishwasher (BONNET) INO36
for Dishwasher hood type (BONNET) INO81



BONNET 983560

3243131 SPINDLE FOR WASH ARM ASSEMBLY



BONNET 5043E

3243685 WASH ARM ASSEMBLY SPINDLE SUPPORT
for Dishwasher (BONNET) EOLYA CRISTAL 35
EOLYA CRISTAL 35A - EOLYA CRISTAL 40
EOLYA CRISTAL 40A



BONNET 2001666H

Pressure reducers

6927150 REDUCER PRESSURE 1/2"



BONNET 2001609H



Suitable for:

BONNET



Suitable for:

Pressure switches

3320003 "Y" CONNECTOR
for fitting with two pressure switches




BONNET 2001576H

3320018 PRESSURE SWITCH 1 LEVEL
calibration 45/25 mm
250V 16A
max operating temperature 85°C



BONNET 2002189H


3320019 PRESSURE SWITCH 1 LEVEL
calibration 55/35 mm
250V 16A
max operating temperature 85°C
for Dishwasher (BONNET) EOLYA FRONTALE
for Glasswasher/Cupwasher (BONNET) VR1000R - VR1000RAD - VR1500C - VR1500CAD
for Dishwasher (BONNET) EOLYA FRONTALE A



BONNET 2001841H

BONNET 5827E

3320020 PRESSURE SWITCH 1 LEVEL
calibration 110/60 mm
250V 16A
max operating temperature 85°C
for Dishwasher (BONNET) EOLYA BATTERIE 600 EOLYA TOP



BONNET 2001959H

BONNET 3882E

3320029 PRESSURE SWITCH 1 LEVEL
calibration 40/20 mm
250V 16A
max operating temperature 85°C
for Dishwasher (BONNET) EOLYA TOP



BONNET 2002189H

3320030 PRESSURE SWITCH 1 LEVEL
calibration 55/20 mm
250V 16A
max operating temperature 85°C
for Dishwasher hood type (BONNET) INO60
for Dishwasher (BONNET) INO60



BONNET 5849E

3320075 PRESSURE SWITCH 1 LEVEL
calibration 50/20 mm
250V 16A
max operating temperature 85°C



BONNET 901311


3320084 PRESSURE SWITCH 1 LEVEL
calibration 140/110 mm
250V 16A



BONNET 2001549H



3320111 PRESSURE SWITCH 1 LEVEL
 calibration 35/17 mm
 250V 16(4)A
 for Dishwasher (BONNET) EOLYA BATTERIE 600
 EOLYA CRISTAL 35 - EOLYA CRISTAL 35A
 EOLYA CRISTAL 40 - EOLYA CRISTAL 40A
 EOLYA FRONTALE PLUS



BONNET 2001877H

3320112 PRESSURE SWITCH 1 LEVEL
 calibration 180/70 mm
 250V 16(4)A
 for Dishwasher (BONNET) EOLYA BATTERIE 600



BONNET 2001875H

BONNET 5915E

3320188 PRESSURE SWITCH 1 LEVEL
 calibration 60/30 mm
 for Dishwasher (BONNET) INO36
 for Dishwasher (BONNET) INO45



BONNET 901300

3320194 PRESSURE SWITCH 1 LEVEL
 calibration 70/50 mm
 230V 16A



BONNET 901026

3320235 PRESSURE SWITCH 1 LEVEL
 calibration 110/75 mm
 250V 16A
 for drain pump
 for Dishwasher (BONNET) EOLYA FRONTALE
 EOLYA FRONTALE A



BONNET 2001548H

3320242 PRESSURE SWITCH 1 LEVEL
 calibration 60/20-110 mm
 250V 15A
 for Dishwasher (BONNET) INO3F



BONNET 5040E

3320192 PRESSURE SWITCH 2 LEVELS
 1st level calibration 70/40 mm
 2nd level calibration 120/60 mm
 230V 16A
 for Dishwasher (BONNET)



BONNET 901303

3320245 PRESSURE SWITCH 2 LEVELS
 1st level calibration 200/110 mm
 2nd level calibration 230/200 mm
 for Dishwasher (BONNET)
 INO61
 for Dishwasher hood type (BONNET)
 INO81
 for Dishwasher (BONNET) INO61



BONNET 914136



Suitable for:

BONNET



Suitable for:

6224018 SET PRESSURE SWITCH ANALOGICAL LA50
for Dishwasher (BONNET) EOLYA FRONTALE PLUS



BONNET 2002283H

Pump motors

3122680 ELECTRIC PUMP AP C22110DX 0.10HP
inlet external \varnothing 28 mm - outlet external \varnothing 28 mm
0.10HP 230V 50Hz - capacitor 6.3 μ f
for Dishwasher hood type (BONNET) INO80



BONNET

3122559 ELECTRIC PUMP AP 2011DX 2HP
inlet external \varnothing 63 mm - outlet external \varnothing 54 mm
2HP 220/400V 50Hz 5.8/3.4A - motor revolut. 2800
for Dishwasher (BONNET) INO20



BONNET 91369308

3122024 SEAL MECHANICAL FOR SHAFT \varnothing 12 mm
metal seal \varnothing internal 11 mm - \varnothing external 24 mm
height 15.5 mm
back. element \varnothing internal 14 mm - \varnothing external 24 mm
height 8 mm
for Dishwasher (BONNET) EOLYA FRONTALE
EOLYA FRONTALE A
for Dishwasher hood type (BONNET)
INO60



BONNET 1475E

BONNET 2001960H

BONNET 904151

3122684 ELECTRIC PUMP AP 391120SX 0.75HP
inlet external \varnothing 45 mm - outlet external \varnothing 40 mm
0.75HP 230V 50Hz - motor revolutions 2700
capacitor 12.5 μ f - flow rate 270 L/min.
for Dishwasher hood type (BONNET) INO60



3122024 SEAL MECHANICAL FOR SHAFT \varnothing 12 mm
metal seal \varnothing internal 11 mm - \varnothing external 24 mm
height 15.5 mm
back. element \varnothing internal 14 mm - \varnothing external 24 mm
height 8 mm
for Dishwasher (BONNET) EOLYA FRONTALE
EOLYA FRONTALE A
for Dishwasher hood type (BONNET)
INO60



BONNET

BONNET 1475E

BONNET 2001960H

BONNET 904151



BONNET



Suitable for:

Suitable for:

3122028 ELECTRIC PUMP FIR 1211SX 0.75HP
 inlet external \varnothing 63 mm - outlet external \varnothing 48 mm
 0.75HP 220/400V 50Hz 2.1/1.2A - motor revol. 2800
 flow rate 360 l/min.

3122024 SEAL MECHANICAL FOR SHAFT \varnothing 12 mm
 metal seal \varnothing internal 11 mm - \varnothing external 24 mm
 height 15.5 mm
 back. element \varnothing internal 14 mm - \varnothing external 24 mm
 height 8 mm
 for Dishwasher (BONNET) EOLYA FRONTALE
 EOLYA FRONTALE A
 for Dishwasher hood type (BONNET)
 INO60



BONNET 904003


BONNET 1475E

BONNET 2001960H

BONNET 904151

3122482 ELECTRIC PUMP FIR 2211DX 0.10HP
 inlet external \varnothing 28 mm - outlet external \varnothing 28 mm
 0.10HP 230V 50Hz 1.1A - motor revolutions 2800
 capacitor 5 μ F
 for Dishwasher hood type (BONNET) INO80

3122147 HOUSING FOR PUMP
 inlet external \varnothing 28 mm
 outlet external \varnothing 28 mm



BONNET 5519E

BONNET 5945E

3122040 IMPELLER \varnothing 72 mm
 for Dishwasher (BONNET) EOLYA BATTERIE 600

3186271 OR-GASKET 04312 EPDM
 for Dishwasher (BONNET) EOLYA BATTERIE 600



BONNET 2000005

BONNET 2000004

3122058 SEAL ROTARY \varnothing 11 mm BACK FACE 8 mm
 for Dishwasher (BONNET)
 INO45
 EOLYA BATTERIE 600



BONNET 2000006
BONNET 3291E

BONNET 2001245H
BONNET 904151

BONNET 2001955H



Suitable for:

3122038 ELECTRIC PUMP FIR 2212SX 0.10HP
 inlet external \varnothing 28 mm - outlet external \varnothing 28 mm
 0.10HP 230V 50Hz 1.1A - motor revolutions 2700
 capacitor 5 μ f - flow rate 80 L/min.
 for Dishwasher (BONNET) PF700



BONNET 1244668

Suitable for:

3068008 CAPACITOR μ F 5 450V 50/60Hz
 operating temperature $-25+85^{\circ}\text{C}$
 in compliance with EEC 93/68 and EEC 92/31 regulat
 for Dishwasher (BONNET) EOLYA CRISTAL 35
 EOLYA CRISTAL 35A



BONNET 2000001


BONNET 2001120H

3122040 IMPELLER \varnothing 72 mm
 for Dishwasher (BONNET) EOLYA BATTERIE 600




BONNET 2000005

3122719 ELECTRIC PUMP FIR 2275SX 3.60HP
 inlet external \varnothing 63 mm - outlet external \varnothing 63 mm
 3.60HP 220/400V 50Hz 10/5.8A - motor revolut. 2800



BONNET 30827

3786468 GASKET FOR PUMP FIR 2275 3.6HP



BONNET

3122660 HOUSING FOR PUMP FIR 2274-2275
 inlet - outlet \varnothing 63 mm
 for Dishwasher (BONNET) EOLYA BATTERIE 600



BONNET 2001951H

BONNET 904112

3122174 IMPELLER FOR PUMP FIR 2275 3.7HP \varnothing 135 m
 for Dishwasher (BONNET) EOLYA BATTERIE 600



BONNET 1445E

BONNET 2001954H

BONNET 904128

3453026 SEAL ROTARY AND BACK FACE FIR
 for PUMPS 2275 and 2274



BONNET 904115

Suitable for:

3122108 ELECTRIC PUMP FIR 3911SX 0.75HP
 inlet external \varnothing 45 mm - outlet external \varnothing 40 mm
 0.75HP 230V 50Hz 4A - motor revolutions 2800
 capacitor 12.5 μ f - flow rate 270 L/min
 for Dishwasher (BONNET) INO6



BONNET 54103

BONNET 904001

3122082 HOUSING FOR PUMP
 inlet external \varnothing 45 mm
 outlet external \varnothing 40 mm
 for Dishwasher (BONNET) INO6



BONNET 3290E

3122024 SEAL MECHANICAL FOR SHAFT \varnothing 12 mm
 metal seal \varnothing internal 11 mm - \varnothing external 24 mm
 height 15.5 mm
 back. element \varnothing internal 14 mm - \varnothing external 24 mm
 height 8 mm
 for Dishwasher (BONNET) EOLYA FRONTALE
 EOLYA FRONTALE A
 for Dishwasher hood type (BONNET)
 INO60



BONNET 1475E

BONNET 2001960H

BONNET 904151

3122717 ELECTRIC PUMP FIR 4263SX 1HP
 inlet external \varnothing 45 mm - outlet external \varnothing 41 mm
 1HP 230V 50Hz 5A - motor revolutions 2750
 capacitor 12.5 μ f
 for Dishwasher (BONNET) PF700




BONNET 1244670

BONNET 904030

Suitable for:

3122020 GASKET FOR PUMP HOUSING
 for Dishwasher (BONNET) INO36



BONNET 3292E

BONNET 904101

3122110 IMPELLER \varnothing 96 mm
 for Dishwasher (BONNET) INO6



BONNET 3203E

5036904 ELECTRIC PUMP LGB CRC-RDX 0,27HP
 entry \varnothing external 28 mm - exit \varnothing external 26 mm
 0,27HP 230V 50Hz 0,9A - capacitor 4 μ F



BONNET 2002220H



Suitable for:

BONNET




3122189 ELECTRIC PUMP LGB W 180SX 0.25HP
 with manifold and filter
 0.25HP 230V 50Hz 1A - motor revolutions 2800
 capacitor 5 µf
 for Dishwasher (BONNET) EOLYA CRISTAL 35
 EOLYA CRISTAL 35A




BONNET 2001296H

3122196 ELECTRIC PUMP LGB W 210SX 0.32HP
 with manifold and filter
 0.32HP 230V 50Hz 1.1A - motor revolutions 2800
 capacitor 6.3 µf
 for Dishwasher (BONNET) EOLYA CRISTAL 40
 EOLYA CRISTAL 40A




BONNET 2001297H

3122860 ELECTRIC PUMP LGB ZFC1121DX 0.32HP
 inlet external ø 28 mm - outlet external ø 26 mm
 0.32HP 230V 50Hz - capacitor 6.3 µF
 for Dishwasher (BONNET) EOLYA FRONTALE PLUS



BONNET 2001524H

3122631 ELECTRIC PUMP LGB ZF400SX 0.80HP
 inlet external ø 50 mm - outlet external ø 50 mm
 0.80HP 230V 50Hz 3.8A - motor revolutions 2800
 capacitor 16 µf
 for Dishwasher (BONNET)
 EOLYA FRONTALE A
 EOLYA FRONTALE - EOLYA FRONTALE A



BONNET 2001513H

3122802 ELECTROPUMP FIR 1227LH 2.70HP
 inlet external ø 63 mm - outlet external ø 48 mm
 2.70HP 220/400V 50Hz - Rpm 2800



BONNET 904034

3122787 ELECTROPUMP FIR 4225/2SX 1.90HP
 inlet external ø 63 mm - outlet external ø 48 mm
 1.90HP 220/400V 50Hz



BONNET 2001515H

BONNET 2001980H

5023441 ELECTROPUMP FIR 4225LH 1.47HP
 inlet external ø 63 mm - outlet external ø 48 mm
 1.47HP 220/400V 50Hz
 for Dishwasher hood type (BONNET)
 INO60



BONNET 2001423H

BONNET 5901E

3122804 ELECTROPUMP FIR 4263LH 1HP
 inlet external ø 45 mm - outlet external ø 40 mm
 1HP 230V 50Hz - capacitor 12.5 µf
 for Dishwasher (BONNET) LCM - LCT - 932H40



BONNET 1244735

BONNET 490000177

Suitable for:

3122862 ELECTROPUMP FIR 5213RH 0.10HP
 inlet external \varnothing 30 mm - outlet external \varnothing 28 mm
 0.10HP 230V 50Hz 1.1A - Rpm 2700
 capacitor 5 μ f
 for Dishwasher hood type (BONNET)
 INO61 - INO81
 for Dishwasher (BONNET) EOLYA BATTERIE 600



BONNET 904135

BONNET 904156

Suitable for:

3122879 HOUSING FOR PUMP FIR 5213
 for Dishwasher (BONNET) EOLYA BATTERIE 600



BONNET 2001772H

3122832 ELECTROPUMP FIR 5295LH 2.15HP
 inlet external \varnothing 63 mm - outlet external \varnothing 50 mm
 2.15HP 220/400V 50Hz



BONNET 2001424H


3122026 GASKET FOR PUMP HOUSING
 for Dishwasher hood type (BONNET)
 INO60



BONNET 1476E

BONNET 2001956H

3122454 ELECTROPUMP LGB PS46RH 0.60HP
 inlet \varnothing 3/8" F - outlet \varnothing 3/8" F
 0.60HP 230V 50Hz 2.5A - Rpm 2800
 capacitor 10 μ F
 with 2 hose-end fittings \varnothing 3/8" x 12mm
 for pressure increase




BONNET 2001856H

3122829 ELECTROPUMP LGB ZF400VLH 1HP 230V
 inlet external \varnothing 50 mm - outlet external \varnothing 50 mm
 1HP 230V 50Hz - capacitor 16 μ F



BONNET 2001521H

5007992 ELECTROPUMP VOLUMETRIC LGB PPL46DX
 0.32Kw 230V 50Hz capacitor 8 μ F
 hose-end fitting inlet-outlet \varnothing 12 mm
 for Dishwasher (BONNET) EOLYA TOP



BONNET 2001516H

BONNET 5842E



Suitable for:

BONNET



3122450 PUMP MOTOR LGB ZF400SX 1.5HP
inlet external \varnothing 60 mm - outlet external \varnothing 50 mm
1.5HP 230V 50Hz 3.8A - rpm 2800
capacitor 16 μ f
for Dishwasher (BONNET) EOLYA TOP



BONNET 2001517H

6080845 IMPELLER \varnothing 101 mm
for RIVER 282
for Dishwasher (BONNET) EOLYA TOP



BONNET 2001707H

3122632 SEAL ROTARY \varnothing 13 BACK FACE 5.5 mm
for Dishwasher (BONNET)
EOLYA CRISTAL 35 - EOLYA CRISTAL 35A
EOLYA CRISTAL 40 - EOLYA CRISTAL 40A
EOLYA FRONTALE A - EOLYA FRONTALE PLUS
EOLYA TOP



BONNET 2001280H

BONNET 2002418H

Suitable for:

3122876 HOUSING FOR PUMP LGB ZF400SX
inlet \varnothing 60 mm - outlet \varnothing 50 mm



BONNET 2002421H

3122365 O-RING 02475 EPDM
for Dishwasher (BONNET)
EOLYA TOP
EOLYA FRONTALE - EOLYA FRONTALE A



BONNET 1255E

BONNET 2001837H

BONNET 5620E

BONNET 2001345H


BONNET 2002422H

BONNET 2001351H

BONNET 3710E

Relays

3351154 BASE OCTAL ES8 10A 400V
8 poles
for Dishwasher (BONNET) INO60
for Dishwasher hood type (BONNET) INO80



BONNET 5937E

3351901 POWER RELAY FINDER 60.62.8.230.0000
230V 50/60Hz
2 exchange contacts 10A



BONNET 2001867H



Suitable for:

3351021 POWER RELAY FINDER 62.82.8.230.0000
 230V 50/60Hz
 2 exchange contacts 16A
 for Dishwasher (BONNET) EOLYA BATTERIE 600
 EOLYA TOP



BONNET 2001873H

Suitable for:

3351029 POWER RELAY FINDER 62.82.8.230.0300
 230V 50/60Hz
 2 contacts NO 16A
 for Dishwasher (BONNET) EOLYA CRISTAL 35
 EOLYA CRISTAL 35A - EOLYA CRISTAL 40
 EOLYA CRISTAL 40A



BONNET 2002044H

3351008 POWER RELAY FINDER 62.83.8.230.0000
 230V 50/60Hz
 3 exchange contacts 16A
 for Dishwasher (BONNET) EOLYA CRISTAL 35
 EOLYA CRISTAL 35A - EOLYA CRISTAL 40
 EOLYA CRISTAL 40A - EOLYA FRONTALE
 EOLYA FRONTALE A - INO45 - INO61



BONNET 2001258H

BONNET 900073

3351602 POWER RELAY FINDER 65.31.8.230.0300
 230V 50/60Hz
 1 contact NO 30A
 for Dishwasher (BONNET) EOLYA CRISTAL 35
 EOLYA CRISTAL 35A - EOLYA CRISTAL 40
 EOLYA CRISTAL 40A - EOLYA FRONTALE A
 EOLYA FRONTALE PLUS - EOLYA TOP



BONNET 2001929H

BONNET 300283

3351605 RELAY POWER FINDER 60.63.8.230.0000
 230V 50/60Hz
 3 exchange contacts 10A



BONNET 2001887H

Rings

6303029 DRIP RING ø 90 mm
 for Dishwasher (BONNET) EOLYA BATTERIE 600
 EOLYA FRONTALE - EOLYA FRONTALE A



BONNET 2001012H

6303032 RING MADE OF PLASTIC ø 44x40x3 mm
 for DISHWASHER ELETTOBAR RIVER81
 for Dishwasher (BONNET)
 EOLYA FRONTALE - EOLYA FRONTALE A
 EOLYA FRONTALE PLUS - EOLYA TOP



BONNET 2001023H

BONNET 2002494H



Suitable for:

BONNET



Suitable for:

Rinse aid pumps and accessories

3090162 DOSING PUMP FOR RINSE AID
for Dishwasher hood type (BONNET) INO60



BONNET 5958E

3090352 FOOT FILTER OF PP
for PIPE 4x6 mm
for DISPENSER SEKO
for Dishwasher (BONNET)
EOLYA BATTERIE 600 - EOLYA CRISTAL 35
EOLYA CRISTAL 35A - EOLYA CRISTAL 40
EOLYA CRISTAL 40A - EOLYA FRONTALE
EOLYA FRONTALE A - EOLYA FRONTALE PLUS



BONNET 2001260H

BONNET 2002447H

5059435 HOSE THERMOPLASTIC 185 mm
internal \varnothing 6 mm - external \varnothing 10 mm - for detergent



BONNET 2002475H

3090040 HYDRAUL.RINSE AID INJECTOR N6 E 05 G4G6
with diaphragm in EPDM
minimum pressure 0.5 bar
intake side connection for tube 4 mm.
pressure side connection for tube 6 mm.
for Dishwasher hood type (BONNET) INO60
for Dishwasher (BONNET) INO5



BONNET 30655

3090308 HYDRAULIC DISPENSER DIB-E
attacco posteriore aperto per collegamento con la
auxiliary pump
hydraulic system for rinse aid dosing
in dishwashers, it does not need
power connection
adjustable flow rate: 0÷3 cm³
connection between solenoid valve and boiler (DIB-
for Dishwasher (BONNET) EOLYA FRONTALE PLUS



BONNET 2001899H

3090601 HYDRAULIC INJECTOR SP205
complete with spring and bellows
for Dishwasher (BONNET) EOLYA CRISTAL 35
EOLYA CRISTAL 35A



BONNET 2001289H

3090603 BELLOWS FOR HYDRAULIC INJECTOR
for Dishwasher (BONNET) EOLYA CRISTAL 35
EOLYA CRISTAL 35A



BONNET 2001647H



Suitable for:

3090148 HYDRAULIC DISPENSER EXTENSION
for Dishwasher (BONNET) EOLYA CRISTAL 35
EOLYA CRISTAL 35A



BONNET 2001591H

BONNET



Suitable for:

3090602 INLET VALVE
for Dishwasher (BONNET) EOLYA CRISTAL 35
EOLYA CRISTAL 35A - EOLYA FRONTALE PLUS



BONNET 2001568H

3090044 HYDRAULIC RINSE AID INJECTOR
0÷3 cm cycle flow rate adjustment screw
complete with hose-end elbows
non-return valve with metal bushing
T-fitting
transparent rubber hose
for Dishwasher (BONNET) INO36AD
for Dishwasher (BONNET) INO45



BONNET 914207

6926278 RINSE AID DOSING PUMP DIB-E
back connection closed
for Dishwasher (BONNET) EOLYA CRISTAL 40
EOLYA CRISTAL 40A - EOLYA FRONTALE
EOLYA FRONTALE A - EOLYA TOP



BONNET 2001520H

3090038 RINSE AID INJECTOR DB2
power supply 220/240V 50Hz
screw for flow rate regulation
for Dishwasher (BONNET) INO8
for Glasswasher/Cupwasher (BONNET) INO7F - VR1000R
for Glasswasher/Cupwasher (BONNET) VR1000RAD



BONNET 42864

3090224 RINSE AID INLET FILTER
for Dishwasher (BONNET) EOLYA CRISTAL 35
EOLYA CRISTAL 35A - EOLYA CRISTAL 40
EOLYA CRISTAL 40A - EOLYA FRONTALE
EOLYA FRONTALE A - EOLYA FRONTALE PLUS



BONNET 2001261H

Rotary switches

3057050 CONNECTING BRACKET 28x21x16 mm
distance between hooking brackets 27 mm
f/connection between selector switch and thermostat.



BONNET 300177

BONNET 905109

3057279 ROTARY SELECTOR SWITCH
5 positions 0 - 4 - 16A - 690V - 50/60Hz
for Dishwasher (BONNET) INO11 - INO14L - INO14LA



BONNET 28627



Suitable for:

BONNET



Suitable for:

3057333 SELECTOR SWITCH WITH KNOB
ELEBERG SCH-X021 16A
for Dishwasher hood type (BONNET) IN081



BONNET 900086

Salt containers and accessories

3067603 CAP FOR SALT CONTAINER
for Dishwasher (BONNET) EOLYA FRONTALE PLUS
for Glasswasher/Cupwasher (BONNET)
VR1000



BONNET 2001828H

BONNET 5542E

3067002 GASKET FOR CONTAINER
external \varnothing 82 mm
internal \varnothing 64 mm
thickness 3 mm
for Dishwasher (BONNET) EOLYA CRISTAL 35
EOLYA CRISTAL 35A - EOLYA CRISTAL 40
EOLYA CRISTAL 40A - EOLYA FRONTALE
EOLYA FRONTALE A - EOLYA FRONTALE PLUS



BONNET 2001962H

3067604 RETAINING NUT FOR CAP
for Glasswasher/Cupwasher (BONNET)
VR1000



BONNET 2001829H

BONNET 5548E

3067001 SALT CONTAINER
for Glasswasher/Cupwasher (BONNET)
VR1000R



BONNET 315728

BONNET 915405

3067002 GASKET FOR CONTAINER
external \varnothing 82 mm
internal \varnothing 64 mm
thickness 3 mm
for Dishwasher (BONNET) EOLYA CRISTAL 35
EOLYA CRISTAL 35A - EOLYA CRISTAL 40
EOLYA CRISTAL 40A - EOLYA FRONTALE
EOLYA FRONTALE A - EOLYA FRONTALE PLUS



BONNET 2001962H



Suitable for:

3067007 SALT CONTAINER CAP



BONNET

BONNET



Suitable for:

3067005 SALT CONTAINER RING NUT
for Dishwasher (BONNET) EOLYA CRISTAL 35
EOLYA CRISTAL 35A - EOLYA CRISTAL 40
EOLYA CRISTAL 40A - EOLYA FRONTALE
EOLYA FRONTALE A



BONNET 2001843H

3067602 SALT CONTAINER ASSEMBLY 85x100 mm
new model
for E35/40/41/42/45/46/50/51/55-MISTRAL40/51
NIAGARA35/40/45/51-RIVER48/50/61
for Dishwasher (BONNET) EOLYA CRISTAL 35
EOLYA CRISTAL 35A - EOLYA CRISTAL 40
EOLYA CRISTAL 40A - EOLYA FRONTALE
EOLYA FRONTALE A - VR1500R/CAD - VR1500R/RAC
for Glasswasher/Cupwasher (BONNET)
VR1000



BONNET 2001838H

BONNET 5622E


3067006 SALT CONTAINER LID
for Dishwasher (BONNET) EOLYA CRISTAL 35
EOLYA CRISTAL 35A - EOLYA CRISTAL 40
EOLYA CRISTAL 40A - EOLYA FRONTALE
EOLYA FRONTALE A



BONNET 2001963H

Scale removers for dishwashers

3094007 NEW 4-COLUMN SCALE REMOVER
dimensions 410x210x35 mm
fittings \varnothing 12 mm
for Dishwasher (BONNET) EOLYA CRISTAL 35
EOLYA CRISTAL 35A - EOLYA CRISTAL 40
EOLYA CRISTAL 40A - EOLYA FRONTALE
EOLYA FRONTALE A



BONNET 2001840H

3094005 4 COLUMN SCALE REMOVER
width 165 mm - length 390 mm
for Dishwasher (BONNET) EOLYA CRISTAL 35
EOLYA CRISTAL 35A - EOLYA CRISTAL 40
EOLYA CRISTAL 40A - EOLYA FRONTALE
EOLYA FRONTALE A



BONNET 2002155H

BONNET 3724E

Shock absorbers

5032656 SHOCK ABSORBER 082643 50N
total length 378mm
for DISHWASHER LFD60



BONNET 2001939H



Suitable for:

BONNET



Suitable for:

Solenoid valves

3120005 SOLEN. VALVE ELBI TYPE 329 1 WAY 180°
 220/240V 50/60Hz - max. temperature 90°C
 inlet 3/4" - outlet ø 10.5 mm
 for Dishwasher (BONNET) EOLYA BATTERIE 600
 EOLYA CRISTAL 35 - EOLYA CRISTAL 35A
 EOLYA CRISTAL 40 - EOLYA CRISTAL 40A
 EOLYA FRONTALE - EOLYA FRONTALE A
 EOLYA FRONTALE PLUS - EOLYA TOP



BONNET 144937
BONNET 314334

BONNET 2001650H

BONNET 2001651H

3120556 SOLEN. VALVE ELBI TYPE 349 2 WAY 180°
 230V 50/60Hz - max. temperature 90°C
 inlet 3/4" - two outlets ø 10.5 mm
 1 outlet with red adjuster 0.5 L/min
 for Dishwasher (BONNET) EOLYA CRISTAL 35
 EOLYA CRISTAL 35A - EOLYA CRISTAL 40
 EOLYA CRISTAL 40A - EOLYA FRONTALE
 EOLYA FRONTALE A



BONNET 2001648H

3120010 SOLEN. VALVE ELBI TYPE 352 2 WAY 90°
 220/240V 50/60Hz - max. temperature 90°C
 inlet 3/4" - two outlets ø 13.5 mm



BONNET 241447

BONNET 241754

3120409 SOLEN. VALVE T&P 1 WAY 180°
 230V 50/60Hz - max. temperature 90°C
 inlet 3/4" - outlet ø 13.5 mm



BONNET 904693

3120408 SOLEN. VALVE T&P 1 WAY 90°
 230V 50/60Hz - max. temperature 90°C
 inlet 3/4" - outlet ø 13.5 mm



BONNET 23458

BONNET 914100

3120407 SOLEN. VALVE T&P 2 WAY 180°
 230V 50/60Hz - max. temperature 90°C
 inlet 3/4" - two outlets ø 10.5 mm



BONNET 1700434

BONNET 3697E

3120410 SOLEN. VALVE T&P 2 WAY 90°
 230V 50/60Hz - max. temperature 90°C
 inlet 3/4" - two outlets ø 13.5 mm



BONNET 914123

3120414 SOLEN. VALVE T&P 3 WAY 180°
 230V 50/60Hz - max. temperature 90°C
 inlet 3/4" - three outlets ø 10.5 mm



BONNET 314345

BONNET 3664E



Suitable for:

5049894 SOLENOID VALVE CHANGEOVER 3-WAY
 230V 50/60Hz - max. temperature 90°C
 three outlets \varnothing 10.5 mm
 1 outlet with red adjuster 0.5 L/min
 for Dishwasher (BONNET) EOLYA CRISTAL 35
 EOLYA CRISTAL 35A - EOLYA CRISTAL 40
 EOLYA CRISTAL 40A - EOLYA FRONTALE
 EOLYA FRONTALE A



BONNET 2002183H

Suitable for:

3120013 SOLENOID VALVE ELBI TYPE 359 3-WAY 90°
 220/240V 50/60Hz - max. temperature 90°C
 inlet 3/4" - three outlets \varnothing 10.5 mm



BONNET 914135

3120434 SOLENOID VALVE ERA \varnothing 1/2" FF 230/240V
 for water - NC
 max temperature 60°C - max pressure 10 bar



BONNET

3120441 SOLENOID VALVE ERA \varnothing 1/2" FF 24Vac
 for water - NC
 max temperature 90°C - max pressure 25 bar



BONNET

3120437 SOLENOID VALVE ERA \varnothing 1/4" FF 230/240V
 for water - NC
 max temperature 90°C - max pressure 25 bar



BONNET 7455050

3120436 SOLENOID VALVE ERA \varnothing 3/8" FF 230/240V
 for water - NC
 max temperature 60°C - max pressure 10 bar
 for Dishwasher (BONNET) INO10L - INO10LA - INO11L
 INO11LA - INO14L - INO14LA - INO15L - INO15LA
 INO18LA - INO19T - INO4CT - INO5F - INO6L
 INO6LA
 for Glasswasher/Cupwasher (BONNET) INO7F



BONNET 9131985

3120426 SOLENOID VALVE INVENSYS 4 WAY 180°
 230V 50/60Hz - max temperature 90°C
 inlet 3/4" - four outlets \varnothing 10.5 mm
 operating pressure from 0.2 to 10 bar



BONNET 147793

3120558 SOLENOID VALVE L182B17 3/4" FF 24V
 EX L180
 for water
 NC
 max. temperature 100°C
 max. differential pressure 16 bar
 coil 24V 50/60Hz



BONNET




Suitable for:

BONNET



Suitable for:

3120554 SOLENOID VALVE VE123 1/2"FF
coil 24V 50/60Hz 9W



BONNET 2002166H

Spare parts for pumps

3122665 HOUSING FOR PUMP
inlet \varnothing 50 mm - outlet \varnothing 38 mm
for Dishwasher (BONNET) INO10 - INO16 - INO16B
INO16L - INO16LA - INO20 - INO35 - INO50



BONNET 1274E

3122178 IMPELLER FOR PUMP FIR B237 50HZ \varnothing 93 mm
for Dishwasher (BONNET) EOLYA FRONTALE
EOLYA FRONTALE A



BONNET 2001716H

BONNET 2002170H

3122666 IMPELLER FOR PUMP PS 41
for Dishwasher (BONNET) INO5 - INO7



BONNET 3316E

3122079 SEAL MECHANICAL \varnothing 10 mm



BONNET 3706E

Springs

3250196 COVER LIFTING SPRING 415 mm
for mod. INO11L/INO11LA



BONNET 42561

5032657 DOOR SPRING
 \varnothing 8 mm overall length 148 mm
for DISHWASHER LFD60



BONNET 2001937H

5029358 DOOR SPRINGS KIT
support dimensions 95x66x61 mm
for DISHWASHER GL80-RIVER 150



BONNET 2001381H

5060752 SET SPRING PRE-WASH DOOR
dimensions support 95x66x61 mm



BONNET 2001228H



BONNET



Suitable for:

6080277 SLIDER SPRING HOOKING
for Dishwasher hood type (BONNET) EOLYA TOP



BONNET 2001231H

Suitable for:

3250155 SPRING ADJUSTING HOOK
for CLEAN 10/12/14/100-E100÷E140
for Dishwasher (BONNET) EOLYA TOP



BONNET 2001870H

5026327 SPRING FOR DOOR WITH HOOK ø 10 mm
overall length 150 mm
for Dishwasher (BONNET) EOLYA FRONTALE PLUS



BONNET 2001627H

3250156 SPRING FOR HOOD LIFTING ø 30x510 mm
for CLEAN 10/12/14/100-E100÷E140
for Dishwasher (BONNET)
EOLYA TOP



BONNET 2001869H

BONNET 2001879H

Supports for wash and rinse arms

3743862 BOTTOM EXTENSIBLE HOSE
for Dishwasher hood type (BONNET)
INO61 - INO81
for Dishwasher (BONNET) PF700



BONNET 1244661

BONNET 981259

3743799 COUPLING FOR EXTERNAL WASH CONVEYOR



BONNET 2001581H

3743800 COUPLING FOR RINSE CONVEYOR ARM



BONNET 2001570H

3743803 COUPLING FOR WASH ARM
fittings ø 62 mm 48 mm
for Dishwasher (BONNET) EOLYA BATTERIE 600



BONNET 2001908H

3743802 FLANGE FRAME FOR WASH ARM SUPPORT
for Dishwasher (BONNET) EOLYA BATTERIE 600



BONNET 2001143H

BONNET 2001908H



Suitable for:

BONNET




3243988 PLASTIC FITTING PIPE
 for Dishwasher (BONNET) EOLYA BATTERIE 600
 EOLYA CRISTAL 35 - EOLYA CRISTAL 35A
 EOLYA CRISTAL 40 - EOLYA CRISTAL 40A
 EOLYA FRONTALE PLUS



BONNET 2001495H

3186605 GASKET FLAT EPDM \varnothing 33x17x1.5 mm
 for Dishwasher (BONNET) EOLYA BATTERIE 600
 EOLYA CRISTAL 35 - EOLYA CRISTAL 35A
 EOLYA CRISTAL 40 - EOLYA CRISTAL 40A
 EOLYA FRONTALE PLUS



BONNET 2001353H

3743798 TOP ARM COMPLETE FITTING



BONNET 2001585H

3243688 UPPER WASH ARM ASSEMBLY SUPPORT



BONNET 3243688

3243861 UPPER WASH ARM ASSEMBLY SUPPORT
 for Dishwasher hood type (BONNET) INO60 - INO80



BONNET 5806E

3243662 CENTER CONDUIT
 for Dishwasher hood type (BONNET) INO60 - INO80



BONNET 5818E

3186432 LOWER SUPPORT GASKET
 for Dishwasher hood type (BONNET) INO60 - INO80



BONNET 5821E

3243596 STAINLESS STEEL ROD FOR UPPER SUPPORT
 for Dishwasher hood type (BONNET)
 INO60 - INO80
 for Dishwasher hood type (BONNET)
 INO60



BONNET 2002413H

BONNET 5807E

3243691 STAINLESS STEEL ROD FOR WASH ARM ASSY



BONNET 5815E

Suitable for:

Suitable for:

5021286 UPPER WASH ARM ASSEMBLY SUPPORT
for PAN WASHER
for Dishwasher (BONNET) EOLYA BATTERIE 600



BONNET 2001125H

BONNET 2001910H

3743070 UPPER WASHING CONDUIT
for Dishwasher hood type (BONNET)
EOLYA TOP
for Dishwasher (BONNET) ECOMAX 683 - EOLYA TOP
for Dishwasher hood type (BONNET)
EOLYA TOP



BONNET 2001130H


3186167 UPPER WASHING INLET GASKET
dimensions 110x68 mm.
for Dishwasher (BONNET) EOLYA TOP



BONNET 2001332H

Switches

3319627 DOUBLE CHANGE OVER SWITCH 16A 250V




BONNET 900053

3319628 DOUBLE CONTACT SWITCH 16(6)A 250V



BONNET 900054

7104505 PUSH-BUTTON HOUSING ELLIPTICAL 21x11 mm
mounting hole 24x15 mm - colour: dark gray



BONNET 2002488H

3319396 PUSH-BUTTON ROUND BLACK \varnothing 12 mm




BONNET 900163

3319758 PUSH-BUTTON ROUND BLACK \varnothing 23 mm
for Dishwasher hood type (BONNET) INO81



BONNET 900056

5020280 SWITCH CHANGE-OVER 2-POLE



BONNET 2001327H




BONNET



Suitable for:

3319529 SWITCH 2-POLE BLACK 10A 250V
16(4)A 250V - max. temperature 120°C
mounting hole 22x30 mm - silk screen printing 0 -
for Dishwasher (BONNET) INO19 - INO5



BONNET 905914

Suitable for:

3319371 SWITCH 2-POLE BLACK 16A 250V
16(4)A 250V
silk screen printing 0 - I
max. temperature 120°C
mounting hole 22x30 mm
for Dishwasher (BONNET)
INO19 - INO5



BONNET 905913

Telethermometers

3441072 BLACK TELETHERMOMETER 58x25 mm 0-120°C
plastic case
capillary length 2000 mm
bulb \varnothing 6x30 mm
for Dishwasher hood type (BONNET) INO60



BONNET 901018

3441084 TELETHERMOM. 58x25 mm 0-120°C TR58.25P
plastic case
black dial
capillary length 1500 mm




BONNET 5866E

BONNET 901018

Terminal blocks

3247009 6-POLE TERMINAL BLOCK FV122/B 40A 600V
for cable max 6 mm²
operating temperature 150°C
nominal voltage 450 V
for Dishwasher (BONNET) EOLYA BATTERIE 600
EOLYA FRONTALE - EOLYA FRONTALE A
EOLYA FRONTALE PLUS - EOLYA TOP



BONNET 306090

Terminals and electrical connectors

6000019 SPIKE FOR CONNECTOR (GET5)
for Dishwasher (BONNET) EOLYA CRISTAL 35
EOLYA CRISTAL 35A - EOLYA CRISTAL 40
EOLYA CRISTAL 40A - EOLYA FRONTALE
EOLYA FRONTALE A - EOLYA FRONTALE PLUS



BONNET 2001208H



Thermostats


3444604 SET TEMPERATURE THERMOSTAT F/TANK 53°C
 preset temperature
 covered capillary 600 mm
 button bulb \varnothing 14x31 mm
 16A 250V
 for Glasswasher/Cupwasher (BONNET)
 VR1000R



BONNET 2001967H


BONNET 5509E

3444282 SINGLE-PHASE THERMOSTAT 90-110°C
 with manual reset
 covered capillary 1500 mm
 bulb \varnothing 6.5x95 mm
 15A 250V



BONNET 901034


3444612 SINGLE-PHASE THERMOSTAT FOR BOILER 85°C
 15A 250V
 covered capillary 600 mm
 bulb \varnothing 6x120 mm
 for Glasswasher/Cupwasher (BONNET)
 VR1000R



BONNET 2001966H

BONNET 5508E

3444613 SINGLE-PHASE THERMOSTAT FOR TANK 60°C
 15A 250V
 covered capillary 600 mm
 button bulb \varnothing 14 mm
 for Dishwasher hood type (BONNET) INO60 - INO80



BONNET 5868E

3186612 GASKET FLAT ASBESTOS FREE \varnothing 20x14x2 mm
 for thermostat bulb



BONNET 2001346H

3444615 NUT FOR THERMOSTAT BULB



BONNET 2001202H




Suitable for:

BONNET



3444899 SINGLE-PHASE THERMOSTAT 135°C
 manual reset
 capillary length 1500 mm
 bulb \varnothing 6x80 mm
 for Dishwasher (BONNET)
 INO11 - INO14L - INO14LA - PF700
 for Dishwasher pull-through (BONNET)
 Series GTI - Series LCM
 for Dishwasher (BONNET) 932H40




BONNET 1244727

BONNET 303641


BONNET 904843

3444510 SINGLE-PHASE THERMOSTAT 30-110°C
 D-shaped pin \varnothing 6x4.6 mm
 capillary length 850 mm - 16A 250V
 bulb \varnothing 6x138 mm - w/ stuffing gland fitting M9x1
 with complete tank sealing fitting M12x1
 for Dishwasher (BONNET) INO10 - INO11 - INO14L
 INO14LA - INO15 - INO16B - INO4CT - INO5F
 INO6
 for Glasswasher/Cupwasher (BONNET) INO7F



BONNET 24650

3444049 SINGLE-PHASE THERMOSTAT 30-90°C
 capillary 1700 mm
 button bulb \varnothing 15x20 mm
 16A 250V
 D shaft \varnothing 6x4.6 mm
 for Glasswasher/Cupwasher (BONNET) VR1000H
 VR1000HAD



BONNET 3650E


1444012 SINGLE-PHASE THERMOSTAT 30-95°C
 D-shaped pin \varnothing 6x4.6 mm
 capillary length 850 mm - 16A 250V
 bulb \varnothing 6x140 mm - with stuffing gland fitting M9x1
 for Dishwasher (BONNET) INOC - INOM20 - INOM35
 INOM50 - INO11 - INO14L - INO14LA - PF700
 for Dishwasher pull-through (BONNET) GTI



BONNET 1244788


BONNET 905838

3744106 SINGLE-PHASE THERMOSTAT 90°-110°C
 covered capillary 1600 mm
 bulb \varnothing 6x80 mm




BONNET 2002136H

3444614 SINGLE-PHASE THERMOSTAT 90°C
 15A 250V
 covered capillary 2000 mm
 bulb \varnothing 6.5x90 mm




BONNET 2001866H

3444004 THERMOSTAT SINGLE-PHASE TR2 0-90°C
 D-shaped pin \varnothing 6x4.6 mm
 capillary length 1500 mm - 15A 250V
 bulb \varnothing 6.5x95 mm
 for Dishwasher (BONNET) INO36 - INO61
 for Dishwasher (BONNET) INO61



BONNET

3744015 THREE-PHASE THERMOSTAT 30-85°C F/BOILER
 capillary 900 mm - with stuffing gland
 bulb \varnothing 6 - length 175 mm
 for Dishwasher pull-through (BONNET) GTI



BONNET 29439

Suitable for:

Suitable for:

3444016 THREE-PHASE THERMOSTAT 30-90°C
 capillary 900 mm
 bulb \varnothing 6x215 mm
 10A 400V
 with temperature adjusting screw



BONNET 5004E

Tubing and hoses

3248133 DRAIN PUMP HOSE
 internal \varnothing 30 e 25 mm - length 66 mm
 for Dishwasher (BONNET)
 EOLYA FRONTALE PLUS
 EOLYA CRISTAL 40 - EOLYA CRISTAL 40A



BONNET 2001393H

BONNET 2002084H


6929164 HOSE ELBOW SHAPED RUBBER \varnothing 60x78 mm
 for Dishwasher (BONNET) EOLYA BATTERIE 600



BONNET 2001892H

BONNET 6002E

6127026 HOSE OUTLET
 internal \varnothing 50 mm - length 55 mm
 for Dishwasher (BONNET) EOLYA FRONTALE
 EOLYA FRONTALE A



BONNET 2001396H

3248040 OUTLET HOSE
 \varnothing internal 48 mm
 overall length 215 mm
 for Dishwasher (BONNET) EOLYA TOP



BONNET 2001930H

3248041 INLET HOSE 335 mm
 internal \varnothing 55 mm
 overall length \varnothing 400 mm
 for Dishwasher (BONNET) EOLYA TOP



BONNET 2001931H



Suitable for:

BONNET



3248135 OUTLET HOSE
internal \varnothing 47 mm
total length 425 mm



BONNET 2001407H

Suitable for:
3248179 OUTLET HOSE
internal \varnothing 25 mm
overall length 370 mm
for Dishwasher hood type (BONNET) INO80



BONNET 5933E

3349472 OUTLET HOSE \varnothing 40x50mm
for Dishwasher (BONNET) INO14 - INO5 - INO7
PF700
for Dishwasher pull-through (BONNET) GTI



BONNET 28445

3243983 PUMP OUTLET HOSE
 \varnothing internal 20-25 mm
for Dishwasher (BONNET) EOLYA CRISTAL 40
EOLYA CRISTAL 40A



BONNET 2001397H

3349476 PUMP OUTLET HOSE
internal \varnothing 47-54 mm
overall length 315 mm
for Dishwasher (BONNET) INO11 - INO14L - INO14LA



BONNET 28782

Wash and rinse arms for warewashers

3743312 ARM ASSEMBLY SPACER
for Dishwasher (BONNET) EOLYA TOP



BONNET 2001604H

3528063 ARM FASTENING SCREW



BONNET 989701

3243976 BODY FOR RINSE IMPELLER
without bushes
for Dishwasher (BONNET) EOLYA BATTERIE 600
EOLYA TOP



BONNET 2001943H

3243978 LOCKING NUT TURNED
 \varnothing thread 5 mm
for Dishwasher (BONNET) EOLYA FRONTALE
EOLYA FRONTALE A - EOLYA FRONTALE PLUS
EOLYA TOP



BONNET 2001104H



Suitable for:

3243977 PIN FOR TURNING ARM
for Dishwasher (BONNET) EOLYA BATTERIE 600
EOLYA TOP



BONNET 2001944H

3243991 STAINLESS STEEL PIN FOR ARM
height 53 mm
for Dishwasher (BONNET) EOLYA TOP



BONNET 2001005H

3743858 BOTTOM BOSS SHAFT
overall length 140 mm - \varnothing internal 17 mm
for Dishwasher hood type (BONNET) INO81



BONNET 981263

3243651 COMPLETE RINSE ARM
for Dishwasher (BONNET) EOLYA CRISTAL 35
EOLYA CRISTAL 35A - EOLYA CRISTAL 40
EOLYA CRISTAL 40A
for Glasswasher/Cupwasher (BONNET)
VR1500C



BONNET 2001830H

BONNET 5556E

BONNET



Suitable for:


3243979 SECURITY BLOCKING FOR LOCKING NUT
for Dishwasher (BONNET)
EOLYA TOP
EOLYA BATTERIE 600



BONNET 2001007H

BONNET 2001008H

3186605 GASKET FLAT EPDM \varnothing 33x17x1.5 mm
for Dishwasher (BONNET) EOLYA BATTERIE 600
EOLYA CRISTAL 35 - EOLYA CRISTAL 35A
EOLYA CRISTAL 40 - EOLYA CRISTAL 40A
EOLYA FRONTALE PLUS



BONNET 2001353H



Suitable for:

3243653 LEFTHAND RINSE ARM

for Dishwasher (BONNET) EOLYA CRISTAL 35
EOLYA CRISTAL 35A - EOLYA CRISTAL 40
EOLYA CRISTAL 40A



BONNET 2001065H

BONNET 5559K

BONNET



Suitable for:

3243607 RING NUT FOR RINSE JET

for Glasswasher/Cupwasher (BONNET)
VR1000R - VR1000RAD - VR1500C - VR1500CAD
VR1500D
for Dishwasher (BONNET) EOLYA CRISTAL 35
EOLYA CRISTAL 35A - EOLYA CRISTAL 40
EOLYA CRISTAL 40A - EOLYA FRONTALE
EOLYA FRONTALE A



BONNET 2001973H

BONNET 2001973HK

BONNET 5531K

3243608 RINSE JET

for Glasswasher/Cupwasher (BONNET)
VR1000R - VR1000RAD - VR1500C - VR1500CAD
VR1500D
for Dishwasher (BONNET) EOLYA CRISTAL 35
EOLYA CRISTAL 35A - EOLYA CRISTAL 40
EOLYA CRISTAL 40A - EOLYA FRONTALE
EOLYA FRONTALE A



BONNET 2001974H

BONNET 2001974HK

BONNET 5532K

3743784 COMPLETE RINSE ARM ASSEMBLY

length 635 mm
for Dishwasher (BONNET) EOLYA BATTERIE 600
for Pan/utensilwashing machines (BONNET)
LP301



BONNET 2001942H

3243637 COMPLETE WASH ARM ASSEMBLY

for Glasswasher/Cupwasher (BONNET) VR1500C
VR1500CAD



BONNET 5522E

3243602 LEFTHAND WASH ARM

for Glasswasher/Cupwasher (BONNET) VR1500C
VR1500CAD



BONNET 5525E



Suitable for:

3243638 LOWER WASH ARM ASSEMBLY BOSS
for Glasswasher/Cupwasher (BONNET)
VR1500C - VR1500CAD
for Dishwasher (BONNET) EOLYA FRONTALE
EOLYA FRONTALE A



BONNET 2001826H

BONNET 5533E

3243640 LOWER WASH ARM ASSY KNOB LOCKING BOLT
for Glasswasher/Cupwasher (BONNET)
VR1500C - VR1500CAD
for Dishwasher (BONNET) EOLYA FRONTALE
EOLYA FRONTALE A



BONNET 2001968H


BONNET 5517E

3243605 RING NUT FOR WASH JET
for Glasswasher/Cupwasher (BONNET)
VR1000R - VR1000RAD - VR1500C - VR1500CDA
for Dishwasher (BONNET) EOLYA FRONTALE
EOLYA FRONTALE A



BONNET 2001822H

3243610 WASH ARM ASSEMBLY LOWER BOSS SPINDLE
for Glasswasher/Cupwasher (BONNET)
VR1500C - VR1500CAD
for Dishwasher (BONNET) EOLYA FRONTALE
EOLYA FRONTALE A



BONNET 2001971H

BONNET 5524E

BONNET

Suitable for:

3243639 LOWER WASH ARM ASSEMBLY LOCKING KNOB
for Glasswasher/Cupwasher (BONNET)
VR1500C - VR1500CAD
for Dishwasher (BONNET) EOLYA FRONTALE
EOLYA FRONTALE A



BONNET 2001970H

BONNET 5523E

3243607 RING NUT FOR RINSE JET
for Glasswasher/Cupwasher (BONNET)
VR1000R - VR1000RAD - VR1500C - VR1500CAD
VR1500D
for Dishwasher (BONNET) EOLYA CRISTAL 35
EOLYA CRISTAL 35A - EOLYA CRISTAL 40
EOLYA CRISTAL 40A - EOLYA FRONTALE
EOLYA FRONTALE A



BONNET 2001973H

BONNET 2001973HK

BONNET 5531K

3243608 RINSE JET
for Glasswasher/Cupwasher (BONNET)
VR1000R - VR1000RAD - VR1500C - VR1500CAD
VR1500D
for Dishwasher (BONNET) EOLYA CRISTAL 35
EOLYA CRISTAL 35A - EOLYA CRISTAL 40
EOLYA CRISTAL 40A - EOLYA FRONTALE
EOLYA FRONTALE A



BONNET 2001974H

BONNET 2001974HK

BONNET 5532K





Suitable for:

BONNET



3743526 COMPLETE WASH/RINSE ARM ASSEMBLY
with polypropylene grey support
for Dishwasher (BONNET) INO11 - INO14 - INO18
INO19 - INO5 - INO61 - INO7
for Dishwasher (BONNET) INO61



BONNET 1244697

BONNET 241758

BONNET 56520

3743531 ARM ASSEMBLY SUPPORT RING NUT
for Dishwasher (BONNET) INO11 - INO14 - INO18
INO19 - INO36 - INO5 - INO7
for Dishwasher (BONNET) INO36



BONNET 31447

BONNET 983562

3743533 BOTTOM AND TOP MANIFOLD
for Dishwasher (BONNET) INO5 - INO7



BONNET 56509

3743532 BOTTOM EXTENSION
for Dishwasher (BONNET) INO5 - INO7



BONNET 44199

3743519 LEFT WASH JET
for Dishwasher (BONNET) INO11 - INO5 - INO7



BONNET 15030K

Suitable for:

3528057 ARM ASSEMBLY FASTENING SCREW
for Dishwasher (BONNET) INO11 - INO14 - INO18
INO19 - INO5 - INO7



BONNET 31589

BONNET 983563

3528059 ARM ASSEMBLY SUPPORT WASHER
for Dishwasher (BONNET) INO11 - INO14 - INO18
INO19 - INO5 - INO7



BONNET 31473

3743534 BOTTOM AND TOP MANIFOLD
for Dishwasher (BONNET) INO11 - INO14 - INO18
INO19 - INO61
for Dishwasher (BONNET) INO61



BONNET 56510

3743529 DISHWASHER BOTTOM BEARING
for Dishwasher (BONNET) INO11 - INO14 - INO18
INO19 - INO5 - INO7



BONNET 31448

3743518 RINSE JET
for Dishwasher (BONNET) INO11 - INO14 - INO18
INO19 - INO5 - INO61 - INO7 - INO81
for Dishwasher (BONNET) INO61 - INO81



BONNET 15027K

BONNET 15189K




Suitable for:

3449272 RINSE WATER INLET BOTTOM PIPE
for Dishwasher (BONNET) INO5 - INO7



BONNET 31454

3743520 SLANTED WASH JET
for Dishwasher (BONNET) INO14 - INO5F
for Glasswasher/Cupwasher (BONNET) INO7F



BONNET 15031K

3743527 SUPPORT FOR RINSE ARM ASSEMBLY
of grey polypropylene
for Dishwasher (BONNET) INO11 - INO14 - INO18
INO19 - INO5 - INO7



BONNET 56507

3743535 WASH JET
for Dishwasher (BONNET) INO11 - INO14 - INO18
INO19 - INO5 - INO7 - INO81
for Dishwasher (BONNET) INO81



BONNET 15032K

3743801 CONVEYOR WASH ARM 520 mm



BONNET 2001995H

BONNET



Suitable for:

3449273 RINSE WATER INLET TOP PIPE
for Dishwasher (BONNET) INO11 - INO14 - INO18
INO19 - INO5 - INO7



BONNET 31455

BONNET 983561

3743528 SUPPORT FOR ARM ASSEMBLY
for Dishwasher (BONNET) INO11 - INO14 - INO18
INO19 - INO5 - INO7



BONNET 56508

BONNET 981262

3743530 TOP BEARING
for Dishwasher (BONNET)
INO5 - INO7
for Dishwasher (BONNET) INO61



BONNET 31449

BONNET 981257

3243658 LEFTHAND RINSE ARM
for Dishwasher (BONNET) EOLYA FRONTALE
EOLYA FRONTALE A



BONNET 2001064H



Suitable for:

BONNET



6308031 RING NUT FOR WASH BUSHING 3/4"
for Dishwasher (BONNET) EOLYA FRONTALE
EOLYA FRONTALE A - EOLYA FRONTALE PLUS



BONNET 2001016H

Suitable for:

3743787 RINSE ARM ASSEMBLY
length 510 mm



BONNET 2001599H

3243873 RINSE ARM ASSEMBLY 500 mm
for Dishwasher hood type (BONNET)
INO60 - INO80



BONNET 2002409H

BONNET 5802E

1186612 O-RING 02025 VITON
for Dishwasher (BONNET) EOLYA BATTERIE 600
EOLYA FRONTALE PLUS - EOLYA TOP



BONNET 2001374H

3243875 RINSE ARM ASSEMBLY SPINDLE
for Dishwasher hood type (BONNET) INO60



BONNET 5810E

3243009 O-RING GASKET 0106 EPDM
for Dishwasher hood type (BONNET)
INO60 - INO80
for Dishwasher (BONNET) EOLYA CRISTAL 35
EOLYA CRISTAL 35A - EOLYA FRONTALE
EOLYA FRONTALE A



BONNET 2001978H

BONNET 2001978HK

BONNET 5814E

3243876 RINSE ARM ASSEMBLY CAP
for Dishwasher hood type (BONNET)
INO60 - INO80
for Dishwasher (BONNET) EOLYA BATTERIE 600
EOLYA CRISTAL 35 - EOLYA CRISTAL 35A
EOLYA CRISTAL 40 - EOLYA CRISTAL 40A
EOLYA FRONTALE PLUS - EOLYA TOP



BONNET 2001977H

BONNET 5813E

3243625 RINSE BOSS
for Dishwasher hood type (BONNET)
INO60 - INO80



BONNET 2002407H

BONNET 5823E

3439003 RINSE ARM CAP



BONNET 981211

3743132 RINSE ARM CENTRAL BOSS
 for Glasswasher/Cupwasher (BONNET)
 VR1500C - VR1500CAD
 for Dishwasher (BONNET) EOLYA CRISTAL 35
 EOLYA CRISTAL 35A - EOLYA CRISTAL 40
 EOLYA CRISTAL 40A



BONNET 2001833H

BONNET 5560E

3186605 GASKET FLAT EPDM ø 33x17x1.5 mm
 for Dishwasher (BONNET) EOLYA BATTERIE 600
 EOLYA CRISTAL 35 - EOLYA CRISTAL 35A
 EOLYA CRISTAL 40 - EOLYA CRISTAL 40A
 EOLYA FRONTALE PLUS



BONNET 2001353H

3243653 LEFTHAND RINSE ARM
 for Dishwasher (BONNET) EOLYA CRISTAL 35
 EOLYA CRISTAL 35A - EOLYA CRISTAL 40
 EOLYA CRISTAL 40A



BONNET 2001065H

BONNET 5559K

3743133 RINSE ARM RING NUT
 for Glasswasher/Cupwasher (BONNET)
 VR1500C - VR1500CAD
 for Dishwasher (BONNET) EOLYA CRISTAL 35
 EOLYA CRISTAL 35A - EOLYA CRISTAL 40
 EOLYA CRISTAL 40A



BONNET 2001831H

BONNET 5557E

3186273 FLAT PTFE GASKET ø 16.5x12.5x1.5 mm
 for Glasswasher/Cupwasher (BONNET)
 VR1500C - VR1500CAD
 for Dishwasher (BONNET) EOLYA CRISTAL 35
 EOLYA CRISTAL 35A - EOLYA CRISTAL 40
 EOLYA CRISTAL 40A



BONNET 2001834H

BONNET 5561E

3743130 HOSE-END FITTING RING NUT
 for Glasswasher/Cupwasher (BONNET)
 VR1500C - VR1500CAD
 for Dishwasher (BONNET) EOLYA CRISTAL 35
 EOLYA CRISTAL 35A - EOLYA CRISTAL 40
 EOLYA CRISTAL 40A - EOLYA FRONTALE PLUS



BONNET 2001021H

3243607 RING NUT FOR RINSE JET
 for Glasswasher/Cupwasher (BONNET)
 VR1000R - VR1000RAD - VR1500C - VR1500CAD
 VR1500D
 for Dishwasher (BONNET) EOLYA CRISTAL 35
 EOLYA CRISTAL 35A - EOLYA CRISTAL 40
 EOLYA CRISTAL 40A - EOLYA FRONTALE
 EOLYA FRONTALE A




BONNET 2001973H

BONNET 2001973HK

BONNET 5531K

3743131 RINSE ARM ROD
 for Glasswasher/Cupwasher (BONNET)
 VR1500C - VR1500CAD
 for Dishwasher (BONNET) EOLYA CRISTAL 35
 EOLYA CRISTAL 35A - EOLYA CRISTAL 40
 EOLYA CRISTAL 40A



BONNET

BONNET 2001832H

BONNET 5558E



Suitable for:

3243608 RINSE JET

for Glasswasher/Cupwasher (BONNET)
VR1000R - VR1000RAD - VR1500C - VR1500CAD
VR1500D
for Dishwasher (BONNET) EOLYA CRISTAL 35
EOLYA CRISTAL 35A - EOLYA CRISTAL 40
EOLYA CRISTAL 40A - EOLYA FRONTALE
EOLYA FRONTALE A



BONNET 2001974H

BONNET 2001974HK

BONNET 5532K

BONNET

Suitable for:



5030189 RINSE ARM 330 mm

for Dishwasher (BONNET) EOLYA CRISTAL 35
EOLYA CRISTAL 35A



BONNET 2001056H

3243009 O-RING GASKET 0106 EPDM

for Dishwasher hood type (BONNET)
INO60 - INO80
for Dishwasher (BONNET) EOLYA CRISTAL 35
EOLYA CRISTAL 35A - EOLYA FRONTALE
EOLYA FRONTALE A



BONNET 2001978H

BONNET 2001978HK

BONNET 5814E

3243876 RINSE ARM ASSEMBLY CAP

for Dishwasher hood type (BONNET)
INO60 - INO80
for Dishwasher (BONNET) EOLYA BATTERIE 600
EOLYA CRISTAL 35 - EOLYA CRISTAL 35A
EOLYA CRISTAL 40 - EOLYA CRISTAL 40A
EOLYA FRONTALE PLUS - EOLYA TOP



BONNET 2001977H

BONNET 5813E

6129066 HUB IMPELLER LOWER

for Dishwasher (BONNET) EOLYA CRISTAL 35
EOLYA CRISTAL 35A - EOLYA CRISTAL 40
EOLYA CRISTAL 40A



BONNET 2001157H

1186411 O-RING 02031 EPDM



BONNET 5814E

3501059 RINSE NOZZLE ø 2.5 mm

for Dishwasher (BONNET)
EOLYA FRONTALE PLUS
EOLYA BATTERIE 600 - EOLYA CRISTAL 35
EOLYA CRISTAL 35A - EOLYA CRISTAL 40
EOLYA CRISTAL 40A - EOLYA FRONTALE
EOLYA FRONTALE A - EOLYA TOP
for Pan/utensilwashing machines (BONNET)
LP301



BONNET 2001281H

BONNET 2001330H

BONNET 2001282H

BONNET 2001330HK

BONNET 2001283H



Suitable for:

BONNET



3743273 RINSE ARM 460 mm
for Dishwasher (BONNET) EOLYA FRONTALE
EOLYA FRONTALE A - EOLYA FRONTALE PLUS




BONNET 2001291H

BONNET 2001293H

Suitable for:

6129054 RINSE ARM ASSEMBLY BOSS
for Dishwasher (BONNET) EOLYA FRONTALE
EOLYA FRONTALE A - EOLYA FRONTALE PLUS



BONNET 2001161H

3743272 RINSE ARM 475 mm
for Dishwasher (BONNET) EOLYA FRONTALE PLUS



BONNET 2001292H

3243981 RINSE IMPELLER 510 mm



BONNET 2001600H

3743786 ARM ASSEMBLY PIN
for Dishwasher (BONNET) EOLYA TOP



BONNET 2001499H

3743785 RING NUT FOR WASH ARM LOWER \varnothing 1"1/2
for Dishwasher (BONNET) EOLYA TOP



BONNET 2001024H

3243984 RINSE WASH GROUP
dimensions 490x500 mm.
for Dishwasher (BONNET) EOLYA FRONTALE
EOLYA FRONTALE A



BONNET 2001300H

3243605 RING NUT FOR WASH JET
for Glasswasher/Cupwasher (BONNET)
VR1000R - VR1000RAD - VR1500C - VR1500CDA
for Dishwasher (BONNET) EOLYA FRONTALE
EOLYA FRONTALE A



BONNET 2001822H



Suitable for:

3243608 RINSE JET

for Glasswasher/Cupwasher (BONNET)
VR1000R - VR1000RAD - VR1500C - VR1500CAD
VR1500D
for Dishwasher (BONNET) EOLYA CRISTAL 35
EOLYA CRISTAL 35A - EOLYA CRISTAL 40
EOLYA CRISTAL 40A - EOLYA FRONTALE
EOLYA FRONTALE A



BONNET 2001974H

BONNET 2001974HK

BONNET 5532K

3743295 ST. STEEL WASH ARM ASSEMBLY INOX 510 mm

complete with sliding bushing
for Dishwasher (BONNET) EOLYA FRONTALE
EOLYA FRONTALE A - EOLYA FRONTALE PLUS



BONNET 2001290H

BONNET 2002186H

3243980 STAINLESS STEEL WASH ARM 510 mm

complete with central hub
for Dishwasher (BONNET) EOLYA TOP



BONNET 2001598H

3743275 SUPPORT FOR WASH ARM

for Dishwasher (BONNET) EOLYA TOP



BONNET 2001669H

3243864 TOP/BOTTOM ARM ASSEMBLY 510 mm

complete with hub and ring nut
for Dishwasher hood type (BONNET)
INO60 - INO80



BONNET 2001845H

BONNET 5803E

BONNET

Suitable for:



3243866 RING NUT FOR BOSS

for Dishwasher hood type (BONNET)
INO60 - INO80



BONNET 2001194H

BONNET 5808E

3243865 WASH ARM ASSEMBLY BOSS

for Dishwasher hood type (BONNET)
INO60 - INO80
for Dishwasher (BONNET) EOLYA FRONTALE PLUS



BONNET 2001846H

BONNET 5809E



BONNET



Suitable for:


3243135 WASH ARM ASSEMBLY END CAP
for Dishwasher (BONNET) INO3F



BONNET 5025E

Suitable for:

3439002 WASH ARM CAP



BONNET 981212

3743201 WASH ARM WITH 3 TURNING ARMS
for Dishwasher (BONNET) EOLYA BATTERIE 600



BONNET 2001893H

5037316 WASH-ARM UPPER PLASTIC
dimensions external size 405x400 mm
for Dishwasher (BONNET) EOLYA CRISTAL 40
EOLYA CRISTAL 40A



BONNET 2001597H

Wash jets and accessories

3743875 COMPLETE WASH JET



BONNET 5600E

BONNET 5601E

BONNET 5612E

3243137 RINSE JET
for Dishwasher (BONNET) INO3F



BONNET 5029K

3243139 O-RING 02025 EPDM
for Dishwasher (BONNET) INO3F



BONNET 5091E

3243138 RINSE JET COUNTER FLANGE
5CF11B-CT92-CT140-CT141-CT142-CT190-CT191
for Dishwasher (BONNET) INO3F



BONNET 5030K



BONNET



Suitable for:

Suitable for:

5052043 RINSE JET \varnothing 2.5 mm PIPE 12 mm

3501611 RINSE JET CLAMP



BONNET 2002468H

BONNET

3501250 STAINLESS STEEL RINSE JET M5X1

3501610 TOP RINSE JET



BONNET 2001284H

BONNET

3743542 WASH JET
for Dishwasher (BONNET) INOM20 - INOM20GTI
INOM35 - INOM35GTI - INOM50 - INOM50GTI

3786402 GASKET FOR NOZZLE
for Dishwasher (BONNET) INO20 - INO35 - INO50



BONNET 30753

BONNET 30787K

3743543 JET SCREW - 10 PCS
for Dishwasher (BONNET) INOM20 - INOM20GTI
INOM35 - INOM35GTI - INOM50 - INOM50GTI




















BONNET 16062K

The data herewith contained may change without notice and LF SpA cannot be held responsible for possible errors stated or resulting by the use of this document. All rights reserved. No part of this publication may be reproduced without written permission by LF SpA.



Distributing Components, Spare Parts & Accessories in original quality worldwide

-
-  **LF SpA HEADQUARTERS**
via Voltri, 80 - 47522 Cesena (FC) ITALY
Tel. +39 0547 34 11 11 - Fax +39 0547 34 11 10
www.lfrcambi724.it - www.lfrcambi724.mobi
info@lfrcambi.it
Export Dept.: Tel. +39 0547 34 11 50 - Fax: +39 0547 34 11 55
www.lfspareparts724.com - www.lfspareparts724.mobi
export@lfspareparts.com
-  **LF SpA HOUSEHOLD COMPONENTS DIVISION**
Via Padriciano, 34149 Trieste - Italia - AREA Science Park
Tel. +39 0547 34 12 42 - Fax +39 0547 34 12 48
www.lfspareparts724.com - www.lfspareparts724.mobi
info@lfspareparts.com
-  **EPGC Sas FRANCE**
13, Rue des Forts - 59960 Neuville en Ferrain
Tel. +33 (0)3 20 25 06 21
Fax +33 (0)3 20 25 34 12
www.epgc.com
www.epgc724.mobi
epgc@epgc.com
-  **LF GmbH GERMANY**
Junkersstrasse, 3 - D-82178 Puchheim - München
Tel. +49 89 89 45 78 66
Fax +49 89 89 45 78 88
www.lfersatzteile724.de
www.lfersatzteile724.mobi
info@lfersatzteile.de
-  **LF China REPUBLIC OF CHINA**
Room 403, No.2, Huadu Mansion, Lane 422, Huanghua Rd.
Minhang Dist. - 201103 Shanghai
Tel. +86 (0)21 33 53 66 31
Fax +86 (0)21 33 53 66 32
www.lfspareparts724.com
www.lfspareparts724.mobi
china@lfspareparts.com
-  **OOO LF RUSSIAN FEDERATION**
Ul. Anatoliya Zhivova, 8 - office 1 - 123100 Moscow
Tel./Fax +7 495 725 26 53
www.lfspareparts724.ru
www.lfspareparts724.mobi
info@lfspareparts.ru
-  **LF Repuestos Horeca S.L.U. SPAIN**
Poligono Industrial Carpetania - C/Miguel Faraday, 8 - 28906 Getafe
Tel. +34 91 477 91 00
Fax +34 91 477 90 81
www.lfrepuestos-horeca724.es
www.lfrepuestos724.mobi
info@lfrepuestos.es
-  **LF SpA Cesena (IT) Swiss Branch Steinhausen SWITZERLAND**
Sennweidstrasse, 45 - CH-6312 Steinhausen
Tel. +41 (0)41 760 15 80-1
Fax +41 (0)41 760 15 85
www.lfersatzteile724.ch
www.lfersatzteile724.mobi
info@lfersatzteile.ch
-  **LF Spare Parts Ltd. UNITED KINGDOM**
A10a Lakeside Business Park, Broadway Lane
South Cerney, Gloucestershire GL7 5XL
Tel. +44 (0)1285 86 16 25
Fax +44 (0)1285 86 39 49
www.lfspareparts724.co.uk
www.lfspareparts724.mobi
info@lfspareparts.co.uk
-
-  **AUSTRALIA AND NEW ZEALAND**
www.lfspareparts724.com
andrea.calvio@lfspareparts.com
-  **AUSTRIA**
www.lfersatzteile724.at
info@lfersatzteile.at
-  **BALKAN COUNTRIES**
www.lfspareparts724.com
matijaramov@lfspareparts.com
-  **BALTIC COUNTRIES**
www.lfspareparts724.com
inara.silina@lfspareparts.com
-  **CENTRAL AND EASTERN EUROPE**
www.lfspareparts724.cz
jiri.kremla@lfspareparts.cz
-  **DENMARK**
www.lfspareparts724.dk
michael.leth@lfspareparts.com
-  **JAPAN**
www.lfspareparts724.jp
hiroshi.ukai@lfspareparts.jp
-  **SOUTH KOREA**
www.lfspareparts724.com
fabio.doni@lfspareparts.com
-  **TURKEY**
www.lfyedekparca724.com
basar.ergun@lfyedekparca.com
-  **USA AND CANADA**
www.lfspareparts724.us
sauro.dallaglio@lfspareparts.us
howard.truitt@lfspareparts.us