



Spare parts for:

Warewashing equipment



Suitable for:

ELETTROBAR



This catalogue is automatically generated.
Therefore, the sequence of the items might
not be always shown at best.
Updates will be issued in case of additions
and/or amendments.

Suitable universal spare parts may not be included





Suitable for:

ELETTROBAR



Suitable for:

Air traps

3060010 AIR CHAMBER \varnothing 26x155 mm
external hose \varnothing 8 mm and length 1050 mm



ELETTROBAR DWT222

3060127 AIR CHAMBER \varnothing 42x33 mm
two hose end fittings \varnothing 6 mm open
for Dishwasher (ELETTROBAR) NIAGARA251
NIAGARA261 - PLUVIA260
for Dishwasher hood type (ELETTROBAR) NIAGARA281



ELETTROBAR 107014

5037065 AIR CHAMBER \varnothing 42x33 mm
one hose end fitting \varnothing 6 mm open
one hose end fitting \varnothing 6 mm closed
for Dishwasher (ELETTROBAR) NIAGARA341
NIAGARA361 - PLUVIA270 - RIVER362C - RIVER362T
for Glasswasher/Cupwasher (ELETTROBAR) NIAGARA241



ELETTROBAR 107013

3060606 AIR CHAMBER COMPLETE \varnothing 33x125 mm
complete with flat O-ring gasket and connector
hose end fitting \varnothing 6 mm
for Dishwasher (ELETTROBAR) E46 - E50 - E51 - E55
E60 - E65 - MISTRAL51 - NIAGARA51 - RIVER71
R706 - R708 - S641 - S643
for Dishwasher hood type (ELETTROBAR) E100 - E110
E120 - E140 - RIVER80 - RIVER81 - RIVER82
for Dishwasher pull-through (ELETTROBAR) CLEAN160
CLEAN161 - CLEAN220 - CLEAN221 - CLEAN270
CLEAN271 - CLEAN361 - CLEAN362 - CLEAN471
for Glasswasher/Cupwasher (ELETTROBAR) E35 - E40
E41 - E42 - E45 - MISTRAL40 - NIAGARA35
NIAGARA40 - NIAGARA45 - RIVER40 - R495 - R499
R501 - R503
for Pan/utensilwashing machines (ELETTROBAR) U131



ELETTROBAR 984002

3060607 FITTING FOR AIR CHAMBER
for Dishwasher (ELETTROBAR)
R706 - R708 - S641 - S643
for Glasswasher/Cupwasher (ELETTROBAR)
R495 - R499 - R501 - R503



ELETTROBAR REB468029

ELETTROBAR 468029

3060608 O-RING O3050 EPDM



ELETTROBAR 456020



Suitable for:

Suitable for:

3060609 AIR CHAMBER COMPLETE \varnothing 34x79 mm
complete with flat O-ring gasket and connector
hose end fitting \varnothing 6 mm
for Glasswasher/Cupwasher (ELETTROBAR)
21F - 31F

3060072 AIR CHAMBER \varnothing 34x79 mm



ELETTROBAR REB984005

ELETTROBAR 984005

ELETTROBAR REB107005

ELETTROBAR 107005

3060607 FITTING FOR AIR CHAMBER
for Dishwasher (ELETTROBAR)
R706 - R708 - S641 - S643
for Glasswasher/Cupwasher (ELETTROBAR)
R495 - R499 - R501 - R503

6437019 GASKET FLAT EPDM \varnothing 22x13x1.5 mm



ELETTROBAR REB468029

ELETTROBAR 468029

ELETTROBAR REB437019

ELETTROBAR 437019

3060608 O-RING O3050 EPDM



ELETTROBAR 456020

3060018 AIR CHAMBER COMPLETE 75x40x80 mm
hose end fitting \varnothing 5.5 mm
complete with flat gasket and fastening nut



ELETTROBAR DWT23F



Suitable for:

ELETTROBAR



3060601 AIR CHAMBER COMPLETE 85x20x80 mm
 with two O-ring gaskets, bajo bolt and
 hose end fitting ø 5 mm
 for Dishwasher (ELETTROBAR)
 E52
 for Glasswasher/Cupwasher (ELETTROBAR)
 S621 - S624 - S626 - S634 - S636 - 22F
 for Glasswasher/Cupwasher (ELETTROBAR) 22F



ELETTROBAR REB984001
ELETTROBAR 984003

ELETTROBAR 107002

ELETTROBAR 984001


3060605 FITTING
 for Glasswasher/Cupwasher (ELETTROBAR) 22F
 for Glasswasher/Cupwasher (ELETTROBAR) 22F



ELETTROBAR REB468007

ELETTROBAR 468007

3060602 FITTING HOSE-END FOR AIR CHAMBER
 hose end fitting ø 6 mm
 for Glasswasher/Cupwasher (ELETTROBAR) 22F
 for Glasswasher/Cupwasher (ELETTROBAR) 22F



ELETTROBAR REB468053

ELETTROBAR 468053

1186318 O-RING 03043 EPDM
 for Glasswasher/Cupwasher (ELETTROBAR)
 S621 - S636 - 22F
 for Glasswasher/Cupwasher (ELETTROBAR)
 22F



ELETTROBAR CGR3043

ELETTROBAR REB456006

ELETTROBAR 456006

3060603 RETAINING BOLT FOR FITTING
 for Glasswasher/Cupwasher (ELETTROBAR) 22F
 for Glasswasher/Cupwasher (ELETTROBAR) 22F



ELETTROBAR REB486002

ELETTROBAR 486002

3060126 AIR CHAMBER 63x35 mm
 hose end fitting ø 6 mm
 for Dishwasher (ELETTROBAR)
 RIVER50
 for Glasswasher/Cupwasher (ELETTROBAR)
 RIVER40
 for Dishwasher (ELETTROBAR)
 TT820WK



ELETTROBAR 107012

5034334 GASKET FOR AIR CHAMBER
 external ø 33 mm - thickness 2.4 mm
 for Dishwasher hood type (ELETTROBAR)
 NIAGARA381 - RIVER282
 for Pan/utensilwashing machines (ELETTROBAR)
 RIVER298



ELETTROBAR 437098



Suitable for:

5034335 NUT PLASTIC GRAY 3/4"
for Dishwasher hood type (ELETTROBAR)
NIAGARA381 - RIVER282
for Pan/utensilwashing machines (ELETTROBAR)
RIVER298



ELETTROBAR 417120

3060128 RING NUT FOR EXHAUST VALVE PS
for Dishwasher (ELETTROBAR) NIAGARA251
NIAGARA261 - PLUVIA260




ELETTROBAR 429076

ELETTROBAR



Suitable for:


5034976 SYSTEM INLET CRP
overall dimensions 154x97x40 mm
three hose end fittings \varnothing 6/8/22 mm



ELETTROBAR 144027

ELETTROBAR 144032

5025701 TANK AIR-GAP LP COMPLETE
external dimensions 470x165x60 mm
for Dishwasher (ELETTROBAR) RIVER44CRPST
RIVER54CRPSP
for Glasswasher/Cupwasher (ELETTROBAR) RIVER40CRP
for Pan/utensilwashing machines (ELETTROBAR)
U61E - U61HE



ELETTROBAR C.41167

ELETTROBAR 41167

Axial motors

3240501 AXIAL FAN SUNON 120x120x38 mm
ball bearings
230V 50/60Hz 22W 2850rpm
DP200A 2123XBT.GN



ELETTROBAR RGFOC00254

ELETTROBAR RTFOC00254

ELETTROBAR 013480-01R



Suitable for:

ELETTROBAR



Suitable for:

Ball valves and accessories

3526703 BALLCOCK VALVE \varnothing 1/2"FF



ELETTROBAR RTFOC00136


3526693 WATER VALVE \varnothing 1"MF
ball valve
heavy series with PN 25 total passage
aluminium lever



ELETTROBAR 160596

Bearings

9063012 BEARING 6004 DDU NSK
external \varnothing 42mm - internal \varnothing 20mm - thickness 12mm



ELETTROBAR RTBF800094


1063912 BEARING 6201 ZZ NSK
external \varnothing 32mm - internal \varnothing 12mm - thickness 10mm



ELETTROBAR REB314001

ELETTROBAR 314001

1063906 BEARING 6203 ZZ NSK
external \varnothing 40mm - internal \varnothing 17mm - thickness 12mm



ELETTROBAR 314003

Boiler safety valves

3526275 EXHAUST VALVE ASSEMBLY



ELETTROBAR 144994

3526276 EXHAUST VALVE ASSEMBLY
for Dishwasher (ELETTROBAR) PLUVIA260



ELETTROBAR 144995

3526277 EXHAUST VALVE DIAPHRAGM



ELETTROBAR 499092

Suitable for:

Suitable for:

3526008 VENT VALVE
 ø fittings 19 mm



ELETTROBAR REB144003

ELETTROBAR 144003

Boilers

3024009 BOILER ø 145x360 mm
 for Dishwasher (ELETTROBAR) E46 - E50 - E51



ELETTROBAR REB104026

ELETTROBAR 104026

6104060 BOILER ø 145x403 mm
 for Dishwasher (ELETTROBAR)
 NIAGARA261 - PLUVIA260
 for Dishwasher hood type (ELETTROBAR)
 NIAGARA281 - PLUVIA280
 for Dishwasher (ELETTROBAR)
 NIAGARA251



ELETTROBAR 104060

3024034 BOILER ø 145x405 mm
 for Dishwasher (ELETTROBAR) E51 - E52 - 500F
 500FD



ELETTROBAR REB104030

ELETTROBAR 104030

3024013 BOILER ø 145x410 mm
 for Dishwasher (ELETTROBAR) E65
 for Dishwasher hood type (ELETTROBAR) E100 - E110
 for Pan/utensilwashing machines (ELETTROBAR) U60



ELETTROBAR DAB290

ELETTROBAR 926026

3024019 BOILER ø 190x410 mm
 for Dishwasher (ELETTROBAR)
 RIVER70 - RIVER71
 for Dishwasher hood type (ELETTROBAR)
 E78 - RIVER80 - RIVER81 - RIVER82



ELETTROBAR C.80389

ELETTROBAR 80389

3024076 BOILER ø 210x410 mm
 2 holes for heating element
 for Pan/utensilwashing machines (ELETTROBAR) U61
 U61H



ELETTROBAR C.41230

ELETTROBAR 41230



Suitable for:

ELETTROBAR



3024065 COMPLETE BOILER \varnothing 230x635 mm
3 holes for heating element



ELETTROBAR /COM330322

Suitable for:

3024110 COMPLETE BOILER SET \varnothing 110x300 mm
complete with heating element 2600W 230V
for Glasswasher/Cupwasher (ELETTROBAR) E35 - E40



ELETTROBAR REB104039

ELETTROBAR 104039

ELETTROBAR 999244

3024111 COMPLETE BOILER SET \varnothing 115x300 mm
complete with heating element 2600W 230V
for Glasswasher/Cupwasher (ELETTROBAR) E41 - 35F
35FD - 350F - 350FD - 40F - 40FD - 400F
400FD



ELETTROBAR REB104027
ELETTROBAR 104062

ELETTROBAR REB104062
ELETTROBAR 999243

ELETTROBAR 104027

3024075 KIT BOILER COMPLETE \varnothing 110x295 mm
with heating element and 2 contact thermostats
for Glasswasher/Cupwasher (ELETTROBAR) E35 - E40
PLUVIA235 - PLUVIA240



ELETTROBAR 104043.SO

ELETTROBAR 104044.SO

ELETTROBAR 104906


Bushings

3243093 STAINLESS STEEL BUSHING FOR RINSE BOSS



ELETTROBAR /ELF000502

6417111 WASHING ARM BUSHING THREAD 3/4"



ELETTROBAR 417111

Capacitors, electrical

3068019 CAPACITOR μ F 12.5 450V 50/60Hz
operating temperature -25+85°C
in compliance with EEC 93/68 and 92/31 regulations



ELETTROBAR 206003

3068024 CAPACITOR μ F 16 450V 50/60Hz
operating temperature -25+85°C
in compliance with EEC 93/68 and 92/31 regulations



ELETTROBAR REB206004

ELETTROBAR RTFOC00700

ELETTROBAR 206004

3068027 CAPACITOR μ F 20 450V 50/60Hz
operating temperature -25+85°C
in compliance with EEC 93/68 and 92/31 regulations



ELETTROBAR DEC220L
ELETTROBAR 206005

ELETTROBAR REB206005

ELETTROBAR RTFOC00053

3068010 CAPACITOR μ F 6.3 450V 50/60Hz
operating temperature -25+85°C
in compliance with EEC 93/68 and EEC 92/31 regulat



ELETTROBAR 206009




Castors, rollers and accessories

3346010 GUIDE PIN
for Dishwasher hood type (ELETTROBAR) RIVER80
RIVER81 - RIVER82



ELETTROBAR 80131

3346033 HANDLE SUPPORT
for Dishwasher hood type (ELETTROBAR)
RIVER80 - RIVER81 - RIVER82



ELETTROBAR 80190

3346135 HOOD BUMPER
for Dishwasher hood type (ELETTROBAR)
RIVER80 - RIVER81 - RIVER81CRP - RIVER82
RIVER82CRP



ELETTROBAR 80105


3242142 LIFTING WHEEL FOR HOOD
for Dishwasher hood type (ELETTROBAR)
RIVER80 - RIVER81 - RIVER82



ELETTROBAR 80132

ELETTROBAR 80132B

6927092 ROLLER CONVEY. SHAFT \varnothing 30x16x30 mm
for Dishwasher pull-through (ELETTROBAR) CLEAN160
CLEAN161 - CLEAN220 - CLEAN221 - CLEAN270
CLEAN271 - CLEAN272 - CLEAN362



ELETTROBAR DWR120

ELETTROBAR 927092

3346602 ROLLER FOR COVERS SLIDING
for Dishwasher hood type (ELETTROBAR) CLEAN100
E100 - E110 - E120 - E140



ELETTROBAR DWR1520B

ELETTROBAR 926006

3346008 SMALL WHEELS FOR DISHWASHER \varnothing 25



ELETTROBAR 927082

3346030 WHEEL BASE
for Dishwasher hood type (ELETTROBAR) RIVER80
RIVER81 - RIVER82



ELETTROBAR 80130

ELETTROBAR 80130B

ELETTROBAR 80130V



Suitable for:

ELETTROBAR



Suitable for:

Clamps

3449402 DOUBLE-WIRE CLAMP 7.8-8.3 - 100 PCS
for hoses \varnothing 7.8÷8.3 mm



ELETTROBAR REB423011

ELETTROBAR 423011

3449453 HOSE CLAMP 25-40
for pipes \varnothing 25÷40 mm
made of stainless steel AISI 304
height 9 mm and screw E7
suitable for food industry



ELETTROBAR RTBF800171

3449472 HOSE CLAMP 40-60
for pipes \varnothing 40÷60 mm
made of stainless steel AISI 304
height 12 mm and screw E7
suitable for food industry



ELETTROBAR CFS1A

Contact thermostats

3444622 CONTACT SAFETY THERMOSTAT 200°C
with manual reset - pin M4
for Dishwasher (ELETTROBAR)
RIVER50 - RIVER61
for Glasswasher/Cupwasher (ELETTROBAR)
RIVER48




ELETTROBAR 236053

3444244 CONTACT THERMOSTAT 100°C
with manual reset - for boiler



ELETTROBAR /ELF110020

3444607 CONTACT THERMOSTAT 110°C
with manual reset
for Dishwasher (ELETTROBAR)
E46 - E50 - E51 - E52 - NIAGARA51 - RIVER50
RIVER61 - 46F - 460F
for Glasswasher/Cupwasher (ELETTROBAR)
E35H - E40H - E41 - E42 - E45 - NIAGARA40



ELETTROBAR REB236039

ELETTROBAR 236039

ELETTROBAR 236057

3443081 CONTACT THERMOSTAT 125°C M4



ELETTROBAR 236056



Suitable for:

3444608 CONTACT THERMOSTAT 60°C
automatic reset - for wash tank
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E40 - E41 - E42



ELETTROBAR REB236035

ELETTROBAR 236035

Suitable for:

3444606 CONTACT THERMOSTAT 80°C
safety thermostat - for boiler
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E40



ELETTROBAR REB236048


ELETTROBAR 236048

3444610 CONTACT THERMOSTAT 90°C 10A 250V
with automatic reset
for BOILER



ELETTROBAR 236052

3444609 CONTACT THERMOSTAT 95°C
manual reset
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E35H - E40 - E40H - E41 - E42 - NIAGARA40



ELETTROBAR DRT140

ELETTROBAR REB236047

ELETTROBAR 236047


Contactors

3454012 CONTACTOR ABB A30-30-10
32A 400V 15Kw - coil 230V 50/60Hz
3 contacts NO
complete with 2 auxiliary contacts NO



ELETTROBAR

3351209 CONTACTOR AEG LS05 9A 230V 4Kw
coil 230V 50/60Hz
3 normally open contacts
1 normally closed auxiliary contact



ELETTROBAR DTC112

ELETTROBAR REB229032

ELETTROBAR 229010

ELETTROBAR 229011


ELETTROBAR 229019

ELETTROBAR 229032

ELETTROBAR 926040

ELETTROBAR 929122

3351202 CONTACTOR AEG LS07 7A 230V 3Kw
coil 230V 50/60Hz
3 normally open contacts
1 normally open auxiliary contact



ELETTROBAR 926147

3446562 CONTACTOR LOVATO BF0901A
coil 9A 230V 50/60Hz 4.2Kw
3 normally open contacts
1 normally closed auxiliary contact



ELETTROBAR RTCU600371



Suitable for:

ELETTROBAR



Suitable for:

3446561 CONTACTOR LOVATO BF0910A
coil 9A 230V 50/60Hz 4.2Kw
3 normally open contacts
1 normally open auxiliary contact



ELETTROBAR RTBF800153

ELETTROBAR RTFOC00466

3446557 CONTACTOR LOVATO BG0901A
coil 9A 230V 50/60Hz 4Kw
3 normally open contacts
1 normally closed auxiliary contact



ELETTROBAR RTCU600233

3454060 CONTACTOR SCHNEIDER LC1D09B7
9A 400V 4Kw - coil 24V 50/60Hz
3 normally open contacts
1 normally open auxiliary contact
1 normally closed auxiliary contact



ELETTROBAR /ELF060670

3351049 CONTACTOR SIEMENS 3RT2016-1AP01
9A 400V 4Kw - coil 230V 50/60Hz
3 normally open contacts
1 normally open auxiliary contact
for Dishwasher hood type (ELETTROBAR) NIAGARA283



ELETTROBAR 229037

ELETTROBAR 73350

ELETTROBAR 80350

3454072 CONTACTOR SIEMENS 3RT2017-1AB01
12A 400V 5.5Kw - coil 24V 50/60Hz
3 contacts NO
1 NO auxiliary contact



ELETTROBAR DTC250

ELETTROBAR 927051

ELETTROBAR 927160

3454030 CONTACTOR SIEMENS 3RT2024-1AL20
12A 400V 5.5Kw - coil 230V 50/60Hz
3 contacts NO
1 auxiliary contact NO
1 auxiliary contact NC
for Dishwasher pull-through (ELETTROBAR) RIVER150




ELETTROBAR C.80351

ELETTROBAR 80351

Controllers and changeover switches


3322613 CONTROL SELECTOR P265 4 CAMS
1st cycle 60 seconds
2nd cycle 20 minutes
230V 50/60Hz
2 motors
for Dishwasher (ELETTROBAR) E46 - E50 - E51 - E52 - 460F
for Glasswasher/Cupwasher (ELETTROBAR) 460FD



ELETTROBAR REB238066

ELETTROBAR 238066


3322602 CONTROLLER D94 4 CAMS
1st cycle 60 seconds
2nd cycle 120 seconds
3rd cycle 180 seconds
220/240V 50/60Hz
for Dishwasher hood type (ELETTROBAR) S850 - S870



ELETTROBAR 238002

Suitable for:

3322615 CONTROLLER D94.5 CAMS
 1st cycle 120 seconds
 2nd cycle 240 seconds
 3rd cycle 360 seconds
 220/240V 50/60Hz
 2 motors
 for Pan/utensilwashing machines (ELETTROBAR) U132
 U61 - U61H - U70



ELETTROBAR DTP41202

ELETTROBAR 929158

Suitable for:

3322601 CONTROLLER D94.04 3 CAMS LEFT-HAND
 180 seconds cycle
 220/240V 50/60Hz
 D-shaped pin \varnothing 6x4.6 mm
 for Dishwasher (ELETTROBAR) R509 - R511 - R704
 R708 - S641 - S643
 for Dishwasher hood type (ELETTROBAR) S870
 for Glasswasher/Cupwasher (ELETTROBAR) R499 - R501
 R503 - R505 - R507




ELETTROBAR 238001

ELETTROBAR 238001.AG

ELETTROBAR 238005


3322612 CONTROLLER D94.92M 6 CAMS
 1st cycle 60 seconds
 2nd cycle 120 seconds
 3rd cycle 180 seconds
 220/240V 50/60Hz
 2 motors
 for Dishwasher (ELETTROBAR) E60 - E65
 for Dishwasher hood type (ELETTROBAR) E100 - E110
 E120



ELETTROBAR DTP52

ELETTROBAR 926042

3322014 CONTROLLER HFD2M16 2 CAMS
 120 seconds cycle
 rinse 16 seconds
 220/240V 50/60Hz
 clockwise rotation
 D-shaped pin \varnothing 6x4.6 mm



ELETTROBAR DTP11

3322017 CONTROLLER HFD4M16 4 CAMS
 270 seconds cycle
 220/240V 50/60Hz
 D-shaped pin \varnothing 6x4.6 mm



ELETTROBAR DTP15

3322019 CONTROLLER HFD4M16 4 CAMS
 240 seconds cycle
 rinse 16 seconds
 220/240V 50/60Hz
 clockwise rotation
 D-shaped pin \varnothing 6x4.6 mm



ELETTROBAR DTP16

3322241 CONTROLLER HFD4M16 4 CAMS
 180 seconds cycle
 220/240V 50/60Hz 16(4)A
 D-shaped pin \varnothing 6x4.6 mm
 for Dishwasher (ELETTROBAR) L1100 - L49



ELETTROBAR DTP49

ELETTROBAR 926122

3322016 CONTROLLER HH4M16 4 CAMS
 270 seconds cycle
 rinse 16 seconds
 220/240V 50/60Hz
 anticlockwise rotation
 without pin



ELETTROBAR DTP13



Suitable for:

ELETTROBAR



3322068 CONTROLLER HL6M 6 CAMS

60-120-180 seconds cycle
two gear motors
220/240V 50/60Hz



ELETTROBAR DTP21

Suitable for:

3322020 CONTROLLER H5M16

3 cycles for a total of 360 seconds
rinse 17 seconds
220/240V 50/60Hz
clockwise rotation
without pin



ELETTROBAR DTP18

3322609 CONTROLLER PWE5 3 CAMS

150 seconds cycle
230V 50/60Hz
without pin
former model 600/636/5200
for Dishwasher (ELETTROBAR)
S651 - S653 - S655
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - S621 - S623 - S624 - S626 - S631 - S633
S634 - S636 - 11F - 11FD - 11R - 11RD
for Dishwasher (ELETTROBAR)
E35



ELETTROBAR REB238053
ELETTROBAR 238026
ELETTROBAR 238041
ELETTROBAR 238053

ELETTROBAR 238007
ELETTROBAR 238033
ELETTROBAR 238042

ELETTROBAR 238012
ELETTROBAR 238036
ELETTROBAR 238046.AG

3322187 CONTROLLER P255 4 CAMS


215 seconds cycle
230V 50/60Hz
square pin 5x5 mm



ELETTROBAR /ELF000590

3322262 CONTROLLER P265 5 CAMS

1st cycle 72 seconds
2nd cycle 20 seconds
230V 50Hz



ELETTROBAR REB238073

ELETTROBAR 238073

3322190 CONTROLLER 600/645/5238 5 CAMS


230V 50/60Hz



ELETTROBAR /ELF005238

3322611 CONTROLLER 7804DV 4 CAMS


1st cycle 6 seconds
2nd cycle 180 seconds
230V 50/60Hz
3 motors
for Dishwasher (ELETTROBAR) 500F - 500FD



ELETTROBAR 238061

3322614 CONTROLLER 7811DV 11 CAMS

1st cycle 90 seconds
2nd cycle 20 minutes
230V 50/60Hz
2 motors
for Glasswasher/Cupwasher (ELETTROBAR) CLEAN3




ELETTROBAR REB238067

ELETTROBAR 238067

Suitable for:


3322605 **CONTROLLER 9449 1 CAM**
 40 seconds cycle
 220/240V 50/60Hz
 without pin
 for Dishwasher (ELETTROBAR)
 S653
 for Glasswasher/Cupwasher (ELETTROBAR)
 S623 - S626 - S633 - S636 - 11FD - 11RD



ELETTROBAR 238011

Suitable for:

3322115 **REGENERATION CONTROLLER 1 CAM**
 40 seconds cycle
 220/240V 50/60Hz
 for Glasswasher/Cupwasher (ELETTROBAR) E35 - E40
 E41 - E42 - E45



ELETTROBAR REB238052

ELETTROBAR 238052

3322607 **TIMER 7003F3 3 CAMS**
 cycle 6 minutes
 230V 50HZ



ELETTROBAR 238050

ELETTROBAR 238050.AG

1348705 **CIRCLIP E-8**
 out of stainless steel for springs C60
 internal \varnothing 7.4 mm - thickness 0.8 mm
 UNI 7435 - DIN 471



ELETTROBAR REB499066

ELETTROBAR 499066

3241934 **KNOB FOR PROGRAMMENR COMPLETE \varnothing 45 mm**



ELETTROBAR REB226051


ELETTROBAR REB447089

ELETTROBAR 226051

ELETTROBAR 447089

Curtains

6927259 **CURTAIN INTAKE/OUTLET 545x575 mm**
 for Dishwasher pull-through (ELETTROBAR) CLEAN160
 CLEAN161 - CLEAN220 - CLEAN221 - CLEAN270
 CLEAN271 - CLEAN272 - CLEAN362



ELETTROBAR DWT69LNT

ELETTROBAR 927259

3456024 **INLET/OUTLET CURTAIN 545x405 mm**
 for Dishwasher pull-through (ELETTROBAR)
 RIVER150
 for Dishwasher (ELETTROBAR)
 NIAGARA2150



ELETTROBAR 75120



Suitable for:

ELETTROBAR



Suitable for:

Door catches

3398043 DOOR CATCH



ELETTROBAR DWS40

ELETTROBAR 927278

3398601 DOOR CATCH

for Dishwasher (ELETTROBAR) S641 - S643
for Glasswasher/Cupwasher (ELETTROBAR) S621 - S623
S624 - S626 - S631 - S633 - S634 - S636 - 21F
21R - 31F - 31R



ELETTROBAR 994001

3398605 DOOR CATCH
for Glasswasher/Cupwasher (ELETTROBAR)
22F - 22R



ELETTROBAR DWS30

ELETTROBAR 994011

ELETTROBAR 994012

3398606 STAINLESS STEEL DOOR RETAINER
for Glasswasher/Cupwasher (ELETTROBAR) 22F - 22R



ELETTROBAR REB325030

ELETTROBAR 325030

6329012 LATCH LOCK ENHANCED
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E40 - E41



ELETTROBAR REB329012

ELETTROBAR 329012

3398077 PAWL SPRING
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E41 - E42 - 11 - 350 - 356 - 40 - 400



ELETTROBAR REB449036

ELETTROBAR 449036

Door gaskets for dishwashers

3786034 DOOR GASKET
profile dimensions 20x6 mm
sold per metre
for U60÷132
for Pan/utensilwashing machines (ELETTROBAR)
U132 - U132E - U60 - U60E - U61 - U61E - U61H
U61HE - U70 - U70E



ELETTROBAR 41247

ELETTROBAR 41247MT

6437071 DOOR GASKET 1160 mm
profile dimensions 17x12 mm



ELETTROBAR 437071

Suitable for:

Suitable for:


3786035 DOOR GASKET 1370 mm
 profile dimensions 13x11 mm
 for Dishwasher (ELETTROBAR)
 RIVER50 - RIVER50D - RIVER61
 for Glasswasher/Cupwasher (ELETTROBAR)
 RIVER48



ELETTROBAR 437088

ELETTROBAR 437097


6437057 DOOR GASKET 395 mm
 profile dimensions 16x11 mm
 for Glasswasher/Cupwasher (ELETTROBAR)
 FAST135



ELETTROBAR REB437057

ELETTROBAR 437057

6437058 DOOR GASKET 430 mm
 profile dimensions 16x11 mm
 per LAVABICCHIERI 40F-400-E40
 for Glasswasher/Cupwasher (ELETTROBAR)
 E40 - 40F - 400



ELETTROBAR REB437058

ELETTROBAR 437058

3786037 DOOR GASKET 567 mm
 for 050F-050FP
 profile dimensions 32x7 mm
 for Dishwasher (ELETTROBAR)
 E50 - E51



ELETTROBAR REB437081


ELETTROBAR 437081

6437052 DOOR GASKET 585 mm
 profile dimensions 32x7 mm



ELETTROBAR 437052

6437075 DOOR GASKET 590 mm
 profile dimensions 21x6 mm



ELETTROBAR REB437075

ELETTROBAR 437075

6437103 GASKET HOLDER 555x400 mm
 for Dishwasher (ELETTROBAR) NIAGARA251
 NIAGARA261 - PLUVIA260



ELETTROBAR 437103

Drain assembly

3316036 COMPLETE DRAIN ASSEMBLY \varnothing 1"1/2
 connection \varnothing 1"1/2



ELETTROBAR C.42185

ELETTROBAR 42185

3316008 DRAIN ASSEMBLY \varnothing 3/4"
 threaded part 48 mm
 complete with ring nut and gasket



ELETTROBAR RIC0002701

ELETTROBAR RIC0002783

ELETTROBAR 3600077



Suitable for:

ELETTROBAR



3316601 DRAIN ASSEMBLY CONNECTION \varnothing 1"1/4
 hole \varnothing 35 mm
 for Dishwasher (ELETTROBAR) E120 - E140
 for Dishwasher pull-through (ELETTROBAR) CLEAN160
 CLEAN220 - CLEAN270 - CLEAN271



ELETTROBAR DZP14CC

ELETTROBAR 929036

3316602 EXTENSION FOR DRAIN ASSEMBLY - CONN. \varnothing 1
 for Dishwasher hood type (ELETTROBAR) E120 - E140



ELETTROBAR DWP89

ELETTROBAR 926050

3186615 GASKET FLAT RUBBER \varnothing 51x40x2.5 mm
 for Dishwasher (ELETTROBAR)
 E46 - E50 - E51 - 46F - 46FD - 460F
 for Glasswasher/Cupwasher (ELETTROBAR)
 E45 - 460FD



ELETTROBAR CGG42

ELETTROBAR 437063

3316606 DRAIN ASSEMBLY CONNECTION \varnothing 1"1/4
 outlet external \varnothing 31 mm
 for Dishwasher (ELETTROBAR)
 E46 - E50 - E51 - 46F - 46FD - 460F - 460FD
 for Glasswasher/Cupwasher (ELETTROBAR)
 E45



ELETTROBAR REB136023

ELETTROBAR 136023

3186615 GASKET FLAT RUBBER \varnothing 51x40x2.5 mm
 for Dishwasher (ELETTROBAR)
 E46 - E50 - E51 - 46F - 46FD - 460F
 for Glasswasher/Cupwasher (ELETTROBAR)
 E45 - 460FD



ELETTROBAR CGG42

ELETTROBAR 437063

3243902 NUT PLASTIC - CONNECTION \varnothing 1"1/4
 for Dishwasher (ELETTROBAR)
 E46 - E50 - E51 - 46F - 46FD - 460F
 for Glasswasher/Cupwasher (ELETTROBAR)
 E45 - 460FD



ELETTROBAR CDP2

ELETTROBAR CDZ14

ELETTROBAR 417081



Suitable for:

3316053 DRAIN ASSEMBLY ELBOW \varnothing 1"1/4
inlet \varnothing 34 mm
outlet \varnothing 30 mm



ELETTROBAR DZP13

3243902 NUT PLASTIC - CONNECTION \varnothing 1"1/4
for Dishwasher (ELETTROBAR)
E46 - E50 - E51 - 46F - 46FD - 460F
for Glasswasher/Cupwasher (ELETTROBAR)
E45 - 460FD



ELETTROBAR CDP2

ELETTROBAR CDZ14

ELETTROBAR 417081

3316603 PLASTIC DRAIN ASSEMBLY 3/4"
inner hole \varnothing 22 mm
for Glasswasher/Cupwasher (ELETTROBAR)
E41 - E42 - 10F - 11F - 11R - 11RD - 35F - 35FD
350F - 350FD - 40F - 40FD - 400F - 400FD



ELETTROBAR REB429036

ELETTROBAR REB429048

ELETTROBAR 429036

ELETTROBAR 429048

3316605 DRAIN ELBOW
outlet external \varnothing 25 mm
for Glasswasher/Cupwasher (ELETTROBAR) E41 - E42
10F - 11F - 11FD - 11R - 11RD



ELETTROBAR REB463008

ELETTROBAR 463008

3186615 GASKET FLAT RUBBER \varnothing 51x40x2.5 mm
for Dishwasher (ELETTROBAR)
E46 - E50 - E51 - 46F - 46FD - 460F
for Glasswasher/Cupwasher (ELETTROBAR)
E45 - 460FD



ELETTROBAR CGG42

ELETTROBAR 437063

3316604 DRAIN ELBOW
outlet external \varnothing 25 mm
for Glasswasher/Cupwasher (ELETTROBAR) 35F - 35FD
350F - 350FD - 40F - 40FD - 400F - 400FD



ELETTROBAR REB463009

ELETTROBAR 463009

3186616 GASKET FLAT ASBESTOS FREE \varnothing 35x27x1.5mm



ELETTROBAR REB437025

ELETTROBAR 437025

1186655 O-RING 04131 EPDM



ELETTROBAR REB456016

ELETTROBAR 456016



Suitable for:


ELETTROBAR



Suitable for:

Drain hoses

3450186 DRAIN PIPE \varnothing 23x630 mm
sleeves internal \varnothing 21 mm
for Glasswasher/Cupwasher (ELETTROBAR)
CLEAN3



ELETTROBAR REB127037

ELETTROBAR 127037

6143137 DRAIN PIPE \varnothing 24x2500 mm
bent hose internal \varnothing 22 mm
straight hose internal \varnothing 18 mm
for Dishwasher (ELETTROBAR)
E50
for Dishwasher (ELETTROBAR)
E50 - E51




ELETTROBAR REB143137

ELETTROBAR 143017

ELETTROBAR 143030

ELETTROBAR 143137

3450184 DRAIN PIPE \varnothing 24x350 mm
elbow sleeves internal \varnothing 20 mm
for Glasswasher/Cupwasher (ELETTROBAR) RIVER44



ELETTROBAR 127083

3450188 DRAIN PIPE \varnothing 28x300 mm
sleeves internal \varnothing 23 mm



ELETTROBAR REB127044

ELETTROBAR 127044

3450028 DRAIN PIPE \varnothing 29x1500 mm
muffs internal \varnothing 24 and 28 mm
max temperature 90°C



ELETTROBAR 143019

6143252 DRAIN PIPE \varnothing 29x1700 mm
hose internal \varnothing 29 mm



ELETTROBAR 143252

3450187 DRAIN PIPE \varnothing 32x1500 mm
sleeve internal \varnothing 40 mm
for Glasswasher/Cupwasher (ELETTROBAR) 22 - 44F



ELETTROBAR REB143183

ELETTROBAR 143183

3450038 DRAIN PIPE \varnothing 34x2000 mm
muff internal \varnothing 33 mm
max temperature 90°C
for Dishwasher (ELETTROBAR)
E50
for Dishwasher (ELETTROBAR)
E50 - E51



ELETTROBAR DZS14


ELETTROBAR REB143178

ELETTROBAR 143178



Suitable for:

3450067 DRAIN PIPE \varnothing 42x500 mm
 elbow sleeve internal \varnothing 50 mm
 straight sleeve internal \varnothing 40 mm
 for Dishwasher (ELETTROBAR) E52 - E65S
 for Dishwasher hood type (ELETTROBAR) E100 - E110
 E120 - E140
 for Pan/utensilwashing machines (ELETTROBAR) U60



ELETTROBAR 127032

Suitable for:

3450604 DRAIN PIPE \varnothing 50x1900 mm
 elbow sleeve internal \varnothing 50 mm
 pipe internal \varnothing 35 mm
 max temperature 90°C



ELETTROBAR DES155
 ELETTROBAR 143136

ELETTROBAR DZS155

ELETTROBAR REB143136

Drain plugs

3179604 COMPLETE DRAIN ASSEMBLY
 in plastic
 for Glasswasher/Cupwasher (ELETTROBAR) 11F - 11FD
 11R - 11RD



ELETTROBAR 999067

6142058 OVERFLOW \varnothing 35x200 mm
 for Glasswasher/Cupwasher (ELETTROBAR) NIAGARA251
 NIAGARA261 - NIAGARA281 - PLUVIA260



ELETTROBAR 142058

3448314 OVERFLOW PIPE \varnothing 21x100 mm
 for Glasswasher/Cupwasher (ELETTROBAR) E41 - E42



ELETTROBAR REB142037

ELETTROBAR 142037

3448607 OVERFLOW PIPE \varnothing 21x98 mm
 in plastic
 for Glasswasher/Cupwasher (ELETTROBAR) 11F - 11FD
 11R - 11RD



ELETTROBAR REB142014

ELETTROBAR 142014

3448616 OVERFLOW PIPE \varnothing 22x165 mm
 made of plastic
 for Glasswasher/Cupwasher (ELETTROBAR) 40F - 40FD
 40R - 40RD - 400F - 400FD - 400R - 400RD



ELETTROBAR REB142034

ELETTROBAR 142034

3448614 OVERFLOW PIPE \varnothing 22x168 mm
 made of plastic
 for Glasswasher/Cupwasher (ELETTROBAR)
 E40 - E45 - MISTRAL40 - NIAGARA35 - RIVER40



ELETTROBAR REB142051

ELETTROBAR 142051



Suitable for:

Suitable for:

3448608 OVERFLOW PIPE \varnothing 24x153 mm
 made of plastic
 for Glasswasher/Cupwasher (ELETTROBAR) 350 - 350F



ELETTROBAR REB142038

ELETTROBAR 142038

3160602 OVERFLOW PIPE \varnothing 25x215 mm - GREY
 for Glasswasher/Cupwasher (ELETTROBAR) S621 - S623
 S624 - S626 - S631 - S633 - S634 - S636 - 21F
 21R - 31F



ELETTROBAR REB142023

ELETTROBAR 142008

ELETTROBAR 142023

1186327 O-RING 03081 EPDM



ELETTROBAR REB456010

ELETTROBAR 456010

ELETTROBAR 456021

3448196 OVERFLOW PIPE \varnothing 32x215 mm
 for Dishwasher (ELETTROBAR)
 RIVER50 - RIVER50D - RIVER61
 for Glasswasher/Cupwasher (ELETTROBAR)
 RIVER48



ELETTROBAR 142054

3448054 OVERFLOW PIPE \varnothing 34x220 mm
 of plastic



ELETTROBAR DZT558

ELETTROBAR 929035

3448195 OVERFLOW PIPE \varnothing 35x147 mm
 for drain electropump
 for Dishwasher (ELETTROBAR)
 E46 - E50 - E51 - MISTRAL51 - NIAGARA51
 for Glasswasher/Cupwasher (ELETTROBAR)
 E45 - NIAGARA45



ELETTROBAR REB142042

ELETTROBAR REB142053

ELETTROBAR 142042

3448613 OVERFLOW PIPE \varnothing 36x148 mm
 made of plastic
 for Dishwasher (ELETTROBAR)
 E46 - E50 - E51 - MISTRAL51 - NIAGARA51 - 46F
 46FD - 460F
 for Glasswasher/Cupwasher (ELETTROBAR)
 E45 - NIAGARA45 - 460FD



ELETTROBAR REB142052

ELETTROBAR 142035

ELETTROBAR 142052

ELETTROBAR 142053

Suitable for:

Suitable for:

3448615 OVERFLOW PIPE \varnothing 37x385 mm
made of plastic
for Pan/utensilwashing machines (ELETTROBAR)
U61 - U61H

1186655 O-RING 04131 EPDM



ELETTROBAR C.41180

ELETTROBAR 041180

ELETTROBAR 80250

ELETTROBAR REB456016

ELETTROBAR 456016

3448605 OVERFLOW PIPE \varnothing 38x160 mm
in plastic
for Dishwasher (ELETTROBAR) R509 - R511 - R704
S641 - S651

3448601 OVERFLOW PIPE \varnothing 38x200 mm
in plastic
for Glasswasher/Cupwasher (ELETTROBAR) R497 - R499
R501 - R503 - R505 - R507



ELETTROBAR 142011

ELETTROBAR 142007

3448167 OVERFLOW PIPE \varnothing 38x287 mm
made of plastic
for Dishwasher (ELETTROBAR)
RIVER71
for Dishwasher hood type (ELETTROBAR)
RIVER80 - RIVER81
for Pan/utensilwashing machines (ELETTROBAR)
U60E

1186655 O-RING 04131 EPDM



ELETTROBAR C.80249

ELETTROBAR C80249

ELETTROBAR 80249

ELETTROBAR REB456016

ELETTROBAR 456016

3448612 OVERFLOW PIPE \varnothing 39x240 mm
made of plastic
for Dishwasher (ELETTROBAR) E52 - E60 - E65 - E65S
for Dishwasher hood type (ELETTROBAR) CLEAN100
E110
for Glasswasher/Cupwasher (ELETTROBAR) 22F - 44F
440F
for Pan/utensilwashing machines (ELETTROBAR) U60

1186655 O-RING 04131 EPDM



ELETTROBAR REB142022

ELETTROBAR 142022

ELETTROBAR REB456016

ELETTROBAR 456016



Suitable for:

ELETTROBAR



Suitable for:

3448050 OVERFLOW PIPE \varnothing 40x110 mm
in plastic



ELETTROBAR DZT551

Drain pumps

3122327 DRAIN ELECTRIC PUMP 40W 240V 50Hz
inlet external \varnothing 24 mm - output external \varnothing 23 mm
for Dishwasher (ELETTROBAR)
E46 - E50 - E51 - MISTRAL51 - NIAGARA51
for Glasswasher/Cupwasher (ELETTROBAR)
RIVER40



ELETTROBAR REB130105
ELETTROBAR 130176

ELETTROBAR 130105

ELETTROBAR 130146

3122906 DRAIN ELECTRO-PUMP 40W 230/240V 50Hz
inlet external \varnothing 30 mm - outlet external \varnothing 23 mm



ELETTROBAR C.80117

ELETTROBAR 130177

ELETTROBAR 80117


3122199 DRAIN ELECTRO-PUMP 40W 230V 50Hz
inlet external \varnothing 30 mm - outlet external \varnothing 22 mm
for Dishwasher (ELETTROBAR)
E35



ELETTROBAR REB130123

ELETTROBAR 130123

3122828 DRAIN PUMP GRE 220V 50Hz
for Glasswasher/Cupwasher (ELETTROBAR) CLEAN3



ELETTROBAR REB130112

ELETTROBAR 130112

3122833 DRAIN PUMP H-21 100W 230V 50Hz
inlet internal \varnothing 26 mm outlet internal \varnothing 22 mm
for Glasswasher/Cupwasher (ELETTROBAR) 21F - 21FD
21R - 21RD - 25F - 25FD - 25R - 25RD - 30F
30FD - 30R - 30RD - 31F - 31FD - 31R - 31RD



ELETTROBAR 130083

3122835 FILTER \varnothing 47 mm FOR GRE PUMP



ELETTROBAR 121053

Suitable for:

3122834 DRAIN PUMP H-32 100W 220/240V 50Hz
inlet \varnothing 30 mm
outlet \varnothing 22 mm



ELETTROBAR 130071

ELETTROBAR 130084


Suitable for:

3122835 FILTER \varnothing 47 mm FOR GRE PUMP




ELETTROBAR 121053

3122822 DRAIN PUMP 100 W 220/240V 50HZ
inlet internal \varnothing 30 mm outlet internal \varnothing 23 mm
for Glasswasher/Cupwasher (ELETTROBAR) 44F - 440F



ELETTROBAR 130094


3122837 DRAIN PUMP 100 W 220/240V 50HZ
inlet external \varnothing 35 mm outlet external \varnothing 30 mm
for Dishwasher (ELETTROBAR) E60 - E65
for Dishwasher hood type (ELETTROBAR) E120 - E140



ELETTROBAR DPE1108R

ELETTROBAR 929114

3122836 DRAIN PUMP 100W 220/240V 50HZ
inlet internal \varnothing 35 mm outlet internal \varnothing 23 mm
for Dishwasher hood type (ELETTROBAR) E100 - E110




ELETTROBAR DPE1108

ELETTROBAR 926103

Electrical cables

3050150 ELECTRICAL CABLE FOR POWER SUPPLY
with plug SCHUKO - 3 wires \varnothing 1.5 mm
overall length 2500 mm



ELETTROBAR REB299040

ELETTROBAR 299040



Suitable for:



Suitable for:

Electronic controllers

3441049 ELECTRONIC THERMOMETER -30/+110°C

power supply 12V AC-DC
 complete with probe type NTC
 mounting hole 58x25 mm
 for Dishwasher pull-through (ELETTROBAR) CLEAN161
 CLEAN221 - CLEAN271 - CLEAN272 - CLEAN362



ELETTROBAR DET164

ELETTROBAR 927333

Electronic printed-circuit boards

5058739 BOARD GET50.1 LA500 BASE dimensions 136x80 mm



ELETTROBAR 215034

ELETTROBAR 215034-3

6041523 CABLE FLAT 10-POLE 1200 m m FOR WAREWASHER



ELETTROBAR 41523

3390194 CABLE FLAT 10-POLE 3100 mm

for Dishwasher (ELETTROBAR)
 MISTRAL51 - NIAGARA51 - RIVER50 - RIVER50D
 RIVER61 - RIVER71
 for Dishwasher hood type (ELETTROBAR)
 RIVER80 - RIVER81 - RIVER82
 for Glasswasher/Cupwasher (ELETTROBAR)
 MISTRAL40 - NIAGARA35 - NIAGARA40 - NIAGARA45
 RIVER40 - RIVER43 - RIVER48
 for Pan/utensilwashing machines (ELETTROBAR)
 U60E




ELETTROBAR 80933

ELETTROBAR 926272


Suitable for:

3390034 CIRCUIT BOARD
 without EPROM
 dimensione 135x100 mm
 for Dishwasher (ELETTROBAR)
 MISTRAL51 - NIAGARA51 - RIVER50 - RIVER61
 RIVER70
 for Dishwasher hood type (ELETTROBAR)
 RIVER78 - RIVER80 - RIVER81 - RIVER82
 for Glasswasher/Cupwasher (ELETTROBAR)
 MISTRAL40 - NIAGARA35 - NIAGARA40 - NIAGARA45
 RIVER40 - RIVER43



ELETTROBAR 215023

3390088 MICROPROCESSOR GET.5 NIAGARA-RIVER
 for Dishwasher (ELETTROBAR) NIAGARA - RIVER



ELETTROBAR 225029

3390036 SET OF 2 TEMPERATURE PROBES GET-5
 bulb \varnothing 5x30 mm
 length 350 mm
 for tank and boiler




ELETTROBAR DWS100

ELETTROBAR 231014

ELETTROBAR 231016

3390601 CIRCUIT BOARD
 for Dishwasher (ELETTROBAR) 50F - 50FD
 for Glasswasher/Cupwasher (ELETTROBAR) 35F - 35FD
 35R - 35RD - 40F - 40FD - 40R - 40RD



ELETTROBAR REB215013

ELETTROBAR 215013


Suitable for:

5028103 CONNECTOR 5-POLE
 for Glasswasher/Cupwasher (ELETTROBAR)
 MISTRAL40 - NIAGARA35 - NIAGARA40 - NIAGARA45



ELETTROBAR CN5

3390035 MICROPROCESSOR GET.5 EB



ELETTROBAR 225024

5037825 SPIKE FOR CONNECTOR (GET5)
 for Glasswasher/Cupwasher (ELETTROBAR)
 MISTRAL40 - NIAGARA35 - NIAGARA40 - NIAGARA45



ELETTROBAR CN7

3390602 TEMPERATURE PROBE



ELETTROBAR REB231006

ELETTROBAR 231006




Suitable for:

ELETTROBAR



3390210 CONTROL BOARD
dimensions 97x120 mm
for Dishwasher hood type (ELETTROBAR)



ELETTROBAR DES101

ELETTROBAR 80889

ELETTROBAR 80900

6080934 CABLE FLAT 10-POLE LENGTH 730 mm
for NIAGARA 281
for Dishwasher hood type (ELETTROBAR) NIAGARA281



ELETTROBAR DWS90

ELETTROBAR 80934

5054819 ELECTROMECHANICAL BOARD MWASH
dimensions 133x82 mm
for Dishwasher (ELETTROBAR)
E500 - FAST160 - FAST161D
for Dishwasher hood type (ELETTROBAR)
PLUVIA280




ELETTROBAR 215029

ELETTROBAR 215033

ELETTROBAR 215038


5059436 ELECTRONIC CIRCUIT BOARD
dimensions 177x126 mm



ELETTROBAR 215032

ELETTROBAR 215032-1

6215027 ELECTRONIC CIRCUIT BOARD
dimensions 152x80 mm
for NIAGARA 251/261/281



ELETTROBAR 215027

3390195 HOOD MICROPROCESSOR RIVER NM
for Dishwasher hood type (ELETTROBAR)
RIVER80 - RIVER81 - RIVER82 - RIVER82CRP




ELETTROBAR 81000

3390369 MICROPROCESSOR
for Dishwasher pull-through (ELETTROBAR) RIVER140
RIVER150



ELETTROBAR 81003

7109050 PC BOARD GET50
dimensions 152x80 mm



ELETTROBAR 999298



Suitable for:

6227074 PUSH BUTTON PANEL
 dimensions 170x35 mm
 for Dishwasher (ELETTROBAR)
 NIAGARA 251 - NIAGARA 261
 for Dishwasher hood type (ELETTROBAR)
 NIAGARA 281
 for Pan/utensilwashing machines (ELETTROBAR)
 NIAGARA 293



ELETTROBAR 227074

Suitable for:


6080929 PUSH-BUTTON BOARD GET50-LA50
 dimensions 220x40 mm
 for Dishwasher (ELETTROBAR) RIVER252 - RIVER253
 RIVER262
 for Dishwasher hood type (ELETTROBAR) RIVER282



ELETTROBAR 227083

ELETTROBAR 80929

3390191 SUPPLEMENTARY CIRCUIT BOARD
 for Dishwasher pull-through (ELETTROBAR)
 RIVER150 - RIVER152 - RIVER154



ELETTROBAR 215022

3319253 4 BUTTONS 2 DISPLAY BOARD NEW MODEL
 totally interchangeable with the old model
 dimensions 285x35 mm
 for Dishwasher (ELETTROBAR)
 MISTRAL51 - NIAGARA51 - RIVER50 - RIVER50D
 RIVER61 - RIVER71
 for Dishwasher hood type (ELETTROBAR)
 RIVER80 - RIVER81 - RIVER82
 for Glasswasher/Cupwasher (ELETTROBAR)
 MISTRAL40 - NIAGARA35 - NIAGARA40 - NIAGARA45
 RIVER40 - RIVER43 - RIVER48
 for Pan/utensilwashing machines (ELETTROBAR)
 U60E



ELETTROBAR 227059

ELETTROBAR 227084

3319250 10-WAYS FLAT CABLE 2300 mm
 for Dishwasher (ELETTROBAR)
 MISTRAL51 - NIAGARA51 - RIVER50 - RIVER50D
 RIVER61
 for Glasswasher/Cupwasher (ELETTROBAR)
 MISTRAL40 - NIAGARA35 - NIAGARA40 - NIAGARA45
 RIVER48



ELETTROBAR 211009

Feet


3313076 ADJUSTABLE FOOT \varnothing 29h
 overall height 32 mm - thread M8x20



ELETTROBAR REB461019

ELETTROBAR 461019

3313601 HEXAGONAL FOOT
 for Glasswasher/Cupwasher (ELETTROBAR)
 S623 - S624 - S626 - S631 - S633 - S634



ELETTROBAR REB461010

ELETTROBAR 461010



Suitable for:

ELETTROBAR



Suitable for:

3313005 STAINLESS STEEL FOOT \varnothing 2" x h 125 mm
with fixed screw M12x25 mm



ELETTROBAR DWP128U

ELETTROBAR 926117

Filters

3160217 DRAIN PUMP FILTER \varnothing 62x117 mm
for Dishwasher (ELETTROBAR)
E46 - E50 - E51 - MISTRAL51 - NIAGARA51
for Glasswasher/Cupwasher (ELETTROBAR)
E45 - NIAGARA45



ELETTROBAR REB121078

ELETTROBAR 121078

3160604 EXTERNAL FILTER \varnothing 135x90 mm - GREY
for Glasswasher/Cupwasher (ELETTROBAR) S621 - S623
S624 - S626 - S631 - S633 - S634 - S636 - 21F
21R



ELETTROBAR REB121054

ELETTROBAR 121014

ELETTROBAR 121054

5026564 FILTER COLLECTION WITH HANDLE
external dimensions 355x118x164 mm
for Dishwasher pull-through (ELETTROBAR)
NIAGARA2150 - RIVER150



ELETTROBAR 75146

5027996 FILTER PLASTIC COMPLETE
dimensions 542x270 mm
for Dishwasher hood type (ELETTROBAR) E78
RIVER78



ELETTROBAR 80259

3160623 FILTER SUPPORT WITH EXTENSION
for Dishwasher (ELETTROBAR)
E46 - E50 - E51 - 460F
for Glasswasher/Cupwasher (ELETTROBAR)
E45 - 460FD



ELETTROBAR 478045+478046

ELETTROBAR 478059

3160616 DRAIN OUTLET BODY
for Glasswasher/Cupwasher (ELETTROBAR)
22F - 22R - 44F



ELETTROBAR REB136020

ELETTROBAR 136020



Suitable for:

3160615 O-RING GASKET 0201 EPDM
for Glasswasher/Cupwasher (ELETTROBAR)
22F - 22R - 44F



ELETTROBAR REB456040

ELETTROBAR 456040

ELETTROBAR



Suitable for:

3160613 PUMP FILTER ø 155x120 mm
for Dishwasher hood type (ELETTROBAR)
RIVER80 - RIVER81 - RIVER82
for Glasswasher/Cupwasher (ELETTROBAR)
22F - 22R - 44F
for Pan/utensilwashing machines (ELETTROBAR)
U61 - U61H



ELETTROBAR DAF136U


ELETTROBAR 121052

ELETTROBAR REB121081

ELETTROBAR 121081

ELETTROBAR 121018


3186614 SUPPORT GASKET
for Dishwasher (ELETTROBAR)
E46 - E50 - E51 - 460F
for Glasswasher/Cupwasher (ELETTROBAR)
E45 - 460FD



ELETTROBAR REB437015

ELETTROBAR 437015

6121123 FILTER TANK PLASTIC 485x223 mm
for Dishwasher (ELETTROBAR) NIAGARA251
NIAGARA261 - PLUVIA260 - PLUVIA270
for Dishwasher hood type (ELETTROBAR) NIAGARA281
PLUVIA280



ELETTROBAR 121123

3160511 INLET/DRAIN UNIT
for Dishwasher (ELETTROBAR) NIAGARA251
NIAGARA261 - PLUVIA260
for Dishwasher hood type (ELETTROBAR) NIAGARA281



ELETTROBAR 136028

5037066 GASKET OR ø 135.9x5.33 mm



ELETTROBAR 456076




Suitable for:

3160513 INLET/DRAIN FILTER
bottom \varnothing 190 mm
top \varnothing 114 mm
height 100 mm
for Dishwasher (ELETTROBAR)
NIAGARA251 - NIAGARA261 - PLUVIA260



ELETTROBAR 121120

3160512 RING NUT FOR INLET/DRAIN UNIT
for Dishwasher (ELETTROBAR) NIAGARA251
NIAGARA261 - PLUVIA260



ELETTROBAR 429072

3160605 INTERNAL FILTER \varnothing 136x75 mm - GREY
for Glasswasher/Cupwasher (ELETTROBAR) S621 - S623
S624 - S626 - S631 - S633 - S634 - S636 - 21F
21R




ELETTROBAR REB121055

ELETTROBAR 121016

ELETTROBAR 121055

ELETTROBAR 121082

3160622 PLASTIC WASH PUMP FILTER \varnothing 112 mm
for Dishwasher (ELETTROBAR)
E46 - E50 - E51 - 460F
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E40 - E45 - NIAGARA40 - 460FD




ELETTROBAR REB121100

ELETTROBAR 121100

ELETTROBAR 121144

3160617 PLASTIC WASH TANK FILTER 245x245 mm
for Dishwasher (ELETTROBAR) E52
for Dishwasher hood type (ELETTROBAR) E100
for Glasswasher/Cupwasher (ELETTROBAR) 22F - 22R



ELETTROBAR REB121056

ELETTROBAR 121056

ELETTROBAR



Suitable for:

3160514 RING NUT FOR CENTRAL CONDUIT x5 \varnothing 1"1/2
for Dishwasher hood type (ELETTROBAR)
RIVER82



ELETTROBAR 429069



Suitable for:

Suitable for:

3160620 PUMP PLASTIC FILTER \varnothing 110 mm
for Glasswasher/Cupwasher (ELETTROBAR) 10F - 11F
11FD - 11R - 11RD



ELETTROBAR REB121076

ELETTROBAR 121047

ELETTROBAR 121076

3186611 GASKET FLAT FIBRE \varnothing 45x34x1.5 mm
for Glasswasher/Cupwasher (ELETTROBAR) 10F - 11F
11FD - 11R - 11RD



ELETTROBAR REB437027

ELETTROBAR 437027

3160621 PUMP INLET CONNECTOR
connection \varnothing 1"
for Glasswasher/Cupwasher (ELETTROBAR) 10F - 11F
11FD - 11R - 11RD



ELETTROBAR 468103

3160614 RETAINING ASSEMBLY FOR DRAIN
for Glasswasher/Cupwasher (ELETTROBAR)
22F - 22R - 44F




ELETTROBAR REB429038

ELETTROBAR 429038

ELETTROBAR 429067

ELETTROBAR 80470

6121111 TANK FILTER 246x265 mm
for Dishwasher (ELETTROBAR) E55



ELETTROBAR 121111

3160619 WASH TANK FILTER \varnothing 245x245 mm WITH HOLE
in plastic
for Dishwasher (ELETTROBAR) E52
for Glasswasher/Cupwasher (ELETTROBAR) 22F - 22R



ELETTROBAR 121057

3160462 WATER FILTER \varnothing 1/2" FF



ELETTROBAR DZF32

ELETTROBAR 927078



Suitable for:

ELETTROBAR



Suitable for:

Fittings

3090609 FITTING FOR RINSE AID INLET
 for boiler
 for Dishwasher (ELETTROBAR)
 E65
 for Dishwasher hood type (ELETTROBAR)
 E100 - E110
 for Pan/utensilwashing machines (ELETTROBAR)
 U60



ELETTROBAR REB468117

ELETTROBAR 468117

3186613 GASKET FLAT FIBRE \varnothing 12x8x1.5 mm
 for Dishwasher (ELETTROBAR)
 E65
 for Dishwasher hood type (ELETTROBAR)
 E100 - E110
 for Pan/utensilwashing machines (ELETTROBAR)
 U60



ELETTROBAR REB437021

ELETTROBAR 437021

3349347 NICHEL-PL.HOSE-END FITTING \varnothing 3/8" M \varnothing 12



ELETTROBAR DZR263

ELETTROBAR 927015

3349334 NICHEL-PLATED FITTING \varnothing 1/2" M-3/8" F



ELETTROBAR DZR550

ELETTROBAR 927234

1349169 T-FITTING \varnothing 1/2" F-1/2" F-1/2" F



ELETTROBAR DZR227

3090616 T-FITTING FOR BOILER
 for Glasswasher/Cupwasher (ELETTROBAR) S621 - S623
 S624 - S626 - S631 - S633 - S634 - S636



ELETTROBAR 468027

ELETTROBAR 468027.CR

3090608 BOILER OUTLET FITTING



ELETTROBAR 468005

Fuses

3049019 DELAY FUSE \varnothing 5x20 mm - 10 PCS
 250V 4A



ELETTROBAR 228010

3049021 DELAY FUSE \varnothing 5x20 mm - 10 PCS
 250V 8A



ELETTROBAR RTFOC00284

ELETTROBAR RTFOC00734



Suitable for:

3049036 QUICK ACTING FUSE \varnothing 5x20 mm - 10 PCS
250V 100mA



ELETTROBAR RTFOC00047

Suitable for:

3049041 QUICK ACTING FUSE \varnothing 5x20 mm - 10 PCS
250V 315mA



ELETTROBAR DEF72

ELETTROBAR 926283

3049045 QUICK ACTING FUSE \varnothing 5x20 mm - 10 PCS
250V 800mA



ELETTROBAR DEF71

ELETTROBAR 926284

3049052 QUICK ACTING FUSE \varnothing 5x20 mm - 10 PCS
250V 4A



ELETTROBAR 228004

Gaskets and seals

3243671 BOSS GASKET



ELETTROBAR REB437016

ELETTROBAR 437016

3786036 FLAT PTFE GASKET \varnothing 22x9x1 mm
for rinse arm
for Glasswasher/Cupwasher (ELETTROBAR)
RIVER48



ELETTROBAR 437090

5048655 GASKET FLAT EPDM \varnothing 45x33x2 mm
shore 70°



ELETTROBAR 437104

3186149 GASKET FLAT EPDM \varnothing 62x42x3 mm
external \varnothing 62 mm.
internal \varnothing 42 mm



ELETTROBAR 437038

5049890 GASKET FLAT EPDM \varnothing 64x49x2 mm



ELETTROBAR 437108

6437102 GASKET FLAT EPDM \varnothing 75x57x2 mm
for Dishwasher (ELETTROBAR) NIAGARA251
NIAGARA261
for Dishwasher hood type (ELETTROBAR) NIAGARA281
PLUVIA280



ELETTROBAR 437102



Suitable for:

ELETTROBAR



Suitable for:

6437091 GASKET FLAT PTFE \varnothing 13x6x0.5 mm



ELETTROBAR 437091

Guides


5014124 COVER SLIDEWAY 588 mm



ELETTROBAR 80068

ELETTROBAR 80069

5033994 SLIDER CONVEYOR SHAFT CARRIAGE
for Dishwasher pull-through (ELETTROBAR)
NIAGARA2150 - NIAGARA2156 - RIVER150



ELETTROBAR 75075

Handles

3242381 FIXING DOOR CLAMP



ELETTROBAR /COM341016

5037999 HANDLE BRIDGE GRAY
distance between holes 73 mm



ELETTROBAR DWP910

ELETTROBAR 926243

3242602 HANDLE FOR DOOR 140x29 mm
for Glasswasher/Cupwasher (ELETTROBAR) S621 - S623
S631 - S633



ELETTROBAR 447036

3242071 HANDLE STAINLESS STEEL
length 412 mm
for S-N-SE-NE-AC-ACR-G



ELETTROBAR /COM331012

3242072 HANDLE SUPPORT



ELETTROBAR /COM190129

Suitable for:

5051174 PULL HANDLE HOOD RIVER
for Dishwasher hood type (ELETTROBAR)
NIAGARA281 - PLUVIA280 - RIVERE78 - RIVER80
RIVER81 - RIVER82



ELETTROBAR 80027

Suitable for:

3242373 SAFETY HOOK FOR DOOR



ELETTROBAR /COM331112

Heating elements

6467002 COVER FOR HEATING ELEMENT BOILER
ø 68 mm - height 40 mm
for Dishwasher (ELETTROBAR)
E50 - FAST160 - FAST161 - PLUVIA260 - PLUVIA270
RIVER362C - RIVER362T
for Dishwasher hood type (ELETTROBAR)
PLUVIA280 - RIVER282



ELETTROBAR REB467002

ELETTROBAR 467002

ELETTROBAR 69870

3355625 HEATING ELEMENT FOR BOILER 10000W 230V
immersed length 375 mm
external ø flange 72 mm - with probe receptacle
complete with O-Ring gasket ø 67 mm (3186014)
for Dishwasher pull-through (ELETTROBAR) CLEAN160
CLEAN220 - CLEAN270 - CLEAN271 - CLEAN361
CLEAN471



ELETTROBAR 927276

3355118 HEATING ELEMENT FOR BOILER 2000W 220V
immersed length 180 mm
connection ø 1" 1/4 (43 mm)
complete with gasket ø 54 mm (3186010)
nut (3528232) and washer (3528238) on request
for Dishwasher (ELETTROBAR) S641 - S643
for Glasswasher/Cupwasher (ELETTROBAR) R497 - R499
R501 - R503 - R505 - R507



ELETTROBAR 230003

3186010 ASBESTOS FREE FLAT GASKET ø 54x42x2 mm



ELETTROBAR 437028

3355195 HEATING ELEMENT FOR BOILER 2100W 220V
immersed length 295 mm
triangular flange with side 60 mm
distance between holes 45 mm



ELETTROBAR DRB21



Suitable for:

Suitable for:

3355601 HEATING ELEMENT FOR BOILER 2400W 220V
 immersed length 200 mm
 external \varnothing flange 63 mm - with probe receptacle
 complete with O-Ring gasket \varnothing 58 mm (3186013)
 for Glasswasher/Cupwasher (ELETTROBAR) S621 - S623
 S624 - S626 - S631 - S633 - S634 - S636

3186013 O-RING GASKET 06187 EPDM \varnothing 58 mm



ELETTROBAR REB230090
ELETTROBAR 230090

ELETTROBAR 230010

ELETTROBAR 230023

ELETTROBAR REB456002

ELETTROBAR 456002

ELETTROBAR 456079

3355196 HEATING ELEMENT FOR BOILER 2500W 220V
 immersed length 285 mm
 flange 80x27 mm - complete with gasket



ELETTROBAR DRV24

3355608 HEATING ELEMENT FOR BOILER 2600/2850W 23
 immersed length 275 mm
 width 50 mm - flange 70x25 mm
 complete with gasket 22x65 mm (3355609)
 for Dishwasher (ELETTROBAR)
 35 - 50
 for Glasswasher/Cupwasher (ELETTROBAR)
 11 - 400F
 for Dishwasher (ELETTROBAR) E35D - 400F

3355609 GASKET FOR HEATING ELEMENT 22x65 mm



ELETTROBAR 230057

ELETTROBAR 230087

ELETTROBAR REB437048

ELETTROBAR 437048

3355618 HEATING ELEMENT FOR BOILER 2600W 230V
 immersed length 270 mm
 width 65 mm - flange 80x27 mm
 for Glasswasher/Cupwasher (ELETTROBAR) NIAGARA40

3455334 HEATING ELEMENT FOR BOILER 2600W 230V
 immersed length 265 mm
 external \varnothing flange 55 mm - with probe receptacle
 complete with O-Ring gasket \varnothing 48 mm (3186001)
 for Glasswasher/Cupwasher (ELETTROBAR)
 E41 - 35F - 350F - 350FD - 40F - 400F - 400FD
 for Dishwasher (ELETTROBAR)
 FAST135D



ELETTROBAR REB230100

ELETTROBAR 230100

ELETTROBAR 230113

Suitable for:

Suitable for:

3355620 HEATING ELEMENT FOR BOILER 2935W 230V
 immersed length 340 mm
 width 55 mm - flange 70x25 mm
 for Dishwasher (ELETTROBAR)
 50F - 50FD - 500F - 500FD



ELETTROBAR REB230088

ELETTROBAR 230075

ELETTROBAR 230088

3355190 HEATING ELEMENT FOR BOILER 3000W 230/380
 immersed length 195 mm
 external \varnothing flange 72 mm - with probe receptacle
 complete with gasket OR \varnothing 67 mm (3186014)
 nut (3528232) and washer (3528238) on request



ELETTROBAR DRB32

3186014 O-RING GASKET 06225 EPDM \varnothing 67 mm



ELETTROBAR /COM200815
 ELETTROBAR 929046

ELETTROBAR CGG55

ELETTROBAR 167956

3455032 HEATING ELEMENT FOR BOILER 3000W 230V
 immersed length 230 mm
 flange 90x75 mm
 complete with gasket (3186004)



ELETTROBAR /ELF203049

3355191 HEATING ELEMENT FOR BOILER 4000W 230/380
 immersed length 320 mm
 external \varnothing flange 72 mm - with probe receptacle
 complete with gasket OR \varnothing 67 mm (3186014)
 nut (3528232) and washer (3528238) on request



ELETTROBAR DRB41

3186014 O-RING GASKET 06225 EPDM \varnothing 67 mm



ELETTROBAR /COM200815
 ELETTROBAR 929046

ELETTROBAR CGG55

ELETTROBAR 167956



Suitable for:

ELETTROBAR



Suitable for:

3355412 HEATING ELEMENT FOR BOILER 4500W 230/415
 immersed length 370 mm
 external flange \varnothing 72 mm
 with probe receptacle \varnothing 8 mm
 complete with gasket \varnothing 67 mm (3186014)
 nut (3528232) and washer (3528238) on request

3186014 O-RING GASKET 06225 EPDM \varnothing 67 mm



ELETTROBAR RTCU700619

ELETTROBAR /COM200815
ELETTROBAR 929046

ELETTROBAR CGG55

ELETTROBAR 167956

3455409 HEATING ELEMENT FOR BOILER 4900W 230/400
 immersed length 330 mm
 external \varnothing flange 63 mm - with probe receptacle
 con guarnizione OR \varnothing 58 mm (3186013)
 for Dishwasher (ELETTROBAR)
 NIAGARA251 - NIAGARA261 - PLUVIA260



ELETTROBAR 230111

3355193 HEATING ELEMENT FOR BOILER 5000W 230/380
 immersed length 375 mm
 external \varnothing flange 72 mm -with probe receptacle
 complete with gasket OR \varnothing 67 mm (3186014)
 nut (3528232) and washer (3528238) on request

3186014 O-RING GASKET 06225 EPDM \varnothing 67 mm



ELETTROBAR DRB51

ELETTROBAR 929040

ELETTROBAR /COM200815
ELETTROBAR 929046

ELETTROBAR CGG55

ELETTROBAR 167956

3355602 HEATING ELEMENT FOR BOILER 5355W 240/415
 immersed length 340 mm
 ext. \varnothing flange 63 mm - with bulbholder sheathing
 complete with gasket OR \varnothing 58 mm (3186013)
 nut (3528232) and washer (3528238) on request
 for Dishwasher (ELETTROBAR)
 R651 - R653 - R654 - R655 - S810 - S815 - S830
 S835 - S950
 for Dishwasher hood type (ELETTROBAR)
 S850 - S870

3186013 O-RING GASKET 06187 EPDM \varnothing 58 mm



ELETTROBAR REB230034
ELETTROBAR 230034

ELETTROBAR REB230081
ELETTROBAR 230081

ELETTROBAR 230014

ELETTROBAR REB456002

ELETTROBAR 456002

ELETTROBAR 456079



Suitable for:

Suitable for:

3355626 HEATING ELEMENT FOR BOILER 7600W 230V
 immersed length 385 mm
 width 65 mm - flange 80x27 mm
 for Dishwasher (ELETTROBAR)
 RIVER50 - RIVER61
 for Glasswasher/Cupwasher (ELETTROBAR)
 RIVER48

3455411 HEATING ELEMENT FOR BOILER 7600W 400V
 immersed length 330 mm
 external \varnothing flange 63 mm - with probe receptacle
 con guarnizione OR \varnothing 58 mm (3186013)
 for Dishwasher hood type (ELETTROBAR)
 NIAGARA281 - PLUVIA280



ELETTROBAR 230106

ELETTROBAR 230117

3355194 HEATING ELEMENT FOR BOILER 8000W 230/380
 immersed length 375 mm
 external \varnothing flange 72 mm - with probe receptacle
 complete with O-Ring gasket \varnothing 67 mm (3186014)

3186014 O-RING GASKET 06225 EPDM \varnothing 67 mm



ELETTROBAR DRB81C

ELETTROBAR 927280

ELETTROBAR /COM200815
 ELETTROBAR 929046

ELETTROBAR CGG55

ELETTROBAR 167956

3355621 HEATING ELEMENT FOR BOILER 8000W 230/400
 immersed length 365 mm
 ext. \varnothing flange 63 mm - with bulbholder sheathing
 complete with gasket OR \varnothing 58 mm (3186013)
 nut (3528232) and washer (3528238) on request
 for Dishwasher hood type (ELETTROBAR)
 RIVER81
 for Dishwasher pull-through (ELETTROBAR)
 RIVER150
 for Pan/utensilwashing machines (ELETTROBAR)
 U70
 for Dishwasher hood type (ELETTROBAR)
 E110



ELETTROBAR REB230020
 ELETTROBAR 230020

ELETTROBAR REB230020C
 ELETTROBAR 230020C

ELETTROBAR REB230095
 ELETTROBAR 230095

3355171 HEATING ELEMENT FOR BOILER 9800W 230V
 immersed length 320 mm
 flange 90x75 mm - with bulbholder sheathing
 complete with gasket 3186004
 nut (3528232) and washer (3528238) on request

3186004 GASKET FLAT RUBBER 87x70x5
 central hole \varnothing 50 mm



ELETTROBAR /ELF003340

ELETTROBAR RIC0000659

ELETTROBAR /ELF000343



Suitable for:

ELETTROBAR



3455412 HEATING ELEMENT FOR TANK 1400W 230V
immersed length 150 mm - width 120 mm
with tube of dispelling paste
for Dishwasher (ELETTROBAR)
RIVER50



ELETTROBAR 230104

ELETTROBAR 999206

Suitable for:

6230102 HEATING ELEMENT FOR TANK 1600W 230V
immersed length 310 mm
flange 50x27 mm - complete with gasket



ELETTROBAR 230102

3355603 HEATING ELEMENT FOR TANK 2000W 220V
immersed length 170 mm
width 140 mm - fittings \varnothing 14 mm
for Glasswasher/Cupwasher (ELETTROBAR) R495



ELETTROBAR 230016

3355604 HEATING ELEMENT FOR TANK 2000W 220V
immersed length 275 mm
width 120 mm - connection \varnothing 10 mm
for Glasswasher/Cupwasher (ELETTROBAR) S621 - S623
S624 - S626 - S631 - S633 - S634 - S636 - 11F
11FD - 11R



ELETTROBAR 230017

3355197 HEATING ELEMENT FOR TANK 2500W 220V
immersed length 260 mm
width 130 mm - height 60 mm
flange 50x27 mm - complete with gasket



ELETTROBAR DRV21

3355199 HEATING ELEMENT FOR TANK 2500W 220V
immersed length 255 mm
width 40 mm - fittings \varnothing 10 mm



ELETTROBAR DRV23

3355200 HEATING ELEMENT FOR TANK 2500W 220V
immersed length 455 mm
width 50 mm - flange 50x27 mm
complete with gasket



ELETTROBAR DRV25

3355372 HEATING ELEMENT FOR TANK 2700W 230V
immersed length 380 mm
width 70 mm - fittings \varnothing 14 mm



ELETTROBAR /ELF203089



Suitable for:

Suitable for:

3355198 HEATING ELEMENT FOR TANK 4500W 220/380V
 immersed length 250 mm
 width 81 mm - height 60 mm
 flange 81x46 mm - complete with gasket

3355619 HEATING ELEMENT FOR TANK 600W 230V
 immersed length 155 mm
 width 47 mm - flange 50x27 mm
 for Glasswasher/Cupwasher (ELETTROBAR)
 E35 - E35H - E40 - E40H - NIAGARA40



ELETTROBAR DRV41

ELETTROBAR 230098

3355617 HEATING ELEMENT TANK 1000/1200W 220/240V
 immersed length 145 mm
 width 45 mm - fittings \varnothing 10 mm
 for Glasswasher/Cupwasher (ELETTROBAR) 350F
 350FD - 350R - 350RD - 400F - 400FD - 400R
 400RD

3355611 HEATING ELEMENT TANK 2050/2450W 220/240V
 immersed length 290 mm
 width 120 mm - fittings \varnothing 10 mm
 for Dishwasher (ELETTROBAR) R509



ELETTROBAR REB230077

ELETTROBAR 230077

ELETTROBAR 230006

ELETTROBAR 230009

ELETTROBAR 230044

ELETTROBAR 230085

3355607 HEATING ELEMENT TANK 2750/3250W 220/240V
 immersed length 370 mm
 connections \varnothing 10 mm
 for Dishwasher (ELETTROBAR)
 22 - 44 - 50
 for Dishwasher hood type (ELETTROBAR)
 CLEAN100
 for Dishwasher (ELETTROBAR)
 E500D

3755073 HEATING ELEMENT TANK 3000W 230V
 immersed depth 320 mm
 width 55 mm - fittings \varnothing 10 mm
 complete with nuts and gaskets
 for Dishwasher (ELETTROBAR)
 RIVER71
 for Dishwasher hood type (ELETTROBAR)
 RIVER80 - RIVER81 - RIVER82
 for Pan/utensilwashing machines (ELETTROBAR)
 U60E



ELETTROBAR REB230060

ELETTROBAR REB230086

ELETTROBAR 230060

ELETTROBAR C.80360

ELETTROBAR 80360

ELETTROBAR 80677

ELETTROBAR 230086

3355168 HEATING ELEMENT TANK 5700W 220/240V
 immersed length 310 mm
 width 85 mm - fitting \varnothing 1" 1/4 (43 mm)
 complete with gasket \varnothing 54 mm (3186010)

3455408 HEATING ELEMENT WITH BLADES 2000W 240V
 immersed length 440 mm
 length of part with blades 400 mm
 width 195 mm - fittings \varnothing 14 mm
 for Dishwasher pull-through (ELETTROBAR)
 RIVER150



ELETTROBAR /ELF003260

ELETTROBAR DRE2

ELETTROBAR 927132



Suitable for:

ELETTROBAR



3455410 HEATING ELEMENT 1400W 230V
immersed length 190 mm
width 160 mm - flange 50x27 mm
complete with gasket
for Dishwasher (ELETTROBAR) NIAGARA251
NIAGARA261 - PLUVIA260



ELETTROBAR 230112

Suitable for:

3355201 HEATING ELEMENT 1500W 220V
immersed length 150 mm
connection \varnothing 1" (33 mm)
complete with gasket \varnothing 45 mm (3186009)



ELETTROBAR

5061400 HEATING ELEMENT 2100W 230V
immersed length 270 mm
width 160 mm - flange 50x27 mm
complete with gasket



ELETTROBAR 230118

3355119 HEATING ELEMENT 3000W 220/380V
for boiler and tank
immersed length 295 mm
fitting for fastening \varnothing 1"1/2 (48 mm)
complete with gasket \varnothing 63 mm (3186011)
for Dishwasher (ELETTROBAR) R708
for Dishwasher hood type (ELETTROBAR) S870



ELETTROBAR 230008

3186011 FLAT CARBO GASKET \varnothing 63x48x2 mm
universal carbo
for heating element



ELETTROBAR 437029

3755947 HEATING ELEMENT 3000W 230V
immersed depth 385 mm
width 78 mm - fittings \varnothing 10 mm



ELETTROBAR 41211

Suitable for:

Suitable for:

5047328 HEATING ELEMENT 3000W 230V
immersed length 335 mm
ext. \varnothing flange 63 mm - with bulbholder sheathing

3186013 O-RING GASKET 06187 EPDM \varnothing 58 mm



ELETTROBAR 230116

ELETTROBAR REB456002

ELETTROBAR 456002

ELETTROBAR 456079

3355105 HEATING ELEMENT 4200W 230/380V
for boiler and wash tank
immersed depth 340 mm
flange external \varnothing 72 mm - with bulb-sheathing
complete with gasket OR \varnothing 67 mm (3186014)

3186014 O-RING GASKET 06225 EPDM \varnothing 67 mm



ELETTROBAR /COM110331

ELETTROBAR /COM200815

ELETTROBAR CGG55

ELETTROBAR 167956

ELETTROBAR 929046

3355169 HEATING ELEMENT 5200W 240/415 6400W 254/
for boiler
immersed depth 330 mm - flange 90x75 mm
complete with gasket (3186004)
nut (3528232) and washer (3528238) on request

3186004 GASKET FLAT RUBBER 87x70x5
central hole \varnothing 50 mm



ELETTROBAR /ELF033200

ELETTROBAR /ELF000343

3355623 HEATING ELEMENT 5500W 220/380V 6543W 240
for boiler
immersed length 360 mm
flange external \varnothing 63 mm - with probe receptacle
complete with gasket OR \varnothing 58 mm (3186013)
nut (3528232) and washer (3528238) on request
for Pan/utensilwashing machines (ELETTROBAR) U61
U61H



ELETTROBAR REB230083

ELETTROBAR 230083



Suitable for:

ELETTROBAR



Suitable for:

3755946 HEATING ELEMENT 9500W 230V
 immersed length 335 mm
 flange external \varnothing 63 mm - bulbholder sheathing
 complete with gasket OR \varnothing 58 mm (3186013)
 nut (3528232) and washer (3528238) on request
 for Dishwasher hood type (ELETTROBAR)
 RIVER80 - RIVER81 - RIVER82



ELETTROBAR C.80398

ELETTROBAR 80398

ELETTROBAR 80398C

3186013 O-RING GASKET 06187 EPDM \varnothing 58 mm



ELETTROBAR REB456002

ELETTROBAR 456002

ELETTROBAR 456079

3455413 KIT HEATING ELEMENT 6000W 240/415V
 immersed length 360 mm
 external \varnothing flange 63 mm - with probe receptacle
 complete with O-Ring gasket \varnothing 58 mm (3186013) e co
 cap for contact protection
 for Dishwasher hood type (ELETTROBAR)
 E78



ELETTROBAR REB230083C

ELETTROBAR 230083C


3755138 SELF STICKING HEATING ELEMENT 130W 230V
 sizes 130x85 mm



ELETTROBAR 230080.AG

Hinges, catches and accessories

6310013 CENTRAL BLOCK HINGES / PIN
 for NIAGARA 251/261-PULVIA 260
 for Dishwasher (ELETTROBAR) NIAGARA251
 NIAGARA261 - NIAGARA361 - PLUVIA260



ELETTROBAR 310013

5038629 DOOR BALANCE SPRING
 \varnothing 10.5x197 mm
 for Dishwasher (ELETTROBAR)
 RIVER262
 PLUVIA270 - RIVER362C - RIVER362T



ELETTROBAR 449059

ELETTROBAR 449063

3053613 DOOR ROD STRIKE PIN
 for Glasswasher/Cupwasher (ELETTROBAR)
 E40 - E40H - MISTRAL40 - NIAGARA40



ELETTROBAR REB307005

ELETTROBAR 307005

3053614 DOOR STRIKE PIN SMALL PLATE
 for Glasswasher/Cupwasher (ELETTROBAR)
 E40 - E40H - MISTRAL40 - NIAGARA40



ELETTROBAR REB028078

ELETTROBAR 028078



Suitable for:

3053615 DOOR SLIDE ROD 270 mm
for Dishwasher (ELETTROBAR)
E46 - E50 - E51 - E55 - MISTRAL51 - NIAGARA51
50F - 50FD - 500F - 500FD
for Glasswasher/Cupwasher (ELETTROBAR)
E45 - NIAGARA45



ELETTROBAR REB304021

ELETTROBAR 304018

ELETTROBAR 304021

Suitable for:

3398609 DOOR RETAINER
for Dishwasher (ELETTROBAR)
E46 - E50 - E51 - E55 - MISTRAL51 - NIAGARA51
50F - 50FD - 500F - 500FD
for Glasswasher/Cupwasher (ELETTROBAR)
E45 - NIAGARA45



ELETTROBAR REB417041

ELETTROBAR 417041

3398607 STRIKE PLATE
for Dishwasher (ELETTROBAR)
E50 - E51 - E55 - MISTRAL51 - NIAGARA51 - 50F
50FD - 500F - 500FD
for Glasswasher/Cupwasher (ELETTROBAR)
E40 - E45 - NIAGARA45



ELETTROBAR REB307003

ELETTROBAR 307003

3053260 DOOR STRIKE PIN SMALL PLATE
for Dishwasher (ELETTROBAR) 453 - 463 - 50 - 503



ELETTROBAR REB028086

ELETTROBAR 028086

ELETTROBAR 28086

3053606 HINGE FOR DOOR LH
for Dishwasher (ELETTROBAR) E52
for Glasswasher/Cupwasher (ELETTROBAR) E41 - E42
11F - 11FD - 11R - 11RD



ELETTROBAR 311005.CR

3053611 HINGE PIN
for Glasswasher/Cupwasher (ELETTROBAR) 11F - 11FD
11R - 11RD



ELETTROBAR 325022



Suitable for:

ELETTROBAR



Suitable for:

3053608 LEFT-HAND DOOR STRIKE PIN HINGE
for Dishwasher (ELETTROBAR) E52
for Glasswasher/Cupwasher (ELETTROBAR) E41 - E42
11F - 11FD - 11R - 11RD



ELETTROBAR 307008

3053605 HINGE FOR DOOR RH
for Dishwasher (ELETTROBAR) E52
for Glasswasher/Cupwasher (ELETTROBAR) E41 - E42
11F - 11FD - 11R - 11RD



ELETTROBAR 311006.CR

3053607 RIGHT-HAND DOOR STRIKE PIN HINGE
for Dishwasher (ELETTROBAR) E52
for Glasswasher/Cupwasher (ELETTROBAR) E41 - E42
11F - 11FD - 11R - 11RD



ELETTROBAR 307009

3053148 PIN ASSY WITH CONNECTING ROD
ø 5x310 mm
for Dishwasher (ELETTROBAR) E65S
for Pan/utensilwashing machines (ELETTROBAR) U60



ELETTROBAR DAT43
ELETTROBAR 929016

ELETTROBAR DWP380
ELETTROBAR 999229

ELETTROBAR 929015

3053149 GASKET FOR DOOR CONNECTING ROD PLATE
dimensions 69x16 mm



ELETTROBAR DAP83

ELETTROBAR 929209

3053612 HINGE PIN ø 8x19 mm
for Glasswasher/Cupwasher (ELETTROBAR) E41 - E42



ELETTROBAR 325033

3053199 DOOR HINGE PIN



ELETTROBAR DWP37

ELETTROBAR 929018

1250023 RADIAL SEEGER RING ø 5 mm
stainless steel - external ø 11.3 - thickness 0.7
UNI 7434 - DIN 6799



ELETTROBAR CWA5D5I

ELETTROBAR 929017



Suitable for:

3053157 SPRING RING RADIAL \varnothing 7 mm
inox - external \varnothing 14.3 mm - thickness 0.9 mm
UNI 7434 - DIN 6799



ELETTROBAR CWA5D7

ELETTROBAR 929014

ELETTROBAR



Suitable for:

3053150 TIE ROD PLATE 60x15 mm



ELETTROBAR DAP74

ELETTROBAR 929210

3053601 RIGHT-HAND DOOR HINGE
for Glasswasher/Cupwasher (ELETTROBAR) S621 - S623
S624 - S626 - S631 - S633 - S634 - S636




ELETTROBAR 311001.CR

6307014 STRIKE FOR SPRING AND CATCH
for DISHWASHER NIAGARA 251/261



ELETTROBAR 307014

6307015 STRIKE PLATE FOR DOOR SHAFT
for NIAGARA 251/261-PULVIA 260



ELETTROBAR 307015

Hose-end fittings

3315031 ELBOW FITTING INLET/OUTLET BOILER
thread 1/4" - tapered connection \varnothing 12 mm
for Dishwasher hood type (ELETTROBAR)
E100 - E110
for Glasswasher/Cupwasher (ELETTROBAR)
RIVER40
for Pan/utensilwashing machines (ELETTROBAR)
U60 - U65



ELETTROBAR DZR2915

ELETTROBAR REB108006

ELETTROBAR 108006

3315014 RINSE HOSE-END FITTING
 \varnothing insert 12 mm
for all new models
for Dishwasher hood type (ELETTROBAR)
RIVER80 - RIVER81 - RIVER82



ELETTROBAR REB143173

ELETTROBAR 143173

ELETTROBAR 143268

3315102 T HOSE-END FITTING 11.5 mm



ELETTROBAR 929085



Suitable for:

ELETTROBAR



Suitable for:

Hydraulic piping

6143174 HOSE RINSE 142 mm
external \varnothing 10 mmm - internal \varnothing 7 mm



ELETTROBAR REB143174

ELETTROBAR 143174

3243696 INSERT FOR CLAMP
for Dishwasher (ELETTROBAR)
E50 - E51 - E52 - E60 - E65
for Dishwasher hood type (ELETTROBAR)
E100 - E110



ELETTROBAR REB441009

ELETTROBAR 441009

3450622 PRESSURE SWITCH PIPE \varnothing 5x11 mm - 5 m
temperature $-30^{\circ}+110^{\circ}\text{C}$
operating pressure 10 bar
burst pressure 40 bar
non-toxic rubber hose
external \varnothing 11 mm
internal \varnothing 5 mm
5-m bundles
for 50-m bundles see 3450652



ELETTROBAR SPG10

ELETTROBAR 143005

3450652 PRESSURE SWITCH PIPE \varnothing 5x11 mm - 50 m
temperature $-30^{\circ}+110^{\circ}\text{C}$
operating pressure 10 bar
burst pressure 40 bar
non-toxic rubber hose
external \varnothing 11 mm
internal \varnothing 5 mm
50-m bundles
for 5-m bundles see 3450622



ELETTROBAR SPG10

ELETTROBAR 143005

3450176 PVC \varnothing 4x7 mm - 150 m



ELETTROBAR REB143013

ELETTROBAR 143013

3449298 PVC HOSE CLEAR \varnothing 4x6 mm
sold per meter



ELETTROBAR H.775601

3450114 PVC PIPE \varnothing 4/7 mm - 10 mt
alimentary



ELETTROBAR REB143194

ELETTROBAR 143194

3450214 PVC PIPE \varnothing 4/7 mm - 100 m
alimentary



ELETTROBAR REB143194

ELETTROBAR 143194



Suitable for:

Suitable for:

3450209 RUBBER PIPE \varnothing 13x20 mm - 40 m
operating temperature -40+100°C

3450651 RUBBER PIPE 110°C. \varnothing 10x16 mm - 40 m
temperature -30°+110°C
operating pressure 10 bar
burst pressure 40 bar
non-toxic rubber hose
external \varnothing 16 mm
internal \varnothing 10 mm
40-m rolls
for 5-m rolls see 3450621



ELETTROBAR SPG17

ELETTROBAR SPG61

ELETTROBAR 143010

ELETTROBAR REB143004

ELETTROBAR REB143182

ELETTROBAR 143004

ELETTROBAR 143182

3450621 RUBBER PIPE 110°C. \varnothing 10x16 mm - 5 m
temperature -30°+110°C
operating pressure 10 bar
burst pressure 40 bar
non-toxic rubber hose
external \varnothing 16 mm
internal \varnothing 10 mm
for 40 m rolls see 3450651

3450125 RUBBER PIPE 20x30 mm
sold per meter
for Pan/utensilwashing machines (ELETTROBAR)
U134 - U61 - U70



ELETTROBAR REB143004

ELETTROBAR REB143182

ELETTROBAR 143004

ELETTROBAR SPG2230

ELETTROBAR 929171

ELETTROBAR 143182

Indicator lights

3221132 GREEN INDICATOR LAMP 230V
head \varnothing 13.5 mm - hole \varnothing 10 mm - 120°C
universal application

3221164 GREEN INDICATOR LAMP 230V
head \varnothing 7 mm - hole \varnothing 6 mm - 120°C
dashboard mounting



ELETTROBAR REB216019

ELETTROBAR 216019

ELETTROBAR DEL15

ELETTROBAR REB216022

ELETTROBAR 216022

3221082 GREEN INDICATOR LAMP 24V
hole \varnothing 11.5 mm
head \varnothing 18 mm

3221083 RED INDICATOR LAMP 24V
hole \varnothing 11.5 mm
head \varnothing 18 mm



ELETTROBAR /COM130117

ELETTROBAR /COM130118



Suitable for:

ELETTROBAR



3221499 GREEN INDICATOR LAMP 250V
head \varnothing 14 mm - hole \varnothing 13 mm



ELETTROBAR

Suitable for:

3221262 GREEN LAMP RECEPTACLE
head \varnothing 14.5 mm - hole \varnothing 12 mm



ELETTROBAR DEP142

ELETTROBAR 926114

5045040 INDICATOR LAMP GREEN 12/24V
head \varnothing 7 mm - hole \varnothing 6 mm
with cable length 220 mm
for Dishwasher hood type (ELETTROBAR)
C600



ELETTROBAR 216028

6216029 INDICATOR LAMP ORANGE 12/24V
head \varnothing 7 mm - hole \varnothing 6 mm
with cable length 200 mm
for Dishwasher hood type (ELETTROBAR)
PLUVIA280



ELETTROBAR 216029

5056480 INDICATOR LAMP ORANGE 12V
head \varnothing 7 mm - hole \varnothing 6 mm
with cable length 280 mm
for Dishwasher (ELETTROBAR)
since 17/11/14
PLUVIA260
for Glasswasher/Cupwasher (ELETTROBAR)
since 15/03/13
PLUVIA240



ELETTROBAR 216032

6927237 INDICATOR LAMP ORANGE 24V
head \varnothing 14 mm - hole \varnothing 12 mm



ELETTROBAR DEL105A

ELETTROBAR 927237

3221024 INDICATOR LAMP RED 230V
head \varnothing 15 mm - hole \varnothing 13 mm - 120°C
faston M 6.3x0.8 mm
universal application



ELETTROBAR RTCU900071

ELETTROBAR RTCU900291

3221025 INDICATOR LAMP ORANGE 230V
head \varnothing 15 mm - hole \varnothing 13 mm - 120°C
faston M 6.3x0.8 mm
universal application



ELETTROBAR RTCU900072

ELETTROBAR RTCU900488



Suitable for:

3221020 LAMP RECEPTACLE ORANGE
 hole \varnothing 12 mm
 head \varnothing 14.5 mm
 universal application



ELETTROBAR DEP140

ELETTROBAR 926115

Suitable for:

3221126 INDICATOR LAMP 24V
 head \varnothing 8 mm



ELETTROBAR DEL99

3221097 NEUTRAL INDICATOR LAMP 220V
 head \varnothing 8 mm - 120°C
 for Dishwasher (ELETTROBAR)
 50F - 50FD - 500F - 500FD
 for Glasswasher/Cupwasher (ELETTROBAR)
 35F - 35R - 35RD - 350F - 350R - 350RD - 40F - 40R
 40RD - 400F - 400R - 400RD



ELETTROBAR DEL25

ELETTROBAR DEL31

ELETTROBAR REB216006

ELETTROBAR 216006

ELETTROBAR 926113

3221112 ORANGE INDICATOR LAMP 220V
 head \varnothing 7 mm - hole \varnothing 6 mm - 120°C
 application to the board
 for Dishwasher hood type (ELETTROBAR) E78



ELETTROBAR DEL14

ELETTROBAR 926287

3221095 ORANGE INDICATOR LAMP 230V
 head \varnothing 13.5 mm - hole \varnothing 10 mm - 120°C
 universal application



ELETTROBAR /ELF281007

ELETTROBAR B.30168500

ELETTROBAR DEL10

ELETTROBAR REB216020

ELETTROBAR 216018

ELETTROBAR 216020

3221096 ORANGE INDICATOR LAMP 230V
 head \varnothing 7 mm - hole \varnothing 6 mm
 wire connection length 210 mm



ELETTROBAR REB216003

ELETTROBAR REB216025

ELETTROBAR 216003

ELETTROBAR 216005

ELETTROBAR 216025

3221137 ORANGE INDICATOR LAMP 250V
 \varnothing head 14 mm - \varnothing hole 12 mm - 120°C



ELETTROBAR 216012



ELETTROBAR



Suitable for:

3221297 ORANGE INDICATOR LIGHT 230V
head \varnothing 14 mm - hole \varnothing 13 mm



ELETTROBAR

Suitable for:

3221111 RED INDICATOR LAMP 230V
head \varnothing 7 mm - hole \varnothing 6 mm - 120°C
application to the board



ELETTROBAR DEL13

3221139 RED INDICATOR LIGHT 230V
head \varnothing 14 mm - hole \varnothing 12 mm - 120°C



ELETTROBAR 216016

3221021 RED LAMP RECEPTACLE
head \varnothing 14.5 mm - hole \varnothing 12 mm



ELETTROBAR DEP141

3221126 INDICATOR LAMP 24V
head \varnothing 8 mm



ELETTROBAR DEL99

3221097 NEUTRAL INDICATOR LAMP 220V
head \varnothing 8 mm - 120°C
for Dishwasher (ELETTROBAR)
50F - 50FD - 500F - 500FD
for Glasswasher/Cupwasher (ELETTROBAR)
35F - 35R - 35RD - 350F - 350R - 350RD - 40F - 40R
40RD - 400F - 400R - 400RD




ELETTROBAR DEL25
ELETTROBAR 216006

ELETTROBAR DEL31
ELETTROBAR 926113

ELETTROBAR REB216006

3221019 RED LAMP 220V



ELETTROBAR DEL24

Inlet hoses

3449034 FLEX HOSE \varnothing 3/4" Fp x CFp 1500 mm
 EPDM hose covered in stainless steel
 hose external \varnothing 17 mm - internal \varnothing 12 mm
 max temperature 90°C
 max pressure 20 bar
 WRAS approved



ELETTROBAR RAT34
 ELETTROBAR 143112

ELETTROBAR REB143016

ELETTROBAR 143016

3449056 INLET ELBOW HOSE \varnothing 3/4" FF 2000 mm
 thermoplastic hose \varnothing 13x19 mm
 brass fittings \varnothing 3/4" F with gaskets
 max temperature 90°C
 max pressure 10 bar
 with WRAS approval



ELETTROBAR RAT32

ELETTROBAR 929169

3449072 INLET ELBOW HOSE \varnothing 3/4" FF 2000 mm
 EPDM hose covered in nylon braiding \varnothing 10x14 mm
 brass fittings 3/4" F
 max temperature 90°C
 max pressure 10 bar



ELETTROBAR REB143170

ELETTROBAR 143170

Interference suppression filters

3160479 INTERFERENCE SUP. FILTER D.E.M.FC701Y2FL
 0.47 μ F



ELETTROBAR DEC50

ELETTROBAR RTFOC00312

ELETTROBAR 926144

Ironmongery (screws,nuts,washers)

3528122 COUNTERSUNK FLAT HEAD SCREWS M4x30
 slotted - stainless steel
 UNI 6109 - DIN 963 - ISO 2009



ELETTROBAR CVI155

1184012 CYLINDER HEAD SCREW M5x10
 stainless steel - with hexagon socket
 UNI 9327 - DIN 7984



ELETTROBAR CIV113

ELETTROBAR CVI113



Suitable for:

ELETTROBAR



1528622 HEXAGON HEAD SCREW M8x16
stainless steel - UNI 5739 - DIN 933 - ISO 4017



ELETTROBAR 486041

3528213 HEXAGONAL NUT MID M5
st./steel - UNI 5588 - DIN 934 - ISO 4032



ELETTROBAR CD1205

1348813 HEXAGONAL NUT M4 MEDIUM
stainless steel - UNI 5588 - DIN 934 - ISO 4032



ELETTROBAR CD1204

6080998 PLASTIC SCREW M4x6 mm
for RIVER 282
for Dishwasher hood type (ELETTROBAR) RIVER282



ELETTROBAR 80998

5003877 SELF-LOCKING HEXAGON NUT M4
stainless steel - with nylon built-in ring
UNI 7473 - DIN 982 - ISO 7040




ELETTROBAR CD1204AU

5006765 SELF-TAPPING SCREW \varnothing 3.5x9.5 mm
stainless steel - cylinder head
cross recessed - C type end
UNI 6954 - DIN 7981 - ISO 7049



ELETTROBAR CVZ531


5061324 WASHER FLAT PTFE \varnothing 22x9.5x1 mm



ELETTROBAR 80623


Knobs

3241863 BLACK KNOB \varnothing 70 mm
D shaft hole 6x4.6 mm



ELETTROBAR

3241860 BLACK KNOB \varnothing 70 mm 0-1-0-1
D shaft hole 6x4.6 mm



ELETTROBAR



Suitable for:


3241861 BLACK KNOB \varnothing 70 mm 0-1-2-3
D shaft hole 6x4.6 mm



ELETTROBAR

Suitable for:

3241862 BLACK KNOB \varnothing 70 mm 0-1-2-3-4-5-6
D shaft hole 6x4.6 mm




ELETTROBAR

3241855 BLACK KNOB \varnothing 70 mm 30-110°C
D shaft hole 6x4.6 mm



ELETTROBAR

3241856 BLACK KNOB \varnothing 70 mm 30-110°C
D shaft hole 6x4.6 mm




ELETTROBAR

3241853 BLACK KNOB \varnothing 70 mm 30-90°C
D shaft hole 6x4.6 mm



ELETTROBAR

3241402 KNOB BLACK \varnothing 70 mm
D shaft hole 6x4.6 mm
for thermostat, selector switch, timer,
program switch, energy regulator



ELETTROBAR

3241864 KNOB BLACK MIN-MAX \varnothing 70 mm
D shaft hole 6x4.6 mm



ELETTROBAR

Labels for control panels

3399069 CONTROL PANEL
sizes 585x70 mm
for Glasswasher/Cupwasher (ELETTROBAR) 22F - 22R



ELETTROBAR 025101

ELETTROBAR 025106



Suitable for:

ELETTROBAR



Suitable for:

Magnets

6999108 **MAGNET FOR MICRO SWITCH DOOR**
 dimensions 23x18 mm
 for Dishwasher (ELETTROBAR)
 E50 - E51
 for Glasswasher/Cupwasher (ELETTROBAR)
 E45



ELETTROBAR REB999108

ELETTROBAR 999108

Manifolds for dishwashers

3743271 **EXTERNAL WASH - RINSE PIPE**
 for Glasswasher/Cupwasher (ELETTROBAR)
 RIVER48



ELETTROBAR 115121

3743270 **EXTERNAL WASH PIPE**
 for Dishwasher (ELETTROBAR)
 RIVER54



ELETTROBAR 115113

3450185 **HOSE OUTLET FOR WASH CONVEYOR H620 mm**
 for Dishwasher pull-through (ELETTROBAR)
 RIVER150



ELETTROBAR 75165

6441010 **INSERT FOR MANIFOLD SEALING**
 internal \varnothing 18 mm



ELETTROBAR 441010

3243731 **LOWER MANIFOLD**
 with one open outlet and one blank outlet
 for Glasswasher/Cupwasher (ELETTROBAR) 35F - 350F
 40F - 400F



ELETTROBAR REB115071

ELETTROBAR 115071

3243732 **CENTER CONDUIT**
 for Glasswasher/Cupwasher (ELETTROBAR) 35F - 350F
 40F - 400F



ELETTROBAR REB115073

ELETTROBAR 115073



Suitable for:

3243734 CENTER CONDUIT
for Glasswasher/Cupwasher (ELETTROBAR) 35R - 35RD
350R - 350RD



ELETTROBAR REB115077 ELETTROBAR 115077

3243733 LOWER RING NUT FOR MANIFOLD
for Glasswasher/Cupwasher (ELETTROBAR) 35F - 350F
40F - 400F



ELETTROBAR REB429051 ELETTROBAR 429051

3186606 O-RING 0144 EPDM



ELETTROBAR CGR144 ELETTROBAR REB456052 ELETTROBAR 456052

3243737 WASH ARM ASSEMBLY SPINDLE EXTENSION
for Glasswasher/Cupwasher (ELETTROBAR) 40F - 40FD
400F - 400FD



ELETTROBAR REB325039 ELETTROBAR 325039

3743804 MANIFOLD LOWER
for Dishwasher (ELETTROBAR) E50 - E51 - E52 - E60
E65
for Dishwasher hood type (ELETTROBAR) E100 - E110



ELETTROBAR 111031

ELETTROBAR



Suitable for:

3243735 CENTER CONDUIT
for Glasswasher/Cupwasher (ELETTROBAR) 40R - 40RD
400R - 400RD



ELETTROBAR REB115078 ELETTROBAR 115078

1186626 O-RING 0114 EPDM




ELETTROBAR CGR114 ELETTROBAR REB456042 ELETTROBAR 456042

3243736 SPINDLE EXTENSION FOR ROTATING SUPPORT
for Glasswasher/Cupwasher (ELETTROBAR) 35R - 35RD
350R - 350RD



ELETTROBAR REB325044 ELETTROBAR 325044

3243686 NUT FOR SPINDLE SUPPORT



ELETTROBAR REB417104 ELETTROBAR 417104



Suitable for:

ELETTROBAR



Suitable for:

6115140 PIPING FOR WASHING
 overall height 710 mm
 for Dishwasher (ELETTROBAR) NIAGARA 261
 PLUVIA260



ELETTROBAR 115140


3743202 WASH OUTLET HOSE GOLD COMPLETE
 for Dishwasher hood type (ELETTROBAR)
 RIVER80 - RIVER81 - RIVER82



ELETTROBAR C.80237

ELETTROBAR 80237

5036646 FITTING WASH UPPER EXTERNAL
 hose-end \varnothing 45 / 12 mm
 for Dishwasher hood type (ELETTROBAR)
 NIAGARA281 - NIAGARA381 - PLUVIA280 - RIVER282
 RIVER80 - RIVER81 - RIVER82



ELETTROBAR 80174

3248215 COUPLING FOR BOTTOM EXTERNAL WASH
 external connection \varnothing 45.5 mm
 internal fitting \varnothing 10.5 mm
 for Dishwasher hood type (ELETTROBAR)
 RIVER282



ELETTROBAR 80179

3786044 GASKET FLAT EPDM \varnothing 61x47x2 mm
 for Dishwasher hood type (ELETTROBAR)
 RIVER80 - RIVER81 - RIVER82



ELETTROBAR 80182


3743072 WASHING UPPER MANIFOLD
 total length 415 mm
 for Dishwasher hood type (ELETTROBAR) CLEAN100
 CLEAN110 - CLEAN120 - CLEAN140



ELETTROBAR DAC14

ELETTROBAR 926036

3786486 GASKET FLAT SPONGE 64x64x4 mm
 central hole \varnothing 45 mm - for wash manifold
 for Dishwasher hood type (ELETTROBAR) CLEAN100
 CLEAN120 - CLEAN140



ELETTROBAR CGM3

ELETTROBAR 926035

5029351 WASHPIPE EXTERNAL
 overall height 695 mm
 for Dishwasher (ELETTROBAR) E50 - E51




ELETTROBAR 115131




Microswitches

3240229 DOOR MICROSWITCH
16A 250V



ELETTROBAR /ELF190005

3240605 DOOR MICROSWITCH M1AX20 10A 250V



ELETTROBAR 218011

3240608 MAGNETIC MICROSWITCH
250-mm cable
for Dishwasher (ELETTROBAR)
E52 - 50F - 50FD - 500F - 500FD
for Glasswasher/Cupwasher (ELETTROBAR)
35F - 35R - 35RD - 350F - 350R - 350RD - 44F



ELETTROBAR REB211002
ELETTROBAR 211002AG

ELETTROBAR REB211002AG
ELETTROBAR 80871

ELETTROBAR 211002

3240610 MAGNET FOR HOOD MICROSWITCH
dimensions 40x13x8 mm



ELETTROBAR CWM7

ELETTROBAR 927088

3240204 MAGNETIC MICROSWITCH E5301C
0.4A 250V - contact NO - head 65x20x9 mm
with magnet 63x19x11 mm
with cable length 1900 mm



ELETTROBAR 927017

3240181 PROTECTED MAGNET 62x18x10 mm



ELETTROBAR CWM8

ELETTROBAR 926014

3240205 MAGNETIC MICROSWITCH E531TM NC
normally closed
contacts capacity 8A 24V
length 1900 mm



ELETTROBAR DEM203

ELETTROBAR 927056

3240609 MAGNETIC MICROSWITCH N.O.
bulb \varnothing 6x29 mm cable 250 mm
for Dishwasher (ELETTROBAR) CLEAN60
for Dishwasher hood type (ELETTROBAR) CLEAN100



ELETTROBAR 211001



Suitable for:

ELETTROBAR



3240607 MICROSWITCH (A061 1V) 0.04A 250V
bulb \varnothing 6x29 mm cable 360 mm
for Dishwasher (ELETTROBAR) E60 - E65
for Dishwasher hood type (ELETTROBAR) E140



ELETTROBAR DEM2038

ELETTROBAR 926195

Suitable for:

3240606 MICROSWITCH ASSEMBLY CONSENSO 250V
contact capacity 5A 250V
for Dishwasher hood type (ELETTROBAR) S850



ELETTROBAR 218007

ELETTROBAR 999022

3240601 MICROSWITCH N16 250V
contact capacity 16A 250V
for Dishwasher (ELETTROBAR) R509 - R511 - R651
R704 - R706 - R708 - S641 - S643 - S651 - S653
S654 - S655 - S815 - S830 - S835
for Glasswasher/Cupwasher (ELETTROBAR) R501 - R503
R505 - R507 - S621 - S623 - S624 - S626 - S631
S633 - S634 - S636 - 44F



ELETTROBAR REB218002

ELETTROBAR 218002

3240206 PUSH ROD FOR MICRO



ELETTROBAR 462005

3240410 MICROSWITCH 16(4)A 250V



ELETTROBAR RTFOC00035

3240123 MICROSWITCH 16A 250V



ELETTROBAR RTFOC00198

ELETTROBAR 218009

Non-return and expansion valves

3523601 NON-RETURN VALVE
for Dishwasher (ELETTROBAR)
E55 - E65S - RIVER50 - RIVER61 - RIVER71
for Dishwasher hood type (ELETTROBAR)
RIVER80 - RIVER81 - RIVER82
for Dishwasher pull-through (ELETTROBAR)
CLEAN160 - CLEAN220 - CLEAN270
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E40 - E45 - MISTRAL40 - NIAGARA35
NIAGARA40 - NIAGARA45 - RIVER48
for Pan/utensilwashing machines (ELETTROBAR)
U60




ELETTROBAR REB144010

ELETTROBAR REB144010NT

ELETTROBAR 144010

ELETTROBAR 144010NT

3526278 NON-RETURN VALVE
for Glasswasher/Cupwasher (ELETTROBAR)
RIVER40



ELETTROBAR REB144011

ELETTROBAR 144011



Suitable for:


3526279 NON-RETURN VALVE
for Dishwasher (ELETTROBAR) NIAGARA251
NIAGARA261 - PLUVIA260



ELETTROBAR H.324091

Suitable for:

3743792 RING NUT FOR EXHAUST VALVE DVGW
for Dishwasher (ELETTROBAR) NIAGARA251
NIAGARA261



ELETTROBAR 429075

OR and ORM gaskets

1186365 "O" RING 02012 EPDM



ELETTROBAR 456014

3786454 EPDM O-RING GASKET 0153



ELETTROBAR REB456061

ELETTROBAR 456061

6456037 GASKET O-RING 02237 EPDM



ELETTROBAR 456037

5022973 GASKET O-RING 04275 EPDM



ELETTROBAR CGR4275

ELETTROBAR 926252

3186015 O-RING GASKET OR 0178 EPDM
for SANMARCO LEVER BREW GROUP



ELETTROBAR 456008

1186231 O-RING GASKET 04106 EPDM



ELETTROBAR CGR4106

ELETTROBAR 929050

6456074 O-RING 02325 EPDM
for pump housing



ELETTROBAR 456074

3786668 O-RING 03024 EPDM
for Glasswasher/Cupwasher (ELETTROBAR) 22F
for Glasswasher/Cupwasher (ELETTROBAR) 22F



ELETTROBAR 456066



Suitable for:

5037072 O-RING 03112 VITON



ELETTROBAR 456081

Suitable for:

6456047 O-RING 04036 EPDM



ELETTROBAR REB456047

ELETTROBAR 456047

Pegs

5033995 **PLUG FOR COVEYOR HALT** \varnothing 17.5x25 mm
for Dishwasher pull-through (ELETTROBAR)
NIAGARA2150 - NIAGARA2156 - RIVER150



ELETTROBAR 75076

Pins

3243990 **PIN FOR TURNING RINSE ARM**



ELETTROBAR DLP7

3743074 **RINSE ARM SPINDLE**



ELETTROBAR REB325051

ELETTROBAR 325051

3243685 **WASH ARM ASSEMBLY SPINDLE SUPPORT**
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E40 - NIAGARA35 - NIAGARA40



ELETTROBAR REB478056

ELETTROBAR 478056

Pressure reducers

6927150 **REDUCER PRESSURE 1/2"**



ELETTROBAR UAA6

ELETTROBAR 927150



Pressure regulators

3350080 PRESSURE REDUCER 1/2" 4ATM



ELETTROBAR /COM281102


Pressure switches

3320003 "Y" CONNECTOR
for fitting with two pressure switches




ELETTROBAR 035031

3320019 PRESSURE SWITCH 1 LEVEL
calibration 55/35 mm
250V 16A
max operating temperature 85°C
for Glasswasher/Cupwasher (ELETTROBAR)
21F - 21R - 22F - 31F - 31R
for Glasswasher/Cupwasher (ELETTROBAR)
22F



ELETTROBAR 224003

3320020 PRESSURE SWITCH 1 LEVEL
calibration 110/60 mm
250V 16A
max operating temperature 85°C
for Glasswasher/Cupwasher (ELETTROBAR)
R503 - 21F - 21R - 31F - 31R



ELETTROBAR 224002

3320023 PRESSURE SWITCH 1 LEVEL
calibration 60/20 mm
250V 16A
max operating temperature 85°C



ELETTROBAR /ELF271001

3320029 PRESSURE SWITCH 1 LEVEL
calibration 40/20 mm
250V 16A
max operating temperature 85°C



ELETTROBAR 69850

3320030 PRESSURE SWITCH 1 LEVEL
calibration 55/20 mm
250V 16A
max operating temperature 85°C



ELETTROBAR DEP4

ELETTROBAR 929039



Suitable for:

ELETTROBAR




3320063 PRESSURE SWITCH 1 LEVEL
calibration 110/70 mm
250V 16A
max operating temperature 85°C



ELETTROBAR 130607

3320083 PRESSURE SWITCH 1 LEVEL
calibration 90/56 mm
250V 16A
for Dishwasher (ELETTROBAR) E46 - E50 - E51 - E52
NIAGARA51 - RIVER50 - RIVER50D
for Glasswasher/Cupwasher (ELETTROBAR) RIVER40



ELETTROBAR REB224005


ELETTROBAR 224005

3320084 PRESSURE SWITCH 1 LEVEL
calibration 140/110 mm
250V 16A
for Dishwasher (ELETTROBAR)
RIVER50 - RIVER50D - RIVER61
for Glasswasher/Cupwasher (ELETTROBAR)
RIVER40 - RIVER48



ELETTROBAR 224008

3320111 PRESSURE SWITCH 1 LEVEL
calibration 35/17 mm
250V 16(4)A



ELETTROBAR REB224004

ELETTROBAR 224004

3320112 PRESSURE SWITCH 1 LEVEL
calibration 180/70 mm
250V 16(4)A



ELETTROBAR DEP45

ELETTROBAR 926049


3320232 PRESSURE SWITCH 1 LEVEL
calibration 115/15 mm



ELETTROBAR REB224006

ELETTROBAR 224006

3320233 PRESSURE SWITCH 1 LEVEL
calibration 170/140 mm
for Glasswasher/Cupwasher (ELETTROBAR) CLEAN3



ELETTROBAR REB224007

ELETTROBAR 224007

3320234 PRESSURE SWITCH 1 LEVEL
calibration 208/178 mm



ELETTROBAR 224009



Suitable for:

3320235 PRESSURE SWITCH 1 LEVEL
calibration 110/75 mm
250V 16A
for drain pump



ELETTROBAR 224010


Suitable for:

3320236 PRESSURE SWITCH 1 LEVEL
calibration 115/85 mm
250V 16A
for Glasswasher/Cupwasher (ELETTROBAR) RIVER43




ELETTROBAR 224011

3320237 PRESSURE SWITCH 1 LEVEL
calibration 165/140 mm
for Dishwasher (ELETTROBAR) NIAGARA251
NIAGARA261 - PLUVIA260
for Dishwasher hood type (ELETTROBAR) PLUVIA280



ELETTROBAR 224023

3320238 PRESSURE SWITCH 1 LEVEL
calibration 105/125 mm
250V 16A
for Dishwasher (ELETTROBAR)
NIAGARA251 - NIAGARA261 - PLUVIA260



ELETTROBAR 224022

ELETTROBAR 224025

6224018 SET PRESSURE SWITCH ANALOGICAL LA50
for Dishwasher (ELETTROBAR)
RIVER262 - RIVER362C - RIVER362T



ELETTROBAR 224018

ELETTROBAR 999328

Pump motors

3122696 ELECTRIC PUMP AP CL170SX 1.20HP
inlet external \varnothing 60 mm - outlet external \varnothing 50 mm
1.20HP 230V 50Hz - motor revolutions 2800
capacitor 16 μ f
for Glasswasher/Cupwasher (ELETTROBAR) 22F - 22R
44F



ELETTROBAR

3122058 SEAL ROTARY \varnothing 11 mm BACK FACE 8 mm



ELETTROBAR 80121

ELETTROBAR 927190



ELETTROBAR



Suitable for:

3122702 ELECTRIC PUMP AP ET42370SX 0.80HP
inlet external \varnothing 50 mm - outlet external \varnothing 48 mm
0.80HP 230V 50Hz - capacitor 16 μ f



ELETTROBAR

Suitable for:

3122058 SEAL ROTARY \varnothing 11 mm BACK FACE 8 mm



ELETTROBAR 80121

ELETTROBAR 927190

3122685 ELECTRIC PUMP AP 12190SX 1HP
inlet external \varnothing 45 mm - outlet external \varnothing 40 mm
1HP 230V 50Hz - motor revolutions 2800
capacitor 12.5 μ f - flow rate 250 L/min.



ELETTROBAR

3122058 SEAL ROTARY \varnothing 11 mm BACK FACE 8 mm



ELETTROBAR 80121

ELETTROBAR 927190

3122687 ELECTRIC PUMP AP 12250SX 1.50HP
inlet external \varnothing 62 mm - outlet external \varnothing 48 mm
1.50HP 220/400V 50Hz



ELETTROBAR

3122024 SEAL MECHANICAL FOR SHAFT \varnothing 12 mm
metal seal \varnothing internal 11 mm - \varnothing external 24 mm
height 15.5 mm
back. element \varnothing internal 14 mm - \varnothing external 24 mm
height 8 mm




ELETTROBAR RAT19
ELETTROBAR 926274

ELETTROBAR RAT72

ELETTROBAR 141002

3122546 ELECTRIC PUMP AP 2012DX 1.50HP
inlet external \varnothing 63 mm - outlet external \varnothing 54 mm
1.50HP 220/400V 50Hz 4.5/2.7A - motor revol. 2850
flow rate 650 L/min.



ELETTROBAR

3122024 SEAL MECHANICAL FOR SHAFT \varnothing 12 mm
metal seal \varnothing internal 11 mm - \varnothing external 24 mm
height 15.5 mm
back. element \varnothing internal 14 mm - \varnothing external 24 mm
height 8 mm



ELETTROBAR RAT19
ELETTROBAR 926274

ELETTROBAR RAT72

ELETTROBAR 141002

3122164 ELECTRIC PUMP FIR 0286SX 0.50HP
inlet external \varnothing 30 mm - outlet external \varnothing 30 mm
0.50HP 230V 50Hz 2.5A - motor revolutions 2800
capacitor 12.5 μ F



ELETTROBAR DPE149

3122033 ELECTRIC PUMP FIR 1225SX 1.50HP
inlet external \varnothing 63 mm - outlet external \varnothing 48 mm
1.50HP 220/400V 50Hz 4.8/2.8A - motor revol. 2800
flow rate 625 L/min.
for Dishwasher hood type (ELETTROBAR) 66



ELETTROBAR 130025

3122027 HOUSING FOR PUMP
inlet external \varnothing 63 mm
outlet external \varnothing 48 mm



ELETTROBAR 116004

3122024 SEAL MECHANICAL FOR SHAFT \varnothing 12 mm
metal seal \varnothing internal 11 mm - \varnothing external 24 mm
height 15.5 mm
back. element \varnothing internal 14 mm - \varnothing external 24 mm
height 8 mm

ELETTROBAR RAT19
ELETTROBAR 926274

ELETTROBAR RAT72

ELETTROBAR 141002

3122026 GASKET FOR PUMP HOUSING



ELETTROBAR RAG48

ELETTROBAR 456023

ELETTROBAR 80120

3122376 IMPELLER \varnothing 111 mm



ELETTROBAR RAG297



Suitable for:

Suitable for:

3122322 ELECTRIC PUMP FIR 1241DX 1.50HP
 inlet external \varnothing 63 mm - outlet external \varnothing 54 mm
 1.50HP 220/400V 50Hz 4.8/2.8A - motor revol. 2800
 flow rate 625 L/min.



ELETTROBAR DEP231 ELETTROBAR DPE231

ELETTROBAR 130002

3122026 GASKET FOR PUMP HOUSING



ELETTROBAR RAG48

ELETTROBAR 456023

ELETTROBAR 80120

3122047 HOUSING FOR PUMP
 inlet external \varnothing 63 mm
 outlet external \varnothing 54 mm



ELETTROBAR RAC420

ELETTROBAR 116005

3122323 IMPELLER \varnothing 111 mm
 height 38 mm



ELETTROBAR RAG18

ELETTROBAR RAG19

ELETTROBAR 124005

3122024 SEAL MECHANICAL FOR SHAFT \varnothing 12 mm
 metal seal \varnothing internal 11 mm - \varnothing external 24 mm
 height 15.5 mm
 back. element \varnothing internal 14 mm - \varnothing external 24 mm
 height 8 mm




ELETTROBAR RAT19

ELETTROBAR RAT72

ELETTROBAR 141002

ELETTROBAR 926274

3122043 ELECTRIC PUMP FIR 1243DX 3HP
 inlet external \varnothing 63 mm - outlet external \varnothing 54 mm
 3HP 220/400V 50Hz 9/5.2A - motor revolutions 2800
 flow rate 585 L/min.



ELETTROBAR DPE4515

ELETTROBAR 130005

3122026 GASKET FOR PUMP HOUSING



ELETTROBAR RAG48

ELETTROBAR 456023

ELETTROBAR 80120

3122047 HOUSING FOR PUMP
 inlet external \varnothing 63 mm
 outlet external \varnothing 54 mm



ELETTROBAR RAC420

ELETTROBAR 116005

3122045 IMPELLER \varnothing 124 mm



ELETTROBAR RAG181

ELETTROBAR 124014



Suitable for:

ELETTROBAR



3122024 SEAL MECHANICAL FOR SHAFT \varnothing 12 mm
 metal seal \varnothing internal 11 mm - \varnothing external 24 mm
 height 15.5 mm
 back. element \varnothing internal 14 mm - \varnothing external 24 mm
 height 8 mm



ELETTROBAR RAT19
ELETTROBAR 926274

ELETTROBAR RAT72

ELETTROBAR 141002

Suitable for:

3122188 ELECTRIC PUMP FIR 1295SX 1.20HP
 inlet external \varnothing 63 mm - outlet external \varnothing 48 mm
 1.20HP 220/400V 50Hz 3.8/2.2A - motor revol. 2800
 flow rate 300 L/min.



ELETTROBAR 130024

3122027 HOUSING FOR PUMP
 inlet external \varnothing 63 mm
 outlet external \varnothing 48 mm



ELETTROBAR 116004

3122024 SEAL MECHANICAL FOR SHAFT \varnothing 12 mm
 metal seal \varnothing internal 11 mm - \varnothing external 24 mm
 height 15.5 mm
 back. element \varnothing internal 14 mm - \varnothing external 24 mm
 height 8 mm



ELETTROBAR RAT19
ELETTROBAR 926274

ELETTROBAR RAT72

ELETTROBAR 141002

3122026 GASKET FOR PUMP HOUSING



ELETTROBAR FAG48

ELETTROBAR 456023

ELETTROBAR 80120

3122161 IMPELLER \varnothing 117 mm



ELETTROBAR 124004




Suitable for:

Suitable for:

3122052 ELECTRIC PUMP FIR 2211DX 0.10HP
 inlet external \varnothing 28 mm - outlet external \varnothing 28 mm
 0.10HP 230V 50Hz 1.1A - motor revolutions 2700
 capacitor 5 μ f - flow rate 80 l/min.
 for Pan/utensilwashing machines (ELETTROBAR) U61E

3122040 IMPELLER \varnothing 72 mm



ELETTROBAR DPE111

ELETTROBAR 929167

ELETTROBAR RAG127

ELETTROBAR 927189

ELETTROBAR 929173

3122058 SEAL ROTARY \varnothing 11 mm BACK FACE 8 mm



ELETTROBAR 80121

ELETTROBAR 927190

3122057 ELECTRIC PUMP FIR 4134SX 0.25HP
 inlet external \varnothing 30 mm - outlet external \varnothing 30 mm
 0.25HP 230V 50Hz 1.5A - motor revolutions 2700
 capacitor 10 μ f - flow rate 95 L/min

3122058 SEAL ROTARY \varnothing 11 mm BACK FACE 8 mm




ELETTROBAR DPE120

ELETTROBAR 80121

ELETTROBAR 927190

3122641 ELECTRIC PUMP FIR 4223SX 1HP
 inlet external \varnothing 60 mm - outlet external \varnothing 50 mm
 1HP 230V 50Hz - motor revolutions 2800
 capacitor 16 μ f

3122648 GASKET FOR PUMP HOUSING



ELETTROBAR DPE210

ELETTROBAR 926151

ELETTROBAR REB437049

ELETTROBAR 437049

3122647 IMPELLER \varnothing 104 mm
 threaded connection

3122024 SEAL MECHANICAL FOR SHAFT \varnothing 12 mm
 metal seal \varnothing internal 11 mm - \varnothing external 24 mm
 height 15.5 mm
 back. element \varnothing internal 14 mm - \varnothing external 24 mm
 height 8 mm



ELETTROBAR RAG299

ELETTROBAR RAT19
ELETTROBAR 926274


ELETTROBAR RAT72

ELETTROBAR 141002



Suitable for:


3122750 ELECTRIC PUMP HANNING UP30 0.15HP
outlet external \varnothing 26 mm
0.15HP 230V 50Hz - capacitor 4 μ f



ELETTROBAR H.775465-001


Suitable for:

3122801 ELECTRIC PUMP LAFERT AMEE-90L-CA2 3HP
inlet external \varnothing 70 mm - outlet external \varnothing 68 mm
3HP 220/400V 50/60Hz 9.5/5.5A
motor revolutions 2860/3420



ELETTROBAR /ELF047159

5036904 ELECTRIC PUMP LGB CRC-RDX 0,27HP
entry \varnothing external 28 mm - exit \varnothing external 26 mm
0,27HP 230V 50Hz 0,9A - capacitor 4 μ F



ELETTROBAR 130163

ELETTROBAR 80627

3122189 ELECTRIC PUMP LGB W 180SX 0.25HP
with manifold and filter
0.25HP 230V 50Hz 1A - motor revolutions 2800
capacitor 5 μ f
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E35H - NIAGARA35



ELETTROBAR 130135

ELETTROBAR 130139

ELETTROBAR 999134

3243687 CLOSING CAP FOR BOSS
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E40 - NIAGARA35 - NIAGARA40



ELETTROBAR REB480087


ELETTROBAR 480087

3122195 FLANGE E35/40
external \varnothing 100 mm
for Glasswasher/Cupwasher (ELETTROBAR) E35 - E40



ELETTROBAR 315024

3186605 GASKET FLAT EPDM \varnothing 33x17x1.5 mm
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E40 - NIAGARA35 - NIAGARA40



ELETTROBAR REB437078

ELETTROBAR 437078

3243684 GASKET FLAT EPDM \varnothing 60x48x2 mm
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E40 - NIAGARA35 - NIAGARA40



ELETTROBAR REB437079

ELETTROBAR 437079

3122194 IMPELLER FOR PUMP T.176 \varnothing 67 mm



ELETTROBAR 124048



Suitable for:

3243682 LOWER BOSS
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E40 - NIAGARA35 - NIAGARA40



ELETTROBAR REB111023 ELETTROBAR 111023

1186237 O-RING 03300 EPDM




ELETTROBAR REB456038 ELETTROBAR 456038

3122632 SEAL ROTARY ø 13 BACK FACE 5.5 mm
for Dishwasher (ELETTROBAR)
NIAGARA251 - NIAGARA261 - PLUVIA260
for Dishwasher hood type (ELETTROBAR)
NIAGARA281



ELETTROBAR RAT211 ELETTROBAR REB141007 ELETTROBAR 141007
ELETTROBAR 141008 ELETTROBAR 141009 ELETTROBAR 80843
ELETTROBAR 926255

3122196 ELECTRIC PUMP LGB W 210SX 0.32HP
with manifold and filter
0.32HP 230V 50Hz 1.1A - motor revolutions 2800
capacitor 6.3 µf
for Glasswasher/Cupwasher (ELETTROBAR)
E40



ELETTROBAR 999135

ELETTROBAR



Suitable for:
1186803 O-RING 02037 EPDM
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E40 - MISTRAL40 - NIAGARA35



ELETTROBAR 456019

3243683 RING NUT FOR LOWER BOSS
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E40 - NIAGARA35 - NIAGARA40



ELETTROBAR REB429065 ELETTROBAR 429065

3743276 TOP WASH CLOSING CAP



ELETTROBAR REB480054 ELETTROBAR 480054

3243687 CLOSING CAP FOR BOSS
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E40 - NIAGARA35 - NIAGARA40



ELETTROBAR REB480087 ELETTROBAR 480087



Suitable for:

3122195 FLANGE E35/40
external \varnothing 100 mm
for Glasswasher/Cupwasher (ELETTROBAR) E35 - E40



ELETTROBAR 315024

3243684 GASKET FLAT EPDM \varnothing 60x48x2 mm
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E40 - NIAGARA35 - NIAGARA40



ELETTROBAR REB437079

ELETTROBAR 437079

3243682 LOWER BOSS
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E40 - NIAGARA35 - NIAGARA40



ELETTROBAR REB111023

ELETTROBAR 111023

1186237 O-RING 03300 EPDM



ELETTROBAR REB456038

ELETTROBAR 456038

3122632 SEAL ROTARY \varnothing 13 BACK FACE 5.5 mm
for Dishwasher (ELETTROBAR)
NIAGARA251 - NIAGARA261 - PLUVIA260
for Dishwasher hood type (ELETTROBAR)
NIAGARA281



ELETTROBAR RAT211

ELETTROBAR REB141007

ELETTROBAR 141007

ELETTROBAR 141008

ELETTROBAR 141009

ELETTROBAR 80843

ELETTROBAR 926255

ELETTROBAR



Suitable for:

3186605 GASKET FLAT EPDM \varnothing 33x17x1.5 mm
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E40 - NIAGARA35 - NIAGARA40



ELETTROBAR REB437078

ELETTROBAR 437078

3122197 IMPELLER FOR PUMP \varnothing 71 mm



ELETTROBAR REB124049

ELETTROBAR 124049

1186803 O-RING 02037 EPDM
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E40 - MISTRAL40 - NIAGARA35



ELETTROBAR 456019

3243683 RING NUT FOR LOWER BOSS
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E40 - NIAGARA35 - NIAGARA40



ELETTROBAR REB429065

ELETTROBAR 429065

3743276 TOP WASH CLOSING CAP



ELETTROBAR REB480054

ELETTROBAR 480054



Suitable for:

ELETTROBAR



3122824 ELECTRIC PUMP LGB X3SX 0.34HP
inlet external \varnothing 33 mm - outlet external \varnothing 26 mm
capacitor 6.3 mf
for Glasswasher/Cupwasher (ELETTROBAR) RIVER40



ELETTROBAR 999241

3122830 ELECTRIC PUMP LGB X3SX 0.34HP
inlet external \varnothing 33 mm - outlet external \varnothing 26 mm
0.34HP 230V 50Hz - capacitor 6.3 μ F
for Glasswasher/Cupwasher (ELETTROBAR) RIVER40




ELETTROBAR 130993

3122831 ELECTRIC PUMP LGB X5SX 1.10HP
with manifold and filter
1.10HP 230V 50Hz - capacitor 16 μ f
for Glasswasher/Cupwasher (ELETTROBAR) RIVER48




ELETTROBAR 130994

3122445 HOUSING FOR PUMP WITH FILTER
for Dishwasher (ELETTROBAR)
RIVER54




ELETTROBAR 111029

3122839 IMPELLER FOR PUMP X5 \varnothing 93 mm
for Dishwasher (ELETTROBAR)
RIVER50



ELETTROBAR 124052

3122860 ELECTRIC PUMP LGB ZFC1121DX 0.32HP
inlet external \varnothing 28 mm - outlet external \varnothing 26 mm
0.32HP 230V 50Hz - capacitor 6.3 μ F
for Glasswasher/Cupwasher (ELETTROBAR)
RIVER40 - RIVER44



ELETTROBAR 130148

3122392 ELECTRIC PUMP LGB ZF130DX 0.28HP
inlet external \varnothing 28 mm - outlet external \varnothing 28 mm
0.28HP 230V 50Hz - motor revolutions 2800
capacitor 6.3 μ f



ELETTROBAR REB130108

ELETTROBAR 130097

ELETTROBAR 130108

1186237 O-RING 03300 EPDM



ELETTROBAR REB456038

ELETTROBAR 456038

3122631 ELECTRIC PUMP LGB ZF400SX 0.80HP
 inlet external \varnothing 50 mm - outlet external \varnothing 50 mm
 0.80HP 230V 50Hz 3.8A - motor revolutions 2800
 capacitor 16 μ f
 for Dishwasher (ELETTROBAR)
 E50



ELETTROBAR REB130109

ELETTROBAR 130098

ELETTROBAR 130109

3122841 ELECTRIC PUMP LGB ZF522VSX 0.94HP
 inlet external \varnothing 62 mm - outlet external \varnothing 50 mm
 0.94HP 230V 50Hz - motor revolutions 2800
 capacitor 16 μ f



ELETTROBAR 80114

6926275 IMPELLER FOR PUMP ZF522 \varnothing 103 mm



ELETTROBAR RAG72

ELETTROBAR 926275

3122255 EPDM O-RING 04625
 for pumps LGB ZF800DX and ZF650DX



ELETTROBAR RAG61

ELETTROBAR 926084

3122024 SEAL MECHANICAL FOR SHAFT \varnothing 12 mm
 metal seal \varnothing internal 11 mm - \varnothing external 24 mm
 height 15.5 mm
 back. element \varnothing internal 14 mm - \varnothing external 24 mm
 height 8 mm



ELETTROBAR RAT19

ELETTROBAR RAT72

ELETTROBAR 141002

ELETTROBAR 926274

3122352 ELECTRIC PUMP LGB 300WSX 0.40HP
 inlet external \varnothing 50 mm - outlet external \varnothing 45 mm
 0.40HP 230V 50Hz - motor revolutions 2800
 capacitor 10 μ F



ELETTROBAR /ELF202480

3122024 SEAL MECHANICAL FOR SHAFT \varnothing 12 mm
 metal seal \varnothing internal 11 mm - \varnothing external 24 mm
 height 15.5 mm
 back. element \varnothing internal 14 mm - \varnothing external 24 mm
 height 8 mm



ELETTROBAR RAT19

ELETTROBAR RAT72

ELETTROBAR 141002


ELETTROBAR 926274



Suitable for:

Suitable for:

3122627 ELECTRIC PUMP OP T.60 0.25HP
 threaded inlet \varnothing 1" F - outlet external \varnothing 28 mm
 0.25HP 230V 50Hz - motor revolutions 2700
 capacitor 5 μ f - flow rate 130 L/min
 for Glasswasher/Cupwasher (ELETTROBAR) 11F - 11FD
 11R - 11RD



ELETTROBAR 130085

ELETTROBAR 130086

ELETTROBAR 130087

3122628 HOUSING FOR PUMP
 inlet \varnothing 1" F
 outlet external \varnothing 28 mm



ELETTROBAR 999175

3122630 IMPELLER \varnothing 75 mm
 for DISHWASHERS from serial number
 141.001/04.91



ELETTROBAR 124025

3122635 IMPELLER \varnothing 75 mm
 for DISHWASHERS up to serial number
 141.000/03.91
 for Glasswasher/Cupwasher (ELETTROBAR)
 till 1/03/91
 11F - 11FD - 11R - 11RD



ELETTROBAR 124028

1186237 O-RING 03300 EPDM



ELETTROBAR REB456038

ELETTROBAR 456038

3122024 SEAL MECHANICAL FOR SHAFT \varnothing 12 mm
 metal seal \varnothing internal 11 mm - \varnothing external 24 mm
 height 15.5 mm
 back. element \varnothing internal 14 mm - \varnothing external 24 mm
 height 8 mm



ELETTROBAR RAT19

ELETTROBAR RAT72

ELETTROBAR 141002

ELETTROBAR 926274

3122273 ELECTRIC PUMP OP T.80 0.33HP
 inlet external \varnothing 32 mm - outlet external \varnothing 30 mm
 additional outlet external \varnothing 24 mm
 0.33HP 230V 50Hz 1.2A - motor revolutions 2700
 capacitor 5 μ f - flow rate 130 l/min
 for Glasswasher/Cupwasher (ELETTROBAR) 403R



ELETTROBAR REB130116

ELETTROBAR 130115


ELETTROBAR 130116



Suitable for:

Suitable for:

3122636 ELECTRIC PUMP OP T.90 0.45HP
 inlet external \varnothing 44 mm - outlet external \varnothing 30 mm
 additional outlet external \varnothing 24 mm
 0.45HP 230V 50Hz - motor revolutions 2700
 capacitor 8 μ f
 for Glasswasher/Cupwasher (ELETTROBAR) E45



ELETTROBAR REB130122

ELETTROBAR 130122

3122639 FLANGE WITH OUTLET HOLES \varnothing 30/24 mm



ELETTROBAR REB315020

ELETTROBAR 315020

3122637 HOUSING FOR PUMP - INLET \varnothing 44 mm



ELETTROBAR REB116024

ELETTROBAR 116024

3122638 IMPELLER CLOSED \varnothing 84 mm
 threaded connection \varnothing 10 mm



ELETTROBAR REB124043

ELETTROBAR 124043

1186237 O-RING 03300 EPDM



ELETTROBAR REB456038

ELETTROBAR 456038

3122024 SEAL MECHANICAL FOR SHAFT \varnothing 12 mm
 metal seal \varnothing internal 11 mm - \varnothing external 24 mm
 height 15.5 mm
 back. element \varnothing internal 14 mm - \varnothing external 24 mm
 height 8 mm



ELETTROBAR RAT19

ELETTROBAR RAT72

ELETTROBAR 141002

ELETTROBAR 926274

3122153 ELECTRIC PUMP TM61E 0.45HP
 inlet \varnothing 1" F - outlet \varnothing 1" F
 0.45HP 230V 50Hz 2.3A - motor revolutions 2900
 capacitor 10 μ f - flow rate 38 l/min.
 max pressure 6 ATM max temperature 90°C
 for pressure increase



ELETTROBAR DPE141

ELETTROBAR REB130013

ELETTROBAR 130013

ELETTROBAR 130049



Suitable for:

3122827 ELECTROPUMP FIR B235RH 0.15HP
 inlet external \varnothing 28 mm - outlet external \varnothing 28 mm
 0.15HP 230V 50Hz - capacitor 5 μ f
 for Glasswasher/Cupwasher (ELETTROBAR) 35F - 35FD
 35R - 35RD - 350F - 350FD - 350R - 350RD



ELETTROBAR REB130107

ELETTROBAR 130107

Suitable for:

3122826 IMPELLER FOR PUMP \varnothing 67 mm
 for pump B235



ELETTROBAR REB124036

ELETTROBAR 124036

3122787 ELECTROPUMP FIR 4225/2SX 1.90HP
 inlet external \varnothing 63 mm - outlet external \varnothing 48 mm
 1.90HP 220/400V 50Hz



ELETTROBAR DPE2640

ELETTROBAR DPE2640RT

ELETTROBAR 919223

ELETTROBAR 926150

ELETTROBAR 929123

ELETTROBAR 929201

3122376 IMPELLER \varnothing 111 mm



ELETTROBAR RAG297

5023441 ELECTROPUMP FIR 4225LH 1.47HP
 inlet external \varnothing 63 mm - outlet external \varnothing 48 mm
 1.47HP 220/400V 50Hz



ELETTROBAR DPE2102

ELETTROBAR 16509

ELETTROBAR 75175

ELETTROBAR 926148

3122862 ELECTROPUMP FIR 5213RH 0.10HP
 inlet external \varnothing 30 mm - outlet external \varnothing 28 mm
 0.10HP 230V 50Hz 1.1A - Rpm 2700
 capacitor 5 μ f



ELETTROBAR 929167

3122879 HOUSING FOR PUMP FIR 5213



ELETTROBAR 80812

3453029 STUFFING GLAND + BACKING ELEMENT
 rotary seal hole 11 mm
 counter face h 5.5 mm



ELETTROBAR 80815

Suitable for:

Suitable for:

3122832 ELECTROPUMP FIR 5295LH 2.15HP
inlet external \varnothing 63 mm - outlet external \varnothing 50 mm
2.15HP 220/400V 50Hz



ELETTROBAR C.80116

ELETTROBAR 80115

ELETTROBAR 80116

3122026 GASKET FOR PUMP HOUSING




ELETTROBAR FAG48

ELETTROBAR 456023

ELETTROBAR 80120


5048653 ELECTROPUMP LGB LA50LH 0.63HP
inlet external \varnothing 42 mm - outlet external \varnothing 38 mm
additional outlet external \varnothing 24 mm
0.63HP 230V 50Hz - capacitor 10 μ F
for Dishwasher (ELETTROBAR)
NIAGARA251



ELETTROBAR 130161

ELETTROBAR 130982

3068016 CAPACITOR μ F 10 450V 50/60Hz
operating temperature $-25+85^{\circ}\text{C}$
in compliance with EEC 93/68 and 92/31 regulations



ELETTROBAR REB206002

ELETTROBAR 206002

5037068 GASKET FOR PUMP MOTOR



ELETTROBAR 456078

3122632 SEAL ROTARY \varnothing 13 BACK FACE 5.5 mm
for Dishwasher (ELETTROBAR)
NIAGARA251 - NIAGARA261 - PLUVIA260
for Dishwasher hood type (ELETTROBAR)
NIAGARA281



ELETTROBAR RAT211

ELETTROBAR REB141007

ELETTROBAR 141007

ELETTROBAR 141008

ELETTROBAR 141009

ELETTROBAR 80843

ELETTROBAR 926255

6124057 IMPELLER \varnothing 90 mm
for NIAGARA 251/261
for Dishwasher (ELETTROBAR) NIAGARA251
NIAGARA261



ELETTROBAR 124057

3528220 SELF-TAPPING SCREW \varnothing 3.5x13 mm
stainless steel - cylinder head
cross recessed - C type end
UNI 6954 - 7981 - ISO 7049



ELETTROBAR 486242




Suitable for:

ELETTROBAR



7102551 ELECTROPUMP LGB LA50LH 0.63HP
 inlet external \varnothing 42 mm - outlet external \varnothing 38 mm
 additional outlet external \varnothing 19 mm
 0.63HP 230V 50Hz - capacitor 10 μ F



ELETTROBAR 69120

5037068 GASKET FOR PUMP MOTOR



ELETTROBAR 456078

3122632 SEAL ROTARY \varnothing 13 BACK FACE 5.5 mm
 for Dishwasher (ELETTROBAR)
 NIAGARA251 - NIAGARA261 - PLUVIA260
 for Dishwasher hood type (ELETTROBAR)
 NIAGARA281



ELETTROBAR RAT211

ELETTROBAR REB141007

ELETTROBAR 141007

ELETTROBAR 141008

ELETTROBAR 141009

ELETTROBAR 80843

ELETTROBAR 928255

5056928 ELECTROPUMP LGB LA500LH 0.63HP
 inlet \varnothing 42 mm - outlet \varnothing 38 mm
 additional outlet \varnothing 24 mm
 0.63HP 230V 50Hz 2A - capacitor 10 μ F
 for Dishwasher (ELETTROBAR) FAST161-2
 for Dishwasher (ELETTROBAR) FAST160-2



ELETTROBAR 130977

Suitable for:

3068016 CAPACITOR μ F 10 450V 50/60Hz
 operating temperature $-25+85^{\circ}\text{C}$
 in compliance with EEC 93/68 and 92/31 regulations



ELETTROBAR REB206002

ELETTROBAR 206002

6124057 IMPELLER \varnothing 90 mm
 for NIAGARA 251/261
 for Dishwasher (ELETTROBAR) NIAGARA251
 NIAGARA261




ELETTROBAR 124057

3528220 SELF-TAPPING SCREW \varnothing 3.5x13 mm
 stainless steel - cylinder head
 cross recessed - C type end
 UNI 6954 - 7981 - ISO 7049



ELETTROBAR 486242

3068016 CAPACITOR μ F 10 450V 50/60Hz
 operating temperature $-25+85^{\circ}\text{C}$
 in compliance with EEC 93/68 and 92/31 regulations



ELETTROBAR REB206002

ELETTROBAR 206002



Suitable for:

5037068 GASKET FOR PUMP MOTOR



ELETTROBAR 456078

3122632 SEAL ROTARY \varnothing 13 BACK FACE 5.5 mm
for Dishwasher (ELETTROBAR)
NIAGARA251 - NIAGARA261 - PLUVIA260
for Dishwasher hood type (ELETTROBAR)
NIAGARA281



ELETTROBAR RAT211
ELETTROBAR 141008
ELETTROBAR 926255

ELETTROBAR REB141007
ELETTROBAR 141009

ELETTROBAR 141007
ELETTROBAR 80843

ELETTROBAR

Suitable for:

6124057 IMPELLER \varnothing 90 mm
for NIAGARA 251/261
for Dishwasher (ELETTROBAR) NIAGARA251
NIAGARA261



ELETTROBAR 124057

3528220 SELF-TAPPING SCREW \varnothing 3.5x13 mm
stainless steel - cylinder head
cross recessed - C type end
UNI 6954 - 7981 - ISO 7049



ELETTROBAR 486242

3122454 ELECTROPUMP LGB PS46RH 0.60HP
inlet \varnothing 3/8"F - outlet \varnothing 3/8"F
0.60HP 230V 50Hz 2.5A - Rpm 2800
capacitor 10 μ F
with 2 hose-end fittings \varnothing 3/8"x 12mm
for pressure increase
for Dishwasher (ELETTROBAR) E50 - E51 - E55
for Glasswasher/Cupwasher (ELETTROBAR) CLEAN3
E45 - NIAGARA45 - RIVER43
for Pan/utensilwashing machines (ELETTROBAR) U132
U70



ELETTROBAR DPE125R

ELETTROBAR REB130120

ELETTROBAR 130120

3122623 ELECTROPUMP LGB ZA400LH 1.20HP
inlet external \varnothing 60 mm - outlet external \varnothing 50 mm
1.2 HP 230V 50Hz 4.7A - Rpm 2800
capacitor 20 μ f
for Glasswasher/Cupwasher (ELETTROBAR) 22F - 22R
44F




ELETTROBAR REB130068
ELETTROBAR 130068

ELETTROBAR 130009
ELETTROBAR 130079

ELETTROBAR 130018

3122648 GASKET FOR PUMP HOUSING



ELETTROBAR REB437049

ELETTROBAR 437049





Suitable for:

3122620 HOUSING FOR PUMP LGB ZA400SX

inlet external \varnothing 60 mm
outlet external \varnothing 50 mm



ELETTROBAR 116013

3122024 SEAL MECHANICAL FOR SHAFT \varnothing 12 mm

metal seal \varnothing internal 11 mm - \varnothing external 24 mm
height 15.5 mm
back. element \varnothing internal 14 mm - \varnothing external 24 mm
height 8 mm



ELETTROBAR RAT19

ELETTROBAR RAT72

ELETTROBAR 141002

ELETTROBAR 926274

ELETTROBAR



Suitable for:

3122634 IMPELLER \varnothing 104 mm



ELETTROBAR RAG291

ELETTROBAR 124031

3122340 ELECTROPUMP LGB ZF400VLH 1HP

inlet external \varnothing 50 mm - outlet external \varnothing 50 mm
1HP 230V 50Hz 3.6A - Rpm 2800
capacitor 16 μ f



ELETTROBAR /ELF002519

3122829 ELECTROPUMP LGB ZF400VLH 1HP 230V

inlet external \varnothing 50 mm - outlet external \varnothing 50 mm
1HP 230V 50Hz - capacitor 16 μ F
for Dishwasher (ELETTROBAR)
E51 - 510




ELETTROBAR REB130126

ELETTROBAR 130126

5007992 ELECTROPUMP VOLUMETRIC LGB PPL46DX

0.32Kw 230V 50Hz capacitor 8 μ F
hose-end fitting inlet-outlet \varnothing 12 mm
for Dishwasher (ELETTROBAR)
RIVER54 - RIVER71
for Dishwasher hood type (ELETTROBAR)
RIVERE78



ELETTROBAR DPE125RRID

ELETTROBAR DPE127

ELETTROBAR REB130127

ELETTROBAR REB130129

ELETTROBAR 130127

ELETTROBAR 130143

Suitable for:

Suitable for:

3122448 PUMP MOTOR LGB CE150SX 1.5HP
 inlet external \varnothing 63 mm - outlet external \varnothing 48 mm
 1.5HP 220/400V 50Hz 3.7/2.3A - rpm 2800
 for Dishwasher hood type (ELETTROBAR) E110



ELETTROBAR DPE2251

ELETTROBAR DPE2251R

ELETTROBAR 926146

3122255 EPDM O-RING 04625
 for pumps LGB ZF800DX and ZF650DX



ELETTROBAR RAG61

ELETTROBAR 926084

3122759 IMPELLER FOR PUMP \varnothing 110 mm



ELETTROBAR RAG29

ELETTROBAR 926085

3122632 SEAL ROTARY \varnothing 13 BACK FACE 5.5 mm
 for Dishwasher (ELETTROBAR)
 NIAGARA251 - NIAGARA261 - PLUVIA260
 for Dishwasher hood type (ELETTROBAR)
 NIAGARA281



ELETTROBAR RAT211

ELETTROBAR REB141007

ELETTROBAR 141007

ELETTROBAR 141008

ELETTROBAR 141009

ELETTROBAR 80843

ELETTROBAR 926255

3122450 PUMP MOTOR LGB ZF400SX 1.5HP
 inlet external \varnothing 60 mm - outlet external \varnothing 50 mm
 1.5HP 230V 50Hz 3.8A - rpm 2800
 capacitor 16 μ f
 for Dishwasher hood type (ELETTROBAR)
 RIVER282 - RIVER81



ELETTROBAR C.80114

ELETTROBAR DPE219

ELETTROBAR 80113

ELETTROBAR 80114

3122876 HOUSING FOR PUMP LGB ZF400SX
 inlet \varnothing 60 mm - outlet \varnothing 50 mm



ELETTROBAR 80846

6080845 IMPELLER \varnothing 101 mm
 for RIVER 282
 for Dishwasher hood type (ELETTROBAR) RIVER282



ELETTROBAR 80845

3122365 O-RING 02475 EPDM
 for Dishwasher hood type (ELETTROBAR)
 RIVER282



ELETTROBAR REB456031

ELETTROBAR 456031

ELETTROBAR 80844



Suitable for:

3122632 SEAL ROTARY \varnothing 13 BACK FACE 5.5 mm
for Dishwasher (ELETTROBAR)
NIAGARA251 - NIAGARA261 - PLUVIA260
for Dishwasher hood type (ELETTROBAR)
NIAGARA281



ELETTROBAR RAT211
ELETTROBAR 141008
ELETTROBAR 928255

ELETTROBAR REB141007
ELETTROBAR 141009

ELETTROBAR 141007
ELETTROBAR 80843


ELETTROBAR



Suitable for:

Relays

3351154 BASE OCTAL ES8 10A 400V
8 poles



ELETTROBAR DEZ3

ELETTROBAR 927045

3351068 POWER RELAY FINDER 62.83.8.230.0300
230V 50/60Hz
3 NO contacts 16A



ELETTROBAR 229040

3351095 POWER RELAY FINDER 60.12.8.024.0040
24Vac 50/60Hz
2 changeover contacts 10A
with test push-button and mechanical indicator



ELETTROBAR DER163

ELETTROBAR 927044

3351901 POWER RELAY FINDER 60.62.8.230.0000
230V 50/60Hz
2 exchange contacts 10A



ELETTROBAR DER11

ELETTROBAR RTFOC00144

ELETTROBAR 229021

ELETTROBAR 229023

3351021 POWER RELAY FINDER 62.82.8.230.0000
230V 50/60Hz
2 exchange contacts 16A



ELETTROBAR DER1106

ELETTROBAR DER1108

ELETTROBAR 929115

3351029 POWER RELAY FINDER 62.82.8.230.0300
230V 50/60Hz
2 contacts NO 16A



ELETTROBAR 229039

Suitable for:

3351008 POWER RELAY FINDER 62.83.8.230.0000
230V 50/60Hz
3 exchange contacts 16A



ELETTROBAR 229036

Suitable for:

3351602 POWER RELAY FINDER 65.31.8.230.0300
230V 50/60Hz
1 contact NO 30A
for Dishwasher (ELETTROBAR)
S651



ELETTROBAR DER111

ELETTROBAR 229025

ELETTROBAR 229029

3351900 POWER RELAY ITALIAN B2-3
230V 50/60Hz
3 exchange contacts 16A-250V



ELETTROBAR 229009

3351603 RELAY A2L-FA 16A 230V
bipolar switch
2 NO contacts



ELETTROBAR REB229030

ELETTROBAR 229030

3351601 RELAY B1-3 16A 230V 50/60Hz
3 NO contacts



ELETTROBAR 229008

3351605 RELAY POWER FINDER 60.63.8.230.0000
230V 50/60Hz
3 exchange contacts 10A



ELETTROBAR DER100

ELETTROBAR RTF0C00144

ELETTROBAR 229024

3351041 TIME LIMIT RELAY E21 5A 240V 50/60Hz
1 switching contact
slow release on excitation
timer 60" ÷ 3'



ELETTROBAR REB238064

ELETTROBAR 238064

Rings

6303029 DRIP RING ø 90 mm
for Dishwasher (ELETTROBAR)
E46 - E50 - E51



ELETTROBAR REB303029

ELETTROBAR 303029

6303032 RING MADE OF PLASTIC ø 44x40x3 mm
for DISHWASHER ELETTROBAR RIVER81
for Dishwasher hood type (ELETTROBAR)
RIVER81



ELETTROBAR 303032

ELETTROBAR 303037

ELETTROBAR 303040



Suitable for:

ELETTROBAR



Suitable for:

Rinse aid pumps and accessories

3090352 FOOT FILTER OF PP
for PIPE 4x6 mm
for DISPENSER SEKO



ELETTROBAR 121075

5058869 HOSE MADE OF SILICONE 200 mm \varnothing 5x10 mm
hose-end \varnothing 6 mm - pipe fitting \varnothing 4x6 mm
for rinse aid



ELETTROBAR 143261

5059435 HOSE THERMOPLASTIC 185 mm
internal \varnothing 6 mm - external \varnothing 10 mm - for detergent



ELETTROBAR 143258

3090040 HYDRAUL. RINSE AID INJECTOR N6 E 05 G4G6
with diaphragm in EPDM
minimum pressure 0.5 bar
intake side connection for tube 4 mm.
pressure side connection for tube 6 mm.



ELETTROBAR

3090308 HYDRAULIC DISPENSER DIB-E
attacco posteriore aperto per collegamento con la
auxiliary pump
hydraulic system for rinse aid dosing
in dishwashers, it does not need
power connection
adjustable flow rate: 0÷3 cm³
connection between solenoid valve and boiler (DIB-
for Dishwasher (ELETTROBAR)
since 1/10/07
RIVER44CRP - RIVER54CRP
for Pan/utensilwashing machines (ELETTROBAR)
U60 - U61 - U70



ELETTROBAR 929198

3090601 HYDRAULIC INJECTOR SP205
complete with spring and bellows




ELETTROBAR REB987023

ELETTROBAR 209985

ELETTROBAR 987023

3090603 BELLOWS FOR HYDRAULIC INJECTOR



ELETTROBAR REB199012

ELETTROBAR 199012



Suitable for:

3090148 HYDRAULIC DISPENSER EXTENSION
for Glasswasher/Cupwasher (ELETTROBAR)
RIVER40



ELETTROBAR 466005

ELETTROBAR



Suitable for:

3090602 INLET VALVE



ELETTROBAR REB144012

ELETTROBAR 144012

ELETTROBAR 144026

3090037 HYDRAULIC RINSE AID INJECTOR



ELETTROBAR /ELF011310

ELETTROBAR RIC0000259

3090029 PERISTALTIC DETERGENT PUMP G200 230V50Hz
detergent flow rate 0.777 gr per second
max flow rate 2 l/hour (equivalent to 2000 cm3)
for DISHWASHER (500 DISHES PER HOUR)



ELETTROBAR 209014

3090017 INLET FILTER MODEL 3000



ELETTROBAR

3090018 T-FITTING BLACK



ELETTROBAR

3090190 PERISTALTIC PUMP FOR DETERGENT
mod. RPS20RMIP - Ext.size. 160 x 80 x 85 mm
220/240 V - 50 Hz
flow rate 0.28 L/h - 2.80 L/h



ELETTROBAR



Suitable for:

ELETTROBAR



3090310 PERISTALTIC PUMP FOR DETERGENT PBR3
230V 50Hz



ELETTROBAR DWD4P

ELETTROBAR DWD4PD

ELETTROBAR 209016

Suitable for:

3090351 SANTOPRENE DIAPHRAGM-TUBE
with connections



ELETTROBAR 143219

3090300 PERISTALTIC PUMP FOR DETERGENT PG-3
fixed flow rate: 3 L/h
santoprene tube
3W 230V 50Hz
complete with assembly kit



ELETTROBAR 165280

ELETTROBAR 209013

3090351 SANTOPRENE DIAPHRAGM-TUBE
with connections



ELETTROBAR 143219

3090142 PERISTALTIC PUMP RINSE AID PS10N
fixed flow rate 1.5 L/h
PLASTO-M® hose for rinse aid
4.5W 230V 50Hz
complete with assembly kit



ELETTROBAR

6926278 RINSE AID DOSING PUMP DIB-E
back connection closed
for Dishwasher (ELETTROBAR)
since 1/10/07
RIVER44 - RIVER54
AMIKA 4X - PLUVIA260 - PLUVIA270
for Dishwasher hood type (ELETTROBAR)
PLUVIA280



ELETTROBAR DWD3

ELETTROBAR 209025

ELETTROBAR 926278

3090038 RINSE AID INJECTOR DB2
power supply 220/240V 50Hz
screw for flow rate regulation
for Glasswasher/Cupwasher (ELETTROBAR) S621 - S636



ELETTROBAR DWD1F

ELETTROBAR 987020

3090039 COIL 220/240V 50Hz
for Glasswasher/Cupwasher (ELETTROBAR) S621 - S636



ELETTROBAR REB201002

ELETTROBAR 201002

3090003 INLET VALVE FOR RINSE AID INJECTOR
for Glasswasher/Cupwasher (ELETTROBAR) S621 - S636



ELETTROBAR

3090224 RINSE AID INLET FILTER
for Dishwasher (ELETTROBAR)
E51



ELETTROBAR CWF1

ELETTROBAR CWF1F

ELETTROBAR 121017

Rotary switches

3057050 CONNECTING BRACKET 28x21x16 mm
distance between hooking brackets 27 mm
f/connection between selector switch and thermost.



ELETTROBAR RTBF900037

ELETTROBAR RTCU900112

3057603 SELECTOR SWITCH EN60947-3
12A 400V 50Hz
square spindle 5x5 mm
for Dishwasher pull-through (ELETTROBAR) CLEAN160
CLEAN220



ELETTROBAR DEC59

ELETTROBAR 927034

3057604 SELECTOR SWITCH EN60947-3 5 POSITIONS
12A 400V 50Hz
square spindle 5x5 mm
for Dishwasher (ELETTROBAR) E60 - E65
for Dishwasher hood type (ELETTROBAR) E100 - E120
E140



ELETTROBAR DEC490

ELETTROBAR 926182

3059078 SELECTOR SWITCH 2-POLE 16A 380V
square spindle 5x5 mm



ELETTROBAR REB213002

ELETTROBAR 213002

3059070 SELECTOR SWITCH 2-POLE 16A 600V
square spindle 5x5 mm



ELETTROBAR /ELF100102

3059011 SELECTOR SWITCH 3-POLE
contact capacity 16A 380V - max 60/75°C
square shaft 5x5 mm



ELETTROBAR /ELF000598



Suitable for:

3057602 SELECTOR SWITCH 4-POLE 16A 250V
square pin 5x5 mm
for Dishwasher (ELETTROBAR) R708



ELETTROBAR 213003

Suitable for:

3059061 SELECTOR SWITCH 6-POLE 16A 400V
square pin 5x5 mm



ELETTROBAR /COM120716

Salt containers and accessories

3067603 CAP FOR SALT CONTAINER



ELETTROBAR REB480006

ELETTROBAR 480006

3067002 GASKET FOR CONTAINER

external \varnothing 82 mm
internal \varnothing 64 mm
thickness 3 mm



ELETTROBAR REB437034

ELETTROBAR 437034

3067604 RETAINING NUT FOR CAP



ELETTROBAR REB429012

ELETTROBAR 429012

3090607 FUNNEL FOR SALT INTAKE
with water cleaner
for all dishwasher models



ELETTROBAR 799002

3067001 SALT CONTAINER



ELETTROBAR 406999

3067002 GASKET FOR CONTAINER

external \varnothing 82 mm
internal \varnothing 64 mm
thickness 3 mm



ELETTROBAR REB437034

ELETTROBAR 437034



Suitable for:

3067007 SALT CONTAINER CAP



ELETTROBAR

ELETTROBAR



Suitable for:

3067005 SALT CONTAINER RING NUT



ELETTROBAR REB429011

ELETTROBAR 429011

3067602 SALT CONTAINER ASSEMBLY 85x100 mm

new model
for E35/40/41/42/45/46/50/51/55-MISTRAL40/51
NIAGARA35/40/45/51-RIVER48/50/61
for Dishwasher (ELETTROBAR) E46 - E50 - E51 - E55
NIAGARA51 - RIVER50 - RIVER61
for Glasswasher/Cupwasher (ELETTROBAR) E35 - E40
E41 - E42 - E45 - MISTRAL40 - MISTRAL50
NIAGARA35 - NIAGARA40 - NIAGARA45 - RIVER48
21F - 21R - 31F



ELETTROBAR 406998

3067006 SALT CONTAINER LID




ELETTROBAR REB480005

ELETTROBAR 480005

Scale removers for dishwashers

3094007 NEW 4-COLUMN SCALE REMOVER

dimensions 410x210x35 mm
fittings \varnothing 12 mm



ELETTROBAR REB117004

ELETTROBAR 117004

3094005 4 COLUMN SCALE REMOVER

width 165 mm - length 390 mm



ELETTROBAR 117001

Shock absorbers

5032656 SHOCK ABSORBER 082643 50N

total length 378mm
for DISHWASHER LFD60
for Dishwasher (ELETTROBAR) LFD60



ELETTROBAR 35070



Suitable for:

ELETTROBAR



Suitable for:

Solenoid valves

3120477 ADJUSTER FOR INLET INVENSYS WHITE
flow rate 10 L/min - tolerance +/- 15%



ELETTROBAR 75976

3120004 SOLEN. VALVE ELBI TYPE 319 1 WAY 90°
220/240V 50/60Hz - max. temperature 90°C
inlet 3/4" - outlet ø 10.5 mm



ELETTROBAR DEV3S

ELETTROBAR 240006

3120504 SOLEN. VALVE ELBI TYPE 319 1 WAY 90°
24V 50/60Hz - max. temperature 90°C
inlet 3/4" - outlet ø 10.5 mm



ELETTROBAR

3120005 SOLEN. VALVE ELBI TYPE 329 1 WAY 180°
220/240V 50/60Hz - max. temperature 90°C
inlet 3/4" - outlet ø 10.5 mm



ELETTROBAR /ELF120021

ELETTROBAR DEV3S16

ELETTROBAR REB240011

ELETTROBAR RTFOC00022

ELETTROBAR 240005

ELETTROBAR 240011

ELETTROBAR 240016

ELETTROBAR 240018

3120505 SOLEN. VALVE ELBI TYPE 329 1 WAY 180°
24V 50/60Hz - max. temperature 90°C
inlet 3/4" - outlet ø 10.5 mm



ELETTROBAR DEV34S

ELETTROBAR DEV34S16

ELETTROBAR 927242

3120007 SOLEN. VALVE ELBI TYPE 349 2 WAY 180°
220/240V 50/60Hz - max. temperature 90°C
inlet 3/4" - two outlets ø 10.5 mm




ELETTROBAR DEV3D

ELETTROBAR RTFOC00203

ELETTROBAR 240003

ELETTROBAR 929172

3120507 SOLEN. VALVE ELBI TYPE 349 2 WAY 180°
24V 50/60Hz - max. temperature 90°C
inlet 3/4" - two outlets ø 10.5 mm



ELETTROBAR DEV32416

ELETTROBAR 927001

3120556 SOLEN. VALVE ELBI TYPE 349 2 WAY 180°
230V 50/60Hz - max. temperature 90°C
inlet 3/4" - two outlets ø 10.5 mm
1 outlet with red adjuster 0.5 L/min



ELETTROBAR 240010

3120511 SOLEN. VALVE ELBI TYPE 350 1 WAY 90°
24V 50/60Hz - max. temperature 90°C
inlet 3/4" - outlet ø 13.5 mm



ELETTROBAR

3120512 SOLEN. VALVE ELBI TYPE 351 1 WAY 180°
24V 50/60Hz - max. temperature 90°C
inlet 3/4" - outlet ø 13.5 mm



ELETTROBAR



Suitable for:

3120408 SOLEN. VALVE T&P 1 WAY 90°
230V 50/60Hz - max. temperature 90°C
inlet 3/4" - outlet ø 13.5 mm



ELETTROBAR

Suitable for:

3120414 SOLEN. VALVE T&P 3 WAY 180°
230V 50/60Hz - max. temperature 90°C
inlet 3/4" - three outlets ø 10.5 mm



ELETTROBAR /ELF120003

ELETTROBAR DEV37


ELETTROBAR VEV3T

5049894 SOLENOID VALVE CHANGEOVER 3-WAY
230V 50/60Hz - max. temperature 90°C
three outlets ø 10.5 mm
1 outlet with red adjuster 0.5 L/min
for Dishwasher (ELETTROBAR)
FAST161 - FAST161-2 - NIAGARA361
for Glasswasher/Cupwasher (ELETTROBAR)
FAST139 - FAST160 - NIAGARA341 - PLUVIA240
RIVER242



ELETTROBAR 999288

3120555 SOLENOID VALVE ELBI TYPE 369 2-WAY 180°
230V 50/60Hz - max temperature 90°C
inlet 3/4" - three outlets ø 10.5 mm
1 outlet with red adjuster 0.5 L/min



ELETTROBAR REB240002

ELETTROBAR 240002


3120014 SOLENOID VALVE ELBI TYPE 369 3-WAY 180°
220/240V 50/60Hz - max temperature 90°C
inlet 3/4" - three outlets ø 10.5 mm



ELETTROBAR DEV3T

ELETTROBAR RTFOC00520

3120399 SOLENOID VALVE INVENSYS 1 WAY 180°
12V 50/60Hz - max temperature 90°C
inlet 3/4" - outlet ø 13.5 mm
operating pressure from 0.2 to 10 bar



ELETTROBAR

3120400 SOLENOID VALVE INVENSYS 1-WAY 90°
12Vac/dc 50/60Hz - max. temperature 90°C
inlet 3/4" - outlet ø 13.5 mm
operating pressure from 0.2 to 10 bar
flow rate 1.2 m3/h



ELETTROBAR

3120612 SOLENOID VALVE L145R2 1"FF 24V
for steam
normally closed (ex L142 M2)
max. temperature 175°C
max. differential pressure 12 bar
coil 24V 50Hz



ELETTROBAR /COM120163



Suitable for:

ELETTROBAR



3120261 SOLENOID VALVE MULLER 1-WAY 180°
220/240V 50/60Hz - max. temperature 90°C
inlet 3/4" - outlet ø 10.5 mm



ELETTROBAR DEV1

6240020 SOLENOID VALVE SWITCHOVER 3-WAY
230V 50/60Hz - max. temperature 90°C
3 outlets ø 10.5 mm
for Dishwasher (ELETTROBAR) NIAGARA251
NIAGARA261



ELETTROBAR 240020

3120554 SOLENOID VALVE VE123 1/2"FF
coil 24V 50/60Hz 9W



ELETTROBAR DEV24

ELETTROBAR 927142

3120517 SOLENOID-VALVE L140B5 1/2"FF 24V
for water - normally closed
max temperature 100°C
coil z615A 24V 50Hz



ELETTROBAR /ELF231402

Spare parts for pumps

3122350 IMPELLER ø 118 mm
new model with threaded pin
for 1.5Hp electropumps



ELETTROBAR /ELF002870

3122838 IMPELLER FOR PUMP ø 62 mm



ELETTROBAR REB124033

ELETTROBAR 124033

3122178 IMPELLER FOR PUMP FIR B237 50HZ ø 93 mm



ELETTROBAR REB124038

ELETTROBAR 124038

3122274 IMPELLER FOR PUMP T.10 ø 66.5 mm



ELETTROBAR 124046

3122825 IMPELLER FOR PUMP T172 ø 73 mm
for Glasswasher/Cupwasher (ELETTROBAR) 40F - 40FD
40R - 40RD - 400F - 400FD - 400R - 400RD



ELETTROBAR REB124032

ELETTROBAR 124032

3122079 SEAL MECHANICAL ø 10 mm



ELETTROBAR REB141001

ELETTROBAR 141001

3122621 SEAL MECHANICAL LCT 160



ELETTROBAR RAT210

ELETTROBAR 141003

Springs

5032657 DOOR SPRING
 ø 8 mm overall length 148 mm
 for DISHWASHER LFD60



ELETTROBAR 35020

5029358 DOOR SPRINGS KIT
 support dimensions 95x66x61 mm
 for DISHWASHER GL80-RIVER 150



ELETTROBAR 75271

5060752 SET SPRING PRE-WASH DOOR
 dimensions support 95x66x61 mm
 for Dishwasher pull-through (ELETTROBAR)
 NIAGARA2156



ELETTROBAR 77560

6080277 SLIDER SPRING HOOKING
 for Dishwasher hood type (ELETTROBAR)
 NIAGARA281 - PLUVIA280 - RIVER282 - RIVER80
 RIVER81 - RIVER82



ELETTROBAR 80277

3250155 SPRING ADJUSTING HOOK
 for CLEAN 10/12/14/100-E100÷E140
 for Dishwasher hood type (ELETTROBAR) CLEAN100
 CLEAN120 - CLEAN140 - E100 - E110 - E120
 E140 - RIVER80 - RIVER81 - RIVER82



ELETTROBAR DAG332

ELETTROBAR 926009

5026327 SPRING FOR DOOR WITH HOOK ø 10 mm
 overall length 150 mm
 for Dishwasher (ELETTROBAR)
 RIVER48 - RIVER50 - RIVER54



ELETTROBAR 449057

3250156 SPRING FOR HOOD LIFTING ø 30x510 mm
 for CLEAN 10/12/14/100-E100÷E140
 for Dishwasher hood type (ELETTROBAR) CLEAN100
 CLEAN120 - CLEAN140 - E100 - E110 - E120
 E140



ELETTROBAR CMT549

ELETTROBAR 926007



Suitable for:

3250054 SPRING KIT FOR DOOR LIFTING
dimensions 117x65 mm.
for CLEAN 160/220/270/271/361/471



ELETTROBAR DWK1ALFA

ELETTROBAR 927267

Suitable for:

5014336 SPRING SR20 \varnothing 36x39 mm
for Dishwasher hood type (ELETTROBAR) CLEAN160
CLEAN220 - CLEAN270 - CLEAN271 - CLEAN361
CLEAN471



ELETTROBAR CMT82
ELETTROBAR 927269

ELETTROBAR CMT84

ELETTROBAR 927020

6449058 WIRE SPRING OPENING/CLOSING DOOR
for NIAGARA 251-PULVIA 260



ELETTROBAR 449058

Supports for wash and rinse arms

3243740 CENTER CONDUIT
for Glasswasher/Cupwasher (ELETTROBAR) E41 - E42



ELETTROBAR 115107

3243609 GASKET CENTER CONDUIT
for Glasswasher/Cupwasher (ELETTROBAR) 10F - 11F
11FD



ELETTROBAR REB437046

ELETTROBAR 437046

3243739 LOWER MANIFOLD
with both outlets open



ELETTROBAR 111024

1186346 O-RING 02043 EPDM



ELETTROBAR 456051

3243615 SPINDLE FOR MANIFOLD



ELETTROBAR REB325025

ELETTROBAR 325025



ELETTROBAR



Suitable for:

Suitable for:

3743799 COUPLING FOR EXTERNAL WASH CONVEYOR

3743800 COUPLING FOR RINSE CONVEYOR ARM



ELETTROBAR 75155

ELETTROBAR 75401

3743803 COUPLING FOR WASH ARM
fittings \varnothing 62 mm 48 mm
for Pan/utensilwashing machines (ELETTROBAR)
U61 - U61H

3743802 FLANGE FRAME FOR WASH ARM SUPPORT
for Pan/utensilwashing machines (ELETTROBAR)
U61 - U61H



ELETTROBAR 42063

ELETTROBAR 4206301

ELETTROBAR C.41064CP

ELETTROBAR 41064CP

3743794 COUPLING/SUPPORT FOR RINSE ARM
for Dishwasher pull-through (ELETTROBAR)

3743796 CHROME-PLATED BRASS COUPLING 1/2"x14



ELETTROBAR DWS506

ELETTROBAR 927070

ELETTROBAR DZR292

ELETTROBAR 927073

3743795 SUPPORT FOR RINSE ARM COUPLING
for Dishwasher pull-through (ELETTROBAR)



ELETTROBAR DWS505

ELETTROBAR 927072

3743789 HOSE END ELBOW \varnothing 35 mm

3743788 FLANGED SLEEVE



ELETTROBAR REB108007

ELETTROBAR 108007

ELETTROBAR 127028

3743313 INTERNAL BOTTOM WASH RING NUT

6115117 LOWER CENTER CONDUIT X5



ELETTROBAR 80181

ELETTROBAR 115117



Suitable for:

ELETTROBAR



6115143 LOWER CENTRE CONDUIT
for NIAGARA 251/261/281-PULVIA 260



ELETTROBAR 115143

3243903 LOWER WASH ARM ASSEMBLY SUPPORT
for Dishwasher hood type (ELETTROBAR) 10 - 12



ELETTROBAR DAS2598

ELETTROBAR 926029

3243988 PLASTIC FITTING PIPE




ELETTROBAR REB468165

ELETTROBAR 408165

ELETTROBAR 468142

ELETTROBAR 468165

3186605 GASKET FLAT EPDM \varnothing 33x17x1.5 mm
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E40 - NIAGARA35 - NIAGARA40



ELETTROBAR REB437078


ELETTROBAR 437078

6429073 RING NUT SUPPORT LOWER LA50
thread 2" - external \varnothing 87 mm
for Dishwasher (ELETTROBAR) NIAGARA251
NIAGARA261 - PLUVIA260
for Dishwasher hood type (ELETTROBAR) NIAGARA281
PLUVIA280



ELETTROBAR 429073

3743798 TOP ARM COMPLETE FITTING



ELETTROBAR 75144

ELETTROBAR 75169

ELETTROBAR 75645

3743274 UPPER MIDDLE DUCT
for Dishwasher (ELETTROBAR) E55



ELETTROBAR 115129

3243688 UPPER WASH ARM ASSEMBLY SUPPORT
for Dishwasher (ELETTROBAR)
E50 - E51
for Pan/utensilwashing machines (ELETTROBAR)
U61



ELETTROBAR REB115074

ELETTROBAR 115074

3186604 SUPPORT GASKET
for Dishwasher (ELETTROBAR) E50 - E51
for Pan/utensilwashing machines (ELETTROBAR) U61



ELETTROBAR REB437064

ELETTROBAR 437064



Suitable for:

3243861 UPPER WASH ARM ASSEMBLY SUPPORT



ELETTROBAR DAS2597

ELETTROBAR 926125

3186432 LOWER SUPPORT GASKET



ELETTROBAR CGG30

3243596 STAINLESS STEEL ROD FOR UPPER SUPPORT
for Dishwasher hood type (ELETTROBAR)
E100 - E110 - E120 - E140



ELETTROBAR DLP527

ELETTROBAR 926127

3243872 SUPPORT STAINLESS STEEL PIPE \varnothing 10x145 mm



ELETTROBAR DZT799

ELETTROBAR 926031

3243865 WASH ARM ASSEMBLY BOSS



ELETTROBAR DAS258

ELETTROBAR 926129

ELETTROBAR



Suitable for:

3243662 CENTER CONDUIT

for Dishwasher (ELETTROBAR) E46 - E60 - E65 - 46F
46FD - 460F
for Dishwasher hood type (ELETTROBAR) E100 - E110
for Glasswasher/Cupwasher (ELETTROBAR) 460FD



ELETTROBAR DAS2596

ELETTROBAR 115076

3243866 RING NUT FOR BOSS



ELETTROBAR CDP258

ELETTROBAR 80314

ELETTROBAR 926128

3243691 STAINLESS STEEL ROD FOR WASH ARM ASSY
for Dishwasher (ELETTROBAR) E60 - E65
for Dishwasher hood type (ELETTROBAR) E100 - E110
E120 - E140



ELETTROBAR DLP526N

ELETTROBAR 926154

3243871 SUPPORT STAINLESS STEEL PIPE \varnothing 10x85 mm



ELETTROBAR DZT798

ELETTROBAR 926065

3243862 WATER SPREADING DISK



ELETTROBAR CWD52

ELETTROBAR 926249



Suitable for:

ELETTROBAR



Suitable for:

5021286 UPPER WASH ARM ASSEMBLY SUPPORT
for PAN WASHER



ELETTROBAR 4205901

3743070 UPPER WASHING CONDUIT
for Dishwasher hood type (ELETTROBAR)
RIVER80 - RIVER81 - RIVER82



ELETTROBAR C.80177

ELETTROBAR C80177

ELETTROBAR 80177

3186167 UPPER WASHING INLET GASKET
dimensions 110x68 mm.
for Dishwasher hood type (ELETTROBAR)
RIVER80 - RIVER81 - RIVER82




ELETTROBAR C.80178

ELETTROBAR 80178

Switches


3319622 CHANGEOVER SWITCH 2 POLE WHITE 16A 250V
16(4)A 250V - max. temperature 120°C
mounting hole 22x30 mm
for Glasswasher/Cupwasher (ELETTROBAR) 10F



ELETTROBAR REB226059

ELETTROBAR 226059

3319627 DOUBLE CHANGE OVER SWITCH 16A 250V
for Dishwasher (ELETTROBAR) E46 - E50 - E51 - E52
for Glasswasher/Cupwasher (ELETTROBAR) E35 - E40
E45



ELETTROBAR REB208011

ELETTROBAR 208011

3319633 BUTTON FOR SWITCH BLOCK
for Dishwasher (ELETTROBAR) E46 - E50 - E51 - E52
for Dishwasher hood type (ELETTROBAR)
since 1/01/92
till 31/12/92
E78
for Glasswasher/Cupwasher (ELETTROBAR) E35 - E40
E45
for Dishwasher (ELETTROBAR)
since 1/01/92
till 31/12/92
E78



ELETTROBAR REB227051

ELETTROBAR 227051




Suitable for:

3319635 CAP SQUARE
mounting hole 25x25 mm
for Dishwasher (ELETTROBAR) E46 - E50 - E51 - E52
for Glasswasher/Cupwasher (ELETTROBAR) E35 - E40
E45



ELETTROBAR 480095

3319482 CHROME-PLATED ELLIPTIC KEY 17x13 mm



ELETTROBAR 227062

3319481 PUSH BUTTON BODY 17x13 mm ELLIPTICAL GRA
mounting hole 21x17 mm - colore grigio scuro



ELETTROBAR 226112

ELETTROBAR 226114

3319170 PUSH-BUTTON ELLIPTICAL 17x13 mm BLACK



ELETTROBAR 227056

3319634 START SWITCH
for Dishwasher (ELETTROBAR) E46 - E50 - E51 - E52
for Glasswasher/Cupwasher (ELETTROBAR) E35 - E40
E45



ELETTROBAR REB227052

ELETTROBAR 227052

ELETTROBAR



Suitable for:

3319632 CAP SQUARE WITH INDICATOR HOLE
mounting hole 25x25 mm
for Dishwasher (ELETTROBAR) E46 - E50 - E51 - E52
for Glasswasher/Cupwasher (ELETTROBAR) E35 - E40
E45



ELETTROBAR 226098

3319177 ELLIPTICAL PUSH-BUTTON INSERT
for Dishwasher hood type (ELETTROBAR) PLUVIA280



ELETTROBAR REB226102

ELETTROBAR 226102

3319164 PUSH-BUTTON BODY 17x13 mm ELLIPTICAL BLA
mounting hole 21x17 mm



ELETTROBAR REB226101

ELETTROBAR 226101

3319636 RECTANGULAR CAP
mounting hole 34x24 mm
for Dishwasher (ELETTROBAR) E46 - E50 - E51 - E52
for Glasswasher/Cupwasher (ELETTROBAR) E35 - E40
E45



ELETTROBAR 480096



Suitable for:

ELETTROBAR



3319628 DOUBLE CONTACT SWITCH 16(6)A 250V
 for Dishwasher (ELETTROBAR) E46 - E50 - E51 - E52
 for Glasswasher/Cupwasher (ELETTROBAR) E35 - E40
 E45



ELETTROBAR REB226095

ELETTROBAR 226093


ELETTROBAR 226095

3319635 CAP SQUARE
 mounting hole 25x25 mm
 for Dishwasher (ELETTROBAR) E46 - E50 - E51 - E52
 for Glasswasher/Cupwasher (ELETTROBAR) E35 - E40
 E45



ELETTROBAR 480095

3319482 CHROME-PLATED ELLIPTIC KEY 17x13 mm



ELETTROBAR 227062

3319481 PUSH BUTTON BODY 17x13 mm ELLIPTICAL GRA
 mounting hole 21x17 mm - colore grigio scuro



ELETTROBAR 226112

ELETTROBAR 226114

3319633 BUTTON FOR SWITCH BLOCK
 for Dishwasher (ELETTROBAR) E46 - E50 - E51 - E52
 for Dishwasher hood type (ELETTROBAR)
 since 1/01/92
 till 31/12/92
 E78
 for Glasswasher/Cupwasher (ELETTROBAR) E35 - E40
 E45
 for Dishwasher (ELETTROBAR)
 since 1/01/92
 till 31/12/92
 E78



ELETTROBAR REB227051

ELETTROBAR 227051

3319632 CAP SQUARE WITH INDICATOR HOLE
 mounting hole 25x25 mm
 for Dishwasher (ELETTROBAR) E46 - E50 - E51 - E52
 for Glasswasher/Cupwasher (ELETTROBAR) E35 - E40
 E45



ELETTROBAR 226098

3319177 ELLIPTICAL PUSH-BUTTON INSERT
 for Dishwasher hood type (ELETTROBAR) PLUVIA280



ELETTROBAR REB226102

ELETTROBAR 226102

3319164 PUSH-BUTTON BODY 17x13 mm ELLIPTICAL BLA
 mounting hole 21x17 mm



ELETTROBAR REB226101

ELETTROBAR 226101



Suitable for:

3319170 PUSH-BUTTON ELLIPTICAL 17x13 mm BLACK



ELETTROBAR 227056

3319634 START SWITCH

for Dishwasher (ELETTROBAR) E46 - E50 - E51 - E52
for Glasswasher/Cupwasher (ELETTROBAR) E35 - E40
E45



ELETTROBAR REB227052

ELETTROBAR 227052

5023745 EMERGENCY PUSH-BUTTON CEMA P9MER4RN
with block - mounting hole \varnothing 22 mm



ELETTROBAR DEP40

ELETTROBAR 927030

5014426 CONTACT CEMA P9B10VN 10A

1 contact NO
for COMENDA DISHWASHER ACRS145-ACRS205-ACRS225-
ACRS245-ACRS260-ACRS265-ACRS305-GMC2702-GMC3502-
GMC4502-GMC5502-LAV1001-LAV1501-NE3002-NE4002-
NE5002-NE5502-NE7002-NE7502-NE9002-NE9502-NG1202-
NG1202E-NG602-NG602E-NG902-NG902E-NL302-NL302E-
NL402-NL402E-NL502-NL502E-NL552-NL552E



ELETTROBAR DEB6

ELETTROBAR 927035

3319741 GREEN PUSH-BUTTON RM 122 (FTSE02)



ELETTROBAR /COM130439

ELETTROBAR



Suitable for:

3319636 RECTANGULAR CAP
mounting hole 34x24 mm
for Dishwasher (ELETTROBAR) E46 - E50 - E51 - E52
for Glasswasher/Cupwasher (ELETTROBAR) E35 - E40
E45



ELETTROBAR 480096

5026339 CONTACT CEMA P9B01VN 10A
1 contatto normalmente chiuso



ELETTROBAR DEB7

ELETTROBAR 927036

6226111 HOUSING FOR PUSH-BUTTON GRAY
mounting hole 25x25 mm - for push-button \varnothing 21 mm



ELETTROBAR 226111



Suitable for:

ELETTROBAR



Suitable for:

5044195 HOUSING FOR PUSH-BUTTON SQUARE BLACK
mounting hole 28x28 mm - for push-button 23x23 mm
for Dishwasher (ELETTROBAR)



ELETTROBAR 226072

3319611 HOUSING PUSH-BUTTON BLACK /2 SQUA. BUTTO
mounting hole 50x28 mm - for push-button 23x23 mm
for Glasswasher/Cupwasher (ELETTROBAR) 35F - 35R
35RD - 350F - 350R - 350RD - 40F - 40R - 40RD
400F - 400R - 400RD



ELETTROBAR REB226073

ELETTROBAR 226073

3319614 CAP BLACK 23x23 mm



ELETTROBAR REB480059

ELETTROBAR 480059

3319617 DOUBLE CONTACT SWITCH 16A 250V



ELETTROBAR REB226071

ELETTROBAR 226071

3221126 INDICATOR LAMP 24V
head ø 8 mm



ELETTROBAR DEL99

3319612 BLACK/GREEN CAM



ELETTROBAR REB409001

ELETTROBAR 409001

3319618 CHANGE-OVER SWITCH 16(4)A 250V



ELETTROBAR REB208010

ELETTROBAR 208010

3319619 HOUSING PUSH-BUTTON BLACK /3 SQUA. BUTTO
mounting hole 74x28 mm - for push-button 23x23 mm
for Dishwasher (ELETTROBAR) 50F - 50FD - 500F
500FD



ELETTROBAR REB226074

ELETTROBAR 226074

3319616 LAMP CAP CYCLE ORANGE



ELETTROBAR 207007



Suitable for:

3319621 LAMP CAP HEATING ELEMENT SYMBOL ORANGE



ELETTROBAR 410008

3221097 NEUTRAL INDICATOR LAMP 220V

head \varnothing 8 mm - 120°C
for Dishwasher (ELETTROBAR)
50F - 50FD - 500F - 500FD
for Glasswasher/Cupwasher (ELETTROBAR)
35F - 35R - 35RD - 350F - 350R - 350RD - 40F - 40R
40RD - 400F - 400R - 400RD



ELETTROBAR DEL25
ELETTROBAR 216006

ELETTROBAR DEL31
ELETTROBAR 926113

ELETTROBAR REB216006

3319613 PUSH-BUTTON SQUARE BLACK 23x23mm "ON/OFF"



ELETTROBAR 227025

6226121 HOUSING PUSH-BUTTON ELLIPT. WHITE 21x11

mounting hole 24x15 mm
for Dishwasher (ELETTROBAR) PLUVIA260



ELETTROBAR 226121

6227068 PUSH-BUTTON ELLIPTICAL 17x13 mm DARK GRA



ELETTROBAR 227068

ELETTROBAR



Suitable for:

3221192 LAMP SUPPORT



ELETTROBAR REB299035

ELETTROBAR 299035

3319615 PUSH-BUTTON SQUARE BLACK 23x23 mm "START"



ELETTROBAR REB227027

ELETTROBAR 227027


5026108 PUSH-BUTTON BODY 21x11 mm ELLIPTICAL GRA

mounting hole 24x15 mm - colore grigio chiaro
for Dishwasher hood type (ELETTROBAR)
since 1/01/06
till 31/12/06
E78
for Dishwasher (ELETTROBAR)
since 1/01/06
till 31/12/06
E78



ELETTROBAR 226113

5057042 PUSH-BUTTON ELLIPTICAL 21x11 mm BLACK



ELETTROBAR 227085



Suitable for:

ELETTROBAR



5029040 **PUSH-BUTTON ELLIPTICAL 21x11 mm BLUE**
 for Dishwasher (ELETTROBAR) E50 - E51 - E55
 PLUVIA260
 for Dishwasher hood type (ELETTROBAR)
 since 15/05/04
 E78
 for Dishwasher (ELETTROBAR)
 since 1/01/06
 till 31/12/06
 E78



ELETTROBAR 227067

Suitable for:

7104506 **PUSH-BUTTON ELLIPTICAL 21x11 mm SILVER**



ELETTROBAR 227077

7104505 **PUSH-BUTTON HOUSING ELLIPTICAL 21x11 mm**
 mounting hole 24x15 mm - colour: dark gray



ELETTROBAR 226120

3319396 **PUSH-BUTTON ROUND BLACK ø 12 mm**



ELETTROBAR 227050


3319758 **PUSH-BUTTON ROUND BLACK ø 23 mm**



ELETTROBAR REB227035

ELETTROBAR 227035

5030640 **PUSH-BUTTON ROUND SATIN SILVER ø 21 mm**
 with indicator window




ELETTROBAR 227061

6227060 **PUSH-BUTTON ROUND SATIN SILVER ø 21 mm**



ELETTROBAR 227060

7108608 **PUSH-BUTTON ROUND WHITE MATT ø 21 mm**
 for Dishwasher (ELETTROBAR) FAST 161-2



ELETTROBAR 227079

3319607 **PUSH-BUTTON 2-POLE RED 16A 250V**
 16(4)A 250V - max. temperature 120°C
 with indicator light and push-button cap
 mounting hole ø 25 mm



ELETTROBAR 999070

3319151 **SWITCH PROTECTION CAP**
 ø external 34 mm
 for push-buttons with mounting hole ø 25 mm



ELETTROBAR CGP5


ELETTROBAR 410005

Suitable for:

Suitable for:

3319608 PUSH-BUTTON 2-POLE WHITE WITH LIGHT
 16(4)A 250V - max. temperature 125°C
 with indicator light - mounting hole 25x27 mm
 for Glasswasher/Cupwasher (ELETTROBAR) 11F - 11FD
 11R - 11RD

3319181 START SWITCH DOMINO




ELETTROBAR 226041

ELETTROBAR /ELF160020

5020280 SWITCH CHANGE-OVER 2-POLE
 for Dishwasher hood type (ELETTROBAR)
 since 1/01/92
 till 31/12/06
 E78
 for Dishwasher (ELETTROBAR)
 since 1/01/92
 till 31/12/06
 E78

3319610 SWITCH CHANGEOVER 2 POLE BLACK 250V 16A
 16(4)A 250V - max. temperature 125°C
 mounting hole 25x27 mm
 for Glasswasher/Cupwasher (ELETTROBAR) 11F - 11FD
 11R - 11RD



ELETTROBAR 80804

ELETTROBAR 208008

ELETTROBAR 208009

3319609 SWITCH 2 POLE WITH LIGHT GREEN
 16(4)A 250V - max. temperature 125°
 with indicator light - mounting hole 25x27 mm
 for Glasswasher/Cupwasher (ELETTROBAR) 11F - 11FD
 11R - 11RD

3319234 TRIPLE SWITCH BLOCK 16(4)A 250V



ELETTROBAR 213007

ELETTROBAR DEP49

ELETTROBAR DEP61

ELETTROBAR 926190

Telethermometers

3441084 TELETHERMOM.58x25 mm 0-120°C TR58.25P
 plastic case
 black dial
 capillary length 1500 mm

3441008 TELETHERMOMETER BLACK Ø 52 mm 0-120°C
 plastic case
 PVC covered capillary 1500 mm
 bulb Ø 6.5x2.6 mm



ELETTROBAR

ELETTROBAR /ELF000601



Suitable for:

3441007 TELETHERMOMETER WHITE \varnothing 60 mm 0-120°C
 metal case
 PVC covered capillary 3000 mm
 spring bulb \varnothing 8x32 mm
 bulb fitting M10x1



ELETTROBAR DET1

ELETTROBAR DET1L

Suitable for:

3441033 TELETHERMOMETER 56x25 mm 0-120°C
 plastic body
 white dial
 PVC covered capillary length 3000 mm
 bulb with spring \varnothing 6x20 mm



ELETTROBAR DET1H

ELETTROBAR DET1HO

ELETTROBAR 926100

3441066 WHITE TELETHERMOMETER \varnothing 60 mm 0-120°C
 covered capillary 1500 mm
 bulb \varnothing 6x34 mm
 sliding fitting M10



ELETTROBAR /ELF007442

Terminal blocks

3247025 TERMINAL BLOCK 12-POLE PLASTIC
 for cable max 2.5 mm²
 operating temperature 150°C
 nominal voltage 450V



ELETTROBAR RTBF900045

7151084 TERMINAL BLOCK 3P WITH CABLE FIXING AND
 dimensions 60x40 mm



ELETTROBAR 459018

3247018 2-POLE TERMINAL BLOCK FV77 20A 600V
 for cable max 4 mm²
 operating temperature 150°C
 nominal voltage 450 V



ELETTROBAR 921045

3247016 3-POLE TERMINAL BLOCK FV273 40A 450V
 for cable max 6 mm²
 operating temperature 150°C
 nominal voltage 450 V



ELETTROBAR 921044



Suitable for:


3247037 4-POLE TERMINAL BLOCK FV173 40A 600V
for cable max 6 mm²
operating temperature 150°C
nominal voltage 450 V



ELETTROBAR 220010

Suitable for:

3247009 6-POLE TERMINAL BLOCK FV122/B 40A 600V
for cable max 6 mm²
operating temperature 150°C
nominal voltage 450 V



ELETTROBAR REB220011
ELETTROBAR 921057

ELETTROBAR 220011

ELETTROBAR 3720150

Terminals and electrical connectors

6000019 SPIKE FOR CONNECTOR (GET5)
for Glasswasher/Cupwasher (ELETTROBAR)
MISTRAL40 - NIAGARA35 - NIAGARA40 - NIAGARA45



ELETTROBAR CN6

Thermostats

3444604 SET TEMPERATURE THERMOSTAT F/TANK 53°C
preset temperature
covered capillary 600 mm
button bulb \varnothing 14x31 mm
16A 250V
for Dishwasher (ELETTROBAR)
E46 - E50 - E51 - E52 - E55 - 510F
for Glasswasher/Cupwasher (ELETTROBAR)
E45
for Dishwasher (ELETTROBAR)
E35H




ELETTROBAR REB236023
ELETTROBAR 236042

ELETTROBAR REB236042

ELETTROBAR 236023

3444612 SINGLE-PHASE THERMOSTAT FOR BOILER 85°C
15A 250V
covered capillary 600 mm
bulb \varnothing 6x120 mm
for Dishwasher (ELETTROBAR)
E46 - E50 - E51 - E52
for Glasswasher/Cupwasher (ELETTROBAR)
E41 - E42 - E45



ELETTROBAR REB236043
ELETTROBAR 236043

ELETTROBAR 236022

ELETTROBAR 236027




Suitable for:

ELETTROBAR



3444613 SINGLE-PHASE THERMOSTAT FOR TANK 60°C
 15A 250V
 covered capillary 600 mm
 button bulb \varnothing 14 mm
 for Dishwasher (ELETTROBAR) E60 - E65
 for Dishwasher hood type (ELETTROBAR) E100 - E110
 E120
 for Pan/utensilwashing machines (ELETTROBAR) U61
 U61H



ELETTROBAR DRT141

ELETTROBAR 926196

ELETTROBAR 926259

3186612 GASKET FLAT ASBESTOS FREE \varnothing 20x14x2 mm
 for thermostat bulb



ELETTROBAR REB437030

ELETTROBAR 437030


3444615 NUT FOR THERMOSTAT BULB



ELETTROBAR REB417017

ELETTROBAR 417017

3444332 SINGLE-PHASE THERMOSTAT 0+85°C
 for tank
 covered capillary 1000 mm
 bulb \varnothing 6x135 mm
 16A 250V
 D shaft \varnothing 6x4.6 mm



ELETTROBAR RTBF800152

3444602 SINGLE-PHASE THERMOSTAT 0-85°C
 for tank
 covered capillary 600 mm
 button bulb \varnothing 14x31 mm
 16A 250V
 D shaft \varnothing 6x4.6 mm
 for Glasswasher/Cupwasher (ELETTROBAR) S621 - S623
 S624 - S626 - S631 - S633 - S634



ELETTROBAR 236003

ELETTROBAR 236014

3444211 SINGLE-PHASE THERMOSTAT 0-90°C
 covered capillary 1000 mm
 bulb \varnothing 6.5x100 mm.
 with adapter nipple gland \varnothing 3/8
 15A 250V
 D shaft \varnothing 6x4.6 mm



ELETTROBAR /ELF005715

ELETTROBAR /ELF057150

3444719 SINGLE-PHASE THERMOSTAT 30-85°C
 covered capillary 850 mm
 bulb \varnothing 6x94 mm
 D-shaped pin \varnothing 6x4.6 mm
 for Glasswasher/Cupwasher (ELETTROBAR) CLEAN3



ELETTROBAR REB236046


ELETTROBAR 236046



Suitable for:

3444014 SINGLE-PHASE THERMOSTAT 30-90°C

capillary 1250 mm
bulb \varnothing 6x110 mm
16A 250V



ELETTROBAR RTBF800364

Suitable for:

3444049 SINGLE-PHASE THERMOSTAT 30-90°C

capillary 1700 mm
button bulb \varnothing 15x20 mm
16A 250V
D shaft \varnothing 6x4.6 mm




ELETTROBAR 236002

ELETTROBAR 236007

3744106 SINGLE-PHASE THERMOSTAT 90°-110°C

covered capillary 1600 mm
bulb \varnothing 6x80 mm



ELETTROBAR DRT14

ELETTROBAR 927057

3444614 SINGLE-PHASE THERMOSTAT 90°C

15A 250V
covered capillary 2000 mm
bulb \varnothing 6.5x90 mm
for Dishwasher (ELETTROBAR)
E60 - E65
for Dishwasher hood type (ELETTROBAR)
E100 - E110 - E120
for Dishwasher pull-through (ELETTROBAR)
RIVER150
for Pan/utensilwashing machines (ELETTROBAR)
E61 - E61H




ELETTROBAR DRT13B

ELETTROBAR 929107

3444006 THERMOSTAT SINGLE-PHASE TR2 0-210°C


D-shaped pin \varnothing 6x4.6 mm
capillary length 1000 mm - 15A 250V
bulb \varnothing 5x140 mm



ELETTROBAR

3444004 THERMOSTAT SINGLE-PHASE TR2 0-90°C

D-shaped pin \varnothing 6x4.6 mm
capillary length 1500 mm - 15A 250V
bulb \varnothing 6.5x95 mm




ELETTROBAR DAT11
ELETTROBAR 929044

ELETTROBAR DRT13

ELETTROBAR DRT13L

3444086 THREE-PHASE THERMOSTAT 108-192°C

D-shaped pin \varnothing 6x4.6 mm
capillary length 900 mm - 10A 400V
bulb \varnothing 6x200 mm



ELETTROBAR /ELF003324



Suitable for:

ELETTROBAR



Suitable for:

Tubing and hoses

3248133 DRAIN PUMP HOSE
internal \varnothing 30 e 25 mm - length 66 mm
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E35H - E40 - E40H



ELETTROBAR REB127054

ELETTROBAR 127054

3248214 DRAIN PUMP SLEEVE
internal \varnothing 19/22 mm
for Dishwasher hood type (ELETTROBAR) NIAGARA281
PLUVIA280



ELETTROBAR 69071

6929164 HOSE ELBOW SHAPED RUBBER \varnothing 60x78 mm
for Dishwasher pull-through (ELETTROBAR)
NIAGARA2150 - NIAGARA2156 - RIVER150



ELETTROBAR DZG60

ELETTROBAR 929164

6127026 HOSE OUTLET
internal \varnothing 50 mm - length 55 mm
for Dishwasher (ELETTROBAR)
E50 - E51 - E52 - E55 - NIAGARA51



ELETTROBAR REB127026

ELETTROBAR 127026

3248606 INLET HOSE
internal \varnothing 45 mm
length 60 mm
for Glasswasher/Cupwasher (ELETTROBAR) S621 - S623
S631 - S633



ELETTROBAR REB127013

ELETTROBAR 127013

3248040 OUTLET HOSE
 \varnothing internal 48 mm
overall length 215 mm
for Dishwasher (ELETTROBAR)
RIVER70
for Dishwasher hood type (ELETTROBAR)
RIVER80 - RIVER81 - RIVER82
for Pan/utensilwashing machines (ELETTROBAR)
U60E



ELETTROBAR C.80188

ELETTROBAR 80188

3248041 INLET HOSE 335 mm
internal \varnothing 55 mm
overall length \varnothing 400 mm
for Dishwasher (ELETTROBAR)
RIVER70
for Dishwasher hood type (ELETTROBAR)
RIVER80 - RIVER81 - RIVER82
for Pan/utensilwashing machines (ELETTROBAR)
U60E



ELETTROBAR 80186

Suitable for:

Suitable for:

3248043 OUTLET HOSE
 internal \varnothing 53 and 50 mm
 overall length 150 mm
 for Dishwasher hood type (ELETTROBAR)
 E100 - E120 - E140



ELETTROBAR DZG47

ELETTROBAR 926034

3248042 INLET HOSE
 internal \varnothing 60 mm
 overall length 170 mm
 for Dishwasher hood type (ELETTROBAR) E100



ELETTROBAR DZG63

ELETTROBAR 926033

3248044 INLET HOSE
 internal \varnothing 61 mm
 size 112x102 mm
 for Dishwasher hood type (ELETTROBAR)
 E120 - E140



ELETTROBAR DZG461

ELETTROBAR 926056

3248134 OUTLET HOSE
 internal \varnothing 53 e 50 mm
 for Dishwasher (ELETTROBAR) ALFA12 - ALFA14
 ALFA9



ELETTROBAR DZG52

ELETTROBAR 927016

3248135 OUTLET HOSE
 internal \varnothing 47 mm
 total length 425 mm
 for Dishwasher hood type (ELETTROBAR)
 RIVER82



ELETTROBAR 80187

3248136 OUTLET HOSE
 internal \varnothing 50 / 45 / 30 mm
 for Dishwasher hood type (ELETTROBAR) E120 - E140



ELETTROBAR DZG6364

ELETTROBAR 916158

ELETTROBAR 926158

3248601 OUTLET HOSE
 internal \varnothing 50 mm
 overflow pipe internal \varnothing 33 mm
 overall length 200 mm
 for Dishwasher (ELETTROBAR) S651 - S653 - S654
 S655 - S830 - S835



ELETTROBAR REB127002

ELETTROBAR 127002



Suitable for:

ELETTROBAR



3248213 OUTLET SLEEVE FOR CONDUIT
internal \varnothing 45-50
for Dishwasher hood type (ELETTROBAR) CLEAN100
E100



ELETTROBAR DZG6162

ELETTROBAR 926157

Suitable for:

3243983 PUMP OUTLET HOSE
 \varnothing internal 20-25 mm
for Dishwasher (ELETTROBAR)
RIVER50
for Glasswasher/Cupwasher (ELETTROBAR)
E40 - E40H - E41 - E42 - MISTRAL40 - NIAGARA40



ELETTROBAR 127053

3248605 PUMP OUTLET HOSE
internal \varnothing 33 mm
for Glasswasher/Cupwasher (ELETTROBAR) S621 - S623
S631 - S633



ELETTROBAR 127012

Wash and rinse arms for warewashers

3743312 ARM ASSEMBLY SPACER
for Dishwasher hood type (ELETTROBAR)
RIVER80 - RIVER81 - RIVER82



ELETTROBAR 80316

3243976 BODY FOR RINSE IMPELLER
without bushes
for Dishwasher (ELETTROBAR)
RIVER71
for Dishwasher hood type (ELETTROBAR)
E78 - RIVER80 - RIVER81 - RIVER82
for Pan/utensilwashing machines (ELETTROBAR)
U60E



ELETTROBAR 129059

ELETTROBAR 80371

3243978 LOCKING NUT TURNED
 \varnothing thread 5 mm
for Dishwasher hood type (ELETTROBAR)
RIVER80 - RIVER81 - RIVER82



ELETTROBAR 454005



Suitable for:

3243977 PIN FOR TURNING ARM
for Dishwasher hood type (ELETTROBAR)
RIVER80 - RIVER81 - RIVER82



ELETTROBAR 80380

3243991 STAINLESS STEEL PIN FOR ARM
height 53 mm
for Dishwasher hood type (ELETTROBAR)
RIVER80 - RIVER81 - RIVER82



ELETTROBAR C.80282

ELETTROBAR 80282

7105081 BUSHING THREAD WASH-ARM



ELETTROBAR 79044

3243651 COMPLETE RINSE ARM
for Glasswasher/Cupwasher (ELETTROBAR)
S621 - S623 - S624 - S626 - S631 - S633 - S634
11F - 11FD



ELETTROBAR REB993031

ELETTROBAR REB993036

ELETTROBAR 993019

ELETTROBAR 993031

ELETTROBAR 993032

ELETTROBAR 993036

3243653 LEFTHAND RINSE ARM



ELETTROBAR REB106035

ELETTROBAR 106035

ELETTROBAR



Suitable for:

3243979 SECURITY BLOCKING FOR LOCKING NUT
for Dishwasher hood type (ELETTROBAR)
RIVER80 - RIVER81 - RIVER82



ELETTROBAR 412030

ELETTROBAR 80374

3186605 GASKET FLAT EPDM \varnothing 33x17x1.5 mm
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E40 - NIAGARA35 - NIAGARA40



ELETTROBAR REB437078

ELETTROBAR 437078

3243607 RING NUT FOR RINSE JET
for Dishwasher (ELETTROBAR)
S651 - S835
for Dishwasher hood type (ELETTROBAR)
S850 - 66
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E40 - S621 - S623 - S624 - S626 - S631
S633 - S634 - S636 - 10F - 11F - 11FD - 11R
11RD - 22F - 40F - 44F



ELETTROBAR REB429006

ELETTROBAR 429006



Suitable for:

3243608 RINSE JET

for Dishwasher (ELETTROBAR)
S651 - S654 - S830 - S835
for Glasswasher/Cupwasher (ELETTROBAR)
S624 - S626 - S634 - S636 - 10F - 11F - 11FD - 11R
11RD - 22F - 40F - 44F



ELETTROBAR REB140007

ELETTROBAR 140007

ELETTROBAR



Suitable for:

3743784 COMPLETE RINSE ARM ASSEMBLY

length 635 mm



ELETTROBAR C.422051

ELETTROBAR 422051

ELETTROBAR 42211

ELETTROBAR 42677

3243600 COMPLETE WASH AND RINSE ARM

for Glasswasher/Cupwasher (ELETTROBAR) 10F - 11F
11FD - 400FD
for Glasswasher/Cupwasher (ELETTROBAR) 400FD



ELETTROBAR REB990046

ELETTROBAR 990046

3243612 CENTER CONDUIT

for Glasswasher/Cupwasher (ELETTROBAR) 10F - 11F
11FD



ELETTROBAR REB115035

ELETTROBAR 115035

3243609 GASKET CENTER CONDUIT

for Glasswasher/Cupwasher (ELETTROBAR) 10F - 11F
11FD



ELETTROBAR REB437046

ELETTROBAR 437046

3501626 JET FIXED SPRING

for Dishwasher (ELETTROBAR) S651 - S653 - S654
S655 - S810 - S815 - S830 - S835 - S950



ELETTROBAR REB449029

ELETTROBAR 449029

3243593 LEFTHAND SUPPORT FOR RINSE JET

for Dishwasher hood type (ELETTROBAR) 66
for Glasswasher/Cupwasher (ELETTROBAR) 22F - 44F



ELETTROBAR REB468125

ELETTROBAR 468125

3243602 LEFTHAND WASH ARM

for Glasswasher/Cupwasher (ELETTROBAR) S621 - S623
S631 - S633 - 10F - 11F - 11FD



ELETTROBAR 106012



Suitable for:

3243638 LOWER WASH ARM ASSEMBLY BOSS
for Dishwasher (ELETTROBAR)
E46 - 460F
for Glasswasher/Cupwasher (ELETTROBAR)
E45 - S621 - S623 - S631 - S633 - 10F - 11F - 11FD
45F - 45FD - 460FD



ELETTROBAR REB129003
ELETTROBAR 129039

ELETTROBAR REB129039

ELETTROBAR 129003

3243642 LOWER WASH WHEEL MANIFOLD (CLOSED)



ELETTROBAR REB111015

ELETTROBAR 111015

3243599 RIGHTHAND SUPPORT FOR RINSE JET
for Dishwasher hood type (ELETTROBAR) 66
for Glasswasher/Cupwasher (ELETTROBAR) 22F - 44F



ELETTROBAR REB468124

ELETTROBAR 468124

3243605 RING NUT FOR WASH JET
for Dishwasher (ELETTROBAR)
E46 - S651 - S653 - S654 - S655 - S810 - S815
S830 - S835 - 460F
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E40 - E40H - E45 - R499 - R501 - R503 - S621
S623 - S624 - S626 - S631 - S633 - S634 - S636
10F - 11F - 11FD - 11R - 11RD - 45F - 45FD
460FD



ELETTROBAR REB429007

ELETTROBAR 429007

ELETTROBAR



Suitable for:

3243616 LOWER WASH ARM ASSY MANIFOLD WITH HOLES



ELETTROBAR 111009

1186803 O-RING 02037 EPDM
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E40 - MISTRAL40 - NIAGARA35



ELETTROBAR 456019

3243607 RING NUT FOR RINSE JET
for Dishwasher (ELETTROBAR)
S651 - S835
for Dishwasher hood type (ELETTROBAR)
S850 - 66
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E40 - S621 - S623 - S624 - S626 - S631
S633 - S634 - S636 - 10F - 11F - 11FD - 11R
11RD - 22F - 40F - 44F



ELETTROBAR REB429006

ELETTROBAR 429006

3243608 RINSE JET
for Dishwasher (ELETTROBAR)
S651 - S654 - S830 - S835
for Glasswasher/Cupwasher (ELETTROBAR)
S624 - S626 - S634 - S636 - 10F - 11F - 11FD - 11R
11RD - 22F - 40F - 44F



ELETTROBAR REB140007

ELETTROBAR 140007




Suitable for:

3243985 RINSE NUT



ELETTROBAR 429039

3243610 WASH ARM ASSEMBLY LOWER BOSS SPINDLE
for Dishwasher (ELETTROBAR)
E46 - 460F
for Glasswasher/Cupwasher (ELETTROBAR)
E45 - S621 - S623 - S631 - S633 - 10F - 11F - 11FD
45F - 45FD - 460FD



ELETTROBAR REB327006

ELETTROBAR 327006

ELETTROBAR



Suitable for:

3243615 SPINDLE FOR MANIFOLD



ELETTROBAR REB325025

ELETTROBAR 325025

3243606 WASH JET
for Dishwasher (ELETTROBAR)
E46 - 460F
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E40 - E40H - E45 - NIAGARA40 - 10F - 11F
11FD - 45F - 45FD - 460FD



ELETTROBAR REB140020

ELETTROBAR 114013

ELETTROBAR 140013

ELETTROBAR 140020

3243613 COMPLETE WASH ARM
for Glasswasher/Cupwasher (ELETTROBAR) R499 - R501
R503



ELETTROBAR 990015

3243637 COMPLETE WASH ARM ASSEMBLY
for Glasswasher/Cupwasher (ELETTROBAR) S621 - S623
S631 - S633



ELETTROBAR 990008

3243638 LOWER WASH ARM ASSEMBLY BOSS
for Dishwasher (ELETTROBAR)
E46 - 460F
for Glasswasher/Cupwasher (ELETTROBAR)
E45 - S621 - S623 - S631 - S633 - 10F - 11F - 11FD
45F - 45FD - 460FD



ELETTROBAR REB129003

ELETTROBAR REB129039

ELETTROBAR 129003


ELETTROBAR 129039

3243602 LEFTHAND WASH ARM
for Glasswasher/Cupwasher (ELETTROBAR) S621 - S623
S631 - S633 - 10F - 11F - 11FD



ELETTROBAR 106012

3243639 LOWER WASH ARM ASSEMBLY LOCKING KNOB
for Dishwasher (ELETTROBAR)
E46 - 460F
for Glasswasher/Cupwasher (ELETTROBAR)
E45 - S621 - S623 - S631 - S633 - 45F - 45FD
460FD



ELETTROBAR REB447030

ELETTROBAR REB447128

ELETTROBAR 447030

ELETTROBAR 447128



Suitable for:

3243640 LOWER WASH ARM ASSY KNOB LOCKING BOLT
for Dishwasher (ELETTROBAR)
E46 - 460F
for Glasswasher/Cupwasher (ELETTROBAR)
E45 - S621 - S623 - S631 - S633 - 45F - 45FD
460FD



ELETTROBAR REB454002

ELETTROBAR 454002

3243605 RING NUT FOR WASH JET
for Dishwasher (ELETTROBAR)
E46 - S651 - S653 - S654 - S655 - S810 - S815
S830 - S835 - 460F
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E40 - E40H - E45 - R499 - R501 - R503 - S621
S623 - S624 - S626 - S631 - S633 - S634 - S636
10F - 11F - 11FD - 11R - 11RD - 45F - 45FD
460FD



ELETTROBAR REB429007

ELETTROBAR 429007

3243610 WASH ARM ASSEMBLY LOWER BOSS SPINDLE
for Dishwasher (ELETTROBAR)
E46 - 460F
for Glasswasher/Cupwasher (ELETTROBAR)
E45 - S621 - S623 - S631 - S633 - 10F - 11F - 11FD
45F - 45FD - 460FD



ELETTROBAR REB327006

ELETTROBAR 327006

3243986 WASH NUT



ELETTROBAR REB429040

ELETTROBAR 429040

ELETTROBAR



Suitable for:

3243607 RING NUT FOR RINSE JET
for Dishwasher (ELETTROBAR)
S651 - S835
for Dishwasher hood type (ELETTROBAR)
S850 - 66
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E40 - S621 - S623 - S624 - S626 - S631
S633 - S634 - S636 - 10F - 11F - 11FD - 11R
11RD - 22F - 40F - 44F



ELETTROBAR REB429006

ELETTROBAR 429006

3243608 RINSE JET
for Dishwasher (ELETTROBAR)
S651 - S654 - S830 - S835
for Glasswasher/Cupwasher (ELETTROBAR)
S624 - S626 - S634 - S636 - 10F - 11F - 11FD - 11R
11RD - 22F - 40F - 44F



ELETTROBAR REB140007

ELETTROBAR 140007

3501612 WASH JET
for Dishwasher (ELETTROBAR)
R509 - R511 - R704 - R706 - R708
for Glasswasher/Cupwasher (ELETTROBAR)
R499 - R501 - R503 - R505 - R507



ELETTROBAR REB110003

ELETTROBAR REB140008

ELETTROBAR 110003

ELETTROBAR 140008



Suitable for:

5038375 COMPLETE WASH ARM ASSEMBLY 495 mm
for Dishwasher (ELETTROBAR) E50



ELETTROBAR 990113

5037067 PTFE FLAT GASKET \varnothing 21x9x0,5 mm



ELETTROBAR 437100

6129068 RINSE/WASH ARM BOSS
for Dishwasher (ELETTROBAR) E55
for Dishwasher hood type (ELETTROBAR) NIAGARA281
PLUVIA280



ELETTROBAR 129068

5032815 WASH/RINSE ARM 230 mm
5 wash nozzles - 3 rinse nozzles
for Dishwasher (ELETTROBAR) E50 - E51



ELETTROBAR 106152

3743801 CONVEYOR WASH ARM 520 mm



ELETTROBAR 75265

ELETTROBAR 75616

Suitable for:

1186438 O-RING GASKET 0132 EPDM



ELETTROBAR 456071

5054316 RATCHET ROUNDED \varnothing 19.5 mm
threaded hole M5
for Dishwasher (ELETTROBAR)
E55
for Dishwasher hood type (ELETTROBAR)
NIAGARA281 - PLUVIA280
for Glasswasher/Cupwasher (ELETTROBAR)
since 27/11/06
E40
since 2/11/05
E35



ELETTROBAR 454006

5032813 WASH/RINSE ARM 230 mm
5 wash nozzles - 3 rinse nozzles
for Dishwasher (ELETTROBAR) E50 - E51



ELETTROBAR 106153

5052712 HUB RINSE ARMS



ELETTROBAR 69632



ELETTROBAR



Suitable for:

3243658 LEFTHAND RINSE ARM



ELETTROBAR 106005

ELETTROBAR 106072.CR

ELETTROBAR 106073.CR

6308031 RING NUT FOR WASH BUSHING 3/4"



ELETTROBAR 308031

3243094 RINSE ARM ASSEMBLY LOCKING RING NUT



ELETTROBAR /ELF000501

3243873 RINSE ARM ASSEMBLY 500 mm



ELETTROBAR DLR951

ELETTROBAR 926134

1186612 O-RING 02025 VITON



ELETTROBAR CGR2025

ELETTROBAR 456060

3243875 RINSE ARM ASSEMBLY SPINDLE



ELETTROBAR DLP52

ELETTROBAR 926130

Suitable for:

3743783 PIVOTING RINSE ARM 580 mm
for Pan/utensilwashing machines (ELETTROBAR)



ELETTROBAR C.41175

ELETTROBAR 41175

3743787 RINSE ARM ASSEMBLY
length 510 mm
for Dishwasher hood type (ELETTROBAR)
RIVER81 - RIVER82



ELETTROBAR 69721

ELETTROBAR 80377

3243009 O-RING GASKET 0106 EPDM



ELETTROBAR CGR106

ELETTROBAR 456030

3243876 RINSE ARM ASSEMBLY CAP



ELETTROBAR DWT312

ELETTROBAR 926132

3243974 RINSE ARM BUSH
ø internal 12 mm.
ø external 16 mm.



ELETTROBAR 926063



Suitable for:

3243625 RINSE BOSS

for Dishwasher hood type (ELETTROBAR)
66
for Glasswasher/Cupwasher (ELETTROBAR)
22F - 44F



ELETTROBAR DAS265

ELETTROBAR 129019

3501628 RINSE JET CLAMP

for Dishwasher (ELETTROBAR) E65
for Pan/utensilwashing machines (ELETTROBAR) U132
U61 - U61H - U70



ELETTROBAR DWS512

ELETTROBAR 926131

3243973 RINSE ARM BLOCKING SUPPORT



ELETTROBAR DWS514

ELETTROBAR 926168

3743132 RINSE ARM CENTRAL BOSS

for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E35H - E40 - E40H - E41 - E42 - E45
MISTRAL40 - NIAGARA35 - NIAGARA40 - NIAGARA45
S621 - S636 - 11F - 11FD



ELETTROBAR REB129002

ELETTROBAR 129002

3186605 GASKET FLAT EPDM ø 33x17x1.5 mm
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E40 - NIAGARA35 - NIAGARA40



ELETTROBAR REB437078

ELETTROBAR 437078

ELETTROBAR



Suitable for:

3501627 RINSE JET

for Dishwasher (ELETTROBAR) E65
for Pan/utensilwashing machines (ELETTROBAR) U132
U61 - U61H - U70



ELETTROBAR CSP2502

ELETTROBAR 926133

3186273 FLAT PTFE GASKET ø 16.5x12.5x1.5 mm
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - S621 - S636 - 11F - 11FD



ELETTROBAR REB437008

ELETTROBAR 437008

3743130 HOSE-END FITTING RING NUT
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - S621 - S636 - 11F - 11FD



ELETTROBAR REB429050

ELETTROBAR 429050



Suitable for:

3243653 LEFTHAND RINSE ARM



ELETTROBAR REB106035

ELETTROBAR 106035

3743133 RINSE ARM RING NUT
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - S621 - S636 - 11F - 11FD



ELETTROBAR REB429008

ELETTROBAR 429008

3243608 RINSE JET
for Dishwasher (ELETTROBAR)
S651 - S654 - S830 - S835
for Glasswasher/Cupwasher (ELETTROBAR)
S624 - S626 - S634 - S636 - 10F - 11F - 11FD - 11R
11RD - 22F - 40F - 44F



ELETTROBAR REB140007

ELETTROBAR 140007

5030189 RINSE ARM 330 mm



ELETTROBAR 993054

ELETTROBAR 993057

3243009 O-RING GASKET 0106 EPDM



ELETTROBAR CGR106

ELETTROBAR 456030

ELETTROBAR



Suitable for:

3243607 RING NUT FOR RINSE JET
for Dishwasher (ELETTROBAR)
S651 - S835
for Dishwasher hood type (ELETTROBAR)
S850 - 66
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E40 - S621 - S623 - S624 - S626 - S631
S633 - S634 - S636 - 10F - 11F - 11FD - 11R
11RD - 22F - 40F - 44F



ELETTROBAR REB429006

ELETTROBAR 429006

3743131 RINSE ARM ROD
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - S621 - S636 - 11F - 11FD



ELETTROBAR REB325001

ELETTROBAR 325001

6129066 HUB IMPELLER LOWER



ELETTROBAR 129066

1186411 O-RING 02031 EPDM



ELETTROBAR CGR2031



Suitable for:

3243876 RINSE ARM ASSEMBLY CAP



ELETTROBAR DWT312

ELETTROBAR 926132

ELETTROBAR



Suitable for:

3501059 RINSE NOZZLE ø 2.5 mm
for Dishwasher (ELETTROBAR) E55
for Dishwasher (ELETTROBAR) E55
for Dishwasher hood type (ELETTROBAR) RIVER80 - RIVER81 - RIVER82
for Glasswasher/Cupwasher (ELETTROBAR) RIVER40



ELETTROBAR 140025
ELETTROBAR 80373

ELETTROBAR 140026

ELETTROBAR 140028

3743793 RINSE ARM 4 HOLES 543 mm
for Dishwasher pull-through (ELETTROBAR)



ELETTROBAR DLR839


ELETTROBAR 927069

3743273 RINSE ARM 460 mm



ELETTROBAR 993048

6129054 RINSE ARM ASSEMBLY BOSS



ELETTROBAR 129054

3243622 RINSE ARM 470 mm
for Dishwasher hood type (ELETTROBAR) 66
for Glasswasher/Cupwasher (ELETTROBAR) 22F - 44F



ELETTROBAR DLR965

ELETTROBAR 993037

3243628 BOTTOM WASH ARM BUSHING
for Dishwasher (ELETTROBAR) E50 - E51 - E52 - E60 E65
for Dishwasher hood type (ELETTROBAR) E100 - E110 E120 - E140 - 66
for Glasswasher/Cupwasher (ELETTROBAR) 22F - 44F



ELETTROBAR REB303009

ELETTROBAR 303009



Suitable for:

3243635 GASKET FOR ARM
 for Dishwasher (ELETTROBAR)
 E46 - E65 - 460F
 for Dishwasher hood type (ELETTROBAR)
 E100 - E110 - E120 - E140 - 66
 for Glasswasher/Cupwasher (ELETTROBAR)
 E45 - 22F - 44F - 45F - 45FD - 460FD



ELETTROBAR REB437014

ELETTROBAR 437014

3243624 RIGHTHAND RINSE ARM END JET (BLANK)
 for Dishwasher hood type (ELETTROBAR) 66
 for Glasswasher/Cupwasher (ELETTROBAR) 22F - 44F



ELETTROBAR REB145004

ELETTROBAR 145004

3243626 RINSE ARM SECURING CLIP
 for Dishwasher hood type (ELETTROBAR) 66
 for Glasswasher/Cupwasher (ELETTROBAR) E35 - E40
 E40H - NIAGARA40 - 22F - 44F



ELETTROBAR CVG5E

ELETTROBAR 454004

3243633 SPACER
 for Dishwasher hood type (ELETTROBAR) 66
 for Glasswasher/Cupwasher (ELETTROBAR) 22F - 44F



ELETTROBAR REB199027

ELETTROBAR 199027

3743272 RINSE ARM 475 mm
 for Glasswasher/Cupwasher (ELETTROBAR)
 44F - 440F



ELETTROBAR 993047

ELETTROBAR



Suitable for:

3243623 RIGHTHAND RINSE ARM END JET
 for Dishwasher hood type (ELETTROBAR) 66
 for Glasswasher/Cupwasher (ELETTROBAR) 22F - 44F



ELETTROBAR REB145003

ELETTROBAR 145003

3243974 RINSE ARM BUSH
 ø internal 12 mm.
 ø external 16 mm.



ELETTROBAR 926063

3243625 RINSE BOSS
 for Dishwasher hood type (ELETTROBAR)
 66
 for Glasswasher/Cupwasher (ELETTROBAR)
 22F - 44F



ELETTROBAR DAS265

ELETTROBAR 129019

3243631 SPINDLE
 for Dishwasher hood type (ELETTROBAR) 66
 for Glasswasher/Cupwasher (ELETTROBAR) 22F - 44F



ELETTROBAR REB325011

ELETTROBAR 325011



Suitable for:

Suitable for:

3243981 RINSE IMPELLER 510 mm
 for Dishwasher (ELETTROBAR)
 RIVER71
 for Dishwasher hood type (ELETTROBAR)
 RIVER80 - RIVER81 - RIVER82
 for Pan/utensilwashing machines (ELETTROBAR)
 U60E



ELETTROBAR 80370

3743786 ARM ASSEMBLY PIN
 for Dishwasher (ELETTROBAR)
 RIVER71
 for Dishwasher hood type (ELETTROBAR)
 RIVER80 - RIVER81 - RIVER82
 for Pan/utensilwashing machines (ELETTROBAR)
 U60E



ELETTROBAR 80283

3743785 RING NUT FOR WASH ARM LOWER ϕ 1"1/2
 for Dishwasher (ELETTROBAR)
 RIVER71
 for Dishwasher hood type (ELETTROBAR)
 RIVER80 - RIVER81 - RIVER82
 for Pan/utensilwashing machines (ELETTROBAR)
 U60E



ELETTROBAR 80281

ELETTROBAR 80285

3243984 RINSE WASH GROUP
 dimensions 490x500 mm.
 for Dishwasher (ELETTROBAR)
 E50 - E51 - MISTRAL51 - NIAGARA51



ELETTROBAR REB990069

ELETTROBAR REB990090

ELETTROBAR 990061

ELETTROBAR 990069

ELETTROBAR 990090

ELETTROBAR 990108

3243605 RING NUT FOR WASH JET
 for Dishwasher (ELETTROBAR)
 E46 - S651 - S653 - S654 - S655 - S810 - S815
 S830 - S835 - 460F
 for Glasswasher/Cupwasher (ELETTROBAR)
 E35 - E40 - E40H - E45 - R499 - R501 - R503 - S621
 S623 - S624 - S626 - S631 - S633 - S634 - S636
 10F - 11F - 11FD - 11R - 11RD - 45F - 45FD
 460FD



ELETTROBAR REB429007

ELETTROBAR 429007

3243608 RINSE JET
 for Dishwasher (ELETTROBAR)
 S651 - S654 - S830 - S835
 for Glasswasher/Cupwasher (ELETTROBAR)
 S624 - S626 - S634 - S636 - 10F - 11F - 11FD - 11R
 11RD - 22F - 40F - 44F



ELETTROBAR REB140007

ELETTROBAR 140007

3243985 RINSE NUT



ELETTROBAR 429039



Suitable for:

3501612 WASH JET

for Dishwasher (ELETTROBAR)
R509 - R511 - R704 - R706 - R708
for Glasswasher/Cupwasher (ELETTROBAR)
R499 - R501 - R503 - R505 - R507



ELETTROBAR REB110003
ELETTROBAR 140008

ELETTROBAR REB140008

ELETTROBAR 110003

ELETTROBAR



Suitable for:

3243986 WASH NUT



ELETTROBAR REB429040

ELETTROBAR 429040

6990075 RINSE/WASH ARM BOSS LOWER

wash arms 500 mm
rinse arms 470 mm



ELETTROBAR REB990075

ELETTROBAR 990075

3243656 LEFTHAND WASH ARM



ELETTROBAR REB106006

ELETTROBAR 106006

3243638 LOWER WASH ARM ASSEMBLY BOSS

for Dishwasher (ELETTROBAR)
E46 - 460F
for Glasswasher/Cupwasher (ELETTROBAR)
E45 - S621 - S623 - S631 - S633 - 10F - 11F - 11FD
45F - 45FD - 460FD



ELETTROBAR REB129003
ELETTROBAR 129039

ELETTROBAR REB129039

ELETTROBAR 129003

3243657 RIGHTHAND RINSE ARM



ELETTROBAR 106007

ELETTROBAR 106072.CR

ELETTROBAR 106073.CR

3243655 RIGHTHAND WASH ARM



ELETTROBAR REB106008

ELETTROBAR 106008

3243607 RING NUT FOR RINSE JET

for Dishwasher (ELETTROBAR)
S651 - S835
for Dishwasher hood type (ELETTROBAR)
S850 - 66
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E40 - S621 - S623 - S624 - S626 - S631
S633 - S634 - S636 - 10F - 11F - 11FD - 11R
11RD - 22F - 40F - 44F



ELETTROBAR REB429006

ELETTROBAR 429006



Suitable for:

3243605 RING NUT FOR WASH JET

for Dishwasher (ELETTROBAR)
E46 - S651 - S653 - S654 - S655 - S810 - S815
S830 - S835 - 460F
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E40 - E40H - E45 - R499 - R501 - R503 - S621
S623 - S624 - S626 - S631 - S633 - S634 - S636
10F - 11F - 11FD - 11R - 11RD - 45F - 45FD
460FD



ELETTROBAR REB429007

ELETTROBAR 429007

3243606 WASH JET

for Dishwasher (ELETTROBAR)
E46 - 460F
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E40 - E40H - E45 - NIAGARA40 - 10F - 11F
11FD - 45F - 45FD - 460FD



ELETTROBAR REB140020

ELETTROBAR 114013

ELETTROBAR 140013

ELETTROBAR 140020

5056384 RINSE/WASH ARM BOSS 340 mm

for Glasswasher/Cupwasher (ELETTROBAR)
since 2/11/05
E35



ELETTROBAR 990111

ELETTROBAR



Suitable for:

3243608 RINSE JET

for Dishwasher (ELETTROBAR)
S651 - S654 - S830 - S835
for Glasswasher/Cupwasher (ELETTROBAR)
S624 - S626 - S634 - S636 - 10F - 11F - 11FD - 11R
11RD - 22F - 40F - 44F



ELETTROBAR REB140007

ELETTROBAR 140007

5035928 CENTRAL HOUSING ARM BOSS

for Glasswasher/Cupwasher (ELETTROBAR)
since 27/11/06
E40
since 2/11/05
E35



ELETTROBAR 129067



Suitable for:

1186438 O-RING GASKET 0132 EPDM



ELETTROBAR 456071

5038702 RINSE/WASH ARM BOSS 405 mm
for Glasswasher/Cupwasher (ELETTROBAR)
since 27/11/06
E40



ELETTROBAR 990110

1186438 O-RING GASKET 0132 EPDM



ELETTROBAR 456071

ELETTROBAR



Suitable for:

5054316 RATCHET ROUNDED \varnothing 19.5 mm
threaded hole M5
for Dishwasher (ELETTROBAR)
E55
for Dishwasher hood type (ELETTROBAR)
NIAGARA281 - PLUVIA280
for Glasswasher/Cupwasher (ELETTROBAR)
since 27/11/06
E40
since 2/11/05
E35



ELETTROBAR 454006

5035928 CENTRAL HOUSING ARM BOSS
for Glasswasher/Cupwasher (ELETTROBAR)
since 27/11/06
E40
since 2/11/05
E35



ELETTROBAR 129067

5054316 RATCHET ROUNDED \varnothing 19.5 mm
threaded hole M5
for Dishwasher (ELETTROBAR)
E55
for Dishwasher hood type (ELETTROBAR)
NIAGARA281 - PLUVIA280
for Glasswasher/Cupwasher (ELETTROBAR)
since 27/11/06
E40
since 2/11/05
E35



ELETTROBAR 454006



Suitable for:

5032363 WASH/RINSE ARM 185 mm
4 wash nozzles - 2 rinse nozzles
for Glasswasher/Cupwasher (ELETTROBAR)
since 27/11/06
E40



ELETTROBAR 106148

6069312 RINSE/WASH ARM BOSS 455 mm
for Dishwasher hood type (ELETTROBAR) NIAGARA281
PLUVIA280



ELETTROBAR 69312

5037067 PTFE FLAT GASKET \varnothing 21x9x0,5 mm



ELETTROBAR 437100

6129068 RINSE/WASH ARM BOSS
for Dishwasher (ELETTROBAR) E55
for Dishwasher hood type (ELETTROBAR) NIAGARA281
PLUVIA280



ELETTROBAR 129068

ELETTROBAR



Suitable for:

5032364 WASH/RINSE ARM 185 mm
4 wash nozzles - 3 rinse nozzles
for Glasswasher/Cupwasher (ELETTROBAR)
since 27/11/06
E40



ELETTROBAR 106149

1186438 O-RING GASKET 0132 EPDM



ELETTROBAR 456071

5054316 RATCHET ROUNDED \varnothing 19.5 mm
threaded hole M5
for Dishwasher (ELETTROBAR)
E55
for Dishwasher hood type (ELETTROBAR)
NIAGARA281 - PLUVIA280
for Glasswasher/Cupwasher (ELETTROBAR)
since 27/11/06
E40
since 2/11/05
E35



ELETTROBAR 454006

5051192 WASH/RINSE ARM 210 mm
5 wash nozzles - 3 rinse nozzles
for Dishwasher hood type (ELETTROBAR) NIAGARA281
PLUVIA280



ELETTROBAR 69316

Suitable for:

5051193 WASH/RINSE ARM 210 mm
4 wash nozzles - 2 rinse nozzles
for Dishwasher hood type (ELETTROBAR) NIAGARA281
PLUVIA280

Suitable for:



ELETTROBAR 69314

6990118 RINSE/WASH ARM BOSS 460 mm
for Dishwasher hood type (ELETTROBAR) RIVER282



ELETTROBAR 990118

5037067 PTFE FLAT GASKET \varnothing 21x9x0,5 mm



ELETTROBAR 437100

6080365 RING NUT PIN STAINLESS STEEL
external \varnothing 20 mm - thread M5



ELETTROBAR 80365

3243971 SECURITY ROD



ELETTROBAR 412023

1186438 O-RING GASKET 0132 EPDM



ELETTROBAR 456071

5054316 RATCHET ROUNDED \varnothing 19.5 mm
threaded hole M5
for Dishwasher (ELETTROBAR)
E55
for Dishwasher hood type (ELETTROBAR)
NIAGARA281 - PLUVIA280
for Glasswasher/Cupwasher (ELETTROBAR)
since 27/11/06
E40
since 2/11/05
E35



ELETTROBAR 454006

6129068 RINSE/WASH ARM BOSS
for Dishwasher (ELETTROBAR) E55
for Dishwasher hood type (ELETTROBAR) NIAGARA281
PLUVIA280



ELETTROBAR 129068

3243216 SIDE CAP



ELETTROBAR DWT33

ELETTROBAR 927305



Suitable for:

ELETTROBAR



Suitable for:

3743295 ST. STEEL WASH ARM ASSEMBLY INOX 510 m m
complete with sliding bushing
for Glasswasher/Cupwasher (ELETTROBAR)
RIVER48



ELETTROBAR 990107

3243647 STAINLESS STEEL WASH ARM ASSEMBLY 490 mm
complete with slide bushing
for Dishwasher (ELETTROBAR) E50 - E51 - E52 - E60
E65
for Dishwasher hood type (ELETTROBAR) E100 - E110
E120 - E140



ELETTROBAR REB990087

ELETTROBAR 990087

3243662 CENTER CONDUIT
for Dishwasher (ELETTROBAR) E46 - E60 - E65 - 46F
46FD - 460F
for Dishwasher hood type (ELETTROBAR) E100 - E110
for Glasswasher/Cupwasher (ELETTROBAR) 460FD



ELETTROBAR DAS2596

ELETTROBAR 115076

3243635 GASKET FOR ARM
for Dishwasher (ELETTROBAR)
E46 - E65 - 460F
for Dishwasher hood type (ELETTROBAR)
E100 - E110 - E120 - E140 - 66
for Glasswasher/Cupwasher (ELETTROBAR)
E45 - 22F - 44F - 45F - 45FD - 460FD



ELETTROBAR REB437014

ELETTROBAR 437014

3243628 BOTTOM WASH ARM BUSHING
for Dishwasher (ELETTROBAR) E50 - E51 - E52 - E60
E65
for Dishwasher hood type (ELETTROBAR) E100 - E110
E120 - E140 - 66
for Glasswasher/Cupwasher (ELETTROBAR) 22F - 44F



ELETTROBAR REB303009

ELETTROBAR 303009

3243695 CENTER CONDUIT
for Dishwasher (ELETTROBAR)
E50 - E51 - E52
for Dishwasher hood type (ELETTROBAR)
E120 - E140



ELETTROBAR REB115075

ELETTROBAR 115075

3243696 INSERT FOR CLAMP
for Dishwasher (ELETTROBAR)
E50 - E51 - E52 - E60 - E65
for Dishwasher hood type (ELETTROBAR)
E100 - E110



ELETTROBAR REB441009

ELETTROBAR 441009



Suitable for:

3243692 SPACER

for Dishwasher (ELETTROBAR) E50 - E51 - E52 - E60
E65
for Dishwasher hood type (ELETTROBAR) E110



ELETTROBAR DZP65

ELETTROBAR 199045

3243596 STAINLESS STEEL ROD FOR UPPER SUPPORT

for Dishwasher hood type (ELETTROBAR)
E100 - E110 - E120 - E140



ELETTROBAR DLP527

ELETTROBAR 926127

3243691 STAINLESS STEEL ROD FOR WASH ARM ASSY

for Dishwasher (ELETTROBAR) E60 - E65
for Dishwasher hood type (ELETTROBAR) E100 - E110
E120 - E140



ELETTROBAR DLP526N

ELETTROBAR 926154

3243648 STAINLESS STEEL WASH ARM ASSEMBLY 490 mm

complete with slide bushing
for Dishwasher (ELETTROBAR) S810 - 50F - 50FD
500F - 500FD - 55
for Dishwasher hood type (ELETTROBAR) 66
for Glasswasher/Cupwasher (ELETTROBAR) 22F - 44F



ELETTROBAR 990055

ELETTROBAR



Suitable for:

3243693 SPACER

for Dishwasher (ELETTROBAR) E50 - E51 - E52 - E60
E65
for Dishwasher hood type (ELETTROBAR) E100 - E110
E120 - E140



ELETTROBAR REB199043

ELETTROBAR 199043

3243690 STAINLESS STEEL ROD FOR WASH ARM ASSY

for Dishwasher (ELETTROBAR) E50 - E51 - E52



ELETTROBAR REB325060

ELETTROBAR 325060

3243699 UPPER WASH ARM ASSEMBLY SUPPORT

for Dishwasher hood type (ELETTROBAR) E100 - E110
E120 - E140



ELETTROBAR DAS2597EB

ELETTROBAR 926153



Suitable for:

Suitable for:

3243980 STAINLESS STEEL WASH ARM 510 mm
 complete with central hub
 for Dishwasher (ELETTROBAR)
 RIVER71
 for Dishwasher hood type (ELETTROBAR)
 RIVER80 - RIVER81 - RIVER82
 for Pan/utensilwashing machines (ELETTROBAR)
 U60E

3243866 RING NUT FOR BOSS



ELETTROBAR C.80311

ELETTROBAR 080311

ELETTROBAR 80311

ELETTROBAR CDP258

ELETTROBAR 80314

ELETTROBAR 926128

3743275 SUPPORT FOR WASH ARM
 for Dishwasher hood type (ELETTROBAR)
 RIVER80 - RIVER81 - RIVER82



ELETTROBAR 80310

3243864 TOP/BOTTOM ARM ASSEMBLY 510 mm
 complete with hub and ring nut

3243865 WASH ARM ASSEMBLY BOSS



ELETTROBAR DLL169
ELETTROBAR 926248

ELETTROBAR DLL18

ELETTROBAR 34110

ELETTROBAR DAS258

ELETTROBAR 926129

3243645 WASH AND RINSE ARM ASSEMBLY 350 mm
 for Glasswasher/Cupwasher (ELETTROBAR) E35



ELETTROBAR 129032.TN

ELETTROBAR 990064

ELETTROBAR 990096

3243644 WASH AND RINSE ARM ASSEMBLY 400 mm
 for Glasswasher/Cupwasher (ELETTROBAR) E40H
 NIAGARA40

3186602 GASKET FLAT PTFE \varnothing 40x34.5x2 mm
 for Glasswasher/Cupwasher (ELETTROBAR)
 E40H - NIAGARA40



ELETTROBAR 990104

ELETTROBAR REB303018

ELETTROBAR 303018



Suitable for:

3243667 LOWER CENTER CONDUIT
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E40H - NIAGARA40



ELETTROBAR REB115106
ELETTROBAR 115110

ELETTROBAR REB115110

ELETTROBAR 115106

3186601 O-RING 04200 EPDM
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E40 - E40H - NIAGARA40



ELETTROBAR RTBF800320

3243605 RING NUT FOR WASH JET
for Dishwasher (ELETTROBAR)
E46 - S651 - S653 - S654 - S655 - S810 - S815
S830 - S835 - 460F
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E40 - E40H - E45 - R499 - R501 - R503 - S621
S623 - S624 - S626 - S631 - S633 - S634 - S636
10F - 11F - 11FD - 11R - 11RD - 45F - 45FD
460FD



ELETTROBAR REB429007

ELETTROBAR 429007

3243666 RINSE ARM - TWO JETS
for Glasswasher/Cupwasher (ELETTROBAR) E40H
NIAGARA40



ELETTROBAR 106114

ELETTROBAR



Suitable for:

3243680 LOWER WASH ARM ASSEMBLY SPINDLE
for Glasswasher/Cupwasher (ELETTROBAR) E35 - E40
E40H - NIAGARA40



ELETTROBAR REB325064

ELETTROBAR 325064

3243607 RING NUT FOR RINSE JET
for Dishwasher (ELETTROBAR)
S651 - S835
for Dishwasher hood type (ELETTROBAR)
S850 - 66
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E40 - S621 - S623 - S624 - S626 - S631
S633 - S634 - S636 - 10F - 11F - 11FD - 11R
11RD - 22F - 40F - 44F



ELETTROBAR REB429006

ELETTROBAR 429006

3243665 RINSE ARM - THREE JETS
for Glasswasher/Cupwasher (ELETTROBAR) E40H
NIAGARA40



ELETTROBAR 106113

3243626 RINSE ARM SECURING CLIP
for Dishwasher hood type (ELETTROBAR) 66
for Glasswasher/Cupwasher (ELETTROBAR) E35 - E40
E40H - NIAGARA40 - 22F - 44F



ELETTROBAR CVG5E

ELETTROBAR 454004



Suitable for:

3243608 RINSE JET

for Dishwasher (ELETTROBAR)
S651 - S654 - S830 - S835
for Glasswasher/Cupwasher (ELETTROBAR)
S624 - S626 - S634 - S636 - 10F - 11F - 11FD - 11R
11RD - 22F - 40F - 44F



ELETTROBAR REB140007

ELETTROBAR 140007

3243663 WASH ARM - FOUR JETS

for Glasswasher/Cupwasher (ELETTROBAR) E40H
NIAGARA40



ELETTROBAR 106112

3243606 WASH JET

for Dishwasher (ELETTROBAR)
E46 - 460F
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E40 - E40H - E45 - NIAGARA40 - 10F - 11F
11FD - 45F - 45FD - 460FD



ELETTROBAR REB140020

ELETTROBAR 114013

ELETTROBAR 140013

ELETTROBAR 140020

3243646 WASH AND RINSE ARM ASSEMBLY 400 mm

for Glasswasher/Cupwasher (ELETTROBAR) E40



ELETTROBAR 990094

3243972 WASH ARM BLOCKING SUPPORT



ELETTROBAR DEM24

ELETTROBAR 926173

ELETTROBAR 929026

ELETTROBAR



Suitable for:

3243901 SPACER

for Glasswasher/Cupwasher (ELETTROBAR)
E40 - E40H - NIAGARA40



ELETTROBAR REB199047

ELETTROBAR REB199052

ELETTROBAR 199047

ELETTROBAR 199052

3243664 WASH ARM - THREE JETS

for Glasswasher/Cupwasher (ELETTROBAR) E40H
NIAGARA40



ELETTROBAR 106111


3743791 WASH/RINSE ARM ASSEMBLY UNIT

for Glasswasher/Cupwasher (ELETTROBAR) E35 - E40



ELETTROBAR 129056

3243114 WASH ARM ASSEMBLY END CAP



ELETTROBAR RAT23

3243970 WASH ARM CAP

ø 16 mm



ELETTROBAR DWT311

ELETTROBAR 926172



3743201 WASH ARM WITH 3 TURNING ARMS



ELETTROBAR 42050

ELETTROBAR 929196

Suitable for:

5037316 WASH-ARM UPPER PLASTIC
 dimensions external size 405x400 mm
 for Glasswasher/Cupwasher (ELETTROBAR)
 E40



ELETTROBAR 129053

ELETTROBAR 990095

3243643 WASH-RINSE ARM ASSEMBLY 445 mm
 for Dishwasher (ELETTROBAR) E46 - 46F - 46FD
 460F
 for Glasswasher/Cupwasher (ELETTROBAR) E45 - 460FD



ELETTROBAR REB990097

ELETTROBAR 990097

3243660 CENTER CONDUIT
 for Glasswasher/Cupwasher (ELETTROBAR) E45



ELETTROBAR REB115094

ELETTROBAR 115094

3243662 CENTER CONDUIT
 for Dishwasher (ELETTROBAR) E46 - E60 - E65 - 46F
 46FD - 460F
 for Dishwasher hood type (ELETTROBAR) E100 - E110
 for Glasswasher/Cupwasher (ELETTROBAR) 460FD



ELETTROBAR DAS2596

ELETTROBAR 115076

3243635 GASKET FOR ARM
 for Dishwasher (ELETTROBAR)
 E46 - E65 - 460F
 for Dishwasher hood type (ELETTROBAR)
 E100 - E110 - E120 - E140 - 66
 for Glasswasher/Cupwasher (ELETTROBAR)
 E45 - 22F - 44F - 45F - 45FD - 460FD



ELETTROBAR REB437014

ELETTROBAR 437014

3243638 LOWER WASH ARM ASSEMBLY BOSS
 for Dishwasher (ELETTROBAR)
 E46 - 460F
 for Glasswasher/Cupwasher (ELETTROBAR)
 E45 - S621 - S623 - S631 - S633 - 10F - 11F - 11FD
 45F - 45FD - 460FD



ELETTROBAR REB129003

ELETTROBAR REB129039

ELETTROBAR 129003

ELETTROBAR 129039

3243639 LOWER WASH ARM ASSEMBLY LOCKING KNOB
 for Dishwasher (ELETTROBAR)
 E46 - 460F
 for Glasswasher/Cupwasher (ELETTROBAR)
 E45 - S621 - S623 - S631 - S633 - 45F - 45FD
 460FD



ELETTROBAR REB447030

ELETTROBAR REB447128

ELETTROBAR 447030

ELETTROBAR 447128



Suitable for:

3243904 LOWER WASH ARM ASSEMBLY SPINDLE
for Dishwasher (ELETTROBAR) E46 - 46F - 46FD
460F
for Glasswasher/Cupwasher (ELETTROBAR) 460FD



ELETTROBAR REB325045

ELETTROBAR 325045

3243607 RING NUT FOR RINSE JET
for Dishwasher (ELETTROBAR)
S651 - S835
for Dishwasher hood type (ELETTROBAR)
S850 - 66
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E40 - S621 - S623 - S624 - S626 - S631
S633 - S634 - S636 - 10F - 11F - 11FD - 11R
11RD - 22F - 40F - 44F



ELETTROBAR REB429006

ELETTROBAR 429006

3243608 RINSE JET
for Dishwasher (ELETTROBAR)
S651 - S654 - S830 - S835
for Glasswasher/Cupwasher (ELETTROBAR)
S624 - S626 - S634 - S636 - 10F - 11F - 11FD - 11R
11RD - 22F - 40F - 44F



ELETTROBAR REB140007

ELETTROBAR 140007

3243661 SPACER
for Dishwasher (ELETTROBAR) E46 - 46F - 46FD
460F
for Glasswasher/Cupwasher (ELETTROBAR) 460FD



ELETTROBAR REB199039

ELETTROBAR 199039

ELETTROBAR



Suitable for:

3243640 LOWER WASH ARM ASSY KNOB LOCKING BOLT
for Dishwasher (ELETTROBAR)
E46 - 460F
for Glasswasher/Cupwasher (ELETTROBAR)
E45 - S621 - S623 - S631 - S633 - 45F - 45FD
460FD



ELETTROBAR REB454002

ELETTROBAR 454002

3243605 RING NUT FOR WASH JET
for Dishwasher (ELETTROBAR)
E46 - S651 - S653 - S654 - S655 - S810 - S815
S830 - S835 - 460F
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E40 - E40H - E45 - R499 - R501 - R503 - S621
S623 - S624 - S626 - S631 - S633 - S634 - S636
10F - 11F - 11FD - 11R - 11RD - 45F - 45FD
460FD



ELETTROBAR REB429007

ELETTROBAR 429007

3243659 SPACER
for Dishwasher (ELETTROBAR) E46 - 460F
for Glasswasher/Cupwasher (ELETTROBAR) E45 - 45F
45FD - 460FD



ELETTROBAR REB199034

ELETTROBAR 199034

3243610 WASH ARM ASSEMBLY LOWER BOSS SPINDLE
for Dishwasher (ELETTROBAR)
E46 - 460F
for Glasswasher/Cupwasher (ELETTROBAR)
E45 - S621 - S623 - S631 - S633 - 10F - 11F - 11FD
45F - 45FD - 460FD



ELETTROBAR REB327006

ELETTROBAR 327006



Suitable for:

3243606 WASH JET

for Dishwasher (ELETTROBAR)
E46 - 460F
for Glasswasher/Cupwasher (ELETTROBAR)
E35 - E40 - E40H - E45 - NIAGARA40 - 10F - 11F
11FD - 45F - 45FD - 460FD



ELETTROBAR REB140020
ELETTROBAR 140020

ELETTROBAR 114013

ELETTROBAR 140013

ELETTROBAR



Suitable for:

3743790 WASH/RINSE ARM ASSEMBLY UNIT



ELETTROBAR REB129057

ELETTROBAR 129057

Wash jets and accessories

3243211 BRASS JET \varnothing 6 mm



ELETTROBAR CSO101

3743875 COMPLETE WASH JET



ELETTROBAR
ELETTROBAR REB140010
ELETTROBAR 140010

ELETTROBAR REB110001
ELETTROBAR 110001

ELETTROBAR REB119003
ELETTROBAR 119003

3501622 GREY WASH JET for Dishwasher (ELETTROBAR) S654 - S815 - S835 for Glasswasher/Cupwasher (ELETTROBAR) 22F - 22R



ELETTROBAR REB140014
ELETTROBAR 140021

ELETTROBAR 140012

ELETTROBAR 140014

3501620 WASH JET PROPELLER for Dishwasher (ELETTROBAR) S654 - S815 - S853



ELETTROBAR REB119004

ELETTROBAR 119004

3243219 JET RING NUT



ELETTROBAR CSD1

3243116 PLASTIC JET \varnothing 1/8"



ELETTROBAR CPD249

ELETTROBAR CSP248

ELETTROBAR CSP249



Suitable for:

ELETTROBAR



3501229 RINSE JET
 for Dishwasher hood type (ELETTROBAR) RIVER80
 RIVER81 - RIVER82
 for Dishwasher pull-through (ELETTROBAR) CLEAN160
 CLEAN161 - CLEAN220 - CLEAN221 - CLEAN270
 CLEAN271 - CLEAN272 - CLEAN361 - CLEAN362



ELETTROBAR CSP290

ELETTROBAR 927068

Suitable for:

5052043 RINSE JET \varnothing 2.5 mm PIPE 12 mm



ELETTROBAR 140036

3501012 RINSE JET CAP



ELETTROBAR 2910201

3501013 RINSE JET BASE



ELETTROBAR 5510008

3501014 RINSE SPINDLE



ELETTROBAR 2910200

3501611 RINSE JET CLAMP
 for Dishwasher (ELETTROBAR) R509 - R511 - R704
 R706 - R708 - S651 - S653 - S654 - S655 - S810
 S815 - S830 - S835
 for Dishwasher hood type (ELETTROBAR) S850 - S870
 for Glasswasher/Cupwasher (ELETTROBAR) R495 - R497
 R499 - R501 - R503 - R505 - R507



ELETTROBAR REB110002

ELETTROBAR 110002

3501250 STAINLESS STEEL RINSE JET M5X1
 for Dishwasher hood type (ELETTROBAR)
 RIVER82
 for Dishwasher pull-through (ELETTROBAR)
 RIVER150



ELETTROBAR 75133

Suitable for:

Suitable for:

3501610 TOP RINSE JET
 for Dishwasher (ELETTROBAR) R509 - R511 - R704
 R706 - R708 - S651 - S653 - S654 - S655 - S810
 S815 - S830 - S835
 for Dishwasher hood type (ELETTROBAR) S850 - S870
 for Glasswasher/Cupwasher (ELETTROBAR) R495 - R497
 R499 - R501 - R503 - R505 - R507

3501010 WASH JET



ELETTROBAR REB138001

ELETTROBAR 138001

ELETTROBAR 2910520

3501011 WASH JET

3501221 WASH JET



ELETTROBAR 2910527

ELETTROBAR CSP2501

ELETTROBAR 926169

3243106 WASH JET CAP

3501222 WASH JET CLAMP



ELETTROBAR RAT24

ELETTROBAR DWS511

ELETTROBAR 926171

Washing baskets and accessories

3055634 ANGLE FOOT FOR BASKET 120x120 mm
 colour: gray

3055610 CUTLERY INSERT RACK 105x105x135 mm
 of plastic



ELETTROBAR REB461003

ELETTROBAR 461003

ELETTROBAR 712001

ELETTROBAR 712003

ELETTROBAR 712019

3055004 CUTLERY INSERT RACK 110x110x124 mm
 of yellow plastic

3055053 CUTLERY INSERT RACK 113x113x130 mm
 plastic



ELETTROBAR 780068

ELETTROBAR /ELFFAA020




Suitable for:

ELETTROBAR



3055607 CUTLERY RACK 500x500x100 mm



ELETTROBAR 780067

ELETTROBAR 780080

Suitable for:

3055021 DISH RACK 500x450x110 mm
for 16 dishes
made of plastic covered wire



ELETTROBAR DCB46

3055617 GLASS BASKET 382x382x170 mm
dimensions with corners 390x390
for GLASSES max \varnothing 110 mm
3 ROWS with SLOPING BASE
of plastic covered wire
for Dishwasher (ELETTROBAR) S611 - S613
for Glasswasher/Cupwasher (ELETTROBAR) S621 - S623
S631 - S633



ELETTROBAR 938041

ELETTROBAR 983041


3055618 GLASS BASKET 382x382x170 mm
dimensions with corners 390x390
for GLASSES max \varnothing 85 mm
4 ROWS with SLOPING BASE
of plastic covered wire
for Dishwasher (ELETTROBAR) S611 - S613
for Glasswasher/Cupwasher (ELETTROBAR) S621 - S623
S631 - S633



ELETTROBAR 938038

ELETTROBAR 983038

3055672 GLASS BASKET 500x500x130 mm




ELETTROBAR 938032

3055612 GLASS INSERT RACK - 10 Pcs
made of plastic
modular plastic grid 385x385 mm



ELETTROBAR 712006

3055233 GLASS RACK \varnothing 350x110 mm
in plastic covered wire



ELETTROBAR 706095

3055629 GLASS RACK \varnothing 370x195 mm
in plastic covered wire
 \varnothing 370 mm
height 195 mm
bottom ring \varnothing 380 mm
for Glasswasher/Cupwasher (ELETTROBAR) R497 - R499
R501 - R503 - S614 - S616 - S624 - S626 - S634
S636



ELETTROBAR 983026

Suitable for:

3055628 GLASS RACK \varnothing 380x170 mm
 in plastic covered wire
 \varnothing 380 mm
 height 105 mm
 for Glasswasher/Cupwasher (ELETTROBAR) R497 - R499
 R501 - R503 - S614 - S616 - S624 - S626 - S634
 S636



ELETTROBAR 938015

ELETTROBAR 983015

Suitable for:

3055630 GLASS RACK \varnothing 400x215 mm
 in plastic covered wire
 \varnothing 400 mm
 height 215 mm
 bottom ring \varnothing 380 mm
 for Dishwasher (ELETTROBAR) R509
 for Glasswasher/Cupwasher (ELETTROBAR) R505 - R507
 S634 - S636



ELETTROBAR 983025

3055077 GLASS RACK 330x500x170 mm
 for glasses and cups
 flat bottom
 in plastic covered wire



ELETTROBAR DCB35

3055019 GLASS RACK 450x500x120 mm
 for glasses and cups
 flat bottom
 in plastic covered wire



ELETTROBAR DCB47

3055652 GLASS RACK 500x500x110 mm
 for 48 ESPRESSO CUPS \varnothing 65 mm
 for 24 TEA CUPS
 for 36 GLASSES \varnothing 70 mm




ELETTROBAR 780065

ELETTROBAR 780078

ELETTROBAR 780135

3055010 GLASS RACK 500x500x120 mm
 in plastic covered wire



ELETTROBAR 983033

3055636 PLATE RACK 500x500x110 mm
 for 12 SOUP PLATES \varnothing 240 mm
 for 18 SHALLOW PLATES \varnothing 240 mm



ELETTROBAR 780050

ELETTROBAR 780051

ELETTROBAR 780072

3055601 RACK PLATES 500x500x100 mm
 for 16 PLATES \varnothing 240 mm
 for 8 PIZZA PLATES \varnothing 320 mm
 for 7 TRAYS dimensions 480x370 mm
 in plastic covered wire
 for Dishwasher (ELETTROBAR) S651 - S810 - S830
 S950
 for Dishwasher hood type (ELETTROBAR) S850 - S870



ELETTROBAR DCA15

ELETTROBAR 983027




Suitable for:

ELETTROBAR




3055602 RACK PLATES 500x500x100 mm
 for 18 PLATES \varnothing 240 mm
 for 9 PIZZA PLATES \varnothing 320 mm
 in plastic covered wire
 for Dishwasher (ELETTROBAR) S651 - S810 - S830
 S950
 for Dishwasher hood type (ELETTROBAR) S850 - S870



ELETTROBAR 983031


3055616 RACK 382x382x200 mm
 for GLASSES and DIFFERENT WARE
 in plastic covered wire
 for Dishwasher (ELETTROBAR) S611 - S613
 for Glasswasher/Cupwasher (ELETTROBAR) S621 - S623
 S631 - S633



ELETTROBAR 938001

ELETTROBAR 983001

3055603 RACK PLATES 540x540x115 mm
 lower basis 50x50 mm.
 for 22 PLATES \varnothing 240 mm
 for 11 PIZZA PLATES \varnothing 320 mm
 for 11 TRAYS dimensions 530x370 mm
 in plastic covered wire
 for Dishwasher (ELETTROBAR) S950
 for Dishwasher hood type (ELETTROBAR) S870



ELETTROBAR 983030

3055615 RACK 382x382x95 mm
 for GLASSES and DIFFERENT WARE
 in plastic covered wire
 for Dishwasher (ELETTROBAR) S611 - S613
 for Glasswasher/Cupwasher (ELETTROBAR) S621 - S623
 S631 - S633



ELETTROBAR 938055

ELETTROBAR 983039

ELETTROBAR 983055

3055613 RACK 500x500x120 mm
 for GLASSES and DIFFERENT WARE
 in plastic covered wire
 for Dishwasher (ELETTROBAR) S651 - S810 - S830
 for Dishwasher hood type (ELETTROBAR) S850 - S870



ELETTROBAR 983032

3055682 ROTATING RACK SUPPORT SPINDLE
 for Glasswasher/Cupwasher (ELETTROBAR) S624 - 21R



ELETTROBAR 322004

3055684 ROTATING RACK SUPPORT SPINDLE
 for Dishwasher (ELETTROBAR) R509



ELETTROBAR 322003

3055685 ROTATING RACK SUPPORT SPINDLE
 for Dishwasher (ELETTROBAR) R651 - R654



ELETTROBAR 322005

Suitable for:

Suitable for:

3055686 ROTATING RACK SUPPORT SPINDLE
for Glasswasher/Cupwasher (ELETTROBAR) 11R - 11RD



ELETTROBAR 322006

3055688 ROTATING RACK SUPPORT SPINDLE
for Glasswasher/Cupwasher (ELETTROBAR) E42 - 35R
35RD - 350R - 350RD - 40R - 40RD - 400R
400RD



ELETTROBAR REB322007

ELETTROBAR 322007

3055309 ROTATING SUPPORT MOTION PIN



ELETTROBAR REB325040

ELETTROBAR 325040

3055611 SAUCER RACK 380x80x100 mm
made of plasticized wire - for 15 saucers



ELETTROBAR 712004

3055526 SUPPORT FOR ROTATING RACK \varnothing 362 mm
for Glasswasher/Cupwasher (ELETTROBAR) E41 - E42



ELETTROBAR REB319003

ELETTROBAR 319003


3055681 SUPPORT FOR ROTATING RACK \varnothing 395 mm
for Glasswasher/Cupwasher (ELETTROBAR) E42 - R499
R501 - S624 - S626 - S634 - S636 - 11R - 11RD



ELETTROBAR REB319002

ELETTROBAR 319002

3055638 TRAY RACK 500x500x110 mm
for 8 TRAYS 530x370 mm



ELETTROBAR 780053

ELETTROBAR 780106

Watertight seals and rings

5018807 SEALING RING FOR WASH SUPPORT
external \varnothing 44 mm
thickness 3 mm



ELETTROBAR 80184

The data herewith contained may change without notice and LF SpA cannot be held responsible for possible errors stated or resulting by the use of this document. All rights reserved. No part of this publication may be reproduced without written permission by LF SpA.



Distributing Components, Spare Parts & Accessories in original quality worldwide

-
-  **LF SpA HEADQUARTERS**
via Voltri, 80 - 47522 Cesena (FC) ITALY
Tel. +39 0547 34 11 11 - Fax +39 0547 34 11 10
www.lfrcambi724.it - www.lfrcambi724.mobi
info@lfrcambi.it
Export Dept.: Tel. +39 0547 34 11 50 - Fax: +39 0547 34 11 55
www.lfspareparts724.com - www.lfspareparts724.mobi
export@lfspareparts.com
 -  **LF SpA HOUSEHOLD COMPONENTS DIVISION**
Via Padriciano, 34149 Trieste - Italia - AREA Science Park
Tel. +39 0547 34 12 42 - Fax +39 0547 34 12 48
www.lfspareparts724.com - www.lfspareparts724.mobi
info@lfspareparts.com
 -  **EPGC Sas FRANCE**
13, Rue des Forts - 59960 Neuville en Ferrain
Tel. +33 (0)3 20 25 06 21
Fax +33 (0)3 20 25 34 12
www.epgc.com
www.epgc724.mobi
epgc@epgc.com
 -  **LF GmbH GERMANY**
Junkersstrasse, 3 - D-82178 Puchheim - München
Tel. +49 89 89 45 78 66
Fax +49 89 89 45 78 88
www.lfersatzteile724.de
www.lfersatzteile724.mobi
info@lfersatzteile.de
 -  **LF China REPUBLIC OF CHINA**
Room 403, No.2, Huadu Mansion, Lane 422, Huanghua Rd.
Minhang Dist. - 201103 Shanghai
Tel. +86 (0)21 33 53 66 31
Fax +86 (0)21 33 53 66 32
www.lfspareparts724.com
www.lfspareparts724.mobi
china@lfspareparts.com
 -  **OOO LF RUSSIAN FEDERATION**
Ul. Anatoliya Zhivova, 8 - office 1 - 123100 Moscow
Tel./Fax +7 495 725 26 53
www.lfspareparts724.ru
www.lfspareparts724.mobi
info@lfspareparts.ru
 -  **LF Repuestos Horeca S.L.U. SPAIN**
Poligono Industrial Carpetania - C/Miguel Faraday, 8 - 28906 Getafe
Tel. +34 91 477 91 00
Fax +34 91 477 90 81
www.lfrepuestos-horeca724.es
www.lfrepuestos724.mobi
info@lfrepuestos.es
 -  **LF SpA Cesena (IT) Swiss Branch Steinhausen SWITZERLAND**
Sennweidstrasse, 45 - CH-6312 Steinhausen
Tel. +41 (0)41 760 15 80-1
Fax +41 (0)41 760 15 85
www.lfersatzteile724.ch
www.lfersatzteilech724.mobi
info@lfersatzteile.ch
 -  **LF Spare Parts Ltd. UNITED KINGDOM**
A10a Lakeside Business Park, Broadway Lane
South Cerney, Gloucestershire GL7 5XL
Tel. +44 (0)1285 86 16 25
Fax +44 (0)1285 86 39 49
www.lfspareparts724.co.uk
www.lfspareparts724.mobi
info@lfspareparts.co.uk
 -  **AUSTRALIA AND NEW ZEALAND**
www.lfspareparts724.com
andrea.calvio@lfspareparts.com
 -  **AUSTRIA**
www.lfersatzteile724.at
info@lfersatzteile.at
 -  **BALKAN COUNTRIES**
www.lfspareparts724.com
matijaramov@lfspareparts.com
 -  **BALTIC COUNTRIES**
www.lfspareparts724.com
inara.silina@lfspareparts.com
 -  **CENTRAL AND EASTERN EUROPE**
www.lfspareparts724.cz
jiri.kremla@lfspareparts.cz
 -  **DENMARK**
www.lfspareparts724.dk
michael.leth@lfspareparts.com
 -  **JAPAN**
www.lfspareparts724.jp
hiroshi.ukai@lfspareparts.jp
 -  **SOUTH KOREA**
www.lfspareparts724.com
fabio.doni@lfspareparts.com
 -  **TURKEY**
www.lfyedekparca724.com
basar.ergun@lfyedekparca.com
 -  **USA AND CANADA**
www.lfspareparts724.us
sauro.dallaglio@lfspareparts.us
howard.truitt@lfspareparts.us