



Spare parts for:

Warewashing equipment



Suitable for:

HOBART



This catalogue is automatically generated.
Therefore, the sequence of the items might
not be always shown at best.

Updates will be issued in case of additions
and/or amendments.

*Suitable **universal spare parts** may not be included*





Suitable for:

HOBART

Suitable for:



Air traps

3060606 AIR CHAMBER COMPLETE \varnothing 33x125 mm
complete with flat O-ring gasket and connector
hose end fitting \varnothing 6 mm

3060607 FITTING FOR AIR CHAMBER



HOBART 139321-550

3060608 O-RING O3050 EPDM



HOBART 129321-178

HOBART 67500-6

3060125 AIR CHAMBER COMPLETE 80x17x65 mm
with two O-ring gaskets, bajo bolt and
hose end fitting \varnothing 5 mm
for Dishwasher hood type (HOBART) AMX



HOBART 324858

3060601 AIR CHAMBER COMPLETE 85x20x80 mm
with two O-ring gaskets, bajo bolt and
hose end fitting \varnothing 5 mm
for Dishwasher (HOBART)
GW600
for Glasswasher/Cupwasher (HOBART)
GW601
for Dishwasher (HOBART) AMXXS1300-13

3060605 FITTING
for Dishwasher (HOBART) GW600
for Glasswasher/Cupwasher (HOBART) GW601



HOBART 139321-47



Suitable for:

3060602 FITTING HOSE-END FOR AIR CHAMBER
hose end fitting \varnothing 6 mm
for Dishwasher (HOBART) GW600
for Glasswasher/Cupwasher (HOBART) GW601



HOBART 139321-202

3060603 RETAINING BOLT FOR FITTING
for Dishwasher (HOBART) GW600
for Glasswasher/Cupwasher (HOBART) GW601



HOBART 139321-180

5067986 AIR CHAMBER 85x22x77 mm
complete with gasket
for Dishwasher hood type (HOBART) AMX - AMXX - AUP
AUX - ECOMAX602-10 - ECOMAX602-11
ECOMAX612-10
for Glasswasher/Cupwasher (HOBART) ECOMAX502 - FP
FX - GP - GX



HOBART 01-240372-1

5034976 SYSTEM INLET CRP
overall dimensions 154x97x40 mm
three hose end fittings \varnothing 6/8/22 mm
for Glasswasher/Cupwasher (HOBART) H40



HOBART E144027

HOBART




Suitable for:

1186318 O-RING 03043 EPDM
for Dishwasher (HOBART)
GW600
for Glasswasher/Cupwasher (HOBART)
GW601



HOBART 139321-178

5037214 AIR TRAP
hose-end fitting \varnothing 10.5 mm - thread 3/4"
for Dishwasher (HOBART) - Series FP - Series FX
Series GP - Series GX
for Glasswasher/Cupwasher (HOBART) GC31 - GC32
GC41 - GC42
for Pan/utensilwashing machines (HOBART) UX - UXL
UXT - UXTL



HOBART 01-297510-1
HOBART 775540-1

HOBART 01-297695-001
HOBART 775540-11

HOBART 01-297695-1



Suitable for:

HOBART



Suitable for:

Bearings

3063121 BEARING 6203 2RSH SKF
external \varnothing 40mm - internal \varnothing 17mm - thickness 12mm



HOBART 603273

9063001 BEARING 6206 DDU NSK
external \varnothing 62mm - internal \varnothing 30mm - thickness 16mm



HOBART BB-17-26

3063149 BEARING 6206 2RS1 SKF
external \varnothing 62 mm - internal \varnothing 30 mm - thickness 16



Bushings

3743765 BUSHING FOR TOP ARM ASSEMBLY
for Dishwasher hood type (HOBART) AM-12EC
AM-12EF



HOBART 228643

5029130 BUSHING 24 mm FOR WASH OUTLET
for Dishwasher pull-through (HOBART) - Series CR
Series UCA



HOBART 493413-1

Capacitors, electrical

3068019 CAPACITOR μ F 12.5 450V 50/60Hz
operating temperature $-25+85^{\circ}\text{C}$
in compliance with EEC 93/68 and 92/31 regulations



HOBART 226568-8



Caps

5069961 CAP \varnothing 61 mm
for Dishwasher pull-through (HOBART) - Series CN
Series CP - Series CS



HOBART 01-245084-002

HOBART 01-245084-2

5029128 CAP FOR WASH ARM
for Dishwasher pull-through (HOBART) - Series CR
Series UCA



HOBART 325112-4

Castors, rollers and accessories

3346135 HOOD BUMPER
for Dishwasher (HOBART) ECOMAX 683
OREANE LB PRO 1 - OREANE LC PRO 500



HOBART E80105

5029976 ROLL TAPE SLIDE \varnothing 25/20x24.5 mm
for Dishwasher conveyor type (HOBART) - Series FTX



HOBART 229319

Clamps

3449414 DOUBLE-WIRE CLAMP 33.2-34.8
for hoses \varnothing 33.2÷34.8 mm



HOBART 324510-341

3449474 HOSE CLAMP 50-70
for pipes \varnothing 50÷70 mm
made of stainless steel AISI 304
height 12 mm and screw E7
suitable for food industry



HOBART 166513-3

Contact thermostats

3444622 CONTACT SAFETY THERMOSTAT 200°C
with manual reset - pin M4




HOBART 139321

HOBART 139321-588

HOBART 139588

3444607 CONTACT THERMOSTAT 110°C
with manual reset
for Dishwasher hood type (HOBART)
AM12



HOBART 371450-17



Suitable for:

3444608 CONTACT THERMOSTAT 60°C
automatic reset - for wash tank



HOBART 371450

HOBART 371450-16

HOBART



Suitable for:

3444609 CONTACT THERMOSTAT 95°C
manual reset
for Dishwasher (HOBART) ECOMAX 683



HOBART E236047

Contactors

3446561 CONTACTOR LOVATO BF0910A
coil 9A 230V 50/60Hz 4.2Kw
3 normally open contacts
1 normally open auxiliary contact




HOBART RTFOC00466

3446227 AUXILIARY CONTACT G218
10A
1 normally open contact
1 normally closed contact



Controllers and changeover switches

3322613 CONTROL SELECTOR P265 4 CAMS
1st cycle 60 seconds
2nd cycle 20 minutes
230V 50/60Hz
2 motors
for Dishwasher (HOBART)
ECOMAX500 - ECOMAX501




HOBART E238066

3322609 CONTROLLER PWE5 3 CAMS
150 seconds cycle
230V 50/60Hz
without pin
former model 600/636/5200




HOBART 139321-226

3322240 CONTROLLER P255 6 CAMS
120 seconds cycle
220/240V 50/60Hz
for Dishwasher (HOBART) FE
for Dishwasher hood type (HOBART) HE



HOBART 323936-5

3322262 CONTROLLER P265 5 CAMS
1st cycle 72 seconds
2nd cycle 20 seconds
230V 50Hz



HOBART 139321-535




HOBART



Suitable for:


3322605 **CONTROLLER 9449 1 CAM**
40 seconds cycle
220/240V 50/60Hz
without pin



HOBART 139321-225

Suitable for:

3322115 **REGENERATION CONTROLLER 1 CAM**
40 seconds cycle
220/240V 50/60Hz



Curtains

3456009 **DISHWASHER CURTAIN 655x400 mm**



HOBART 1244722

HOBART 1244723

Door catches

3398601 **DOOR CATCH**
for Glasswasher/Cupwasher (HOBART) GW601



HOBART 139321-24

3398605 **DOOR CATCH**



HOBART 139321-817

3242677 **DOOR LOCK**
for Dishwasher (HOBART) FE600 - FX - GX



HOBART 324221

3398606 **STAINLESS STEEL DOOR RETAINER**



HOBART 139321-821

3242618 **LOCK NUT**



HOBART 602481



Suitable for:

HOBART



Suitable for:

Door gaskets for dishwashers

5030387 DOOR GASKET 560 mm
profile dimensions 16x4 mm
for Dishwasher (HOBART) - Series FX - Series GX



HOBART 886253-1

5058542 GASKET FOR DOOR
profile 14x16 mm - dimensions 490x560x490 mm
for Glasswasher/Cupwasher (HOBART)
since 22/08/07
Series FP - Series FX - Series GP - Series GX



HOBART 01-240077-1


Drain hoses

3450173 DRAIN PIPE \varnothing 25x2100 mm
elbow sleeve internal \varnothing 22 mm
straight sleeve internal \varnothing 19 mm
for Glasswasher/Cupwasher (HOBART) FP - FX - GP
GX



HOBART 883961-2

3450029 DRAIN PIPE \varnothing 29x2000 mm
muffs internal \varnothing 24 and 28 mm
max temperature 90°C



HOBART 323801-1

Drain plugs

3448614 OVERFLOW PIPE \varnothing 22x168 mm
made of plastic



HOBART E142051

HOBART 139321-743

3160602 OVERFLOW PIPE \varnothing 25x215 mm - GREY



HOBART 139321-157

1186327 O-RING 03081 EPDM



HOBART 139321-49

Suitable for:

Suitable for:

3448224 OVERFLOW PIPE \varnothing 32x250 mm
made of plastic
for Dishwasher (HOBART) - Series FE



HOBART 323999-1

3448615 OVERFLOW PIPE \varnothing 37x385 mm
made of plastic
for Dishwasher (HOBART) ECOMAX 683



HOBART 139321-905

1186655 O-RING 04131 EPDM
for Dishwasher (HOBART) ECOMAX 683



HOBART 139321-192

3448167 OVERFLOW PIPE \varnothing 38x287 mm
made of plastic



HOBART 139321-904

1186655 O-RING 04131 EPDM
for Dishwasher (HOBART) ECOMAX 683



HOBART 139321-192

Drain pumps

3122327 DRAIN ELECTRIC PUMP 40W 240V 50Hz
inlet external \varnothing 24 mm - output external \varnothing 23 mm
for Dishwasher (HOBART) ECOMAX501A



HOBART E130105

3122411 HOUSING FOR PUMP
inlet external \varnothing 23 mm - outlet external \varnothing 23 mm



3122906 DRAIN ELECTRO-PUMP 40W 230/240V 50Hz
inlet external \varnothing 30 mm - outlet external \varnothing 23 mm
for Dishwasher (HOBART) ECOMAX 683



HOBART E80117

3122402 DRAIN ELECTRO-PUMP 80W 230V 50Hz
inlet external \varnothing 24 mm - outlet external \varnothing 24 mm
for Glasswasher/Cupwasher (HOBART) GC32



HOBART 01-297682-1

HOBART 165653-1

HOBART 883993-1




Suitable for:

HOBART



Suitable for:

3122828 DRAIN PUMP GRE 220V 50Hz



HOBART 327450-1

Electronic printed-circuit boards

3390194 CABLE FLAT 10-POLE 3100 mm
for Dishwasher (HOBART)
ECOMAX701L




HOBART 139321

HOBART 139451

HOBART 80933

3390034 CIRCUIT BOARD
without EPROM
dimensione 135x100 mm
for Dishwasher (HOBART)
ECOMAX661
ECOMAX 683




5028103 CONNECTOR 5-POLE
for Dishwasher (HOBART) ECOMAX 683



HOBART 139321-451

3390088 MICROPROCESSOR GET.5 NIAGARA-RIVER



3390035 MICROPROCESSOR GET.5 EB



3390036 SET OF 2 TEMPERATURE PROBES GET-5
bulb \varnothing 5x30 mm
length 350 mm
for tank and boiler
for Dishwasher (HOBART) ECOMAX 683



HOBART 139321-731

5037825 SPIKE FOR CONNECTOR (GET5)



HOBART 139321

HOBART 139321-591

HOBART 139591



HOBART



Suitable for:

5054819 ELECTROMECHANICAL BOARD MWASH
dimensions 133x82 mm
for Dishwasher (HOBART)
ECOMAX500A – ECOMAX501 – ECOMAX501A




HOBART E215029

HOBART 215029


Suitable for:

3390195 HOOD MICROPROCESSOR RIVER NM
for Dishwasher (HOBART)
ECOMAX 683
ECOMAX 683



HOBART 139321-688

3446202 TIMER BOARD
with connection diagram
for Dishwasher (HOBART) - Series FX - Series GX
for Dishwasher hood type (HOBART) - Series HX



HOBART 374391-1

HOBART 785422-1

Filters

3160476 COMPLETE TANK FILTER
for Dishwasher hood type (HOBART) AMX - AUX



HOBART 323534

HOBART 323534-1

3160508 PRE-FILTER SIEVE
for Dishwasher hood type (HOBART) AMX - AUX




HOBART 324768

3160604 EXTERNAL FILTER ø 135x90 mm - GREY



HOBART 139321-50

5064508 FILTER ø 136 mm
for Glasswasher/Cupwasher (HOBART) ECOMAX502



HOBART 01-240630-002


HOBART 01-240630-2

3391071 FILTER SUPPORT



HOBART 983766

3160605 INTERNAL FILTER ø 136x75 mm - GREY



HOBART 139321-51




Suitable for:

HOBART



3160622 PLASTIC WASH PUMP FILTER ø 112 mm



HOBART 139321-744

Suitable for:

3160509 TANK FILTER
for Dishwasher hood type (HOBART) AMXX - AMXXT




HOBART 323534-3

3160414 TANK FILTER ASSEMBLY
for Dishwasher (HOBART) - Series FX - Series GX



HOBART 324179

3786563 GASKET FILTER ø 100x79x4 mm
for Dishwasher (HOBART) FX - GX



HOBART 324056

3160510 TOP FILTER WITH PIPE
for Dishwasher (HOBART) SEFCRA100 - UX30 - UX60
for Dishwasher pull-through (HOBART) - Series CR



HOBART 323534-2
HOBART 774457-1

HOBART 774412-2

HOBART 774457-01

Floats

3188006 FLOAT
for Dishwasher pull-through (HOBART) - Series FTX



HOBART 122674

5029871 SWITCH FLOATER 0.3-10 Bar
thread 3/4" hose-end fitting ø 14 mm
type 21.010.115
for Dishwasher pull-through (HOBART) - Series CSA




HOBART 897665-1

HOBART 897665-2

Gaskets and seals

5022939 BOILER GASKET
external ø 257 mm - internal ø 209 mm



HOBART B-230994

HOBART 230994

5061620 GASKET FLAT PTFE ø 24x13x1 mm
for Dishwasher hood type (HOBART) AMX - AMXX - AUP
AUX - ECOMAX602-10 - ECOMAX602-11
ECOMAX612-10
for Glasswasher/Cupwasher (HOBART) ECOMAX502



HOBART 774072-7

Suitable for:

5032589 GASKET WASH ARM
for Dishwasher conveyor type (HOBART) - Series FTN



HOBART 885500-1

Suitable for:

3786705 TOP ARM FLANGE GASKET



HOBART 966090

Guides

5053196 SLIDE 869 mm



HOBART 302207-4

Heating elements

5021682 CAP FOR HEATING ELEMENT
flange 81x27 mm
for Pan/utensilwashing machines (HOBART) UXT
UXTL



HOBART 774808-1

3755168 HEATING ELEMENT FOR BOILER 2200W 220V
immersed length 415 mm
width 45 mm - flange 62x62 mm
with bulbholder sheathing



HOBART 324206-3

3355601 HEATING ELEMENT FOR BOILER 2400W 220V
immersed length 200 mm
external \varnothing flange 63 mm - with probe receptacle
complete with O-Ring gasket \varnothing 58 mm (3186013)



HOBART 139221-246

HOBART 139321-246

3186013 O-RING GASKET 06187 EPDM \varnothing 58 mm
for Dishwasher (HOBART) ECOMAX 683



HOBART E456002
HOBART 67500-81

HOBART JOTO1249

HOBART 067500-81



Suitable for:

HOBART



3355620 HEATING ELEMENT FOR BOILER 2935W 230V
 immersed length 340 mm
 width 55 mm - flange 70x25 mm
 for Dishwasher (HOBART)
 ECOMAX500



HOBART E230088

Suitable for:

3455311 HEATING ELEMENT FOR BOILER 3000W 240V
 immersed length 320 mm
 width 65 mm - flange 80x27 mm
 for Dishwasher (HOBART)
 FE11 - FE26 - FX - FX40S - GX
 for Dishwasher hood type (HOBART) AM900



HOBART 775464-02

HOBART 775464-2

3755169 HEATING ELEMENT FOR BOILER 4500W 240V
 immersed length 415 mm
 flange 62x62 mm - with bulbholder sheathing
 for Dishwasher hood type (HOBART) HX
 for Glasswasher/Cupwasher (HOBART) FX10 - FX20
 FX30 - FX40



HOBART 324206-1

HOBART 324206-4

3355602 HEATING ELEMENT FOR BOILER 5355W 240/415
 immersed length 340 mm
 ext. \varnothing flange 63 mm - with bulbholder sheathing
 complete with gasket OR \varnothing 58 mm (3186013)
 nut (3528232) and washer (3528238) on request



HOBART 2001858H

HOBART 371450-12

HOBART 5845E

3186013 O-RING GASKET 06187 EPDM \varnothing 58 mm
 for Dishwasher (HOBART) ECOMAX 683



HOBART E456002
HOBART 67500-81

HOBART JOTO1249

HOBART 067500-81

3455312 HEATING ELEMENT FOR BOILER 6000W 240V
 immersed length 320 mm
 flange 80x27 mm
 for Dishwasher hood type (HOBART)
 AMX - AUX
 for Dishwasher hood type (HOBART) AM900



HOBART 775464-01

HOBART 775464-1

3855039 HEATING ELEMENT FOR BOILER 6000W 240V
 immersion depth 325 mm
 ext. \varnothing flange 63 mm - with bulbholder sheathing
 with O-ring gasket \varnothing 58 mm (3186013)
 for Dishwasher (HOBART) ECOMAX402 - ECOMAX452
 ECOMAX502



HOBART 01-240761-1



HOBART



Suitable for:

Suitable for:

3355626 HEATING ELEMENT FOR BOILER 7600W 230V
immersed length 385 mm
width 65 mm - flange 80x27 mm

3355621 HEATING ELEMENT FOR BOILER 8000W 230/400
immersed length 365 mm
ext. \varnothing flange 63 mm - with bulbholder sheathing
complete with gasket OR \varnothing 58 mm (3186013)
nut (3528232) and washer (3528238) on request
for Dishwasher (HOBART)
ECOMAX661



HOBART 139321-463

HOBART E230020C

3455240 HEATING ELEMENT FOR BOILER 9000W 230/400
immersed length 515 mm
ext. \varnothing flange 72 mm
with O-ring gasket \varnothing 67 mm (3186014)
for Dishwasher pull-through (HOBART) CX

3186014 O-RING GASKET 06225 EPDM \varnothing 67 mm



HOBART 229148-01

HOBART 229148-1

HOBART 67500-118

HOBART 67500-16

3355604 HEATING ELEMENT FOR TANK 2000W 220V
immersed length 275 mm
width 120 mm - connection \varnothing 10 mm
for Dishwasher (HOBART) GW600

3355619 HEATING ELEMENT FOR TANK 600W 230V
immersed length 155 mm
width 47 mm - flange 50x27 mm



HOBART 139321-203

HOBART 139321203

HOBART 139321-719

HOBART 324646-04

3455406 HEATING ELEMENT FOR TANK 9000W 240/415V
immersed length 525 mm
ext. \varnothing flange 72 mm
with O-ring gasket \varnothing 67 mm (3186014)
for Dishwasher pull-through (HOBART) CX

3355607 HEATING ELEMENT TANK 2750/3250W 220/240V
immersed length 370 mm
connections \varnothing 10 mm
for Dishwasher (HOBART)
ECOMAX500



HOBART 229148-2

HOBART E230086



Suitable for:

HOBART



3355647 HEATING ELEMENT 1830W 254V
immersed length 410 mm
width 35 mm - flange 50x27 mm



HOBART 324646-1

Suitable for:

5026499 HEATING ELEMENT 1830W 254V
immersed length 430 mm
flange 80x27 mm



HOBART 229189-22

3355644 HEATING ELEMENT 2440W 254V
immersed length 410 mm
width 35 mm - flange 50x27 mm



HOBART 324646-2

3755128 HEATING ELEMENT 2440W 254V
immersed length 425 mm
width 65 mm - flange 80x27 mm



HOBART 324644-2

3355646 HEATING ELEMENT 2700W 240V
immersed length 375 mm
width 50 mm - flange 50x27 mm
for Dishwasher (HOBART) FX - GX



HOBART 324187-2

3355652 HEATING ELEMENT 3000W 230V
immersed length 410 mm
width 35 mm - flange 50x27 mm
for Dishwasher (HOBART) FE11 - FE26 - FX40S



HOBART 324646-4

5047328 HEATING ELEMENT 3000W 230V
immersed length 335 mm
ext. ø flange 63 mm - with bulbholder sheathing
for Dishwasher (HOBART) ECOMAX500A



HOBART E230116

3186013 O-RING GASKET 06187 EPDM ø 58 mm
for Dishwasher (HOBART) ECOMAX 683



HOBART E456002
HOBART 67500-81

HOBART JOTO1249

HOBART 067500-81

3355643 HEATING ELEMENT 3050W 254V
immersed length 410 mm
width 35 mm - flange 50x27 mm



HOBART 324646-3

3355651 HEATING ELEMENT 3240W 240V
immersed length 405 mm
width 65 mm - flange 80x27 mm
for Dishwasher hood type (HOBART) AMX - AUX
for Dishwasher pull-through (HOBART) FTN



HOBART 324644-1



Suitable for:

Suitable for:

3755129 HEATING ELEMENT 4880W 254V
 immersed length 420 mm
 width 65 mm - flange 80x27 mm
 for Dishwasher (HOBART) CRA100EW

3755140 HEATING ELEMENT 6000W 220V
 immersed length 225 mm
 width 125 mm - ext. ø flange 60 mm



HOBART 324637-102

HOBART 324637-2

HOBART 170495-1

HOBART 170495-2

3355645 HEATING ELEMENT 610W 254V
 immersed length 370 mm
 width 50 mm - flange 50x27 mm
 for Dishwasher (HOBART) FE11 - FE26 - FX - GX
 for Dishwasher hood type (HOBART) HX

5031719 HEATING ELEMENT 6100W 254V
 immersed length 420 mm
 width 65 mm - flange 80x27 mm
 for Dishwasher hood type (HOBART) AMXX1300
 AMX900 - AUXX1300



HOBART 231982-9

HOBART 324637-3

3355649 HEATING ELEMENT 6540W 240V
 immersed length 415 mm
 width 65 mm - flange 80x27 mm
 for Dishwasher pull-through (HOBART) FTN
 for Dishwasher hood type (HOBART) AMXX1300.31



HOBART 324637-01

HOBART 324637-1

5045907 HEATING ELEMENT 7260W 250V
 immersed length 380 mm
 ext. ø flange 63 mm - with bulbholder sheathing
 with O-ring gasket ø 58 mm (3186013)
 for Dishwasher (HOBART) FP - FX - GP - GX
 for Dishwasher hood type (HOBART) AMX - AUP - AUXX
 for Dishwasher hood type (HOBART) AMXX

3186013 O-RING GASKET 06187 EPDM ø 58 mm
 for Dishwasher (HOBART) ECOMAX 683



HOBART 01-240135-002

HOBART 01-240135-2

HOBART E456002
 HOBART 67500-81

HOBART JOTO1249

HOBART 067500-81



Suitable for:

5060790 O-RING 06187 VITON



HOBART 01-240135-11

3755167 HEATING ELEMENT 7500W 220V
immersed length 230 mm
width 120 mm - ext. ø flange 60 mm



HOBART 173649-1

3755130 HEATING ELEMENT 9000W 230V
immersed length 225 mm
width 125 mm - ext. ø flange 60 mm



HOBART 226506-1
HOBART 226807-2

HOBART 226506-2

HOBART 226807-1

3786661 GASKET ORM 0450-55 EPDM
for heating element



HOBART 226988


3755138 SELF STICKING HEATING ELEMENT 130W 230V
sizes 130x85 mm



HOBART 371450-37

Hinges, catches and accessories

3053217 LEFT-HAND HINGE



HOBART 324002-2

3053214 DOOR LOCKING SPRING ø 13 mm
for Dishwasher (HOBART) FX - GX



HOBART 227855




HOBART



Suitable for:

3053216 GASKET FOR HINGE



HOBART 228693-1

3053480 LH HINGE
for Dishwasher (HOBART) FX - GX



HOBART 775279-2

3053481 HINGED BUSHING



HOBART 775248-1

3053482 SPRING WASHER



HOBART 602295

HOBART 609303

3053479 RH HINGE
for Dishwasher (HOBART) FX - GX




HOBART 775279-1

HOBART



Suitable for:

3053483 WASHER FLAT



HOBART 228694-1

3528050 COUNTERSUNK FLAT HEAD SCREWS M5x14
cross recessed - stainless steel
UNI 7688 - DIN 965 - ISO 7046




HOBART 603182

3528049 LARGE PAN HEAD SCREW M5x8
stainless steel - slotted
for Dishwasher (HOBART) - Series FX - Series GX



HOBART 603645

3053483 WASHER FLAT



HOBART 228694-1

3528050 COUNTERSUNK FLAT HEAD SCREWS M5x14
cross recessed - stainless steel
UNI 7688 - DIN 965 - ISO 7046



HOBART 603182



Suitable for:

3053481 HINGED BUSHING



HOBART 775248-1

3053482 SPRING WASHER



HOBART 602295

HOBART 609303

3053601 RIGHT-HAND DOOR HINGE




HOBART 139321-266

3053218 RIGHT-HAND HINGE



HOBART 324002-1

3053216 GASKET FOR HINGE



HOBART 228693-1

HOBART




Suitable for:

3528049 LARGE PAN HEAD SCREW M5x8
stainless steel - slotted
for Dishwasher (HOBART) - Series FX - Series GX



HOBART 603645

3053483 WASHER FLAT




HOBART 228694-1

3053214 DOOR LOCKING SPRING \varnothing 13 mm
for Dishwasher (HOBART) FX - GX



HOBART 227855

3053483 WASHER FLAT



HOBART 228694-1

Hose-end fittings

3315031 ELBOW FITTING INLET/OUTLET BOILER
thread 1/4" - tapered connection \varnothing 12 mm



HOBART 139321-379



Hydraulic piping

3450622 PRESSURE SWITCH PIPE \varnothing 5x11 mm - 5 m
 temperature $-30^{\circ}+110^{\circ}\text{C}$
 operating pressure 10 bar
 burst pressure 40 bar
 non-toxic rubber hose
 external \varnothing 11 mm
 internal \varnothing 5 mm
 5-m bundles
 for 50-m bundles see 3450652
 for Dishwasher (HOBART)
 ECOMAX 683



HOBART E143005

3449298 PVC HOSE CLEAR \varnothing 4x6 mm
 sold per meter



HOBART 775601

3090759 PVC PIPE \varnothing 4/6 mm - 10 m
 alimentary



HOBART 775590

HOBART 775590-1

HOBART 775590-10MT

3090259 PVC PIPE \varnothing 4/6 mm - 100 m
 alimentary



HOBART 775590

HOBART 775590-1

3450114 PVC PIPE \varnothing 4/7 mm - 10 mt
 alimentary



HOBART 324402

HOBART 324402-3

HOBART 324402-4

3450115 PVC PIPE \varnothing 6/9 mm - 10 mt
 alimentary



HOBART 165168-10

3450215 PVC PIPE \varnothing 6/9 mm - 100 m
 alimentary



HOBART 165168-10

1449682 SILICONE HOSE \varnothing 5x8 SHORE 60 - 10 m
 alimentary



HOBART 324081-3



Suitable for:

HOBART



Suitable for:

Indicator lights

3221592 INDICATOR LAMP GREEN 250V
ø hole 6 mm - 120°C



HOBART 907533

3221686 LAMP CAP FLAT GREEN SU2/C
mounting hole ø 6 mm - head ø 7 mm



5047239 INDICATOR LAMP ORANGE 250V
hole ø 6 mm - 120°C



HOBART 907534

3221686 LAMP CAP FLAT GREEN SU2/C
mounting hole ø 6 mm - head ø 7 mm



3221519 ORANGE INDICATOR LAMP 400V
head ø 7 mm - hole ø 6 mm
connection by PVC wires length 250 mm



HOBART 905445

3221646 WHITE LAMP 250V



HOBART 907535

5007773 LAMP CAP FLAT WHITE SU2
mounting hole ø 6 mm - head ø 7 mm



Ironmongery (screws,nuts,washers)

3528204 SELF-LOCKING HEXAGON NUT M12
stainless steel - with nylon built-in ring
UNI 7474 - DIN 985 - ISO 10511



HOBART 602505

5023164 SELF-TAPPING SCREW ø 4.2x9.5 mm
stainless steel - cylinder head
cross recessed - C type end
UNI 6954 - 7981 - ISO 7049



HOBART 602681



HOBART



Suitable for:

3528235 WASHER FLAT WIDE M6
internal/external \varnothing 6.4/18 mm - thickness 1.6 mm
stainless steel - UNI 6593 - DIN 9021 - ISO 7093



HOBART VC011-17

HOBART 603362

Suitable for:

5027044 WASHER PTFE 19x14x0.5 mm



HOBART 774072-1

5027764 WASHER PTFE 24x16x0.5 mm



HOBART 774072-2

Labels for control panels

7100814 OVERLAY SILK-SCREEN PRINTED STICKER
for Pan/utensilwashing machines (HOBART)
till 31/12/03
UX60 - UX60B - UX60H - UX60HB



HOBART 774052

Manifolds for dishwashers

3743860 BOTTOM MANIFOLD



HOBART 56596

3186333 EPDM O-RING GASKET 06200



HOBART 15082K

3743270 EXTERNAL WASH PIPE



HOBART E115113



Suitable for:

HOBART




3743202 WASH OUTLET HOSE GOLD COMPLETE
for Dishwasher (HOBART) ECOMAX 683



HOBART 139321-906

5036646 FITTING WASH UPPER EXTERNAL
hose-end \varnothing 45 / 12 mm
for Dishwasher (HOBART) ECOMAX 683



HOBART E80174

Suitable for:

3248215 COUPLING FOR BOTTOM EXTERNAL WASH
external connection \varnothing 45.5 mm
internal fitting \varnothing 10.5 mm
for Dishwasher (HOBART) ECOMAX 683



3786044 GASKET FLAT EPDM \varnothing 61x47x2 mm
for Dishwasher (HOBART) ECOMAX 683



Microswitches

3240228 DOOR MICROSWITCH 250V 10A
for Dishwasher (HOBART) FE - FX - GX



HOBART 735221-1

3240475 LEVEL SWITCH HORIZONTAL L221 WITH CABLE
1 contact NO-NC 250V 50W 1A
max. fixing hole \varnothing 22.5 mm



HOBART 735171-1

HOBART 896960

3240608 MAGNETIC MICROSWITCH
250-mm cable
for Dishwasher (HOBART)
ECOMAX 683



HOBART 139321-344

HOBART 139321-586

3240610 MAGNET FOR HOOD MICROSWITCH
dimensions 40x13x8 mm
for Dishwasher (HOBART)
ECOMAX 683



3240227 MAGNETIC MICROSWITCH 220V 0.2A
sizes 80x30 mm
complete with cable length 3800 mm



HOBART 229517-2

3240226 MAGNETIC MICROSWITCH 250V 3A
sizes 80x30 mm
complete with cable length 1600 mm



HOBART 297980-4




HOBART



Suitable for:

3803008 **MAGNETIC SWITCH 250V 50HZ**
for Dishwasher (HOBART) FX - GX



HOBART 775491-01

HOBART 775491-1

Suitable for:

3240189 **MICRO SWITCH M1DX20 10A 250V**



HOBART 1700340

HOBART 300682

5053203 **MICROSWITCH MAGNETIC**
MAGNET \varnothing 5.7 mm - cable length 300 mm
for Dishwasher hood type (HOBART) AMX - AMXX - AUP
AUX - ECOMAX602-10 - ECOMAX602-11
ECOMAX612-10
for Glasswasher/Cupwasher (HOBART) ECOMAX502



HOBART 01-240288-001


HOBART 01-240288-1

5065617 **MICROSWITCH MAGNETIC DOOR**
MAGNET 80x30x15 mm - cable 1300 mm



HOBART 297980-3

3240601 **MICROSWITCH N16 250V**
contact capacity 16A 250V



HOBART 139321-41

3240206 **PUSH ROD FOR MICRO**



Non-return and expansion valves

3526279 **NON-RETURN VALVE**



HOBART 324091

Outlet solenoid valves and accessories

3120553 **DRAIN VALVE ASCO 230V 50Hz**
inlet \varnothing 17 mm - outlet \varnothing 19 mm
for Dishwasher (HOBART) FX - GX



HOBART 323785-11

HOBART 323785-12

5032588 **SOLENOID VALVE 230V 50/60Hz**
inlet \varnothing 36x41 mm - outlet \varnothing 33x40 mm
for Dishwasher conveyor type (HOBART) - Series FTN
for Dishwasher pull-through (HOBART) - Series CSA



HOBART 774683-1



Suitable for:

HOBART



Suitable for:

OR and ORM gaskets

5022973 GASKET O-RING 04275 EPDM



HOBART E926252

1186712 GASKET ORM 0160 - 20 EPDM



HOBART 276903-7

5034718 GASKET ORM 1030-35 EPDM



HOBART 276903-18

1186220 O-RING 06135 EPDM



HOBART 67500-120

5018795 O-RING 06150 VITON



HOBART 303117-1

HOBART 67500-15

Pegs

5061118 FINGER CONVEYOR
for Dishwasher conveyer type (HOBART) - Series FTX



HOBART 229102

5029977 PEG FOR DRAGGING
for Dishwasher pull-through (HOBART) - Series FTX



HOBART 229049-2

5055809 PIN STAINLESS STEEL FOR TAPE PEG
dimensions \varnothing 7x600 mm
for Dishwasher conveyer type (HOBART) - Series FTX



HOBART 229326-1



Pins

3743859 BOTTOM WATER INLET PIPE



HOBART 983560

5055224 PIN FOR RINSE ARM ASSEMBLY 29 mm
for Dishwasher hood type (HOBART) ECOMAX602-10
ECOMAX602-11 - ECOMAX612-10
for Glasswasher/Cupwasher (HOBART) ECOMAX502



HOBART 01-240095-001

HOBART 01-240095-1

HOBART 240095-1

Pressure switches

7101901 PRESSURE SWITCH 0-50 mbar 0.5-3.5Vdc



HOBART 00-775866-002


HOBART 775866-2

3320044 PRESSURE SWITCH 0/30 mBAR
1 level



HOBART 775866-1


3320019 PRESSURE SWITCH 1 LEVEL
calibration 55/35 mm
250V 16A
max operating temperature 85°C



HOBART 139321-23

HOBART 139321-833

3320020 PRESSURE SWITCH 1 LEVEL
calibration 110/60 mm
250V 16A
max operating temperature 85°C



HOBART

3320029 PRESSURE SWITCH 1 LEVEL
calibration 40/20 mm
250V 16A
max operating temperature 85°C
for Dishwasher hood type (HOBART)
ECOMAX663



HOBART 69850

3320108 PRESSURE SWITCH 1 LEVEL
calibration 35/20 mm



HOBART 231981-3

HOBART 378758-3



Suitable for:

HOBART



3320111 PRESSURE SWITCH 1 LEVEL
calibration 35/17 mm
250V 16(4)A




HOBART E224004

HOBART 139321-521


Suitable for:

3320232 PRESSURE SWITCH 1 LEVEL
calibration 115/15 mm



HOBART 371450-8

3320233 PRESSURE SWITCH 1 LEVEL
calibration 170/140 mm



HOBART 371450-9

3320103 PRESSURE SWITCH 2 LEVELS
1st level calibration 35/20 mm
2nd level calibration 80/60 mm
for UK market productions
for Dishwasher hood type (HOBART) AMX - AUX



HOBART 231981-2

HOBART 231981-6

3320196 PRESSURE SWITCH 2 LEVELS
1st level calibration 35/25 mm
2nd level calibration 80/60 mm
250V 16A
for Dishwasher hood type (HOBART)
since 1/01/99
AMX-E - AUX-E



HOBART 378758-6

3320245 PRESSURE SWITCH 2 LEVELS
1st level calibration 200/110 mm
2nd level calibration 230/200 mm



HOBART 914136

3320099 PRESSURE SWITCH 3 LEVELS
1st level calibration 40/25 mm
2nd level calibration 57/37 mm
3rd level calibration 125/105 mm
for Dishwasher (HOBART) FE
for Dishwasher hood type (HOBART) HE



HOBART 231981-1

3320104 PRESSURE SWITCH 3 LEVELS
1st level calibration 40/25 mm
2nd level calibration 57/42 mm
3rd level calibration 125/105 mm
for mechanical control dishwashers
for Dishwasher hood type (HOBART) AMX - AUX



HOBART 378760-1

HOBART 378760-3

Suitable for:

3320213 PRESSURE SWITCH 3 LEVELS
 1st level calibration 40/25 mm
 2nd level calibration 57/42 mm
 3rd level calibration 125/105 mm
 for digital control dishwashers
 for Dishwasher hood type (HOBART) AMX-E - AUX-E
 for Glasswasher/Cupwasher (HOBART) - Series FX
 Series GX



HOBART 378758-4

Suitable for:

3320230 PRESSURE SWITCH 3 LEVELS
 1st level calibration 40/25 mm
 2nd level calibration 92/77 mm
 3rd level calibration 160/140 mm
 for Dishwasher hood type (HOBART) AMXXT - AUXXT



HOBART 378758-5

Probes

3397005 BOILER TEMPERATURE PROBE
 bulb \varnothing 5x30 mm
 capillary 3500 mm
 for Dishwasher hood type (HOBART) HX



HOBART 378584

3397198 TEMPERATURE PROBE



HOBART 775612-1

Pump motors

3122680 ELECTRIC PUMP AP C22110DX 0.10HP
 inlet external \varnothing 28 mm - outlet external \varnothing 28 mm
 0.10HP 230V 50Hz - capacitor 6.3 μ f
 for Dishwasher (HOBART) FE26 - Series FX
 Series GX
 for Dishwasher hood type (HOBART) HE - HX



HOBART 324093

3122506 HOUSING FOR PUMP
 inlet external \varnothing 28 mm
 outlet external \varnothing 28 mm



3122503 IMPELLER \varnothing 72 mm



1186237 O-RING 03300 EPDM





Suitable for:

3122058 SEAL ROTARY \varnothing 11 mm BACK FACE 8 mm
for Dishwasher (HOBART)
ECOMAX 683



HOBART

Suitable for:



3122550 ELECTRIC PUMP AP 2010DX 3HP
inlet external \varnothing 63 mm - outlet external \varnothing 54 mm
3HP 220/400V 50Hz 9/5.2A - motor revolutions 2800



3122547 HOUSING FOR PUMP
inlet external \varnothing 63 mm
outlet external \varnothing 54 mm




HOBART

3122553 IMPELLER \varnothing 125 mm



3122552 O-RING 04587 EPDM



3122024 SEAL MECHANICAL FOR SHAFT \varnothing 12 mm
metal seal \varnothing internal 11 mm - \varnothing external 24 mm
height 15.5 mm
back. element \varnothing internal 14 mm - \varnothing external 24 mm
height 8 mm



3122052 ELECTRIC PUMP FIR 2211DX 0.10HP
inlet external \varnothing 28 mm - outlet external \varnothing 28 mm
0.10HP 230V 50Hz 1.1A - motor revolutions 2700
capacitor 5 μ f - flow rate 80 l/min.
for Dishwasher (HOBART)
Series FE - FE26 - Series FX - Series GX
for Dishwasher hood type (HOBART)
HE - HX



3122147 HOUSING FOR PUMP
inlet external \varnothing 28 mm
outlet external \varnothing 28 mm



HOBART E929167

HOBART 324093-1

HOBART 324093-1V



Suitable for:

3122040 IMPELLER ø 72 mm



3122058 SEAL ROTARY ø 11 mm BACK FACE 8 mm
for Dishwasher (HOBART)
ECOMAX 683



HOBART

Suitable for:

3186271 OR-GASKET 04312 EPDM



3122333 ELECTRIC PUMP FIR 4255SX 0.73HP
inlet external ø 45 mm - outlet external ø 41 mm
0.73HP 230V 50Hz - motor revolutions 2750
capacitor 12.5 µf



HOBART 774047-01

HOBART 774047-1


3122750 ELECTRIC PUMP HANNING UP30 0.15HP
outlet external ø 26 mm
0.15HP 230V 50Hz - capacitor 4 µf
for Dishwasher (HOBART) - Series FX - Series GX



HOBART 775465-1

HOBART 897929

3122334 ELECTRIC PUMP HOBART UP60 0.33HP
inlet external ø 28 mm - outlet external ø 26 mm
0.33HP 230V 50Hz 1.2A - capacitor 5 µf
flow rate 150 l/min.
for Dishwasher (HOBART) FE - Series FX - Series GX
for Dishwasher hood type (HOBART) HE - HX



HOBART 324093-21

HOBART 324093-21V

3786662 RING GASKET KIT
for Dishwasher (HOBART) FX - GX
for Dishwasher hood type (HOBART) HX



HOBART 896974

3122189 ELECTRIC PUMP LGB W 180SX 0.25HP
with manifold and filter
0.25HP 230V 50Hz 1A - motor revolutions 2800
capacitor 5 µf



HOBART 139321-551

3243687 CLOSING CAP FOR BOSS





Suitable for:

3122195 FLANGE E35/40
external \varnothing 100 mm



3243684 GASKET FLAT EPDM \varnothing 60x48x2 mm



3243682 LOWER BOSS



HOBART 139321-762

1186237 O-RING 03300 EPDM



3122632 SEAL ROTARY \varnothing 13 BACK FACE 5.5 mm



3122196 ELECTRIC PUMP LGB W 210SX 0.32HP
with manifold and filter
0.32HP 230V 50Hz 1.1A - motor revolutions 2800
capacitor 6.3 μ f
for Dishwasher (HOBART)
ECOMAX
for Dishwasher (HOBART)
ECOMAX400




HOBART E999135

HOBART



Suitable for:

3186605 GASKET FLAT EPDM \varnothing 33x17x1.5 mm



3122194 IMPELLER FOR PUMP T.176 \varnothing 67 mm



1186803 O-RING 02037 EPDM



HOBART 67500-30

HOBART 67500-55

3243683 RING NUT FOR LOWER BOSS



HOBART 139321-746

3743276 TOP WASH CLOSING CAP



3243687 CLOSING CAP FOR BOSS





Suitable for:

3122195 FLANGE E35/40
external \varnothing 100 mm



3243684 GASKET FLAT EPDM \varnothing 60x48x2 mm



3243682 LOWER BOSS



HOBART 139321-762

1186237 O-RING 03300 EPDM



3122632 SEAL ROTARY \varnothing 13 BACK FACE 5.5 mm



3122631 ELECTRIC PUMP LGB ZF400SX 0.80HP
inlet external \varnothing 50 mm - outlet external \varnothing 50 mm
0.80HP 230V 50Hz 3.8A - motor revolutions 2800
capacitor 16 μ f
for Dishwasher (HOBART)
ECOMAX662




HOBART 139321-963

HOBART



Suitable for:

3186605 GASKET FLAT EPDM \varnothing 33x17x1.5 mm



3122197 IMPELLER FOR PUMP \varnothing 71 mm



1186803 O-RING 02037 EPDM



HOBART 67500-30

HOBART 67500-55

3243683 RING NUT FOR LOWER BOSS



HOBART 139321-746

3743276 TOP WASH CLOSING CAP



3122237 BRACKET FOR ELECTROPUMP 51x44x35 mm





Suitable for:


3122633 HOUSING FOR PUMP
inlet external \varnothing 50 mm
outlet external \varnothing 50 mm



3122365 O-RING 02475 EPDM



3122694 ELECTRIC PUMP UP60-343RU 0.29HP
inlet external \varnothing 28 mm - outlet external \varnothing 25 mm
0.29HP 230V 50Hz - capacitor 5 μ f
for Dishwasher hood type (HOBART) AMX - AUX



HOBART 324913-1

HOBART 324913-1V

3122862 ELECTROPUMP FIR 5213RH 0.10HP
inlet external \varnothing 30 mm - outlet external \varnothing 28 mm
0.10HP 230V 50Hz 1.1A - Rpm 2700
capacitor 5 μ f



HOBART 904156P

3453029 STUFFING GLAND + BACKING ELEMENT
rotary seal hole 11 mm
counter face h 5.5 mm



HOBART



Suitable for:

3122634 IMPELLER \varnothing 104 mm



3122632 SEAL ROTARY \varnothing 13 BACK FACE 5.5 mm



3786659 KIT GASKETS FOR PUMP
for Dishwasher pull-through (HOBART) CNREW



HOBART ML74328

HOBART 324815-4

HOBART 896444

3122879 HOUSING FOR PUMP FIR 5213



Suitable for:

3122829 ELECTROPUMP LGB ZF400VLH 1HP 230V
 inlet external \varnothing 50 mm - outlet external \varnothing 50 mm
 1HP 230V 50Hz - capacitor 16 μ F
 for Dishwasher (HOBART)
 ECOMAX501



HOBART E130126

HOBART 130126

Suitable for:

5007992 ELECTROPUMP VOLUMETRIC LGB PPL46DX
 0.32Kw 230V 50Hz capacitor 8 μ F
 hose-end fitting inlet-outlet \varnothing 12 mm
 for Dishwasher (HOBART) ECOMAX 683



HOBART 139321-651

3122450 PUMP MOTOR LGB ZF400SX 1.5HP
 inlet external \varnothing 60 mm - outlet external \varnothing 50 mm
 1.5HP 230V 50Hz 3.8A - rpm 2800
 capacitor 16 μ f



HOBART 139321

HOBART 139321-471

HOBART 13947

3122876 HOUSING FOR PUMP LGB ZF400SX
 inlet \varnothing 60 mm - outlet \varnothing 50 mm



6080845 IMPELLER \varnothing 101 mm
 for RIVER 282



3122365 O-RING 02475 EPDM



3122632 SEAL ROTARY \varnothing 13 BACK FACE 5.5 mm



Relays

3351068 POWER RELAY FINDER 62.83.8.230.0300
 230V 50/60Hz
 3 NO contacts 16A



HOBART 229040

3351008 POWER RELAY FINDER 62.83.8.230.0000
 230V 50/60Hz
 3 exchange contacts 16A



HOBART 900073



Suitable for:

3351602 POWER RELAY FINDER 65.31.8.230.0300
230V 50/60Hz
1 contact NO 30A



HOBART 371450-10

HOBART 37145010

Suitable for:

3351603 RELAY A2L-FA 16A 230V
bipolar switch
2 NO contacts



HOBART 371450-11

3351605 RELAY POWER FINDER 60.63.8.230.0000
230V 50/60Hz
3 exchange contacts 10A



HOBART 139321-354

HOBART 139321-395

Rinse aid pumps and accessories

3090222 DETERGENT DISPENSER 220/240V 50/60Hz
for Dishwasher (HOBART) FX - GX - UX30



HOBART 378625-1

3090165 DETERGENT INJECTOR 230V 50Hz
for Pan/utensilwashing machines (HOBART) UW135
UW135H



HOBART 172927-1

3090133 VALVE HOLDER



3090601 HYDRAULIC INJECTOR SP205
complete with spring and bellows




HOBART E987023

HOBART 139321-499

HOBART 139321-499V

3090603 BELLOWS FOR HYDRAULIC INJECTOR





Suitable for:

3090148 HYDRAULIC DISPENSER EXTENSION



HOBART



Suitable for:

3090602 INLET VALVE



3090190 PERISTALTIC PUMP FOR DETERGENT
mod. RPS20RMIP - Ext.size. 160 x 80 x 85 mm
220/240 V - 50 Hz
flow rate 0.28 L/h - 2.80 L/h



3090354 ELBOW FITTING FOR HOSE 4x6
for tank inlet
in stainless steel
for Dishwasher (HOBART) ECOMAX 683



HOBART

3090154 FOOT FILTER WITH 4 m PVC PIPE



3090196 HOSE NORPRENE



3090142 PERISTALTIC PUMP RINSE AID PS10N
fixed flow rate 1.5 L/h
PLASTO-M® hose for rinse aid
4.5W 230V 50Hz
complete with assembly kit



HOBART

3090038 RINSE AID INJECTOR DB2
power supply 220/240V 50Hz
screw for flow rate regulation



3090039 COIL 220/240V 50Hz



HOBART 139321-39

HOBART 297891

HOBART 139321-40

3090003 INLET VALVE FOR RINSE AID INJECTOR





Suitable for:

HOBART



Suitable for:

Rotary switches


3057050 CONNECTING BRACKET 28x21x16 mm
distance between hooking brackets 27 mm
f/connection between selector switch and thermost.



HOBART 300177

HOBART 905109

3057327 SELECTOR SWITCH FOR PROGRAM SELECTION
for Dishwasher (HOBART) FX - GX
for Dishwasher hood type (HOBART) AMX - HX



HOBART 231960-03-13

HOBART 231960-13


HOBART 231960-5

3057333 SELECTOR SWITCH WITH KNOB
ELEBERG SCH-X021 16A



HOBART 900086

3057049 SELECTOR SWITCH 4-POLE 16A 250V



HOBART

Salt containers and accessories

3067603 CAP FOR SALT CONTAINER



HOBART 139321-123

3067002 GASKET FOR CONTAINER
external \varnothing 82 mm
internal \varnothing 64 mm
thickness 3 mm



HOBART 139321-194

3067604 RETAINING NUT FOR CAP



HOBART 139321-217

3067001 SALT CONTAINER



HOBART 139321-122

3067016 FUNNEL FOR SALT INTAKE
external \varnothing 93 mm hole \varnothing 27 mm





Suitable for:

3067002 GASKET FOR CONTAINER

external \varnothing 82 mm
internal \varnothing 64 mm
thickness 3 mm



HOBART 139321-194

3067198 O-RING 04162 EPDM



3067005 SALT CONTAINER RING NUT



HOBART 139321-193

3067006 SALT CONTAINER LID



HOBART 139321-191

HOBART



Suitable for:

3450152 HOSE RUBBER REINFORCED \varnothing 13/19 mm

internal \varnothing 13 mm - external \varnothing 19 mm
SOLD PER METER
for Dishwasher (HOBART)
ECOMAX 683



3067007 SALT CONTAINER CAP



HOBART

Solenoid valves

3120005 SOLEN. VALVE ELBI TYPE 329 1 WAY 180°
220/240V 50/60Hz - max. temperature 90°C
inlet 3/4" - outlet \varnothing 10.5 mm
for Dishwasher (HOBART) ECOMAX 683



HOBART 371450-21

HOBART 775742-2

3120019 ADJUSTER FOR INLET ELBI BLACK
flow rate 5.5 L/min - tolerance +/- 15%





Suitable for:

3120021 ADJUSTER FOR INLET ELBI BLACK
flow rate 12 L/min - tolerance +/- 15%



3120204 ADJUSTER FOR OUTLET ELBI BROWN
flow rate 5.5 L/min - tolerance +/- 25%



3120037 ADJUSTER FOR OUTLET ELBI GREEN
flow rate 0.25 L/min - tolerance +/- 25%



3120017 ADJUSTER FOR OUTLET ELBI ORANGE
flow rate 2.5 L/min - tolerance +/- 25%



3120203 ADJUSTER FOR OUTLET ELBI WHITE
flow rate 2 L/min - tolerance +/- 25%



3120000 FILTER FOR INLET SOLENOID VALVE ELBI



HOBART

Suitable for:

3120022 ADJUSTER FOR INLET ELBI BLACK
flow rate 16 L/min - tolerance +/- 15%



3120201 ADJUSTER FOR OUTLET ELBI GRAY
flow rate 4.7 L/min - tolerance +/- 25%



3120016 ADJUSTER FOR OUTLET ELBI NEUTRAL
flow rate 1.2 L/min - tolerance +/- 25%



3120015 ADJUSTER FOR OUTLET ELBI RED
flow rate 0.5 L/min - tolerance +/- 25%



3120202 ADJUSTER FOR OUTLET ELBI YELLOW
flow rate 0.35 L/min / tolerance +/- 25%





5055901 SOLENOID VALVE MULLER 1 WAY 180°
 220/240V 50/60Hz - max temperature 90°C
 inlet 3/4" - outlet ø 3/4"



HOBART 297808-1

3120163 SOLENOID VALVE MULLER 1-WAY 90°
 220/240V 50/60Hz - max. temperature 90°C
 inlet 3/4" - outlet ø 13.5 mm
 for Dishwasher (HOBART) AMXE70 - AMX70 - FE11
 FE26 - FE600 - FX - GX - HE33 - HX40 - HX40E
 UX30 - UX60



HOBART 324207-01

HOBART 324207-1

3120271 COIL MULLER 220/240V 50/60Hz
 max temperature 90°C



3120274 COIL MULLER 220/240V 50/60Hz
 max. temperature 90°C
 with cable length 2000 mm



5027729 SPRING FOR MULLER SOLENOID VALVE COIL



3120164 SOLENOID VALVE MULLER 2-WAY 90°
 220/240V 50/60Hz - max. temperature 90°C
 inlet 3/4" - two outlets ø 13.5 mm



HOBART 324208-1

3120271 COIL MULLER 220/240V 50/60Hz
 max temperature 90°C



3120274 COIL MULLER 220/240V 50/60Hz
 max. temperature 90°C
 with cable length 2000 mm





Suitable for:

HOBART



Suitable for:

5060793 SOLENOID VALVE 1-WAY 180°
220/240V 50/60Hz 7W - max. temperature 90°C
inlet 3/4" - outlet ø 10.5 mm



HOBART 883658-1

Spare parts for pumps

5047186 GASKET
for Dishwasher conveyor type (HOBART) - Series FTX



HOBART 229402

5030896 SEAL ROTARY ø 16 mm
ceramic counterface 10 mm
for Dishwasher (HOBART) FM30



HOBART 104329

Springs

5026762 ASSEMBLY SPRING DOOR
external ø 50x48 mm - hole ø 10.5 mm
for Dishwasher pull-through (HOBART) - Series CNA
Series CNR - Series CR




HOBART 774749-2

5026763 ASSEMBLY SPRING DOOR
external ø 50x48 mm - hole ø 10.5 mm
for Dishwasher pull-through (HOBART) - Series CNA
Series CNR



HOBART 774749-5

5026781 DOOR SPRING ø 41x40 mm
length 900 mm
for Dishwasher (HOBART) CX



HOBART 229277

3250202 DOOR SPRING ø 45x400 mm
for AMX/AUX



HOBART 119079-2

3250223 DOOR SPRING 115 mm
with bushing
for FX-GX



HOBART 897928

5004248 SPRING DOOR POT-WASHER
dimensions ø 55x65 mm
for Pan/utensilwashing machines (HOBART) UW100
UW105 - UW120 - UW125 - UW200 - UW205



HOBART 299110

HOBART 378591

5032980 SPRING FOR DOOR
 support \varnothing 50x48 mm - hole \varnothing 10.5 mm
 for Dishwasher conveyor type (HOBART) - Series FTN
 for Dishwasher pull-through (HOBART) - Series CNR
 for Dishwasher pull-through (HOBART) - Series CNA



HOBART 774749-4

Supports for wash and rinse arms


3743771 BOSS FOR TOP TURNING ARM
 for Dishwasher (HOBART) UX30
 for Dishwasher hood type (HOBART) AMX - AUX



HOBART 324670

HOBART 886607

3743766 ARM ASSEMBLY SUPPORTING RING
 for Dishwasher hood type (HOBART) AMX - AUX



HOBART 324751

3786660 GASKET FLAT EPDM \varnothing 71x59x2 mm
 for Dishwasher hood type (HOBART) - Series AMX
 Series AUX



HOBART 172986-22

3743774 SPACER FOR LH ARM ASSEMBLY
 for Dishwasher hood type (HOBART) AMX - AUX



HOBART 324698-1

3743773 ARM ASSEMBLY PIN
 for Dishwasher (HOBART) FX15 - GX60
 for Dishwasher hood type (HOBART) AMX - HX
 for Glasswasher/Cupwasher (HOBART) FX30 - FX40



HOBART 324607

3786658 GASKET FLAT EPDM \varnothing 60x46x1 mm
 for Dishwasher (HOBART) FX - GX



HOBART 172986-19

3743772 RING NUT FOR ARM ASSEMBLY
 for Dishwasher (HOBART) FX15 - GX60
 for Dishwasher hood type (HOBART) AMX - HX
 for Glasswasher/Cupwasher (HOBART) FX30 - FX40



HOBART 01-240205-1

HOBART 324036



Suitable for:

3743764 BOSS FOR UPPER WASH ARM ASSEMB. WITH PIN
for Dishwasher hood type (HOBART) AM12E - AM12EC
AM12EF - AM600 - AM600C



HOBART 172695


Suitable for:

5048529 GASKET WASH ARM ASSEMBLY
for Dishwasher hood type (HOBART) AM12E - AM12EC
AM12EF - AM600 - AM600C



HOBART 226643

3743862 BOTTOM EXTENSIBLE HOSE



HOBART 1244661

3743803 COUPLING FOR WASH ARM
fittings \varnothing 62 mm 48 mm



HOBART E4206301

3743802 FLANGE FRAME FOR WASH ARM SUPPORT



HOBART E041064

3743768 RINSE ARM COUPLING KIT



HOBART 324268

HOBART 324480

5042614 SUPPORT FOR LOWER WASH ARM ASSEMB. WITH P
for Dishwasher hood type (HOBART) AM12E - AM12EC
AM12EF - AM600 - AM600C



HOBART 172694

5037932 SUPPORT WASH ARM LOWER
for Dishwasher hood type (HOBART) AMS900 - AMX900
AM700 - AM900 - ECOMAX650 - ECOMAX652



HOBART 898194-1

5037933 GASKET FLAT EPDM \varnothing 59x47x3 mm
for Dishwasher hood type (HOBART) AMS900 - AMX900
AM700 - AM900 - ECOMAX650 - ECOMAX652



HOBART 172986-33



Suitable for:

3743775 WASH ARM ASSEMBLY SPACER
for Dishwasher (HOBART) FE



HOBART 231893-1

3743070 UPPER WASHING CONDUIT




HOBART E80177

HOBART



Suitable for:

5037934 WASHER 70x49x3 mm
for Dishwasher hood type (HOBART) AMS900 - AMX900
AM700 - AM900 - ECOMAX650 - ECOMAX652



HOBART 898263-1

3186167 UPPER WASHING INLET GASKET
dimensions 110x68 mm.
for Dishwasher (HOBART) ECOMAX 683



HOBART E80178

Switches

3319058 BIPOLAR SWITCH 250V 5A
with indicator lamp receptacle
without bulb
contact capacity 5(3)A 250V



HOBART 324267-2

HOBART 374267-2

HOBART 897904

6226111 HOUSING FOR PUSH-BUTTON GRAY
mounting hole 25x25 mm - for push-button \varnothing 21 mm
for Glasswasher/Cupwasher (HOBART) ECOMAX400
for Glasswasher/Cupwasher (HOBART) ECOMAX350



HOBART E226111

3319265 INFINITE PUSH-BUTTON KIT
250V 6A



HOBART 324267-4

HOBART 897900

3319260 INFINITE SCREEN PRINTING 16x16 mm




HOBART 324265-11

3319259 ON/OFF SILK SCREEN PRINTING 16x16 mm



HOBART 324265-10

5030640 PUSH-BUTTON ROUND SATIN SILVER \varnothing 21 mm
with indicator window
for Dishwasher (HOBART) ECOMAX500
for Glasswasher/Cupwasher (HOBART) ECOMAX350
ECOMAX400



HOBART E227061

HOBART 227061



Suitable for:

6227060 PUSH-BUTTON ROUND SATIN SILVER ø 21 mm




HOBART E227060

HOBART




Suitable for:

5020280 SWITCH CHANGE-OVER 2-POLE
for Dishwasher (HOBART)
ECOMAX600HE



HOBART E80804


3319428 SWITCH PUSH-BUTTON



HOBART 324266-1

HOBART 897902

3319269 TIMER PUSH-BUTTON KIT
250V 6A



HOBART 324267-5

HOBART 897901

3319263 TIMER SCREEN PRINTING 16x16 mm



HOBART 324265-1

3319264 WATER SILK SCREEN PRINTING 16x16 mm



HOBART 324265-12

Thermostats

3444249 SAFETY SINGLE-PHASE THERMOSTAT 125°C

with manual reset
capillary 1200 mm
bulb ø 4x128 mm
insulating part 800 mm
16A 230V
for Dishwasher (HOBART)
FE11 - FE26
for Dishwasher hood type (HOBART)
HX40
for Glasswasher/Cupwasher (HOBART)
FX10 - FX20 - FX25 - FX30 - FX40 - Series GX
for Dishwasher (HOBART) CX95



HOBART 227879

3444270 SAFETY THREE-PHASE THERMOSTAT 100°C


with manual reset
covered capillary 850 mm
bulb ø 4x230 mm
16A 230V
for Glasswasher/Cupwasher (HOBART) - Series FX



HOBART 378791

Suitable for:

3444612 SINGLE-PHASE THERMOSTAT FOR BOILER 85°C
 15A 250V
 covered capillary 600 mm
 bulb \varnothing 6x120 mm



HOBART E236043

HOBART 139321-532

Suitable for:


3444602 SINGLE-PHASE THERMOSTAT 0-85°C
 for tank
 covered capillary 600 mm
 button bulb \varnothing 14x31 mm
 16A 250V
 D shaft \varnothing 6x4.6 mm



HOBART E236042


HOBART 139321-20

3444719 SINGLE-PHASE THERMOSTAT 30-85°C
 covered capillary 850 mm
 bulb \varnothing 6x94 mm
 D-shaped pin \varnothing 6x4.6 mm



HOBART 371450-15

3444274 SINGLE-PHASE THERMOSTAT 93°C
 screw adjustment
 covered capillary 2200 mm
 bulb \varnothing 4x200 mm
 16A 250V
 for Dishwasher (HOBART) FE11 - FE26
 for Dishwasher hood type (HOBART) AMX - AUX - HE HX
 for Glasswasher/Cupwasher (HOBART) - Series FX Series GX



HOBART 228505

HOBART 886638

Tubing and hoses

3248211 INLET SLEEVE
 for Dishwasher (HOBART) - Series FX - Series GX



HOBART 227751

HOBART 886640

3248212 CAP FOR INLET SLEEVE
 for Dishwasher (HOBART) - Series FX - Series GX



HOBART 227883

3248605 PUMP OUTLET HOSE
 internal \varnothing 33 mm



HOBART 139321-110

3349476 PUMP OUTLET HOSE
 internal \varnothing 47-54 mm
 overall length 315 mm



HOBART 28782



Suitable for:


HOBART



Suitable for:

Wash and rinse arms for warewashers

3243976 BODY FOR RINSE IMPELLER
without bushes



HOBART 139321-948

3243977 PIN FOR TURNING ARM
for Dishwasher (HOBART) ECOMAX 683



HOBART 139321-947

3243991 STAINLESS STEEL PIN FOR ARM
height 53 mm
for Dishwasher (HOBART) ECOMAX 683



HOBART 139321-918

3743858 BOTTOM BOSS SHAFT
overall length 140 mm - \varnothing internal 17 mm



HOBART 981263

5031215 CAP \varnothing 13 mm



HOBART 226816

3243978 LOCKING NUT TURNED
 \varnothing thread 5 mm
for Dishwasher (HOBART) ECOMAX 683



HOBART 139321-954

3243979 SECURITY BLOCKING FOR LOCKING NUT
for Dishwasher (HOBART)
ECOMAX 683



5050386 BUSHING FOR ARM ASSEMBLY WITH NUT
for mod. AMX



HOBART 00-883974-001

HOBART 883974-1

3743767 CAP FOR WASH ARM - 6 PCS
for Dishwasher pull-through (HOBART) - Series CN
Series CR - Series FTN - Series UCA



HOBART ML-102845

HOBART ML102845

HOBART 325109-1



HOBART



Suitable for:

Suitable for:

3243651 COMPLETE RINSE ARM

3186605 GASKET FLAT EPDM \varnothing 33x17x1.5 mm



HOBART 139321-270

HOBART 139321-768

3243653 LEFTHAND RINSE ARM

3243607 RING NUT FOR RINSE JET
for Dishwasher (HOBART)
ECOMAX501A



HOBART 139321-272

HOBART E429006

HOBART 139321-33

3243608 RINSE JET
for Dishwasher (HOBART)
ECOMAX350 - ECOMAX501A



HOBART E140007

HOBART 139321-34

3243637 COMPLETE WASH ARM ASSEMBLY

3243602 LEFTHAND WASH ARM



HOBART 139321-112

HOBART 139321-29-2

3243638 LOWER WASH ARM ASSEMBLY BOSS

3243639 LOWER WASH ARM ASSEMBLY LOCKING KNOB



HOBART 139321-35

HOBART 139321-28

3243640 LOWER WASH ARM ASSY KNOB LOCKING BOLT

3243607 RING NUT FOR RINSE JET
for Dishwasher (HOBART)
ECOMAX501A



HOBART 139321-107

HOBART E429006

HOBART 139321-33




Suitable for:

3243605 RING NUT FOR WASH JET
for Dishwasher (HOBART)
ECOMAX501A



HOBART E429007


3243610 WASH ARM ASSEMBLY LOWER BOSS SPINDLE
for Dishwasher (HOBART)
ECOMAX501A



HOBART E327006

HOBART 139321-113

3243986 WASH NUT



5032915 CONNECTION RINSE ARM
for Dishwasher pull-through (HOBART) - Series CR



HOBART 325308

HOBART 325308-1

3743605 RINSE ARM 515 mm
for Dishwasher (HOBART) FX300 - FX800 - Series GX
for Dishwasher hood type (HOBART) AMX - AUX



HOBART 01-240096-2

HOBART 242-01-240096

HOBART 324052

HOBART



Suitable for:

3243608 RINSE JET
for Dishwasher (HOBART)
ECOMAX350 - ECOMAX501A



HOBART E140007

HOBART 139321-34

3501612 WASH JET
for Dishwasher (HOBART)
ECOMAX501A



HOBART E140008

HOBART 139321-31

HOBART 139321-32

3743787 RINSE ARM ASSEMBLY
length 510 mm
for Dishwasher (HOBART) ECOMAX 683



HOBART 139321-957

3439010 WASH/RINSE ARM CAPS 4 PCS
for Dishwasher (HOBART) FE



HOBART 324172

HOBART 867429-1

HOBART 886609

Suitable for:

Suitable for:

3743769 RINSE ARM 675 mm
for Pan/utensilwashing machines (HOBART) UX - UXL
UXLS - UXS



HOBART 324738

HOBART 886898-1

3243981 RINSE IMPELLER 510 mm



HOBART 139321-956

3743785 RING NUT FOR WASH ARM LOWER \varnothing 1"1/2
for Dishwasher (HOBART) ECOMAX 683



3743786 ARM ASSEMBLY PIN
for Dishwasher (HOBART) ECOMAX 683
OREANE LB PRO 1



6990075 RINSE/WASH ARM BOSS LOWER
wash arms 500 mm
rinse arms 470 mm
for Dishwasher (HOBART) ECOMAX500



HOBART E990075

3243638 LOWER WASH ARM ASSEMBLY BOSS



HOBART 139321-35

3243656 LEFTHAND WASH ARM



3243657 RIGHTHAND RINSE ARM





Suitable for:

3243655 RIGHTHAND WASH ARM



3243605 RING NUT FOR WASH JET
for Dishwasher (HOBART)
ECOMAX501A



HOBART E429007

3243606 WASH JET
for Glasswasher/Cupwasher (HOBART) ECOMAX350



HOBART E140020

3743295 ST. STEEL WASH ARM ASSEMBLY INOX 510 mm
complete with sliding bushing



HOBART 139321-640

3243980 STAINLESS STEEL WASH ARM 510 mm
complete with central hub
for Dishwasher (HOBART) ECOMAX 683



HOBART 139321-943

HOBART



Suitable for:

3243607 RING NUT FOR RINSE JET
for Dishwasher (HOBART)
ECOMAX501A



HOBART E429006

HOBART 139321-33

3243608 RINSE JET
for Dishwasher (HOBART)
ECOMAX350 - ECOMAX501A



HOBART E140007

HOBART 139321-34

3243866 RING NUT FOR BOSS
for Dishwasher (HOBART) ECOMAX 683





Suitable for:

3743275 SUPPORT FOR WASH ARM
for Dishwasher (HOBART) ECOMAX 683



HOBART



Suitable for:

3743300 WASH ARM ASSEMBLY 395 mm
for Glasswasher/Cupwasher (HOBART) GC



HOBART 775762-1

3743650 WASH ARM ASSEMBLY 510 mm
for Dishwasher (HOBART) FX15
for Dishwasher hood type (HOBART) HE33 - HE600/33
for Glasswasher/Cupwasher (HOBART) FX10 - FX20
FX25 - FX30 - FX40



HOBART 324039

HOBART 324444

HOBART 883472-1

3743775 WASH ARM ASSEMBLY SPACER
for Dishwasher (HOBART) FE



HOBART 231893-1

3439010 WASH/RINSE ARM CAPS 4 PCS
for Dishwasher (HOBART) FE



HOBART 324172

HOBART 867429-1

HOBART 886609

3743301 PTFE WASHER \varnothing 21x8x1.5 mm



HOBART 775808-1

3743630 BOSS FOR WASH ARM
for Dishwasher (HOBART) FX15 - GX60
for Dishwasher hood type (HOBART) HE33 - HE600/33
for Glasswasher/Cupwasher (HOBART) FX10 - FX20
FX25 - FX30 - FX40



HOBART 734803-1

3743685 WASH SHAFT PIN 60 mm
for Dishwasher (HOBART) FX15 - GX60
for Glasswasher/Cupwasher (HOBART) FX30 - FX40



HOBART 324040




Suitable for:

Suitable for:

7103498 WASH ARM ASSEMBLY 512 mm
 for Dishwasher hood type (HOBART) ECOMAX602-10
 ECOMAX602-11 - ECOMAX612-10
 for Glasswasher/Cupwasher (HOBART) ECOMAX502 - FP
 FX - GP - GX

3743770 WASH ARM CAP - 4 PCS KIT
 for Dishwasher hood type (HOBART) AMX



HOBART 01-240050-1

HOBART 324785

HOBART 886610


7105110 WASH ARM END CAP
 for Dishwasher (HOBART)
 CN-LADS
 for Dishwasher (HOBART) CS-E-A-22



HOBART 01-245084-1

3743606 WASH ARM 535 mm
 for Dishwasher hood type (HOBART) AMX - AUX

3743632 WASH ARM SET
 for Dishwasher hood type (HOBART) AMX - AUX



HOBART 324614

HOBART 324798-1

HOBART 883453-1

HOBART 324727

HOBART 734804-1

3743790 WASH/RINSE ARM ASSEMBLY UNIT
 for Dishwasher (HOBART) ECOMAX350



HOBART E129057

Wash jets and accessories

3743875 COMPLETE WASH JET



HOBART 139321-763


HOBART 139321-96



Wash jets and accessories

3501622 GREY WASH JET

HOBART 139321-98

3501620 WASH JET PROPELLER

HOBART 139321-97

3501229 RINSE JET

HOBART 139321-483

3501249 RINSE JET

HOBART 226800-2

3743550 RINSE JETfor Dishwasher hood type (HOBART) AM-12E - AM-12EC
AM-12EF

HOBART 226800-01

HOBART 226800-1

Watertight seals and rings

5061621 SEALING RING \varnothing 46 mmfor Dishwasher hood type (HOBART) AMX
ECOMAX602-10 - ECOMAX602-11 - ECOMAX612-10
for Glasswasher/Cupwasher (HOBART) ECOMAX502


















HOBART 01-515356-1

HOBART 775933-3

The data herewith contained may change without notice and LF SpA cannot be held responsible for possible errors stated or resulting by the use of this document. All rights reserved. No part of this publication may be reproduced without written permission by LF SpA.



Distributing Components, Spare Parts & Accessories in original quality worldwide

-
-  **LF SpA HEADQUARTERS**
via Voltri, 80 - 47522 Cesena (FC) ITALY
Tel. +39 0547 34 11 11 - Fax +39 0547 34 11 10
www.lfircambi724.it - www.lfircambi724.mobi
info@lfircambi.it
Export Dept.: Tel. +39 0547 34 11 50 - Fax: +39 0547 34 11 55
www.lfspareparts724.com - www.lfspareparts724.mobi
export@lfspareparts.com
-  **LF SpA HOUSEHOLD COMPONENTS DIVISION**
Via Padriciano, 34149 Trieste - Italia - AREA Science Park
Tel. +39 0547 34 12 42 - Fax +39 0547 34 12 48
www.lfspareparts724.com - www.lfspareparts724.mobi
info@lfspareparts.com
-  **EPGC Sas FRANCE**
13, Rue des Forts - 59960 Neuville en Ferrain
Tel. +33 (0)3 20 25 06 21
Fax +33 (0)3 20 25 34 12
www.epgc.com
www.epgc724.mobi
epgc@epgc.com
-  **LF GmbH GERMANY**
Junkersstrasse, 3 - D-82178 Puchheim - München
Tel. +49 89 89 45 78 66
Fax +49 89 89 45 78 88
www.lfersatzteile724.de
www.lfersatzteile724.mobi
info@lfersatzteile.de
-  **LF China REPUBLIC OF CHINA**
Room 403, No.2, Huadu Mansion, Lane 422, Huanghua Rd.
Minhang Dist. - 201103 Shanghai
Tel. +86 (0)21 33 53 66 31
Fax +86 (0)21 33 53 66 32
www.lfspareparts724.com
www.lfspareparts724.mobi
china@lfspareparts.com
-  **OOO LF RUSSIAN FEDERATION**
Ul. Anatoliya Zhivova, 8 - office 1 - 123100 Moscow
Tel./Fax +7 495 725 26 53
www.lfspareparts724.ru
www.lfspareparts724.mobi
info@lfspareparts.ru
-  **LF Repuestos Horeca S.L.U. SPAIN**
Poligono Industrial Carpetania - C/Miguel Faraday, 8 - 28906 Getafe
Tel. +34 91 477 91 00
Fax +34 91 477 90 81
www.lfrepuestos-horeca724.es
www.lfrepuestos724.mobi
info@lfrepuestos.es
-  **LF SpA Cesena (IT) Swiss Branch Steinhausen SWITZERLAND**
Sennweidstrasse, 45 - CH-6312 Steinhausen
Tel. +41 (0)41 760 15 80-1
Fax +41 (0)41 760 15 85
www.lfersatzteile724.ch
www.lfersatzteile724.mobi
info@lfersatzteile.ch
-  **LF Spare Parts Ltd. UNITED KINGDOM**
A10a Lakeside Business Park, Broadway Lane
South Cerney, Gloucestershire GL7 5XL
Tel. +44 (0)1285 86 16 25
Fax +44 (0)1285 86 39 49
www.lfspareparts724.co.uk
www.lfspareparts724.mobi
info@lfspareparts.co.uk
-
-  **AUSTRALIA AND NEW ZEALAND**
www.lfspareparts724.com
andrea.calvio@lfspareparts.com
-  **AUSTRIA**
www.lfersatzteile724.at
info@lfersatzteile.at
-  **BALKAN COUNTRIES**
www.lfspareparts724.com
matijaramov@lfspareparts.com
-  **BALTIC COUNTRIES**
www.lfspareparts724.com
inara.silina@lfspareparts.com
-  **CENTRAL AND EASTERN EUROPE**
www.lfspareparts724.cz
jiri.kremla@lfspareparts.cz
-  **DENMARK**
www.lfspareparts724.dk
michael.leth@lfspareparts.com
-  **JAPAN**
www.lfspareparts724.jp
hiroshi.ukai@lfspareparts.jp
-  **SOUTH KOREA**
www.lfspareparts724.com
fabio.doni@lfspareparts.com
-  **TURKEY**
www.lfyedekparca724.com
basar.ergun@lfyedekparca.com
-  **USA AND CANADA**
www.lfspareparts724.us
sauro.dallaglio@lfspareparts.us
howard.truitt@lfspareparts.us